

SERVICE MANUAL

USE

Screw Compressor

Model: M 26

GL-Nr.: 1_9969_10040-00 08

Serial No.:

1	Technical Specification	1 – 1
1.1	Compressor Unit	1 – 1
1.2	Compressor	1 – 1
1.3	Motor	1 – 2
1.4	Battery	1 – 2
1.5	Setting Value of the Safety Relief Valve(s)	1 – 2
1.6	Installation Requirements	1 – 2
1.7	Recommended Oils	1 – 2
1.8	Torque	1 – 4
1.9	Sound Pressure Level	1 – 4
1.10	Identification	1 – 4
1.11	Dimensional Diagram	1 – 4
2	Safety Regulations	2 – 6
2.1	Explanation of Symbols and References	2 – 6
2.2	General Safety Instructions	2 – 8
2.3	Road Traffic Act Regulations	2 – 9
2.4	General References	2 – 10
2.5	Environmental Protection	2 – 10
2.6	Spare Parts	2 – 10
3	General	3 – 11
3.1	Operation According to Regulations	3 – 11
3.2	Incorrect Use	3 – 11
3.2.1	Temperature–dependent operation of the compressor	3 – 11
3.3	Compressed Air Treatment	3 – 11
3.4	Copyright	3 – 12
3.5	Warranty	3 – 12
4	Transport	4 – 13
4.1	Towing the Portable Compressor Unit:	4 – 13
4.2	Removing the Compressor Unit from Towing Vehicle	4 – 14
4.3	Transporting with a crane	4 – 14
4.4	Packaging and shipping as freight	4 – 15
5	Construction and Operation	5 – 16
5.1	Principle of Compression	5 – 16
5.2	Brief Description	5 – 16
5.3	Identification of the Components	5 – 17
5.4	Pipe and Instrument Diagrams (P & I Diagrams)	5 – 19
5.5	Description of the Piping and Instrument Flow Diagram	5 – 23
5.5.1	Air Circulation	5 – 23
5.5.2	Oil Circulation	5 – 23
5.5.3	Safety Chain	5 – 24
5.5.4	Partial Load Control	5 – 24

	Chapter – Page
6 Installation	6 – 26
6.1 Installation Instructions	6 – 26
7 Putting into Operation	7 – 27
7.1 Points to be Observed before Putting into Operation	7 – 27
7.2 Points to be Observed before Starting the Compressor Unit:	7 – 27
7.3 Shutdown – Putting into Operation after a Long Period of Shutdown	7 – 28
7.3.1 Temporary storage (up to approximately four months)	7 – 28
7.3.2 Long term storage (longer than five months)	7 – 28
7.3.3 Start up after long term storage	7 – 29
8 Operation	8 – 31
8.1 Operating Controls	8 – 31
8.2 Starting and Stopping the Compressor Unit	8 – 31
8.2.1 Starting	8 – 32
8.2.2 Stopping	8 – 33
8.3 Checks during Operation	8 – 33
8.4 Measures for Freezing Conditions (Winter Operation)	8 – 34
8.4.1 Temperature–dependent operation of the compressor	8 – 34
8.4.2 Starting help (starter battery discharged)	8 – 34
8.5 Faults	8 – 36
8.5.1 Motor refuses to start or remains stationary	8 – 36
8.5.2 Motor does not reach full speed	8 – 37
8.5.3 Working pressure too high	8 – 37
8.5.4 Working pressure too low	8 – 37
8.5.5 Safety relief valve blowing	8 – 37
8.5.6 The compressor unit overheats	8 – 38
8.5.7 Charging control lamp does not extinguish	8 – 38
8.5.8 High concentration of oil in the compressed air	8 – 38
8.5.9 Oil runs out of the compressor air filter after switching off	8 – 38
9 Maintenance	9 – 39
9.1 Observe the following rules during all maintenance and servicing:	9 – 39
9.2 Maintenance Instructions	9 – 39
9.3 Regular Maintenance	9 – 40
9.3.1 Check/top off the oil in the oil separator tank	9 – 43
9.3.2 Compressor oil change (oil separator tank and oil cooler)	9 – 44
9.3.3 Compressor oil filter cartridge change	9 – 46
9.3.4 Oil separator cartridge change	9 – 48
9.3.5 Clean / replace the compressor air intake filter	9 – 50
9.3.6 Clean/replace the motor air filter	9 – 51
9.3.7 Maintaining the fuel de–watering filter unit	9 – 52
9.3.8 Cleaning the oil cooler and radiator	9 – 54
9.3.9 Checking the Motor Coolant	9 – 55

	Chapter – Page
9.3.10 Battery maintenance	9 – 57
9.3.11 Checking motor fan belt tension	9 – 59
9.3.12 Chassis maintenance	9 – 59
9.3.13 Motor oil change	9 – 59
9.3.14 Maintaining the canopy pivot point components	9 – 61
9.3.15 Rubber sealing strip maintenance	9 – 61
9.3.16 Checking the safety relief valve	9 – 61
10 Spare Parts and After Sales Service	10 – 62
10.1 Service parts and expendable parts	10 – 62
10.2 Motor Servicing	10 – 63
11 Appendix	11 – 64
11.1 Wiring Diagram	11 – 64
11.2 Lighting and signalling system diagram	11 – 70
11.3 Fuel circulation schematic diagram	11 – 73
11.4 Maintenance Schedule	11 – 76

1 Technical Specification

1.1 Compressor Unit

Model	M 26
Maximum gauge working pressure	100 psig
Free air delivery at max. gauge working pressure	92 cfm
Temperature at the air end discharge port	194 °F (at 50°F ambient)
Temperature at the air end discharge port	140 °F (at 77°F ambient)
Total weight	1098 lbs
Maximum gross weight (axle load)	1653 lbs
Tongue weight (dep. on adjustment)	44–110 lbs
Permissible weight at tow–bar coupling	110 lbs
Tires	145/80 R 13
Recommended tire pressure	32 psi
Wheel bolts	M12 x 1,5
Torque see chapter 1.8.	
Air outlet valves	2x G 3/4

Drawings:

Dimensional diagram	T10232.00
P & I flow diagram	FFMM26ST–00430.01 (Pipework and instrument flow diagram)
Compressed air option	FFMM26DLAO–00432.02
Electrical diagram	SFA26–00926.01
Lighting and signalling system connection diagram	SFAUSA.BEL–00909.01
Fuel circulation schematic diagram	KFMM26K–00035.00

1.2 Compressor

Single stage screw compressor with oil injection	Sigma 145
Total volume of oil in circulation	1,2 gal
Oil carryover in the air at the discharge port	approx. ca. 5 ppm

1.3 Motor

Make/Model Kubota D1105-EB
 Rated power 25,3 HP
 Speed under full-load running 2900 rpm
 Speed under idle running 2100 rpm
 Fuel consumption under full-load running 1,4 gal/h
 Oil consumption ca. 1% of the consumed fuel volume
 Diesel fuel tank capacity 7,9 gal
 Quantity of coolant in the motor cooling system 1,32 gal

1.4 Battery

Voltage 12 V
 Capacity 44 Ah
 Cold test current 360 A

1.5 Setting Value of the Safety Relief Valve(s)

Blow-off pressure 130 psig

1.6 Installation Requirements

Max. altitude above sea level of the place of use 3000 ft.
 Min. ambient temperature* 14 °F
 Max. ambient temperature 113 °F

*When operating the compressor at temperatures generally below 32 °F, observe the points detailed in chapter 8.4!

1.7 Recommended Oils

Assembly	Contents	For ambient temperatures from	Product / Make
Motor	0,92 gal	14° F to 122° F -4° F to 86° F -4° F to 122° F	Synthetic SAE 15 W / 40 SAE 5 W / 30 SAE 10 W / 40
Compressor	1,2 gal	5° F to 32° F 32° F to 122° F	KAESER SIGMA S-320 Compressor Oil KAESER SIGMA S-460 Compressor Oil
Preserving oil for long term compressor shutdown			Shell ENSIS Motor oil 30
Chassis			lithium enriched multi-purpose grease non-corroding oil

Recommended cooling oil:

Ordering: see 'Service parts and expendable parts' chapter 10.1.

A sticker showing the type of oil filled is to be found near the oil separator filling port.

	SIGMA S-460 / FLUID PLUS
Description	Synthetic oil
Application:	Standard oil for all applications except in connection with foodstuff.
Authorization	—
Viscosity at 104 ° F	0.23 ft/s ² (DIN 51562-1) / 0.15 ft/s ² (D 445; ASTM test)
Viscosity at 212 ° F	0.035 ft/s ² (DIN 51562-1) / 0.024 ft/s ² (D 445; ASTM test)
Flash point	500 ° F (ISO 2592) / 460.4 ° F (D 92; ASTM test)
Density at 59 ° F	52.63 / 53.94 lb/ft ³ (ISO 12185)
Pour point	-38.2 ° F (ISO 3016) / -50.8 ° F (D 97; ASTM test)
Demulsibility at 129.2 ° F	30 min (ISO 6614) / 40/40/0/10 min (D1401; ASTM-Test)
Ambient tempera- ture	-4 – 122 ° F

This oil is also recommended for unsuitable operating conditions such as minor gaseous contamination of the inlet air and for high ambient temperatures.

Topping off the oil:

Always use the same manufacture and type of oil (see label on the oil separator tank).

Oil change and changing type of oil:

The compressor unit must be completely drained of all oil before an oil change or changing the type of oil. Remove all scale and deposits by hand. For hard to reach areas, an appropriate compressor flush is recommended. It is possible that the oil separator cartridge will need to be changed soon after changing the oil. This is due to the new oil's ability to clean up existing oil deposits.

A Material Safety Data Sheet covering this cooling oil can be requested from KAESER.

1.8 Torque

Tightening torque for wheel fixing:

	Thread	Socket size	Torque [lbf in]
Wheel bolts	M12 x 1,5	SW 17	885
Wheel bolts	M14 x 1,5	SW 19	1328
Wheel nuts	M16 x 1,5	SW 22	2124
Wheel nuts	M18 x 1,5	SW 24	2655


Standard values for hexagon bolts with a strenght factor of 8.8:

Thread size	M6	M8	M10	M12	M14	M16	M18
Torque value (lbf in)	80	204	407	708	1106	1814	2124

1.9 Sound Pressure Level

Noise level to US EPA at 23 ft distance 76 dB (A)

1.10 Identification








MGB009311

- 1 Vehicle ID number *)
(stamped in bodywork)
 - 2 Engine number
(see nameplate on the engine block)
 - 3 Unit number
(see nameplate)
 - 4 Compressor number
(see nameplate on the air end)
- *) vehicle-identification

1.11 Dimensional Diagram

(see following page)

View X



All dimensions are in inches

2003	Typl.	Name	Friedenstah	
Gez.	20.01		Friedenstah	
Gepr.			Friedenstah	
Frequenz			F-satz für	
Maßstab	1:20 auf A3		F-satz für	

Portable compressor M 26

KAESER
KOMPRESSOREN

T 10232 USE

A-Index 000

10021767_01

2 Safety Regulations

Read this service manual and the motor service manual carefully and observe cautionary references before putting this mobile compressor unit into operation and before carrying out any maintenance on the unit.

2.1 Explanation of Symbols and References



This symbol is placed before all references to safety where danger to life and limb can occur during work. It is especially important that these rules are observed and that extreme care is taken in these cases. For their own protection, inform all other users of these safety rules. Observe all general safety and accident prevention regulations as well as the safety rules laid down in this service manual.

Attention!

This symbol identifies recommendations, regulations, references and correct sequence of work to prevent damage and/or destruction of the compressor unit and/or other equipment.



This symbol identifies environmental concerns.



This symbol indicates operations and actions to be carried out by the operator or service technician.

- This bullet identifies listings.

Explanation of prohibiting and warning notices on the compressor unit:



Prohibiting:
Do not operate the portable compressor unit with the canopy or panels open.
Hood can close unexpectedly!



Warning:
Hot or dangerous gases exhaust into the normal work area.
Only use in well ventilated areas or only operate compressor outdoors.



Warning:
Do not touch hot surfaces.

Optional:

⚠ WARNING



DEATH OR SERIOUS INJURY CAN OCCUR FROM INHALING COMPRESSED AIR WITHOUT USING PROPER SAFETY EQUIPMENT.

SEE OSHA STANDARDS ON SAFETY EQUIPMENT.

⚠ WARNING



CONNECT AIR HOSES ONLY IN FULL COMPLIANCE WITH OSHA STANDARD 29 CFR 1926,302 (bX7).

THE REQUIRED SAFETY DEVICES SHOULD BE TESTED IN ACCORDANCE WITH THEIR MANUFACTURER'S RECOMMENDATIONS TO VERIFY THAT THEY REDUCE PRESSURE IN CASE OF HOSE FAILURE AND WILL NOT NUISANCE TRIP WITH THE HOSE AND TOOL COMBINATIONS IN USE.

⚠ WARNING



Do not operate without fan guard in place.

⚠ WARNING



Keep clear of unguarded moving parts.



2.2 General Safety Instructions

During installation, operation, maintenance and repair of the compressor unit, OSHA Standards or any applicable Federal, State and Local codes, standards and regulations must be complied with.

Users of compressor units are obliged to comply with the safety and accident prevention regulations concerning the compressor unit that are valid in the country of use. If necessary, corresponding measures must be taken to ensure compliance with these national regulations before the compressor unit is put into operation.

Also, the following instructions must be complied with:

- Never use the compressor in enclosed spaces because the exhaust gases contain deadly carbon monoxide! If it is absolutely necessary to operate the portable compressor in an enclosed space then the exhaust gases must be fed to the open air via a suitably sized pipe (at least 4" dia.).
- Fire hazard!
Never refuel with the compressor running!
Keep fuel away from hot components such as air discharge pipes or engine exhaust pipes. If an automatic pump is used to refuel the compressor unit a ground must be connected to discharge any static electricity that may build up. Never allow fuel, oil, coolant or cleaning agents to spill over and never leave spilled remains inside the compressor unit.
- Scalding hazard!
Always allow the compressor unit to cool down before removing a pressurized cap on engines with a sealed cooling system.
- While welding on or near the compressor unit, ensure that sparks, open flames, or high temperatures cannot cause fire or explosion.
- Ensure that the compressor unit is fed with clean intake air. Operation of the unit in environments containing ammonia or other harmful gases may damage the unit and should be avoided.

- Do not operate the unit in ambient temperatures exceeding recommended levels (see chapter 1.6), for operation in higher ambient temperatures, please consult the manufacturer.
- Ensure that the compressor unit cannot be inadvertently started before carrying out any repair work. Remove the starter battery or place insulating caps over the battery terminals. A notice with the words *“This machine is under repair, do not start!”* must be attached to the compressor unit.
- Change the oil at the recommended interval or once a year, whichever occurs first.
- Do not mix cooling oils of different types. Be careful not to accidentally add compressor oil to the engine, or engine oil to the compressor.
- During operation, maintain the proper operating temperature as stipulated in the manufacturer’s specifications to avoid build-up of condensate in the oil circulation (due to low operating temperatures) or other damage (due to high operating temperatures).
- Use only cooling oils as recommended by the manufacturer.
- If maintenance work is carried out on any part of the oil circulation system, remember to refill the oil in the separator tank to the maximum level. Run the compressor and keep it under constant observation for a short period. Re-check the oil level again and add oil if necessary.
- Re-use of the filter cartridge located inside the oil separator tank is permitted as long as the pressure drop across the filter is below 15 psi. Check the pressure drop regularly.
- To reduce strain at the compressor outlet valves, do not connect accessories such as lubricators, water separators, etc. to the outlet valves. Do not pull on the air hoses when they are connected to the outlet valves.

2.3 Road Traffic Act Regulations

Attention!

Observe all Federal, State, and Local laws while towing this equipment.

The maximum permissible trailer weight for the towing vehicle and the maximum permissible weight at the trailer coupling may not be exceeded! See rated limit in tow vehicle Operator’s Manual and review its instructions and other requirements for safe towing.

The speed limit for towed vehicles as prescribed by Federal, State, and Local laws shall not be exceeded.

Use wheel chocks to secure the compressor unit against possible movement before uncoupling from the towing vehicle.



This equipment may be tongue heavy. DO NOT attempt to raise or lower the drawbar by hand if the weight is more than you can safely handle.

2.4 General References



Work on power driven systems may only be carried out by trained or specialized personnel.



Splashing oil can cause injuries and fires.

- ☞ Check all pipes, hoses and screw fittings for leaks and visible damage every three to four weeks. Repair any damage immediately!



Inspect the electrical equipment of the compressor unit every three to four weeks. Defects, such as loose connections and/or overheated cable should be repaired immediately. Carry out the following precautions before working on the electrical system:

Disconnect the battery, the ground cable first and then the positive cable.

When reconnecting the battery, attach the positive cable first, then the ground cable.

- ☞ Check all screw connections and cables of the electrical system. Repair any faults, such as loose connections and/or overheated cable immediately.

Attention!

Any alterations or reconstruction performed without the previous written consent of KAESER COMPRESSORS may void the warranty.

2.5 Environmental Protection

Maintenance materials/wear items/replacement parts



Ensure that all wear items, maintenance and replacement parts accumulating during operation of the compressor unit are disposed of according to environmental regulations!

2.6 Spare Parts

Safe and reliable operation of the compressor unit is guaranteed only with KAESER original spare parts and KAESER SIGMA compressor oil.

3 General

Attention!

The service manual must always be available where the compressor package is being used.

This Service Manual applies only to rotary screw compressors for use in the construction sector.

The right is reserved to make technical changes and improvements to equipment which may then result in discrepancies in the details of that equipment contained in this manual.

If the compressor package is operated in an air distribution network, the maximum network pressure may not exceed 232 psig.

3.1 Operation According to Regulations

This compressor unit is intended solely for the purpose of generating compressed air. Any further use outside of this purpose is considered incompatible to regulations. The manufacturer cannot accept liability for any damage caused by such incorrect use; the user alone is liable for any risks incurred.

Use of the compressor according to regulations also encompasses adherence to the installation, removal, commissioning, operational and maintenance conditions laid down by the manufacturer.

Attention!

The equipment may only be used or serviced by authorized and trained personnel.

3.2 Incorrect Use



Never direct compressed air toward persons. Compressed air is a concentrated form of energy and as such is dangerous to life.

Attention!

Inlet air may not contain any explosive or chemically unstable gas or vapour.

3.2.1 Temperature–dependent operation of the compressor

Attention!

The compressor is designed for an ambient temperature range from 14° F to 113° F. The compressor may not be operated in ambient temperatures outside this range.

3.3 Compressed Air Treatment



Never use compressed air from oil injected compressor units for breathing purposes and production methods where the air has direct contact with food, without subjecting the compressed air to additional treatment.

3.4 Copyright

The copyright of this service manual is the property of the firm of KAESER KOMPRESSOREN. This service manual is intended for installation personnel, operating personnel, maintenance personnel and supervisory personnel use only. It contains regulations and diagrams of a technical nature that may not be copied either completely or partly, distributed or evaluated for the purpose of competition or divulged to any other third party by unauthorised persons.

3.5 Warranty

This service manual contains no independent warranty commitment. Our general terms and conditions of business apply with regard to warranty.

A condition of our warranty is that the machine is used for the purpose for which it is intended under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

✎ Obtain confirmation from the manufacturer that the machine is suitable for your specific application.

Furthermore, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- unauthorized modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of genuine KAESER spare parts and operating materials.

4 Transport

4.1 Towing the Portable Compressor Unit:



Riding on or in a compressor package is strictly forbidden.

Attention!

When towing the compressor unit with a towing vehicle observe the road traffic regulations (see chapter 2.3).


Precautions to be taken before towing the compressor

- ☞ Check that the compressor is shut down and secured against accidental restarting. If necessary, carry out the following:
- ☞ Loosen and remove all connecting lines to the compressor.
- ☞ Check for unsecured tools on or in the compressor package and remove any found.
- ☞ Close and lock the canopy.

Attention!

Check that the towing vehicle coupling is compatible with the compressor towing eye or coupling.
The compressor drawbar must be horizontal when towing.
If the compressor tilts forward or backward the dynamics of towing can lead to damage.

- ☞ Place the compressor drawbar in horizontal position to the towing vehicle coupling.



- ☞ Hook up the compressor unit to the towing vehicle.

Attention!

After hooking up the mobile compressor unit, check that the safety locking device on the tow-bar coupling is engaged.

- ☞ Lift the jack support and secure with the clamp.
- ☞ Connect the cable for the lighting and indicator systems and carry out a functional check.
- ☞ Check that the wheel nuts are tight and the tyres are in good condition.
- ☞ Check the tyre pressures.

Attention!

The portable compressors are designed for a maximum road speed of 55 mph.
The regulations of the road traffic act specific to the country of use must be observed.

4.2 Removing the Compressor Unit from Towing Vehicle

Work to be done after transporting the mobile compressor unit as a towed vehicle on the road:

- ☞ Lower and secure the support.
- ☞ Disconnect the lighting and direction indicator cable.

Attention!

When uncoupling on a slope or hill secure the compressor unit against movement.

- ☞ Uncouple the compressor unit from the towing vehicle.

4.3 Transporting with a crane

Attention!

Always comply with the safety regulations concerning load suspension devices and lifting appliances when transporting a portable compressor unit by means of a crane.



Do not stand beneath a hanging load.

Do not exceed the maximum permissible compressor weight (see chapter 1.1).

Do not lift or lower the compressor unit with a jerk because of the danger of damage to components.

Do not tamper with the fixing points of the lifting eye.

All loose, hinged parts such as doors must be secured before lifting the compressor package. Never affix wire cable, chain or slings directly to the lifting eye, always use a regulation crane hook or shackle!

A lifting eye is provided for transport with a crane.

This lifting eye is accessible through the canopy (under the rubber cover in the top of the canopy).

(see illustration for the lifting eye in chapter 5.3).

- ☞ Check that the compressor is shut down and secured against accidental restarting. Carry out this measure, if necessary.

Attention!

Do not pull the compressor along with the compressed air supply hoses.

- ☞ Release and remove all connection lines from the uncoupled compressor unit.
- ☞ Close and lock the canopy.
- ☞ Open the rubber cover in the top of the canopy.

Attention!

Lifting hooks and lifting eye shackles, etc, must never be deformed and must always be in line with the load axis. For maximum safety and efficiency the load applied to all lifting points should be as near to vertical as possible.

- ☞ Hook the crane hook into the lifting eye.

4.4 Packaging and shipping as freight

The transport route is a deciding factor for the type of packaging and for securing. KAESER KOMPRESSOREN always tries to transport goods directly to the customer. Our packaging and securing methods are always selected such that, assuming proper handling, the goods arrive in perfect condition at the customer's premises.



Always observe valid accident and safety regulations when transporting equipment!

Attention!

The freight is to be secured against rolling, tipping and slipping.



Dispose of the packaging according to environmental regulations and where possible, recycle.

Chocks, restraints or squared timber must be used for securing freight. If required, guys should be tightened across the chassis and the towbar. It is not permitted to tighten guys or straps across the encasement!

On rented, hired or trade fair packages the transport restraints should be used again for the return journey.

KAESER KOMPRESSOREN will be pleased to answer any queries with regard to transport and securing of equipment. KAESER KOMPRESSOREN can accept no liability whatsoever for damages arising through incorrect transport methods or insufficient or wrong securing of freight.

Observe before shipping by air:



The machine has a internal combustion motor.

- Which may contain a residual amount of fuel and fuel vapor.
 - They also contain wet cell battery(s).
 - The motor and airend both contain lubricants.
- ☞ Be aware that all hazardous materials regulations must be adhered to when shipping these units including the requirements in the US–Code of Federal Regulations CFR Title 49 – Transportation.

The machine are considered dangerous goods when shipped by air and failure to follow the appropriate regulations could result in steep fines!

- ☞ Remove all hazardous materials.

5 Construction and Operation


5.1 Principle of Compression

The compressor unit is fitted with a single stage, oil injected air end.

Two rotors, the driven male rotor and the female rotor, both mounted in roller bearings, are fitted into the airend. As the rotors rotate, air is drawn into the upper side through the inlet and is compressed on the lower side.

The oil that is injected into the lower side absorbs heat generated by compression, prevents metallic contact between the rotors, seals the rotors and the housing from each other and also lubricates the roller bearings.

The compressed air and oil mixture leaves the airend via the discharge outlet.



MGB002011

- | | |
|-----------------|------------------|
| 1 Oil injection | 4 Discharge port |
| 2 Male rotor | 5 Air inlet port |
| 3 Female rotor | |

5.2 Brief Description

The air end is directly driven by a water-cooled three-cylinder diesel engine via a coupling (see chapter 1.3).

An oil separator cartridge providing practically oil-free compressed air is built into the oil separator tank.

The compressor oil is unsuitable for the lubrication of tools connected to the compressor. If necessary, a tool lubricator should be fitted for this purpose.

The compressor control ensures that the compressed air generated is matched to the actual compressed air demand.

A safety shut-down system protects the motor, compressor and the unit by automatically stopping the motor if important systems fail.

The built in air fan provides optimum cooling of all components with the body work closed.


A fully automatic combination valve registers the ambient temperature and regulates the compressor temperature accordingly.

The chassis is fitted with flexible rubber element torsion axle suspension.

A lifting eye is provided for transport using a crane (see chapter 4.3).


5.3 Identification of the Components

Position details in () correspond with the Pipe and Instrument Flow Diagram (P & I Diagram)




- | | | | |
|---|-----------------------------|---|--|
| 1 | Water cooler (56) | 5 | Fuel tank |
| 2 | Diesel engine (15) | 6 | Airend (4) |
| 3 | Motor – air filter (24) | 7 | Pressure relief valve (13) |
| 4 | Compressor – air filter (1) | 8 | Cooling water compensation tank (56.1) |

MFB066111



- | | | | |
|----|---|----|------------------------------|
| 9 | Combination valve – Oil temperature controller (19) | 14 | Oil cooler (20) |
| 10 | Oil filter (21) | 15 | Fuel de-watering filter unit |
| 11 | Oil separator tank (5) | 16 | Lifting eye |
| 12 | Battery | 17 | Control panel |
| 13 | Proportional controller (23) | | |

MFB073011



MFB073111

20 Engine (15)
21 Oil cooler (20)

22 Drain plug
23 Fuel de-watering filter unit

5.4 Pipe and Instrument Diagrams (P & I Diagrams)

(see following pages)

1. P & I Diagram, machine
2. P & I Diagram, compressed air outlet

5.5 Description of the Piping and Instrument Flow Diagram

Details in () correspond to the component identification number on the P & I Diagram.

5.5.1 Air Circulation

The air drawn in from the atmosphere flows through the inlet air filter (1) of the compressor, the inlet valve (3) and is compressed in the airend (4).

The oil injected into the compression chamber absorbs the heat generated during compression, seals the gap between the rotors and the air end housing and simultaneously lubricates the bearings of the rotors.

The air and oil mixture is forced into centrifugal movement by a 90° deflector in the oil separator tank (5). A preliminary separation of oil and air takes place under the influence of the centrifugal force and the force of gravity. The remaining oil carry-over in the compressed air is filtered out by the oil separator cartridge (7). The oil accumulating in the oil separator tank (5) through these measures is returned to the compressor airend (4).

The compressed air then passes to the compressed air distributor (10) via the minimum pressure nozzle (8). The minimum pressure nozzle also ensures the necessary minimum pressure in the oil separator (5) required to guarantee the oil supply to the compressor air end.

The compressed air then passes to the compressed air distributor (10) from where it is supplied to the consumers.

5.5.2 Oil Circulation

The oil flows from the oil separating tank (5) to the combination valve (19).

Combination valve with ambient temperature acquisition

When ambient temperatures are low the combination valve (19) bypasses the cooler (20) and directs the still cold compressor oil directly back to the airend (4) so the airend discharge temperature* reaches the ideal 194° F as quickly as possible. The whole machine is warmed through and brought quickly to operating temperature. The combination valve works automatically to hold the temperature level steady.

When the ambient temperature exceeds 50° F* the combination valve directs oil through the cooler, which reaches its full cooling capacity from 77° F. This allows the airend discharge temperature to be regulated at about 140° F.

This ambient temperature dependent control offers the user beneficial operating conditions.

- Winter operation – a higher airend discharge temperatures is reached quickly in cold weather.
- Summer operation – unpleasantly high surface temperatures of air tools is avoided in hot weather.

*Airend discharge temperature – ambient–dependant temperature measured at the airend discharge port.

*Between the ambient temperature values 50° F.....77° F there is an airend discharge temperature transition zone.

Oil Circulation to be continued

Contaminants in the oil are filtered out by the oil filter (21) and the screen filter (18) of the compressor air end. Subsequently, the oil is injected into the air end again.

The oil accumulating in the oil separating cartridge (7) is returned to the compressor air end via the oil return line (16) and the dirt trap with jet (17). The oil circulation system functions under the influence of the natural pressure gradient and requires no oil circulation pump.

5.5.3 Safety Chain

Safety Relief Valve:



It is forbidden to alter the setting!

The overall air circulation system is protected against excess pressure by a safety relief valve.

If a defect causes the pressure to increase above the maximum gauge working pressure (see chapter 1.1 for values), then the compressed air is blown off via the safety relief valve.

The activation pressure (see chapter 1.5) is preset at the safety relief valve.

It is forbidden to alter the setting!

Temperature gauge switch:

The temperature gauge switch switches and shuts down the compressor unit if the maximum allowed compressor discharge temperature.

Oil-Pressure Switch – Motor:

If the oil pressure in the diesel motor sinks below the permissible minimum pressure, the compressor shuts down.

Cooling water thermostat:

The compressor shuts down if the temperature of the coolant in the motor exceeds the maximum allowed value.

Fan belt monitoring:

If the motor fan belt should part, causing failure of the fan, the compressor unit is shut down.

5.5.4 Partial Load Control

Description of the operating modes

Full Load:

If the gauge working pressure lies approximately 0.5 bar below the maximum gauge working pressure (see chapter 1.1 for the value) the compressor works under full load.

The pressure in the control line from the proportional controller (23) is still so slight that the inlet valve (3) is open and the motor speed adjustment lever is in the "max. speed" position.

If the compressed air demand is higher than the maximum air delivery of the compressor unit, the compressor settles at a working pressure that is less than the working pressure mentioned above. However, the minimum pressure nozzle (8) ensures that even if the discharge valves are fully opened, the pressure in the oil separator tank (5) cannot fall below the minimum pressure.

This minimum pressure is necessary to ensure sufficient lubrication of the compressor air-end (4).

Partial Load:

If the compressed air demand is lower than the maximum air delivery of the compressor unit, then the pressure in the oil separator tank rises, whereby the pressure in the control line from the proportional controller (23) also rises.

The increased pressure in this control line initially activates the piston in the inlet valve (3) and with further increase in pressure the motor speed adjustment cylinder (26) is also activated.

By these means the volume of air entering the compressor is initially reduced and subsequently the motor speed is reduced.

Off-load running:

If the air consumption reduces to zero the pressure in the control line increases, the proportional controller opens, adjusts engine speed to idling speed with the engine speed adjustment cylinder and closes the inlet valve.

6 Installation

6.1 Installation Instructions

Observe the following instructions when setting up the compressor unit:

- Maintain sufficient distance (at least 60 inch) to building trenches, banks, ramps, etc.
- Locate the compressor unit on a flat, horizontal surface (max. 15° slope in the longitudinal or cross direction!).
- Do not set up the compressor unit so that the wind should blows in the direction of the cooling air outlet.
- Do not allow exhaust gases and heated cooling air to be sucked into the compressor.

Attention!

Do not place the compressor directly in front of a wall.

Make sure that there is sufficient space for ventilation and exhaust gases when selecting the compressor's place of use.

The drive motor's exhaust system becomes very hot during operation.

If there is only a short distance between the compressor and a wall the compressor can overheat and damage can be caused.

- Always locate the compressor at the longest distance possible from a wall.
- Make sure there is sufficient space around and over the compressor.

See chapter 1.6 for ambient temperatures required for operation of the compressor unit.

See chapter 4.2 for setting up instructions after transport of the compressor unit.

7 Putting into Operation

7.1 Points to be Observed before Putting into Operation

Every compressor unit is given a test run in the factory and carefully checked before shipment.

The test run confirms that the compressor unit conforms to the specification data and runs perfectly.

However, independent of the checks made at the factory, the compressor unit could be damaged during transport.

For this reason, we recommend that the compressor unit is examined for such possible damage.

Observe the compressor unit carefully during the first hours of operation for any possible malfunction.

Attention!

Important functional components in the compressor unit (such as safety relief valve and inlet valve) are adjusted and fitted to factory standards and specifications.

Alterations to these components are not allowed without previous written consultation with the manufacturer.



Do not make alterations to the safety relief valve or inlet valve without first consulting the manufacturer.
The safety relief valve and inlet valve are spring loaded.

7.2 Points to be Observed before Starting the Compressor Unit:



ANY NON-OBSERVANCE OF THIS OR OTHER REFERENCES (WARNING; ATTENTION) CAN LEAD TO ACCIDENTS CAUSING INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.



It is not allowed to operate the compressor within an enclosed space because of the danger of toxic exhaust gases.



It is not allowed to operate the compressor with the canopy open because injury to persons could be caused by hot or rotating parts and electrical equipment.

Also the cooling system would be severely affected.

✎ Remove all packing material, tools and transport securing devices on and in the compressor unit.


- It is expected that the operator employs safe working techniques and that all lawful operating and safety regulations are followed when operating this compressor unit.
- The user of this compressor unit is responsible for its safe operating condition.
- Do not operate this compressor unit in areas where heavy dust conditions, poisonous or inflammable gases could exist.

Before putting into operation carry out the following:

- ☞ Check the oil level in the oil separating tank (see chapter 9.3.1).
- ☞ Check the oil level in the motor (see motor service manual).
- ☞ Check the motor coolant level (see chapter 9.3.9).
- ☞ Check the fuel level in the fuel tank (see motor service manual for details).

7.3 Shutdown – Putting into Operation after a Long Period of Shutdown**7.3.1 Temporary storage (up to approximately four months)**

- ☞ Disconnect the battery (first the negative cable and then the positive cable).
- ☞ Seal the air intake openings of the motor, the air intake openings of the compressor and the motor exhaust with plastic foil and moisture resistant adhesive tape.
- ☞ Secure a warning notice on the instrument panel informing of the shutdown measures taken.




Example of a warning notice informing of temporary shutdown measures

7.3.2 Long term storage (longer than five months)

- ☞ Check the motor coolant level (see chapter 9.3.9).
- ☞ Drain the motor oil, the oil in the oil separator tank and the oil in the oil cooler with the compressor unit at operating temperature (see chapter 9.3.2 and the motor service manual).
- ☞ Fill the motor and the oil separating tank with preserving oil (see motor service manual and chapter 1.7, "Oil Recommendations").
- ☞ Run the compressor unit for approximately 10 minutes to distribute a film of oil (see chapter 8.2 for starting and stopping the compressor unit).
- ☞ Disconnect the battery (first the negative cable and then the positive cable).
- ☞ Check the level of electrolyte in the battery (see chapter 9.3.10 for battery maintenance).

- ☞ Check the battery charge monthly and recharge if necessary otherwise there is danger of the electrolyte freezing under cold conditions.
- ☞ Clean the battery connections and grease with acid resistant grease.
- ☞ Close the ball valve at the air discharge.
- ☞ Place a bag of desiccant (silica gel) in the air inlet filter opening and affix with adhesive tape if necessary.
- ☞ Close the air inlet openings of the motor, the air inlet openings of the compressor and the motor exhaust with plastic foil and moisture resistant adhesive tape.
- ☞ Seal the air intake openings of the motor, the air intake openings of the compressor and the motor exhaust with plastic foil and moisture resistant adhesive tape.
- ☞ Clean the bodywork and then treat with a preservative.
- ☞ Secure a warning notice on the instrument panel informing of the shutdown measures taken.



Example of a warning notice informing of shutdown measures

Store the compressor unit in a dry environment subject to consistent temperatures.


7.3.3 Start up after long term storage

- ☞ Check the tire pressures (see chapter 1.1 for tire pressures).
- ☞ Clean the bodywork with a grease and dirt cleaning solvent.
- ☞ Remove the plastic foil and adhesive tape from the air inlet opening of the motor, air inlet opening of the compressor and the motor exhaust.
- ☞ Remove the desiccant (silica gel) bag from the opening of the air inlet filters of motor and compressor.
- ☞ Drain the preserving oil from the motor (see motor service manual).
- ☞ Carry out a visual inspection of the air and oil filters.
Replace, if necessary (see motor service manual and chapters 9.3.5 and 9.3.3).
- ☞ Fill with motor oil (see motor service manual).
- ☞ Fill with compressor oil (see chapter 9.3.2).

- ☞ Check the motor coolant level (see chapter 9.3.9).
- ☞ Check the state of battery charge.
Recharge, if necessary (see chapter 9.3.10).
- ☞ Reconnect the battery / batteries (first the positive cable, then the negative cable).
- ☞ Check all fuel lines, motor oil lines and compressor oil lines for leaks, loose connections, wear and damage.
- ☞ Immediately repair any faults found!
- ☞ Put the compressor unit into operation according to chapter 7.1 and 8.2.
- ☞ Check the function of the lights and direction indicators.


8 Operation

8.1 Operating Controls



- 1 Operating hours counter
- 2 Pressure gauge
- 3 Ignition switch
- 4 Shut-down procedure pictogram
- 5 Starting procedure pictogram
- 6 Charge monitor lamp
- 7 Temperature gauge switch
- 8 "Controller on" switch

8.2 Starting and Stopping the Compressor Unit



- 0 STOP position
- 1 ON position
- 2 PREHEAT position
- 3 START position
- 4 Ignition switch

8.2.1 Starting

- ☞ Disconnect all consumers.
- ☞ Open outlet valve/–s.
- ☞ Open the canopy.
- ☞ Turn the “CONTROL ON” switch (on the underside of the canopy, at the rear) to the “ON” position.
- ☞ Close the canopy.
- ☞ Turn the starter switch to the “1” position.
The charging lamp must illuminate (red).

Preheating:

- ☞ Turn the ignition switch to the “II” position and hold.

The glow plugs in the diesel motor are switched on and the motor is preheated. Dependent to the ambient temperature, the preheating time shall be amount between min. 5 seconds and max. 15 seconds – low ambient temperatures demand long preheating times!

Attention! Max. preheating time appropriate 15 seconds.

The electrical fuel pump is automatic started during the preheating phase. Therefore the fuel pipes are bled before the motor is started.

Further starting instructions:

- ☞ Turn the ignition switch to the “III” position and hold.

The starter turns.

Attention! Never operate the ignition switch if the engine is running. Do not turn and hold the ignition switch in the “III” position for longer than 20 seconds. Wait for 30 seconds after each attempt to start the engine.

The starter cannot be operated if the engine is running or running down and cannot be over–driven.

- ☞ As soon as the engine starts and runs at a constant speed release the ignition switch immediately.

The ignition automatically returns to the “I” position under spring tension.

When the engine starts and runs normally, the charging indicator lamp should extinguish after a few seconds.

When the motor starts and runs normally, the charging lamp should extinguish after a few seconds.

Attention! If the charging lamp does not extinguish, there is a fault. (see chapter 8.5.7)

- ☞ Close the discharge cock/–s.

The compressor unit is operational and the supply of compressed air is available.

8.2.2 Stopping

- ☞ Turn the ignition switch to the "0" position.

The ignition switch must remain in the "0" position until the engine is stationary because of the start inhibit.

Complete shutdown:

- ☞ Turn the ignition switch to the "0" position.
- ☞ Open the canopy.
- ☞ Turn the "Controller" switch (on the underside of the canopy, at the rear) to the OFF position.
- ☞ Close the canopy.

8.3 Checks during Operation



Raise the canopy during operation for a short period only, e.g. to carry out checks.



There is danger of injury to personnel through heated, rotating and electrically live components!





The constructional soundproofing measures are without function when the canopy is raised and the compressor unit is operational. Protective ear muffs must be worn.

- ☞ Check the air intake filter maintenance indicator.

If the red cylinder is visible in the window, clean or renew the filter cartridge (see chapter 9.3.5 and 9.3.6).

Attention!

The pressure generated by the compressor unit should never exceed the stated maximum gauge pressure (see chapter 1.1 for the value) under any operational condition.
The maximum temperature of the compressed air at the discharge port may not be exceeded (see chapter 1.1 for the value).



MFB014212

- | | |
|---|---|
| <p>1 Contamination indicator, compressor – air filter (2)</p> <p>2 Compressor – air filter (1)</p> <p>3 Compressor air filter element</p> | <p>4 Engine – air filter (24)</p> <p>5 Contamination indicator, engine – air filter (25)</p> <p>6 Engine air filter element</p> |
|---|---|

8.4 Measures for Freezing Conditions (Winter Operation)

The electrical system starts the unit without problem at temperatures down to 14° F.

Attention!

If the compressor is operated at ambient temperatures below 32° F, then the following points must be observed:

- Use winter motor oil (see service manual for the motor).
- Use low viscosity compressor oil (see chapter 1.7).
- Use winter diesel fuel.
- Fit a heavy duty winter battery (see chapter 9.3.10).

Attention!

The pneumatic control of the compressor unit can defect under ambient temperatures below 32° F. This could be caused by small particles of ice forming in the control and regulation devices.

Attention!

To ensure faultless regulation allow the compressor to run up to operational temperature with the discharge valves open.

8.4.1 Temperature–dependent operation of the compressor

Attention!

The compressor is designed for an ambient temperature range from 14° F to 113° F. The compressor may not be operated in ambient temperatures outside this range.

8.4.2 Starting help (starter battery discharged)

If the starter battery is discharged, the compressor unit can be started with the help of the starter battery in another vehicle or another portable compressor.

Attention!

Pay attention to safety requirements of batteries

Connect batteries of the same voltage only. (see chapter 1.4 for the voltage).

Only use standardized battery jumper cables of sufficient cross–sectional area and with insulated pole clamps.

Pay attention to instructions for use of battery jumper cables.

Arrange the jumper cables so that they cannot be caught up by rotating parts of the compressor unit or the assisting vehicle.

Connecting the battery jumper cables:

- ☞ Park the assisting vehicle as near to the battery in the portable compressor as possible.
- ☞ Stop the motor.
- ☞ Switch off all unnecessary power consumers.
- ☞ Connect the first jumper cable to the “+” terminal of the discharged battery and the “+” terminal of the battery in the assisting vehicle.

Attention!

Do not connect the jumper cable to the “-” terminal of the discharged battery as well as the body of the portable compressor.

- ☞ Connect one end of the second jumper cable to the “-” terminal of the battery in the assisting vehicle and the other end to the earth rail of the motor in the portable compressor.

Starting the motor:

- ☞ Start the motor of the assisting vehicle and run at high speed.
- ☞ Start the motor of the portable compressor.

When the portable compressor has successfully started, allow both the portable compressor and the assisting vehicle to run with the jumper cables still connected for approximately 3 minutes.

Removing the jumper cables:

- ☞ Remove the jumper cable from the “-” terminal of the battery in the assisting vehicle and from the metal part of the motor in the portable compressor.
- ☞ Remove the jumper cable from the “+” terminal of the battery in the portable compressor and the “+” terminal of the battery in the assisting vehicle.

8.5 Faults



When attempting to remove faults, the instructions in the 'Safety' chapter and the appropriate local safety regulations (see chapter 2) must be complied with!

Re-starting after a fault:

See chapter 7.2 'Putting into Operation' and chapter 8.2.1 'Starting'.

Explanation of symbols for the following fault finding help:

- *1 – have checked by a specialist.
- *2 – check at KAESER after sales service.
- *3 – see motor service manual.

8.5.1 Motor refuses to start or remains stationary

See also motor service manual.

Possible cause:

- Defective starter.
- Fuel shut-off device has not opened.
- Fuel tank empty.
- Airlock in the pipe between the tank and injection pump.
- Fuel filter blocked.
- Fuel line defective.
- Control fuse or relay defective.
- Discharge temperature too high
- Defective remote contact thermometer providing no enable signal.
- Coolant temperature too high
- Defective cooling water temperature sensor providing no enable signal.
- Start switch defective.
- Connections and/or cable in the electrical wiring loose or open circuit.
- Battery voltage too low.
- Battery defective or charge too low.
- Defective motor generator.
- Defective motor generator regulator.
- Insufficient oil pressure
- Oil pressure switch indicating insufficient oil pressure.

Fault removal:

- Replace; *1.
- Check the solenoid and electrics, replace if necessary; *1.
- Refill.
- Bleed the fuel pipe; *3.
- Clean or replace.
- Replace; *1.
- Replace; *1 or *2.
- *1 or *2.
- Replace; *2.
- *1 or *3
- Replace; *2.
- Replace; *1 or *3.
- Tighten, if necessary, replace; *1.
- Carry out battery maintenance, see chapter 9.3.10.
- Carry out battery maintenance, see chapter 9.3.10.
- Replace if necessary; *3 oder *1.
- Replace if necessary; *3 oder *1.
- Refill; *3 oder *1.
- Check the motor oil pressure. Replace the oil pressure switch, if necessary, have the motor repaired; *3 or *1.

8.5.2 Motor does not reach full speed

See also motor service manual.

Possible cause:

Airlock in the pipe between the tank and injection pump.

Fuel filter blocked.

Fuel line defective.

Speed adjustment cylinder maladjusted or defective.

Fault removal:

Bleed the fuel pipe; *3.

Clean or replace.

Replace; *1.

Repair, replace if necessary; *2.

8.5.3 Working pressure too high**Possible cause:**

Proportional controller misadjusted or defective.

Inlet valve not closing.

Pressure gauge indicating false pressure.

Venting valve does not blowing off.

Fault removal:

Check the diaphragm, clean the nozzle, replace proportional controller if necessary; *2.

Check the controller, control line and inlet valve, replace if necessary; *2.

Replace; *2.

Check the connections and function, repair or replace as necessary *2.

8.5.4 Working pressure too low**Possible cause:**

Proportional controller misadjusted or defective.

Inlet valve not opening or only opening partially.

Pressure gauge indicating false pressure.

Safety relief valve venting.

Venting valve venting.

Motor not running at full speed.

Motor air filter contaminated.

Compressor air filter contaminated.

Oil separator cartridge contaminated.

Fault removal:

Check the diaphragm, clean the nozzle, replace proportional controller if necessary; *2.

Repair, replace if necessary; *2.

Replace; *2.

Leaky or maladjusted, replace if necessary; *2.

Check the connections and function, if necessary, repair or replace; *2.

See chapter 8.5.2.

Clean or replace, see chapter 9.3.6.

Clean or replace, see chapter 9.3.5.

Replace, see chapter 9.3.4.

8.5.5 Safety relief valve blowing**Possible cause:**

Oil separator cartridge contaminated.

Inlet valve not closing.

Safety relief valve maladjusted or leaky.

Fault removal:

Replace, see chapter 9.3.4.

Check the controller, control line and inlet valve, replace if necessary; *2.

Replace; *2.

8.5.6 The compressor unit overheats**Possible cause:**

Compressor unit fan wheel damaged or malfunctioning.

Compressor oil cooler surface contaminated.

Working element of the combination valve faulty.

Working pressure too high (proportional controller maladjusted).

Oil separator cartridge contaminated.

Compressor oil filter cartridge contaminated.

Oil level too low.

Leaky oil pipes.

Motor water cooling system or cooling fan defective.

Ambient temperature too high.

Fault removal:

Replace blades or the complete fan wheel; *2.

Clean the surface, see chapter 9.3.8.

Replace; *2.

Reset to the permissible value or replace; *2.

Measure the differential pressure and if greater than 15 psi, replace. See chapter 9.3.4 for replacement.

Replace, see chapter 9.3.3.

Top up, see chapter 9.3.1.

Seal or replace the oil pipes; *1 or *2.

Repair; *3 or *1.

See installation conditions chapter 1.6.

8.5.7 Charging control lamp does not extinguish**Possible cause:**

Connections and/or cable in the electrical wiring loose or open circuit.

Fault removal:

Tighten, if necessary, replace; *1.

8.5.8 High concentration of oil in the compressed air**Possible cause:**

Oil return line of the oil separating cartridge blocked.

Oil separating cartridge of the compressor fractured.

Compressor oil level too high.

Fault removal:

Clean the filter screen in the dirt trap of the oil separating cartridge, replace if necessary (see chapter 9.3.4); otherwise *2

Replace, see chapter 9.3.4.

Reduce to max. level, see chapter 9.3.1.

8.5.9 Oil runs out of the compressor air filter after switching off**Possible cause:**

Non return function of the inlet valve defective.

Incorrect type of oil (excess frothing).

Fault removal:

Repair, replace if necessary; *2

Drain the oil and refill with oil conforming to the oil recommendations (see chapter 1.7 for oil types).

9 Maintenance

9.1 Observe the following rules during all maintenance and servicing:



Only specialised or trained personnel may work on power driven equipment.

Before starting the compressor unit, ensure that:

1. No maintenance personnel are working on the compressor unit.
2. All protective guards and cover panels are screwed back on.
3. All tools are removed from the compressor unit.



The following points must be observed when handling fuel, oil, lubricating and cooling materials:

Avoid contact with skin and eyes.
Do not inhale vapours and oil mist.
Do not eat or drink when handling such materials.
Fire, open flame and smoking are strictly forbidden.



Before starting work, disconnect the negative cable of the battery / batteries to prevent an inadvertent start of the compressor unit.

☞ See chapter 8.2 to start the compressor unit.

9.2 Maintenance Instructions

The maintenance instructions for the motor are found in the motor service manual!

☞ Before starting repair work or maintenance clean the compressor unit, especially connections and screw joints of all oil or protective agents.

☞ Do not use aggressive cleaning materials!
Use non-fibrous cloth!

Attention!

Always tighten down any screw connections that have been loosened during maintenance work.



Ensure that all lubricants, consumable materials and replacement parts accumulating during operation and servicing of the compressor package are disposed of according to environmental regulations.

9.3 Regular Maintenance

Maintenance schedule	daily	50 hours after putting into operation for the first time	six-month (every 200 – 250 h)	yearly (every 400 – 500 h)	
Components / Maintenance					see chapter
Engine:					
check the engine oil level	X				engine SM
check the contamination alarm of the air intake filter	X				8.3
clean / replace the air intake filter*			X	X	9.3.6
check / adjust the valve clearance		X	X	X	engine SM
change the engine oil*		X	X	X	engine SM
change the engine oil filter*		X	X	X	engine SM
check the engine fan belt tension, tension if necessary		X	X	ex- change	9.3.11 engine SM
have the fuel injectors checked				every 3000 h	
Compressor:					
check the oil level		X	X	X	9.3.1
change the compressor oil*				every 1000 h	9.3.2
replace the compressor oil filter*		X		every 1000 h	9.3.3
check the contamination alarm of the air intake filters	X				8.3
clean / replace the air intake filter			X	X	9.3.5
change the oil separating cartridge in the oil separator*				every 2 years	9.3.4
clean the oil cooler*			X	X	9.3.8
Engine radiator					
check the engine coolant level	X	X			9.3.9+ Engine SM
clean the radiator*			X	X	9.3.8
check the antifreeze			X	X	9.3.9

Maintenance schedule	daily	50 hours after putting into operation for the first time	six-month (every 200 – 250 h)	yearly (every 400 – 500 h)	
Components / Maintenance					<i>see chapter</i>
Engine radiator					
check the antifreeze protection, change the engine coolant if necessary				every 3 years	9.3.9
check the radiator hoses and hose clamps			X	X	Engine SM
Fuel supply:					
fill the fuel tank	X				
clean or replace all fuel filters			X	X	engine SM
clean the filling strainer				X	
clean the fuel tank				X	
check the fuel hoses and hose clamps, replace if necessary		every 50h		X	engine SM
Chassis:					
check the tire pressures	X				1.1
check the wheel bolts for tightness		X	X	X	1.1
chassis maintenance			X	X	9.3.12+ CH SM
grease the coupling head, joints, towbar			X	X	
Battery:					
check the battery electrolyte and pole connections				X	9.3.10
Lifting frame:					
check				X	
Hose pipes:					
check for wear and tightness				X	
Miscellaneous:					
Check all accessible screw connections, pipes and clamps for wear and tightness				X	
Maintain the pivot point components				X	9.3.14

Maintenance schedule	daily	50 hours after putting into operation for the first time	six-month (every 200 – 250 h)	yearly (every 400 – 500 h)	
Components / Maintenance					<i>see chapter</i>
Fuel water separator:					
check the fuel water separator	X				9.3.7
change the water separator filter				X	9.3.7
Safety relief valve:					
have checked				X	9.3.16

* The maintenance intervals given are recommended intervals and could shorten considerably under unsuitable ambient or operational conditions.

motor SM ⇒ refers to motor service manual
 See this manual for further maintenance instructions.

CH SM ⇒ refers to separate manual for "Chassis Maintenance"

We urgently recommend that a record is kept of all maintenance carried out. A sample maintenance record form is shown in chapter 11.4.



9.3.1 Check/top off the oil in the oil separator tank

Check the oil level daily before starting the compressor unit.

Carry out the check with the compressor unit standing horizontally, with the compressor unit switched off and with the oil separator tank vented.

Oil level check:

- ☞ Switch off the compressor unit (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented (check that the pressure gauge indicates zero psig)!
- ☞ Open the canopy
- ☞ Disconnect the negative cable of the battery.
- ☞ Uncouple all pneumatic tools and open the discharge valve.



MFB015712

- 1 Oil separator tank (5)
- 2 Plug
- 3 Oil filler

- ☞ Unscrew the oil filler cap.
- ☞ Check that oil is visible.
- ☞ If none can be seen, top up.

Top off the oil:**Attention!**

The oil should never exceed the normal quantity otherwise operational malfunctions could occur. If too much oil is added, oil will enter the air control valve upon restarting, cause malfunctioning regulation and enrichment of the compressed air with excess oil.

Attention!

Always use the same type of oil (see label on the oil separator tank, or chapter 1.7).

Contrary to the diesel motor, a mixture of different oils for compressor lubrication may never be used!

- ☞ Top off with oil to the maximum mark using an oil funnel.
- ☞ Check the oil level again.

- ☞ Check the sealing ring of the oil filler plug and then screw in tightly.
- ☞ Connect the negative cable of the battery again.

Exact check of oil level and for leaks :

There is danger of injury through contact with:

- very hot surfaces.
- rotating parts.
- electrical components.

Hearing protection should be worn when operating the compressor with its canopy raised.

- ☞ Start the compressor unit and allow to run until the operating temperature (see chapter 1.1) is reached (the cooling oil then starts to circulate).

Check the oil level again as follows:

- ☞ Run the compressor in 'idle' (with no air users connected) and close the outlet valves (maximum system pressure).
- ☞ Shut down the compressor (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented (check that the pressure gauge reads zero psig).

Check the oil level (see 'Oil Level Check', chapter 9.3.1).

- ☞ Correct the oil level if necessary.
- ☞ Carry out a visual check for leaks.
- ☞ Close the canopy.

9.3.2 Compressor oil change (oil separator tank and oil cooler)

Change the oil after approximately 1000 operating hours, depending on the degree of pollution of the intake air, but at least once annually.

Change the oil with the compressor unit at operational temperature.



The compressor oil can get very hot, beware of scalding!

- ☞ Switch off the compressor unit (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented (check that the pressure gauge indicates zero psig)!
- ☞ Open the canopy
- ☞ Disconnect the negative cable of the battery.
- ☞ Uncouple all pneumatic tools and open the discharge valve.
- ☞ Unscrew the oil filler plug.



**Hot compressor oil; beware of scalding.
Therefore, shut the compressor down and allow to cool.**



Catch the used oil in a suitable container and dispose of according to environmental regulations.

Drain the oil separator tank as follows:

- ☞ place an oil catcher under the oil separator tank.
- ☞ remove the drain plug from the underside of the tank.
- ☞ allow the oil to drain out.

Drain the oil cooler as follows:

- ☞ Place an oil catcher under the oil collecting box.
- ☞ Loosen the hose clamp under the oil collecting box.


**Danger of Injury**

Turn the hose in both directions vigorously to loosen its grip before pulling it off the cooler drain pipe.

This eases withdrawal of the hose.

This prevents collision injury on hands and elbows.

- ☞ Rotate the hose to loosen it.
- ☞ Pull off the hose.
- ☞ Allow the oil to drain out.



1 Oil cooler
2 Oil collection box

3 Hose clamp for oil drainage

MFB016021

Attention!

When changing oil, make sure that the oil separator tank, oil cooler and the oil pipelines are completely drained of old oil.

- ☞ Change the oil filter, if necessary (see chapter 9.3.3).
- ☞ Use a funnel to fill with the type and quantity of new oil as specified on the label on the oil separator tank and stated in chapter 1.7.

Attention!

The oil charge should never exceed the specified maximum or breakdowns could occur.

- ☞ Check the oil level (see chapter 9.3.1).
- ☞ Screw in the oil filler plug again and tighten down.
- ☞ Reconnect the battery negative terminal.

Exact check of oil level and for leaks :



There is danger of injury through contact with:

- very hot surfaces.
- rotating parts.
- electrical components.

Hearing protection should be worn when operating the compressor with its canopy raised.

- ☞ Start the compressor unit and allow to run until the operating temperature (see chapter 1.1) is reached (the cooling oil then starts to circulate).

Check the oil level again as follows:

- ☞ Run the compressor in 'idle' (with no air users connected) and close the outlet valves (maximum system pressure).
- ☞ Shut down the compressor (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented (check that the pressure gauge reads zero psig).


Check the oil level (see 'Oil Level Check', chapter 9.3.1).

- ☞ Correct the oil level if necessary.
- ☞ Carry out a visual check for leaks.
- ☞ Close the canopy.

9.3.3 Compressor oil filter cartridge change



The cooling oil can get very hot, beware of scalding!



MFB025211

- | | | | |
|---|---------------------------|---|---|
| 1 | Airend (4) | 3 | Oil filter (21) |
| 2 | Thermostatique valve (19) | 4 | Direction of rotation to unscrew the oil filter |

- ☞ Switch off the compressor unit (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented (check that the pressure gauge indicates zero psig)!
- ☞ Open the canopy

- ✎ Disconnect the negative cable of the battery.
- ✎ Uncouple all pneumatic tools and open the discharge valve.



Dispose of the old oil filter and any used, accumulated oil according to environmental regulations!

- ✎ Unscrew the contaminated oil filter cartridge counter-clockwise and dispose of (if the filter cartridge is seized, use an appropriate tool to remove).
- ✎ Capture and dispose of any leaking oil.
- ✎ Carefully clean sealing surfaces using non-fibrous cloth.


Lightly oil the sealing gasket of the new oil filter cartridge, using fresh oil.

- ✎ Use your fingers to apply a light coat of fresh oil to the seal of the new cartridge.

Attention!

Do not use a filter wrench when installing a new oil filter cartridge. Hand-tighten only!

- ✎ Screw on the new oil filter cartridge by hand until the gasket is firmly seated.
- ✎ Firmly hand-tighten the new cartridge.



- 1 Combination valve
- 2 Sealing face

- ✎ Check the oil level in the oil separator tank (see chapter 9.3.1).
- ✎ Reconnect the negative cable of the battery.

Exact check of oil level and for leaks :

There is danger of injury through contact with:
– very hot surfaces.
– rotating parts.
– electrical components.

Hearing protection should be worn when operating the compressor with its canopy raised.

- ✎ Start the compressor unit and allow to run until the operating temperature (see chapter 1.1) is reached (the cooling oil then starts to circulate).

Check the oil level again as follows:

- ✎ Run the compressor in 'idle' (with no air users connected) and close the outlet valves (maximum system pressure).
- ✎ Shut down the compressor (see chapter 8.2).
- ✎ Wait until the compressor has automatically vented (check that the pressure gauge reads zero psig).

Check the oil level (see 'Oil Level Check', chapter 9.3.1).

- ✎ Correct the oil level if necessary.
- ✎ Carry out a visual check for leaks.
- ✎ Close the canopy.

9.3.4 Oil separator cartridge change

References to numbers in () refer to the numbers in the following illustration.

The differential pressure across the cartridge may not exceed 15 psi.

- ✎ Switch off the compressor unit (see chapter 8.2).
- ✎ Wait until the compressor has automatically vented (check that the pressure gauge indicates zero psi)!
- ✎ Open the canopy
- ✎ Disconnect the negative cable of the battery.
- ✎ Uncouple all pneumatic tools and open the discharge valve.
- ✎ Unscrew the clamping nut (1) of the oil return line and remove the plastic piping.
- ✎ Remove the dirt trap by unscrewing the clamping nut (5).
- ✎ Loosen the oil scavenge line (12) completely and pull it out.
- ✎ Remove the control line at the proportional controller by unscrewing the clamping nut (13).
- ✎ Remove the control lines at the cover plate by unscrewing the clamping nuts (8) and (14).
- ✎ Unscrew the clamping nut (6) and remove the compressed air hose (7).
- ✎ Unscrew the cover plate bolts (4) and remove.
- ✎ Carefully remove the cover plate (9) and put to one side.
- ✎ Extract the used oil separator cartridge (11), with O rings (10) and clean the sealing surfaces.


Attention!

When cleaning the sealing surfaces take care that no foreign bodies (dirt particles) fall into the oil separator tank.



Dispose of the used oil separator cartridge according to environmental care regulations!

- ✎ Dispose of the used oil separator cartridge.
- ✎ Insert the new oil separator cartridge (11), with new O rings (10) and screw down the cover plate (9) with the cover plate clamping bolts (4).
- ✎ Change the strainer (3) and the O ring (2) in the dirt trap together with the oil separator cartridge.
- ✎ Reassemble in the reverse order.



MGB001911

- | | | | |
|---|--------------------------------------|----|----------------------------------|
| 1 | Clamping nut for the oil return line | 9 | Cover plate |
| 2 | O ring (Oil return line) | 10 | O ring (Oil separator cartridge) |
| 3 | Strainer | 11 | Oil separator cartridge |
| 4 | Cover plate clamping bolt | 12 | Oil return line, cpl. |
| 5 | Clamping nut for dirt trap | 13 | Clamping nut, control line |
| 6 | Clamping nut for discharge hose | 14 | Clamping nut, control line |
| 7 | Druckluftschlauch | 15 | Proportional controller |
| 8 | Discharge hose | 16 | Oil separator tank |

Exact check of oil level and for leaks :



There is danger of injury through contact with:

- very hot surfaces.
- rotating parts.
- electrical components.

Hearing protection should be worn when operating the compressor with its canopy raised.

- ☞ Start the compressor unit and allow to run until the operating temperature (see chapter 1.1) is reached (the cooling oil then starts to circulate).

Check the oil level again as follows:


- ☞ Run the compressor in 'idle' (with no air users connected) and close the outlet valves (maximum system pressure).
- ☞ Shut down the compressor (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented (check that the pressure gauge reads zero psig).

Check the oil level (see 'Oil Level Check', chapter 9.3.1).

- ✎ Correct the oil level if necessary.
- ✎ Carry out a visual check for leaks.
- ✎ Close the canopy.

9.3.5 Clean / replace the compressor air intake filter

Clean the compressor air intake filter at the latest when the maintenance indicator activates (see chapter 8.3).



- | | | | | |
|---|---|-----|---|-------------------------------|
| 1 | Reset knob for the maintenance indicator | in- | 3 | Compressor air filter element |
| 2 | Maintenance indicator compressor air filter | | 4 | Filter cap |

MFB019711

- ✎ Switch off the compressor unit (see chapter 8.2.2).
- ✎ Open the canopy.

To open the filter housing:

- ✎ Unscrew the wing nut on the cover assembly. Remove the cover assembly and gently pull out the air filter cartridge.
- ✎ Clean the filter housing, cover assembly and sealing surfaces.

Cleaning the air filter cartridge by tapping:

- ✎ Tap the air filter cartridge several times on the front with the ball of the hand so that the dust falls out.

Attention! Do not use excessive force, otherwise the air filter cartridge may be damaged.

- ✎ Clean all seating surfaces.

Cleaning the air filter cartridge with compressed air:


- ✎ Blow dry compressed air at a pressure of not more than 30 psig at a slant from the inside to the outside of the air filter cartridge surfaces.



Do not direct compressed air toward any person. Compressed air is contained energy and as such may cause injury or death.

Attention!

Do not clean the air filter cartridge with fluids. If the air filter cartridge is heavily contaminated or has been cleaned several times (max. five times, or has not been replaced within one year) then it must be replaced.



- 1 Air intake filter cartridge
- 2 Direction of blow out (from the inside to the outside!)

Resetting the maintenance indicator:




- ☞ When filter maintenance is finished, press the reset button of the maintenance indicator.

The maintenance indicator is ready for operation again.

- ☞ Insert the cleaned or new air filter cartridge into the filter housing.
- ☞ Reassemble the air filter in the reverse order of opening (see “To open the filter housing”).
- ☞ Close the canopy.

9.3.6 Clean/replace the motor air filter

Clean the motor air filter at the latest when the maintenance indicator activates (see chapter 8.3).



- 1 Filter cap
- 2 Dust evacuating valve
- 3 Spring retaining flap
- 4 Engine air filter element
- 5 Maintenance indicator engine air filter
- 6 Reset knob for the maintenance indicator

MFB015812

- ☞ Shut down the compressor unit (see chapter 8.2.2).

To empty the dust evacuator valve:

- ☞ Empty the dust evacuator valve by pressing the valve orifice together at the ends.
- ☞ Clean the orifice.
- ☞ Remove any dust clumps that may have collected by pressing together the upper part of the valve.

Opening the filter housing:

- ☞ Press both spring flaps together, remove the cover and then the filter cartridge (note the position of the cover for the reassembly!).
- ☞ Clean the filter housing and the filter cover assembly.

Cleaning the air filter cartridge with compressed air:

(see also chapter 9.3.5)



Do not direct compressed air toward any person. Compressed air is contained energy and as such may cause injury or death.

- ☞ Blow dry compressed air at a pressure of not more than 30 psig at a slant from the inside to the outside of the air filter cartridge surfaces.

Attention!

Do not clean the air filter cartridge with fluids. If the air filter cartridge is heavily contaminated or has been cleaned several times (max. five times, at the latest after a period of one year) then it must be changed.

Cleaning the filter cartridge by tapping with the hand:

(see also chapter 9.3.5)

- ☞ Tap the air filter cartridge several times on the front with the ball of the hand so that the dust falls out.

Attention!

Do not use excessive force, otherwise the air filter cartridge may be damaged.

Resetting the maintenance indicator:

- ☞ When filter maintenance is finished, press the reset button of the maintenance indicator.

The maintenance indicator is ready for operation again.

- ☞ Insert the cleaned or new air filter cartridge into the filter housing.
- ☞ Reassemble the air filter in the reverse order of opening (see “To open the filter housing”).
- ☞ Close the canopy.

9.3.7 Maintaining the fuel de–watering filter unit

A combined fuel de–watering and filter unit is installed between the fuel tank and the pump.


A check should be made daily for accumulated water and dirt. The de–watering filter unit should be emptied as required.

Water trap emptying:

- ☞ Switch off the compressor unit (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented .
(Check that the pressure gauge indicates zero psig!)
- ☞ Open the canopy.

Water, being denser than diesel fuel, sinks to the bottom of the separator. The presence of water can be detected by the colour of the fuel.

- ☞ Place a collecting container under the drain plug.
- ☞ Loosen the drain screw in the underside of the separator and allow separated water and dirt particles to run out.
- ☞ Re-tighten drain plug
- ☞ Close the canopy.



1 Filter head
2 Filter element

3 Separator tank
4 Drain plug

Changing the filter element

The filter element of the fuel de-watering unit should be changed:

- at least every 500 operating hours,
- if the motor cannot draw in enough fuel and loses power,
- when changing the motor fuel filter.

The interval between filter element changes is dependent on fuel quality and cleanliness.

Attention!

The fuel tank should be nearly empty when the filter element is changed.

- ☞ Switch off the compressor unit (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented .
(Check that the pressure gauge indicates zero psig!)
- ☞ Open the canopy.



Any contaminated fuel must be collected and disposed of, along with the old filter element, in accordance with local environmental regulations.


- ☞ Place a collecting container under the drain plug.
- ☞ Open the drain screw on the underside of the separator bowl and drain the unit.
- ☞ Unscrew the filter element from the filter head (anti-clockwise).

- ✎ Unscrew the separator bowl from the filter element and clean the bowl.
- ✎ Check the gasket and replace if damaged, lightly smear the gasket with clean fuel and check that it is positioned correctly.
- ✎ Screw the separator bowl onto a new filter element.
- ✎ Check the filter head gasket and replace if damaged, lightly smear the gasket with clean fuel and check that it is positioned correctly.
- ✎ Check that the drain screw on the underside of the unit is closed and fill the filter element with clean fuel.
- ✎ Screw the filter element carefully into the filter head.
- ✎ Close the canopy.

9.3.8 Cleaning the oil cooler and radiator

Check the oil and water coolers for clogging at least every 125 operating hours as heavy clogging of the cooler grill and honeycomb can cause excess temperatures within the oil circulation system and overheating of the engine.

- ✎ Shut down the compressor unit (see chapter 8.2.2) and allow to cool.
- ✎ Open the canopy.
- ✎ Disconnect the battery (see chapter 9.3.10).
- ✎ Close up the air intakes of the engine and compressor air filters (see chapter 7.3.1).
- ✎ Cover electrical components such as the alternator, starter or instruments.
- ✎ Unscrew and remove the sound proofing from the air outlet.



- 1 Soundproofing removed
2 Flow direction of water or steam jet used for cleaning

- 3 Air outlet, engine coolant cooler
4 Air outlet, compressor oil cooler



Do not direct compressed air, water or steam jets toward any person. These represent contained energy and as such may cause injury or death.



The soiled cooler must be cleaned with water or steam jet at cleaning points with oil separators suited for such purpose only!

Attention! Do not direct water or steam jets directly at sensitive components such as the alternator, starter or the instruments.

- ☞ Clean the cooler with compressed air, water or steam jet in the opposite direction to the cooling air flow.
- ☞ Screw on the soundproofing again.
- ☞ Open the inlets of the air filters again.
- ☞ Reconnect the battery.
- ☞ Close the canopy.
- ☞ Put the compressor into operation (see chapter 8.2.1) and run up to operating temperature so that any accumulated water evaporates.

9.3.9 Checking the Motor Coolant

Check the motor coolant daily before putting the compressor into operation.


The coolant is a mixture of water, antifreeze and corrosion inhibitor. Because of the need for the corrosion inhibitor and need to raise the boiling point, the coolant must remain in the cooling system throughout the whole year.

Attention! The coolant must be renewed every two years because of degradation of the corrosion inhibitor.

- ☞ Shut down the compressor (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented.
(The pressure gauge must show zero psig!)

See chapter 1.3 for the quantity of coolant.

The expansion tank is located directly above the radiator.



MFB015921

- | | | | |
|---|---------------------------|---|----------------------|
| 1 | Coolant level sight glass | 3 | Fan |
| 2 | Coolant expansion tank | 4 | Filler neck with cap |

- ☞ Open the canopy.

Attention! Never unscrew the filler cap on the engine cooling system unless the coolant temperature has fallen below 194 °F; beware of scalding.

Protect your eyes and skin against engine coolant, there is danger of acid burns. If the eyes are affected rinse immediately with running water.

- ☞ Turn the filler cap to the first stop, allow pressure to escape.
- ☞ Remove the filler cap

Checking the coolant level / topping up:

The antifreeze/corrosion inhibitor agent in the coolant should not fall below 40 vol.-% (protection down to approx. -13°F).

When topping up (after loss of coolant) ensure that the antifreeze/corrosion inhibitor proportion is at least 50 vol.-% (protection down to approx. -35°F).

There should not be more than 55 vol.-% (protection down to approx. -49°F , = max. protection), because below this ratio the antifreeze properties are reduced and heat dissipation worsens.

Make sure that there is sufficient room for expansion when the coolant is hot.

The coolant level may reach the centre of the sight glass.

- ☞ Check the level of the coolant.
- ☞ Mix a quantity of coolant and top up to the mark.
- ☞ Screw on the filler cap.
- ☞ Start the engine and run for approx. one minute.
- ☞ Stop the engine .
- ☞ Turn the filler cap to the first stop, allow pressure to escape.
- ☞ Remove the filler cap.
- ☞ Top up the coolant to the mark again.

Checking the antifreeze/corrosion inhibitor in the coolant:

The antifreeze protection must be -35°F throughout the whole year.

- ☞ Check the component of antifreeze agent in the coolant with an antifreeze tester.

If the antifreeze component is below 40% then top up with pure antifreeze agent or change the coolant.

Drain the coolant from the drain point on the engine

- ☞ To drain the coolant see engine service manual.

Drain the coolant from the coolant cooler (radiator).

- ☞ Place a coolant catcher under the coolant collecting box.

To drain coolant from the cooler, loosen the hose clamp on the collecting box and pull off the hose.

**Danger of Injury**


Turn the hose in both directions vigorously to loosen its grip before pulling off the cooler drain pipe.

This eases withdrawal of the hose.

This prevents collision injury on hands and elbows.

- ☞ Rotate the hose to loosen it.
- ☞ Pull off the hose.


- ☞ Allow coolant to drain.
- ☞ Close the canopy.



1 Cooler
2 Hose clamp for coolant drainage

3 Coolant collecting box

Coolant drain point on the engine



1 Motor
2 Coolant drain

3 Starter

9.3.10 Battery maintenance



When working on the batteries, observe the following points:

1. Fire, sparks, open flames and smoking are forbidden.
2. Eye protection must be worn.
3. Keep children well away from batteries or acid.
4. Batteries contain corrosive acid.

Wear appropriate protective clothing including acid-proof rubber gloves.
Do not tip the batteries as acid can escape from vent holes.

5. Observe the battery manufacturer's instructions.

6. Explosion hazard.

Take particular care when the battery has been in service for a long time or has just been charged as highly explosive gas is emitted.
Ensure adequate ventilation.

Do not remove battery terminal covers unnecessarily.
Do not lay tools on the battery if the terminals are uncovered because of the danger of a short circuit resulting in heat build-up and battery explosion.



Danger sticker on battery

Winter operation:

Be advised that the available battery power is lower during the winter. Only a fraction of the original starting energy is available at low temperatures.

Attention!

A discharged battery is endangered by freezing temperatures and could freeze at a temperature of 14 ° F.

- ☞ Check the battery charge with a hydrometer before the start of the cold season and recharge, if required. At the same time, clean and grease the poles with acid-proof grease, if necessary.

In extreme cases, the use of a high performance cold-start battery or an additional battery is recommended.

Shutdown of the compressor unit for several weeks under freezing conditions:

- ☞ Remove the battery and store in a warm place to prevent the battery freezing!

Battery removal:

Never short circuit the battery (e.g. with a tool) because the battery heats excessively under short circuit conditions and could explode.

Attention!

**Do not disconnect the battery with the motor running otherwise the regulator and the generator diodes could be destroyed.
If the battery discharges for no apparent reason, check the charging system.**

- ☞ First disconnect the negative cable and then the positive cable, then unscrew the battery clamping system.
- ☞ Reassemble in the reverse order.

Battery replacement:

If the battery must be replaced, fit a new battery of equal capacity, current rating and shape as the original battery.



Dispose of the old battery according to environmental regulations!

9.3.11 Checking motor fan belt tension

Check the belt tension every 100 operating hours.



Stop the engine before checking, tensioning or changing engine V-belts. Do not tension or loosen the belts as long as they are hot.

- ☞ Shut down the compressor (see chapter 8.2).
- ☞ Wait until the compressor has automatically vented.
(The pressure gauge must read zero psig)
- ☞ Open the canopy.
- ☞ Remove the belt guard, if necessary. See engine service manual for removal.
- ☞ Check the belts thoroughly for cracks, fraying or stretching.

Replace damaged belts. See engine service manual for removal and replacement.

Checking the tension of the V-belts:

Check belt tension when they are hot.

There should be a play of about 7 to 9 mm when the belt is pressed in.

- ☞ Press with the thumb on the the belt midway between the pulleys.

See engine service manual for tensioning the V-belts.

- ☞ Reassemble the belt guard.
- ☞ Close the canopy.

9.3.12 Chassis maintenance

⇒ For further instructions see separate manual for “Chassis Maintenance”, and ALKO-Fahrzeugtechnik Operating instructions.

Wheels:

Check the wheels after the first stress run and after each wheel change.

Check the wheels for tightness, condition and tire pressures every 200 service hours.

- ☞ Check the tightness of the wheel nuts and the condition of the tires.
- ☞ Check the tire pressures with a tire pressure gauge (see chapter 1.1 for the tire pressure values).

9.3.13 Motor oil change

Change the motor oil, depending upon the contamination of the intake air, according to maintenance schedule (see chapter 9.3), but at least annually.

Carry out the first oil change see maintenance schedule (see chapter 9.3) too.

Always change the oil with the motor at operational temperature.



**Scalding hazard
Motor oil can get very hot.**

- ☞ Shut down the compressor unit (see chapter 8.2.2).
- ☞ Open the canopy.
- ☞ Disconnect the minus pole of the battery / batteries.




Catch the drained oil in a suitable container and dispose of according to environmental care regulations!

- ☞ Carry out the oil change as described in the motor service manual.
- ☞ Use the hose with coupling provided.
- ☞ Use a container.

User-friendly engine oil drainage:

- The engine oil sump is fitted with a drain valve for use during an oil change.
- The drain valve is located between the engine oil sump and the cooler.
- Oil drainage is eased by simply screwing the hose coupling on to the oil drain valve.


	Hose coupling	State of oil drain valve
Oil change	connected	open
Operation	disconnected	closed



- 1 Engine oil sump
- 2 Protective cap
- 3 Position of floor pan opening
- 4 Oil drain valve
- 5 Male hose coupling

MFB022311

Drain valve position



- 1 Airend (4)
- 2 Engine (15)
- 3 Oil drain valve
- 4 Hose coupling
- 5 Floor pan opening
- 6 Container
- 7 Hose
- 8 Cooler

MGB002212


- ☞ Position the container.
- ☞ Pass the loose end of the drain hose through the opening in the floor pan.
- ☞ Place the end of the hose in a suitable container.
- ☞ Unscrew the protective cap from the drain valve.

- ☞ Screw the hose coupling onto the valve.
- ☞ Allow the oil to drain out.
- ☞ Disconnect the hose coupling.
- ☞ Replace the protective cap.
- ☞ Reconnect the minus pole of the battery / batteries.
- ☞ Close the canopy.

9.3.14 Maintaining the canopy pivot point components

Observe the pivot point components greasing interval in chapter 9.3.

The pivot point component grease nipples are located on each side of the machine, beneath the canopy.



9.3.15 Rubber sealing strip maintenance

The rubber sealing strips between the lower body and the canopy serve both as a sound-proofing measure and the prevention of rain water ingress.

Care of the rubber sealing strips is especially necessary during the winter months to prevent the strips from sticking and thus tearing when the canopy is opened.

- ☞ Grease the rubber sealing strips regularly with silicon oil or vaseline.

9.3.16 Checking the safety relief valve

To check the operating pressure of the safety relief valve / valves the final pressure of the compressor package must be increased above the adjusted maximum working pressure.

See chapter 1.5 for the operating pressure.

Attention!

The safety relief valve must be checked by an authorized KAESER service agency when the interval quoted in the regular maintenance table (see chapter 9.3) has expired.

10 Spare Parts and After Sales Service**10.1 Service parts and expendable parts**

Description	Quantity	Order No.
Compressor parts:		
Air filter cartridge	1	6.2003.0
Oil filter cartridge	1	6.3462.0
Oil separator cartridge complete	1	6.4522.0
Oil separator cartridge	1	6.3574.0
O–Ring 109,0 x 3,00	2	5.1524.0
O–Ring 18,0 x 2,00	1	5.1517.0
Dirt trap strainer	1	2.8699.0
Sealing ring for the oil filler	1	5.1522.0
Fuse 10,0 [A]	1	7.6411.00050
Fuse 20,0 [A]	1	7.6411.00080
Fuse 40,0 [A]	1	7.6411.00090
Compressor oil:		
KAESER SIGMA FLUID S–460	5 gal	9.5409.00010
Kubota motor parts:		
Air filter cartridge	1	6.3528.0
Fuel filter	1	6.2004.0
Fuel filter change element	1	6.4550.0
Oil filter	1	8.9150.0
Injector sealing ring	1	8.9152.0
Injector, complete	1	8.9171.0
V–belt	1	8.9153.00010
Glow plug	3	8.9158.0
Fuel water separator:		
Fuel filter element	1	8.7766.0
Motor oil:		
SAE 10W–40	5.3 gal	8.7817.00020

Please state the following data for all inquiries and spare parts orders (see also the nameplate):

- Compressor unit, model
- Serial number of the compressor unit
- Name of the part
- Order number of the part

In case of warranty, state the following information:

- Date of first putting into operation
- Serial number of the compressor unit
- Serial number of the motor

Important: Enter the data on the nameplate on the unit in the following illustrated nameplate!

KAESER COMPRESSORS	
Package type:	
Serial no.:	
Part no.:	
Vehicle ID no.:	
Total weight:	lbs
Permissible axle loading:	lbs
Working pressure (g):	psi
Vessel capacity:	gal
Motor speed:	rpm
Constr. year:	

Attention!

Do not use inferior parts. Always order original spare parts from the compressor manufacturer to avoid lower quality spare parts in your own compressor unit.

We must point out that service parts not delivered by Kaeser Compressors, Inc. are also not tested and cleared by us. The fitting and/or use of such products can, under certain circumstances, change constructional and conditional characteristics of the compressor unit negatively and therefore affect the active and/or passive safety of the unit.

KAESER COMPRESSORS is released from all liabilities and warranties for damages caused by the use of non-original KAESER COMPRESSORS parts and accessories.

10.2 Motor Servicing

A booklet giving the addresses and telephone numbers of authorized dealers providing service and spare parts is enclosed with the technical documents for the motor.


11 Appendix

11.1 Wiring Diagram

11.2 Lighting and signalling system diagram

1	2	3	4	5	6	7	8	
<div data-bbox="279 309 683 1115" style="border: 1px solid black; padding: 20px; margin: 0 auto; width: 80%;"> <p style="text-align: center;">Wiring Diagram Mobilair M26 US trailer light kit</p> </div> <p style="text-align: center; margin-top: 20px;"> manufacturer: Kaeser Kompressoren GmbH Postfach 2143 96410 Coburg </p>								
<p>The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p>								
c		Datum	07.07.2003	USE	Kaeser Kompressoren			cover page
b		Bearb.	Weid		Mobilair M26			Mobilair M26
a		Gepr.	Weid		US trailer light kit			US trailer light kit
D	Änderung	Datum	Name	Norm	Ersetzt durch:			Ersetzung: afa00909_00
					Ersetzt für:			7.9058.0
								DFAUSA.BEL-00909.01
								Blatt 1
								Bl.

11.3 Fuel circulation schematic diagram



c	Datum	05.07.2004	P&I Diagram	
b	Bearb.	Martin	3-Cylinder-diesel engine	
a	Gepr.	Martowski	Mobilair M 26 (Kubota)	
Änderung	Datum	Name	Ursprung:	KFM57K-00034,00
			Ersatz durch:	
			Ersatz für:	
				KFMM26K-00035.00
				Blatt 1
				E

1	2	3	4	5	6	7	8	
<p>1 Fuel tank</p> <p>2 Fuel prefilter</p> <p>3 Fuel feed pump</p> <p>4 Injection pump</p> <p>5 Injection pipe</p> <p>6 Injection nozzle</p> <p>7.1 Fuel filter (with optional water separator)</p> <p>8 Fuel supply line</p> <p>9 Fuel return line</p>								
c	Datum	05.07.2004	P&I Diagram Legend					
b	Bearb.	Martin	3-Cylinder-diesel engine					
a	Gepr.	Martowski	Mobilair M 26 (Kubota)					
Änderung	Datum	Name	Ersatz durch:				Ersatz für:	
			KAESEKOMPRESSOREN				KFMV57-00034,00	
			Ursprung:				KFMV57-00034,00	
			KFMV26K-00035,00					
			Blatt 2					E

