

# Operating manual

## Booster

### DN C N2 SIGMA CONTROL 2

No.: 901771 27 USE

Read this manual before using this product.

Failure to follow the instructions and safety precautions in this manual can result in serious injury or death.

Manufacturer:

**KAESER KOMPRESSOREN SE**

96410 Coburg • PO Box 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

[www.kaeser.com](http://www.kaeser.com)

Original instructions  
/KKW/PDNC 2.07 en Z1 SBA-NV-AGGREGAT-GAS  
/KKW/SSC 2.11 Z1  
20210325 115759

<b>1</b>	<b>Regarding this Document</b>	
1.1	Using this document .....	1
1.2	Further documents .....	1
1.3	Copyright .....	1
1.4	Symbols and labels .....	1
1.4.1	Warnings .....	1
1.4.2	Potential damage warnings .....	2
1.4.3	Other alerts and their symbols .....	2
<b>2</b>	<b>Technical Data</b>	
2.1	Nameplate .....	4
2.2	Compressor block type .....	4
2.3	Options .....	5
2.4	Weight .....	5
2.5	Temperature .....	5
2.6	Ambient conditions .....	5
2.7	Ventilation .....	6
2.8	Pressure .....	6
2.9	Calculating the volumetric flow rate .....	7
2.10	Example for determining the permissible initial pressure .....	10
2.11	Calculating the configurable switching differential SD .....	10
2.12	Noise emission [dB(A)] .....	12
2.13	Motors and power .....	12
2.13.1	Compressor motor .....	12
2.13.2	Fan motor .....	12
2.14	Compressor oil recommendation .....	13
2.14.1	Compressor oil charge quantity .....	13
2.15	Power supply .....	13
2.15.1	Power supply specifications .....	14
2.16	Water-cooling .....	15
2.17	Water-cooling (shell and tube heat exchanger) .....	16
2.17.1	Component specifications .....	17
2.17.2	Cooling water quality .....	17
2.17.3	Design data for the cooling system .....	18
2.18	Machine duty cycle .....	18
<b>3</b>	<b>Safety and Responsibility</b>	
3.1	Basic instructions .....	19
3.2	Specified use .....	19
3.3	Improper use .....	19
3.4	User's responsibilities .....	19
3.4.1	Observe statutory and universally accepted regulations .....	19
3.4.2	Qualified personnel .....	20
3.4.3	Complying with inspection schedules and accident prevention regulations .....	20
3.5	Dangers .....	20
3.5.1	Safely dealing with sources of danger .....	20
3.5.2	Safe machine operation .....	23
3.5.3	Organizational Measures .....	25
3.5.4	Danger areas .....	25
3.6	Safety devices .....	25
3.7	Service life of safety functions .....	25
3.8	Safety signs .....	26
3.9	Information signs .....	28
3.10	Emergency situations .....	29
3.10.1	Correct fire fighting .....	29

3.10.2	Treating injuries from handling cooling oil .....	29
3.11	Warranty .....	30
3.12	Environmental protection .....	30
<b>4</b>	<b>Design and Function</b>	
4.1	Enclosure .....	31
4.2	Machine function .....	31
4.2.1	Description .....	32
4.3	Safety devices .....	32
4.4	Operating panel SIGMA CONTROL 2 .....	33
4.5	Operating modes and control modes .....	35
4.5.1	Machine operating modes .....	35
4.5.2	Control modes .....	36
4.6	Oil level monitoring .....	38
4.7	Floating relay contacts .....	38
4.8	Options .....	38
4.8.1	KAESER FILTER KD .....	38
4.8.2	Machine mountings .....	39
4.8.3	Oil collection tray .....	39
4.8.4	Water-cooling .....	40
<b>5</b>	<b>Installation and Operating Conditions</b>	
5.1	Ensuring safety .....	41
5.2	Installation conditions .....	41
5.2.1	Determining the installation location and clearances .....	41
5.2.2	Ensuring adequate machine room ventilation .....	42
5.2.3	Installing a nitrogen warning system .....	43
5.2.4	Exhaust air ducting design .....	43
5.3	Operating the machine in a nitrogen network .....	43
<b>6</b>	<b>Installation</b>	
6.1	Ensuring safety .....	44
6.2	Reporting transport damage .....	45
6.3	Connecting the machine to the nitrogen network .....	45
6.3.1	Connecting the machine to the low-pressure network .....	45
6.3.2	Connecting the machine to the high-pressure network .....	46
6.4	Installation example .....	47
6.5	Connecting the condensate drain .....	48
6.6	Connecting the machine to a power supply network .....	50
6.7	Options .....	51
6.7.1	Anchoring the Machine .....	51
6.7.2	Oil collection tray .....	51
6.7.3	Connecting the cooling water .....	52
<b>7</b>	<b>Initial Start-up</b>	
7.1	Ensuring safety .....	54
7.2	Instructions to be observed before commissioning .....	54
7.3	Checking installation and operating conditions .....	55
7.4	Setting the overload protection relay .....	56
7.5	Checking the motor protection switch settings .....	56
7.6	Starting the machine for the first time .....	56
7.7	Inlet and discharge pressure .....	57
7.8	Checking the door interlock switch .....	57
7.9	Setting the display language .....	58
<b>8</b>	<b>Operation</b>	
8.1	Switching on and off .....	60

8.1.1	Switching on .....	60
8.1.2	Switching off .....	60
8.2	Switching off in an emergency and switching on again .....	61
8.3	Using the remote control for switching on and off .....	61
8.4	Switching on and off with the clock .....	62
8.5	Interpreting operation messages .....	63
8.6	Acknowledging alarm and warning messages .....	63
<b>9</b>	<b>Fault Recognition and Rectification</b>	
9.1	Basic instructions .....	65
9.2	Other faults .....	65
<b>10</b>	<b>Maintenance</b>	
10.1	Ensuring safety .....	67
10.2	Following the maintenance plan .....	68
10.2.1	Logging maintenance work .....	68
10.2.2	Resetting maintenance interval counters .....	68
10.2.3	Regular maintenance and service work .....	68
10.3	Control cabinet: Clean or renew the filter mat .....	72
10.4	Cooler maintenance .....	73
10.5	Changing the cooler .....	74
10.6	Water-cooling Maintenance .....	74
10.7	Motor maintenance .....	74
10.8	Testing the safety relief valve .....	75
10.8.1	Cooler safety relief valve .....	75
10.8.2	Distribution tank safety relief valve .....	76
10.9	Checking the overheating safety shutdown function .....	77
10.10	Checking the EMERGENCY STOP push button .....	78
10.11	Cooler nitrogen inlet temperature switch .....	78
10.12	Venting the machine (depressurizing) .....	80
10.13	Checking the oil level .....	83
10.14	Topping off the compressor oil .....	83
10.15	Changing the compressor oil .....	84
10.16	Changing the micro-filter element in the crankcase vent .....	86
10.17	Changing the crankcase oil filter .....	87
10.18	Dirt trap maintenance .....	89
10.18.1	Dirt trap in the inlet line .....	89
10.18.2	Dirt trap in the crankcase .....	90
10.18.3	Dirt trap in the filter .....	91
10.18.4	Dirt trap in the return line .....	92
10.19	Check valve maintenance .....	92
10.19.1	Housing ventilation check valve .....	93
10.19.2	Unloading the check valve .....	94
10.20	Replacing the condensate drain solenoid valve .....	95
10.21	Checking the filter for condensate .....	96
10.22	Replacing the filter element .....	96
10.22.1	Removing the filter element .....	97
10.22.2	Installing the filter element .....	98
10.22.3	Installing the filter housing .....	99
10.22.4	Pressurizing the filter .....	100
10.23	Drive belt maintenance .....	100
10.24	Cylinder head and valves .....	101
10.25	Documenting maintenance and service work .....	102
<b>11</b>	<b>Spares, Operating Materials, Service</b>	
11.1	Note the nameplate .....	103

11.2	Ordering consumable parts and operating fluids/materials .....	103
11.3	KAESER AIR SERVICE .....	103
11.4	Replacement parts for service and repair .....	104
11.4.1	Spare parts option K1 (air cooling) .....	104
11.4.2	Spare parts option K9 (water cooling: tube heat exchanger) .....	122
<b>12</b>	<b>Decommissioning, Storage and Transport</b>	
12.1	Decommissioning .....	141
12.2	Packing .....	141
12.3	Storage .....	141
12.4	Transport .....	142
12.4.1	Safety .....	142
12.4.2	Transport with a forklift truck .....	142
12.4.3	Transport with a hoist .....	142
12.5	Disposal .....	144
12.5.1	Battery disposal .....	144
<b>13</b>	<b>Annex</b>	
13.1	Pipeline and instrument flow diagram (P+I diagram) .....	145
13.2	Dimensional drawing .....	148
13.3	Electrical Diagram .....	153
13.4	Determining the permissible initial pressure .....	186
13.5	Safety relief valve data sheet .....	194
13.5.1	Data Sheet 1 of 4 .....	194
13.5.2	Data Sheet 2 of 4 .....	197
13.5.3	Data Sheet 3 of 4 .....	200
13.5.4	Data Sheet 4 of 4 .....	206

Fig. 1	Initial pressure diagram .....	10
Fig. 2	Three-phase star (wye); 4 wire; center point solidly grounded .....	13
Fig. 3	Three-phase star (wye); 3 wire; center point solidly grounded .....	14
Fig. 4	Location of safety signs .....	26
Fig. 5	Enclosure overview .....	31
Fig. 6	Machine overview .....	32
Fig. 7	Keys – overview .....	33
Fig. 8	Indicators – overview .....	34
Fig. 9	RFID sensor field .....	35
Fig. 10	Oil level monitoring .....	38
Fig. 11	Option F15 KAESER FILTER KD .....	39
Fig. 12	Machine mountings .....	39
Fig. 13	Oil collection tray .....	39
Fig. 14	Water cooling (Option K9) .....	40
Fig. 15	Recommended installation, distances [in.] .....	42
Fig. 16	Low-pressure network connection .....	45
Fig. 17	High-pressure network connection .....	46
Fig. 18	Piping example .....	47
Fig. 19	Installation example (suggestion) .....	48
Fig. 20	Connecting the condensate drain .....	50
Fig. 21	Machine mountings .....	51
Fig. 22	Oil collection tray .....	52
Fig. 23	Connecting the cooling water .....	53
Fig. 24	Position of the door interlock switch .....	58
Fig. 25	Switching on and off .....	60
Fig. 26	Switching off in an emergency .....	61
Fig. 27	Using the remote control for switching on and off .....	62
Fig. 28	Switching on and off with the clock .....	62
Fig. 29	Acknowledging messages .....	64
Fig. 30	Switching cabinet ventilation .....	72
Fig. 31	Cleaning the cooler .....	73
Fig. 32	Motor maintenance .....	75
Fig. 33	Testing the safety relief valve .....	77
Fig. 34	Checking the EMERGENCY STOP push button .....	78
Fig. 35	Nitrogen inlet temperature switch .....	79
Fig. 36	Unlocking the temperature switch .....	79
Fig. 37	Mount the user's shut-off valves. ....	81
Fig. 38	Venting the cooler. ....	82
Fig. 39	Venting the inlet pressure side .....	82
Fig. 40	Checking the oil level .....	83
Fig. 41	Topping off the compressor oil .....	84
Fig. 42	Changing the compressor oil .....	85
Fig. 43	Changing the micro-filter element in the crankcase vent .....	87
Fig. 44	Changing the crankcase oil filter .....	88
Fig. 45	Dirt trap in the inlet line .....	89
Fig. 46	Dirt trap in the crankcase .....	90
Fig. 47	Dirt trap in the filter .....	91
Fig. 48	Dirt trap in the return line .....	92
Fig. 49	Housing ventilation check valve .....	93
Fig. 50	Relieving the check valve .....	94
Fig. 51	Replacing the condensate drain solenoid valve .....	95
Fig. 52	Checking the filter for condensate .....	96
Fig. 53	Removing the filter element .....	97
Fig. 54	Installing the filter element .....	98

Fig. 55	Installing the filter housing .....	99
Fig. 56	Filling out the maintenance sticker .....	99
Fig. 57	Visually check for damage .....	100
Fig. 58	Re-tighten the drive belt .....	101
Fig. 59	Transporting with a forklift truck .....	142
Fig. 60	Transport with a crane .....	143
Fig. 61	Battery disposal .....	144



Tab. 1	Danger levels and their definition (personal injury) .....	1
Tab. 2	Danger levels and their definition (damage to property) .....	2
Tab. 3	Nameplate .....	4
Tab. 4	Compressor block type .....	4
Tab. 5	Options .....	5
Tab. 6	Weight .....	5
Tab. 7	Temperature .....	5
Tab. 8	Ambient conditions .....	5
Tab. 9	Ventilation .....	6
Tab. 10	Safety relief valve opening pressure .....	6
Tab. 11	Compressor block rated speed .....	7
Tab. 12	Flow rate parameters .....	8
Tab. 13	Example 1 .....	10
Tab. 14	Example 2 .....	11
Tab. 15	Noise emission [dB(A)] .....	12
Tab. 16	Compressor motor (60Hz) .....	12
Tab. 17	Fan motor (60Hz) .....	12
Tab. 18	Compressor oil recommendation .....	13
Tab. 19	Compressor oil charge quantity .....	13
Tab. 20	Supply 208V / 3ph / 60Hz .....	14
Tab. 21	Supply 230V / 3ph / 60Hz .....	14
Tab. 22	Supply 380V / 3ph / 60Hz .....	15
Tab. 23	Supply 460V / 3ph / 60Hz .....	15
Tab. 24	Supply 575V / 3ph / 60Hz .....	15
Tab. 25	Water cooling K9: Individual design data .....	16
Tab. 26	Component specifications (Option K9) .....	17
Tab. 27	Cooling water quality (shell and tube heat exchanger) .....	17
Tab. 28	Cooling water temperature ( $\Delta T=18^{\circ}$ F) .....	18
Tab. 29	Danger areas .....	25
Tab. 30	Category and Performance Level .....	25
Tab. 31	Safety signs .....	27
Tab. 32	Information signs .....	29
Tab. 33	Keys .....	33
Tab. 34	Indicators .....	34
Tab. 35	RFID sensor field .....	35
Tab. 36	Energy-efficient control modes .....	37
Tab. 37	Condensate line .....	49
Tab. 38	Condensate collection line .....	49
Tab. 39	Condensate collection line: Line cross-section .....	49
Tab. 40	Re-commissioning after storage/standstill .....	55
Tab. 41	Checklist for installation conditions .....	55
Tab. 42	Machine identification .....	62
Tab. 43	Remote control identification .....	62
Tab. 44	Machine identification .....	63
Tab. 45	Other faults and remedies .....	65
Tab. 46	Advise others that the machine is being serviced. ....	67
Tab. 47	Maintenance intervals, regular maintenance and service work .....	69
Tab. 48	Regular machine maintenance and service work .....	69
Tab. 49	Compressor oil: Change intervals .....	72
Tab. 50	Logged maintenance tasks .....	102
Tab. 51	Machine maintenance parts .....	103



# 1 Regarding this Document

## 1.1 Using this document

The operating manual is a component of the product. It describes the machine as it was at the time of first delivery after manufacture.

- Keep the operating manual in a safe place throughout the life of the machine.
- Supply any successive owner or user with this operating manual.
- Please insert any amendment or revision of the operating manual sent to you.
- Enter details from the machine nameplate and individual items of equipment in the table in chapter 2.

## 1.2 Further documents

Further documents included with this operating manual are:

- Certificate of acceptance / operating instructions for the pressure vessel.
- Operating manual for SIGMA CONTROL 2.

Missing documents can be requested from KAESER.

- Make sure all documents are complete and observe the instructions contained in them.
- Make sure you provide the data from the nameplate when ordering documents.

## 1.3 Copyright

This operator manual is copyright protected. Queries regarding use or duplication of the documentation should be referred to KAESER. Correct use of information will be fully supported.

## 1.4 Symbols and labels

- Please note the symbols and labels used in this document.

### 1.4.1 Warnings

Warning notices indicate dangers that may result in injury when disregarded.

Warning notices indicate three levels of danger identified by the corresponding signal word:

Signal term	Meaning	Consequences of disregard
DANGER	Warns of an imminent danger	Will very likely result in death or severe injury
WARNING	Warns of a potentially imminent danger	May result in death or severe injury
CAUTION	Warns of a potentially dangerous situation	May result in a moderate physical injury

Tab. 1 Danger levels and their definition (personal injury)

Warning notices preceding a chapter apply to the entire chapter, including all sub-sections.

Example:

# 1 Regarding this Document

## 1.4 Symbols and labels

### **⚠ DANGER**

*The type and source of the imminent danger is shown here!*

*The possible consequences of ignoring a warning are shown here.*

*If you ignore the warning notice, the "DANGER" signal word indicates a lethal or severe injury will occur very likely.*

➤ *The measures required to protect yourself from danger are shown here.*

Warning notes referring to a sub-section or the subsequent action are integrated into the procedure and numbered as an action.

Example:

1. **⚠ WARNING** *The type and source of the imminent danger is shown here!*  
*The possible consequences of ignoring a warning are shown here.*  
*If you ignore the warning notice, the "WARNING" signal word indicates that a lethal or severe injury may occur.*  
➤ *The measures required to protect yourself from danger are shown here.*
2. Always read and comply with warning instructions.

### 1.4.2 Potential damage warnings

Contrary to the warnings shown above, damage warnings do not indicate a potential personal injury.

Warning notices for damages are identified by their signal term.

Signal term	Meaning	Consequences of disregard
NOTE	Warns of a potentially dangerous situation	Damage to property is possible

Tab. 2 Danger levels and their definition (damage to property)

Example:

### **NOTICE**

*The type and source of the imminent danger is shown here!*

*Potential effects when ignoring the warning are indicated here.*



➤ *The protective measures against the damages are shown here.*

➤ Carefully read and fully comply with warnings against damages.

### 1.4.3 Other alerts and their symbols



This symbol identifies particularly important information.

- Material Here you will find details on special tools, operating materials or spare parts.
- Precondition Here you will find conditional requirements necessary to carry out the task.  
The conditions relevant to safety shown here will help you to avoid dangerous situations.
- Option H1 ➤ This symbol denotes lists of actions comprising one stage of a task.  
Operating instructions with several steps are numbered in the sequence of the operating steps.  
Information relating to one option only are marked with an option code (e.g., H1 indicates that this section applies only to machines with machine mountings). Option codes used in this operator manual are explained in chapter 2.3.
-  Information referring to potential problems are identified by a question mark.  
The cause is named in the help text ...  
➤ ... as is a solution.
-  This symbol identifies important information or measures regarding the protection of the environment.
- Further information Further subjects are introduced here.

## 2 Technical Data

### 2.1 Nameplate

The machine's nameplate contains the model type and important technical information.

The nameplate is located on the outside of the machine:

- at the rear of the machine.

➤ Enter the data from the nameplate here as a reference:

Feature	Value
booster	
Material No.:	
Serial No.:	
Ambient temperature*	
Compressed nitrogen inlet temp. TS*	
Rated power	
Inlet pressure* (ref. value: PS)	
Max. working pressure PS	
Rated motor speed	
Phases:	
Frequency:	
Voltage	
Full load current	
Full load current drive motor	
Electrical wiring diagram	
Option	

\*Deviating values are given in the operating manual.

Tab. 3 Nameplate

Further information The **rated speed of the compressor block** and the **type of compressor block installed** can be found in the (Operating data/operands) menu in the SIGMA CONTROL 2 controller.

### 2.2 Compressor block type

Type	DN 22 C	DN 30 C	DN 37 C	DN 37 CXL	DN 45 C
Compressor block	N 753	N 753 N 1100	N 753 N 1100	N 2001	N 1100

Tab. 4 Compressor block type

## 2.3 Options

The table contains a list of available options. The options for this machine are displayed on the nameplate.

➤ Enter the options here as a reference:

Option	Option code	Available?
KAESER FILTER KD	F15	
Adjustable machine feet	H1	
Oil collection tray	H4	
Air-cooling	K1	
Water-cooling: Shell and tube heat exchanger	K9	
Supplied: ✓		
Not Supplied: -		

Tab. 5 Options

## 2.4 Weight

The values shown are maximum values. The actual weight depends on equipment fitted.

	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Weight [lb.]	3087	3307	3373	3395

Tab. 6 Weight

## 2.5 Temperature

	DN 22 C-DN 45 C
Maximum Nitrogen discharge temperature <sup>1)</sup> [°F]	≤140
Maximum Block discharge temperature <sup>1)</sup> [°F]	≤430
<sup>1)</sup> Automatic shutdown	

Tab. 7 Temperature

## 2.6 Ambient conditions

	DN 22 C-DN 45 C
Maximum elevation AMSL <sup>1)</sup> [ft.]	3000
<sup>1)</sup> Higher altitudes are permissible only after consultation with the manufacturer.	

	<b>DN 22 C-DN 45 C</b>
Permissible ambient temperature [°F]	37 – 115
Permissible inlet temperature [°F]	37 – 115

<sup>1)</sup> Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 8 Ambient conditions

## 2.7 Ventilation

The values given are minimum guide values that must be maintained.

	<b>DN 22 C</b>	<b>DN 30 C</b>	<b>DN 37 C / CXL</b>	<b>DN 45 C</b>
Ventilation inlet air opening $\square$ see Figure 15 [ft <sup>2</sup> ] (Free cross-section)	11.8 / 5.4 <sup>1)</sup>	14.0 / 5.4 <sup>1)</sup>	16.2 / 8.6 <sup>1)</sup>	21.5 / 11.8 <sup>1)</sup>
Required volume of air for exhaust fan $\square$ at static compression 0.01 psi [cfm] (machine in enclosed space without ducts)	8240 8240 <sup>1)</sup>	10594 8240 <sup>1)</sup>	12950 8240 <sup>1)</sup>	15892 8240 <sup>1)</sup>
Exhaust air (hot air) without duct [cfm] <sup>2)</sup>	8240 8240 <sup>1)</sup>	8240 8240 <sup>1)</sup>	8240 8240 <sup>1)</sup>	8240 8240 <sup>1)</sup>
Permissible pressure drop for user's cooling air ducts [inches of water]	1/4 1/4 <sup>1)</sup>	1/4 1/4 <sup>1)</sup>	1/4 1/4 <sup>1)</sup>	1/4 1/4 <sup>1)</sup>

<sup>1)</sup> Option K9

<sup>2)</sup> Basis for duct design

Tab. 9 Ventilation

## 2.8 Pressure

See nameplate for maximum working pressure

<b>Maximum working pressure [psig]</b>	<b>Safety relief valve activating pressure [psig]</b>
<b>145</b>	175
<b>217</b>	245
<b>290</b>	320
<b>360</b>	390
<b>435</b>	465
<b>500</b>	535
<b>580</b>	610



Maximum working pressure [psig]	Safety relief valve activating pressure [psig]
650	670

Tab. 10 Safety relief valve opening pressure

Further information See chapter 13.5 for safety relief valve data.

## 2.9 Calculating the volumetric flow rate

Compressor block rated speed

Type	Rated speed 60Hz [rpm]
N 735 / N1100	790
	843
	895
	948
	1001
	1054
	1117
	1180
	1243
	1317
	—
	—
	N 2001
790	
843	
895	
948	
1001	
1054	
1117	
1180	
1243	
—	
—	

Tab. 11 Compressor block rated speed

**Volumetric flow rate parameters**

	<b>N 753</b>	<b>N 1100</b>	<b>N 2001</b>
<b>KL<sub>a</sub> = Coefficient Flow rate: a</b>	0.603187	0.0134438	0.00914418
<b>KL<sub>b</sub> = Coefficient Flow rate: b</b>	-0.0468106	-0.0476777	-0.0469224
<b>KL<sub>c</sub> = Coefficient Flow rate: c</b>	0.0253737	0.0670051	0.331378
<b>KL<sub>d</sub> = Coefficient Flow rate: d</b>	-2.116820	-0.9540620	-0.00000388326
<b>KL<sub>e</sub> = Coefficient Flow rate: e</b>	0.00077485	0.00104363	-0.0000362599
<b>KL<sub>f</sub> = Coefficient Flow rate: f</b>	-0.00000001138	0.03055930	0.00171004
<b>KL<sub>g</sub> = Coefficient Flow rate: g</b>	—	—	0.000629749
<b>KL<sub>h</sub> = Coefficient Flow rate: h</b>	—	—	-0.00500716
<b>KL<sub>i</sub> = Coefficient Flow rate: i</b>	—	—	-0.000829702
<b>KL<sub>k</sub> = Coefficient Flow rate: k</b>	—	—	-3.38295
<b>KL<sub>r</sub> = Coefficient Flow rate: r</b>	14.50377	14.50377	14.50377
<b>KL<sub>s</sub> = Coefficient Flow rate: s</b>	35.31467	35.31467	35.31467

Tab. 12 Flow rate parameters

**Flow rate calculation formula** (valid for installed compressor block type N 753)

$$Q = \left( a + b \times \left( \frac{p_4 - p_1}{r} \right) + c \times \left( \frac{p_1}{r} \right) \times \left( \frac{p_4}{p_1} \right)^d + e \times \left( \frac{p_1}{r} \right) \times n + f \times n^2 \right) \times s$$

Description of formula:

- Q = Flow rate as per ISO 1217: 2009 (Annex C)
- n = Compressor rated speed
- p<sub>1</sub> = Initial pressure [psi (g)]
- p<sub>4</sub> = Final pressure [psi (g)]

**Example for N 753 compressor block:**

 p<sub>1</sub> = 100 psi(g)

 p<sub>4</sub> = 400 psi(g)

n = 1054 rpm

$$Q = \left( 0.603187 + -0.0468106 \times \left( \frac{400-100}{14.50377} \right) + 0.0253737 \times \left( \frac{100}{14.50377} \right) \times \left( \frac{400}{100} \right)^{-2.11682} + 0.00077485 \times \left( \frac{100}{14.50377} \right) \times 1054 + -0.00000001138 \times 1054^2 \right) \times 35.31467$$

Q = 186 cfm

**Flow rate calculation formula** (valid for installed compressor block type N 1100)

$$Q = \left( a + b \times \left( \frac{p_4 - p_1}{r} \right) + c \times \left( \frac{p_1}{r} \right) \times \left( \frac{p_4}{p_1} \right)^d + e \times \left( \frac{p_1}{r} \right) \times n + f \times n^{0.5} \right) \times s$$

Description of formula:

- Q = Flow rate as per ISO 1217: 2009 (Annex C)
- n = Compressor rated speed
- p1 = Initial pressure [psi (g)]
- p4 = Final pressure [psi (g)]

**Example for N 1100 compressor block:**

p1 = 100 psi(g)

p4 = 400 psi(g)

n = 1054 rpm

$$Q = \left( 0.0134438 + -0.0476777 \times \left( \frac{400-100}{14.50377} \right) + 0.0670051 \times \left( \frac{100}{14.50377} \right) \times \left( \frac{400}{100} \right)^{-0.9540620} + 0.00104363 \times \left( \frac{100}{14.50377} \right) \times 1054 + 0.03055930 \times 1054^{0.5} \right) \times 35.31467$$

Q = 273 cfm

**Flow rate calculation formula** (valid for installed compressor block type N 2001)

$$Q = \left( k + a \times n + b \times \left( \frac{p_4}{r} \right) + c \times \left( \frac{p_1}{r} \right) + d \times (n)^2 + e \times n \times \left( \frac{p_4}{r} \right) + f \times n \times \left( \frac{p_1}{r} \right) + g \times \left( \frac{p_4}{r} \right)^2 + h \times \left( \frac{p_4}{r} \right) \times \left( \frac{p_1}{r} \right) + i \times \left( \frac{p_1}{r} \right)^2 \right) \times s$$

Description of formula:

- Q = Flow rate as per ISO 1217: 2009 (Annex C)
- n = Compressor rated speed
- p1 = Initial pressure [psi (g)]
- p4 = Final pressure [psi (g)]

**Example for N 2001 compressor block:**

p1 = 100 psi(g)

p4 = 350 psi(g)

n = 790 rpm

$$Q = \left( -3.38295 + 0.00914418 \times 790 + -0.0469224 \times \left( \frac{350}{14.50377} \right) + 0.331378 \times \left( \frac{100}{14.50377} \right) + -0.00000388326 \times (790)^2 + -0.0000362599 \times 790 \times \left( \frac{350}{14.50377} \right) + 0.00171004 \times 790 \times \left( \frac{100}{14.50377} \right) + 0.000629749 \times \left( \frac{350}{14.50377} \right)^2 + -0.00500716 \times \left( \frac{350}{14.50377} \right) \times \left( \frac{100}{14.50377} \right) + -0.000829702 \times \left( \frac{100}{14.50377} \right)^2 \right) \times 35.31467$$

Q = 377 cfm

2.10 Example for determining the permissible initial pressure



For more diagrams to be used when calculating the permissible initial pressure, see chapter 13.4.




Fig. 1 Initial pressure diagram

- (A)  $p_4=190 \text{ psi(g)}$   $45 \text{ psi(g)} \leq p_1 \leq 178 \text{ psi(g)}$  at all speeds
- (B)  $p_4=260 \text{ psi(g)}$   $50 \text{ psi(g)} \leq p_1 \leq 190 \text{ psi(g)}$  at  $n= 1243 \text{ min}^{-1}$
- (C)  $p_4=350 \text{ psi(g)}$   $77 \text{ psi(g)} \leq p_1 \leq 140 \text{ psi(g)}$  at  $n= 1243 \text{ min}^{-1}$

2.11 Calculating the configurable switching differential SD

Star-delta machine

$$SD = 14.5 \times \frac{Q}{4 \times \text{receiver size}} \text{ psi}$$

Condition  $SD < p_4 - p_1$

Flow rate Q in cfm (according to ISO 1217:2009, Annex C)

Receiver size in  $\text{ft}^3$

Switching differential SD in psi

Inlet pressure  $p_1$  in [psi (g)]

Final pressure  $p_4$  in [psi (g)]

Example 1

Flow rate Q of machine	307 cfm
Receiver size	53 $\text{ft}^3$

**Example 1**

Inlet pressure p1	145 psi(g)
Final pressure p4	580 psi(g)

Tab. 13 Example 1

$$SD = 14.5 \times \frac{307}{4 \times 53} \text{ psi}$$

SD = 21.0 psi

Checking the condition:

$p_4 - p_1 = 580 \text{ psi(g)} - 145 \text{ psi(g)} = 435 \text{ psi} >$  as switching differential SD 21.0 psi → Condition fulfilled



The set value for the switching differential SD at the controller must not be less than 21.0 psi.

**Example 2**

Flow rate Q of machine	505 cfm
Receiver size	35 ft <sup>3</sup>
Inlet pressure p1	145 psi(g)
Final pressure p4	190 psi(g)

Tab. 14 Example 2

$$SD = 14.5 \times \frac{505}{4 \times 35} \text{ psi}$$

SD = 52.3 psi

Checking the condition:

$p_4 - p_1 = 190 \text{ psi(g)} - 145 \text{ psi(g)} = 45 \text{ psi} <$  as switching differential SD 52.3 psi → Condition **not** fulfilled



Receiver is too small.

**Selected new receiver size 70 ft<sup>3</sup>**

$$SD = 14.5 \times \frac{505}{4 \times 70} \text{ psi}$$

SD = 26,1 psi

Checking the condition:

$p_4 - p_1 = 190 \text{ psi(g)} - 145 \text{ psi(g)} = 44 \text{ psi} >$  as switching differential SD 26.1 psi → Condition fulfilled



The set value for the switching differential SD at the controller must not be less than 26.1 psi.

**2.12 Noise emission [dB(A)]**

Mains frequency	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
60 Hz	79 / 77 <sup>1)</sup>	79 / 77 <sup>1)</sup>	79 / 77 <sup>1)</sup>	79 / 77 <sup>1)</sup>

Noise pressure level in operation at maximum gauge working pressure and maximum attainable speed as per ISO 2151 and the basic standard ISO 9614-2, uncertainty: ±3 dB(A)

<sup>1)</sup> Option K9

Tab. 15 Noise emission [dB(A)]

**2.13 Motors and power**
**2.13.1 Compressor motor**

**Mains frequency: 60 Hz**

	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Rated power [hp]	30	40	50	60
Rated speed [rpm]	3600	3600	3600	3600
Enclosure protection	TEFC	TEFC	TEFC	TEFC
Motor bearing re-greasing interval [h]	4000	4000	4000	4000
Grease requirement, each bearing [g]	10	10	10	10

h = operating hours

Tab. 16 Compressor motor (60Hz)

**2.13.2 Option K1/K9**
**Fan motor**

**Mains frequency: 60 Hz**

	DN 22 C-DN 45 C
Rated power [hp]	2.0
Rated speed [rpm]	1800
Enclosure protection	TEFC
Motor bearing re-greasing interval [h]	6000
Grease requirement A-side bearing [g]	5
Grease requirement B-side bearing [g]	3

h = operating hours

Tab. 17 Fan motor (60Hz)

## 2.14 Compressor oil recommendation

For the nitrogen compression, the ISO320N compressor oil has been filled.  
Information regarding ordering of compressor oil is found in chapter 11.

Oil type	ISO320N
Description	Synthetic oil
Application	Standard oil for all applications in nitrogen compression except food processing.

Tab. 18 Compressor oil recommendation

### 2.14.1 Compressor oil charge quantity

Type	Total charge [quarts]	Topping off volume [qt] (minimum–maximum)
N 753	5.0	0.5
N 1100	5.0	0.5
N 2001	5.0	0.5

Tab. 19 Compressor oil charge quantity

## 2.15 Power supply

### Basic requirements

The machine is designed for an electrical supply according to National Electric Code (NEC), edition 2020, particularly article 670 and NFPA 79, edition 2018, particularly section 4.3. In the absence of any user-specified alternatives, the limits given in these standards must be adhered to. Consult manufacturer for any other specific power supply.

The incoming line within the control panel should be as short as possible.


If external sensors or communication lines are to be connected to the machine, use shielded cables and insert the same through EMC fittings into the control panel.

### Three-phase

Do **NOT** operate package on any unsymmetrical power supply. Also do **NOT** operate package on power supplies such as a three phase WYE system with center point not solidly grounded or three-phase (open) delta.

The machine requires a symmetrical three-phase power supply transformer with a WYE configuration output as shown in Figure 2 and Figure 3. In a symmetrical three phase supply the phase angles and voltages are all the same.

Other power supplies are not suitable.



03-S0235

Fig. 2 Three-phase star (wye); 4 wire; center point solidly grounded



Fig. 3 Three-phase star (wye); 3 wire; center point solidly grounded

Further information Please contact an authorized KAESER service representative for options.  
 The electrical diagram 13.3 contains further specifications for electrical connection.

### 2.15.1 Power supply specifications

The following multi-strand copper core wires are given according to 2020 NEC 310.14, 310.15, 310.16 and table 310.16 for 40°C ambient temperature.

If other local conditions prevail, like for example high temperature, the cross section should be checked and adjusted according to 2020 NEC 110.14(C), 220.3, 310.14, 310.15, 310.16, table 310.15(B)(1), table 310.15(C)(1), 430.6, 430.22, 430.24, 670.4(A) and other local codes.

Dual element time delay fuses are selected according to 2020 NEC 240.6, 430.52 and tables 430.52, 430.248 and 430.250.

It is recommended to use a ground conductor the same size as the current carrying conductors, if local codes allow. Neither the minimum ground wire size as pointed out in 2020 NEC table 250.122 nor using conduit as the sole ground connection is recommended.

Further information The electrical diagram in chapter 13.3 contains further specifications for electrical connection.

#### Rated power supply: 208V / 3ph / 60Hz

Type	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Rated power [hp]	30	40	50	60
Pre-fuse [A]	125	175	200	250
Supply per phase and ground (75 °C)	AWG1/0	AWG3/0	AWG3/0	MCM250
Consumption [A]	92.2	117.4	137.3	167.8

Tab. 20 Supply 208V / 3ph / 60Hz

#### Rated power supply: 230V / 3ph / 60Hz

Type	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Rated power [hp]	30	40	50	60
Pre-fuse [A]	125	150	175	225
Supply per phase and ground (75 °C)	AWG1/0	AWG2/0	AWG3/0	AWG4/0
Consumption [A]	96.1	107.6	125.5	153.8

Tab. 21 Supply 230V / 3ph / 60Hz



Rated power supply: 380V / 3ph / 60Hz

Type	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Rated power [hp]	30	40	50	60
Pre-fuse [A]	70	100	110	125
Supply per phase and ground (75 °C)	AWG4	AWG3	AWG2	AWG1/0
Consumption [A]	48.3	65.2	76.6	93.4

Tab. 22 Supply 380V / 3ph / 60Hz

Rated power supply: 460V / 3ph / 60Hz

Type	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Rated power [hp]	30	40	50	60
Pre-fuse [A]	60	80	90	110
Supply per phase and ground (75 °C)	AWG6	AWG4	AWG3	AWG2
Consumption [A]	42.2	53.8	63.2	76.9

Tab. 23 Supply 460V / 3ph / 60Hz

Rated power supply: 575V / 3ph / 60Hz

Type	DN 22 C	DN 30 C	DN 37 C / CXL	DN 45 C
Rated power [hp]	30	40	50	60
Pre-fuse [A]	45	60	70	90
Supply per phase and ground (75 °C)	AWG8	AWG4	AWG4	AWG3
Consumption [A]	32.1	43.0	50.5	61.5

Tab. 24 Supply 575V / 3ph / 60Hz

## 2.16 Option K9 Water-cooling



Cooling oil may contaminate the cooling water if a leak occurs.

- A special heat exchanger must be used for heating drinking water.

The specific heat capacity and required volume flow rate of the cooling water changes if anti-freeze is added.

- Consult an authorized KAESER service representative to ensure optimum cooling-system performance.
- Comply with the specified minimum requirements for the cooling water in order to avoid downtimes due to corrosion, calcification and contamination.

It is imperative that measures for cooling water treatment and filtration are implemented and performed.

KAESER can provide the names of companies specializing in cooling water analysis and the supply of suitable treatment devices.

The following design types are available:

- Option K9: Water cooling with bundled pipe heat exchanger: Chapter 2.17

**Open cooling system**

An open cooling system may be a cooling circuit with open cooling towers for cooling via evaporation. As a portion of the cooling water evaporates, it must be replenished regularly. During evaporation, the material content of the cooling water concentrates and the contact with ambient air can contaminate the cooling water. When replenishing cooling water, you must ensure the minimum requirements for the cooling water.

**Closed cooling system**

In a closed cooling system, the cooling water has not contact with the atmosphere. Thus, it cannot be contaminated by the atmosphere or enriched with oxygen, for example.

**Continuous-flow cooling system**

A continuous-flow cooling system is an open cooling system. Ground, surface or drinking water circulate once through the cooling system.

Further information The dimensional drawing in chapter 13.2 gives the flow direction, size and position of the connection ports.

**2.17 Option K9  
Water-cooling (shell and tube heat exchanger)**



Some typical design examples are provided here. Individual conditions for each installation may vary from these guidelines.

- If required, enter your own individual values in the table provided.
- In the event of deviating design data, arrange for the SIGMA CONTROL 2 settings to be checked by KAESER service representative.

The primary side of the heat exchanger is connected to the machine. The following figures relate to the secondary side of the heat exchanger.

**Individual design data**

	My value
Cooling water temperature rise [F]	—
Flow rate [gpm]	—
Pressure loss [psi]	—

Tab. 25 Water cooling K9: Individual design data

**2.17.1 Component specifications**

Feature	Value
Material (Heat exchanger)	CuNi10Fe
Maximum gauge working pressure, air side [psig]	725
Maximum gauge working pressure, water side [psig]	145
Minimum permissible inlet temperature <sup>1)</sup> , water side [°F]	14
Maximum permissible inlet temperature, water side [°F]	203
Unsuitable cooling media	Seawater Always consult KAESER regarding the suitability of cooling water solutions

<sup>1)</sup> Suitable antifreeze required.

Tab. 26 Component specifications (Option K9)

**2.17.2 Cooling water quality**

Characteristics/content	Approximate concentration range in [mg/l]	Evaluation
pH value	<6.0	0
	6.0 to 9.0	+
	>9.0	0
Chlorides (Cl) [mg/l]	Up to 1000	+
	>1000	+ (<25000mg/l)
Sulfate (SO <sub>4</sub> ) [mg/l]	Up to 70	+
	70 to 300	+
	>300	+ (<3000mg/l)
Nitrate (HNO <sub>3</sub> ) [mg/l]	Up to 100	+
	>100	0
Free (aggressive) carbon dioxide	Up to 200	+
	20 to 50	0
	>50	-
Oxygen (O <sub>2</sub> )	Up to 2	+
	>2	+

+ ≙ Normally sound resistance

0 ≙ Problems with corrosion may occur, particularly when multiple factors are evaluated as 0

- ≙ High corrosion levels (use not recommended)

Characteristics/content	Approximate concentration range in [mg/l]	Evaluation
Ammonium (NH <sub>4</sub> <sup>+</sup> ) [mg/l]	Up to 2	+
	2 to 20	+
	>20	0
Iron (Fe), dissolved [mg/l]	Up to 10	0
	>10	-
Manganese (Mn), dissolved [mg/l]	Up to 1	0
	>1	-
Free chlorine	Up to 5	Permanent chlorination + <0.5mg/l
	>5	Shock chlorination + <3mg/l
Sulphite (SO <sub>4</sub> ) [mg/l]		0
Ammonia		+ (<15mg/l)

+ ≙ Normally sound resistance

0 ≙ Problems with corrosion may occur, particularly when multiple factors are evaluated as 0

- ≙ High corrosion levels (use not recommended)

Tab. 27 Cooling water quality (shell and tube heat exchanger)

### 2.17.3 Design data for the cooling system

Cooling water temperature rise by 18° F:

	DN 22 C	DN 30 C	DN 37 C	DN 37 CXL	DN 45 C
Maximum permissible inlet temperature [°F]	104	104	104	104	104
Flow rate [gpm]	3.0	4.4	5.2	7,9	6.6
Pressure loss [psi]	3.0	3.0	4.3	7.2	5.8

Tab. 28 Cooling water temperature (ΔT=18° F)

### 2.18 Machine duty cycle

The machine control guarantees a 100% duty cycle.

## 3 Safety and Responsibility

### 3.1 Basic instructions

The machine is manufactured to the latest engineering standards and acknowledged safety regulations. Nevertheless, dangers can arise through its operation:

- danger to life and limb of the operator or third parties,
- impairments to the machine and other material assets.



Disregard of warning or safety instructions can cause serious injuries!

- Use this machine only if it is in a technically perfect condition and only for the purpose for which it is intended; observe all safety measures and the instructions in the service manual.
- Immediately rectify (have rectified) any faults that could be detrimental to safety!

### 3.2 Specified use

The machine is intended solely for generating nitrogen for industrial use. Any other use is considered incorrect. The manufacturer is not liable for any damages that may result from incorrect use. The user alone is liable for any risks incurred.

- Comply with the instructions in this service manual.
- Operate the machine only within its performance limits and under the permitted ambient conditions.

### 3.3 Improper use

Improper usage can cause damage to property and/or (severe) injuries.

- Only use the machine as intended.
- Never direct compressed nitrogen at persons or animals.
- Use hot cooling air for heating purposes only if there is no risk to the health of humans or animals. If necessary, hot cooling air should be treated by suitable means.
- Do not operate the machine in areas in which specific requirements with regard to explosion protection are in force.

### 3.4 User's responsibilities

#### 3.4.1 Observe statutory and universally accepted regulations

These are, for example, nationally implemented European directives and/or applicable national legislation, safety and accident prevention regulations.

- Observe relevant statutory and accepted regulations during installation, operation and maintenance of the machine.

### 3.4.2 Qualified personnel

Suitable personnel are experts who, by virtue of their training, knowledge and experience as well as their knowledge of relevant regulations can assess the work to be done and recognize the possible dangers involved.

Authorized operators possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to operation,
- have received adequate training and authorization to safely handle electrical and nitrogen devices.

Authorized installation and maintenance personnel have the following qualifications:

- are of legal age,
  - must have read, be conversant with and adhere to the safety instructions and sections of the operating manual applicable to installation and maintenance,
  - are fully conversant with the safety concepts and regulations of electrical and nitrogen engineering,
  - are able to recognize the possible dangers of electrical and nitrogen devices and take appropriate measures to safeguard persons and property,
  - have received adequate training in and authorization for the safe installation and maintenance of this machine.
- Ensure that personnel entrusted with operation, installation and maintenance are qualified and authorized to carry out their tasks.

### 3.4.3 Complying with inspection schedules and accident prevention regulations

The machine is subject to local inspection schedules.

- The user must ensure that, for compressors with motor power above 0.5 hp, safety devices are inspected for their proper function at least annually.  
The user must ensure that compressors used for compressing gasses with hazardous properties are checked for leakage at recurring intervals after maintenance work that may affect their tightness. This also applies to pipe that are parts of compressors, as far as these pipes may contain or discharge gasses with hazardous properties.
- Keep to inspection intervals in accordance with the Ordinance on Industrial Health and Safety.

## 3.5 Dangers

### Basic instructions

The following describes the various forms of danger that can occur during machine operation.

Basic safety instructions are found in this service manual at the beginning of each chapter in the section entitled "Safety".

Warning instructions are found before a potentially dangerous task.

### 3.5.1 Safely dealing with sources of danger

The following describes the various forms of danger that can occur during machine operation.

**Electricity**

Touching voltage carrying components can result in electric shocks, burns or death.

- Allow only qualified and authorized electricians or trained personnel under the supervision of a qualified and authorized electrician to carry out work on electrical equipment according to electrical engineering regulations.
- Before commissioning or re-commissioning the machine, the user must make sure there is adequate protection against electric shock from direct or indirect contact.
- Before starting any work on electrical equipment:  
Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Switch off any external power sources.  
These could be connections to floating relay contacts or electrical machine heating, for example.
- Use fuses corresponding to machine power.
- Check regularly that all electrical connections are tight and in proper condition.

**Forces of compression**

Compressed nitrogen is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following information concerns work on components that could be under pressure.

- Close shut-off valves or otherwise isolate the machine from the distribution network to ensure that no nitrogen can flow back into the machine.
- Depressurize all pressurized components and enclosures.
- Do not carry out welding, heat treatment or mechanical modifications to pressurized components (e.g. pipes and vessels) as this influences the component's resistance to pressure. The safety of the machine is then no longer ensured.

**Spring forces**

Springs under tension or compression store energy. Uncontrolled release of this energy can cause serious injury or death.

Check valves, solenoid valves and inlet valves are powerfully spring-loaded.

- Do not open or dismantle any valves.

**Rotating components**

Touching the fan while the machine is running can result in serious injury.

- Do not open the enclosure while the machine is switched on.
- Switch off and lock out the power supply disconnecting device, and verify the absence of any voltage.
- Wear close-fitting clothes and a hair net if necessary.
- Ensure that all covers and safety guards are in place and secured before re-starting.

**Temperature**

High temperatures are generated during compression. Touching hot components may cause injuries.

- Avoid contact with hot components.  
These include, for example, compressor blocks, pressure lines, coolers, motors and machine heaters.
- Wear protective clothing.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting oil vapors or parts of the machine.

#### **Noise**

The enclosure absorbs the machine noise to a tolerable level. This function will be effective only if the enclosure is closed.

- Operate the machine only with intact sound insulation.
- Wear hearing protection if necessary.  
The safety relief valve blowing off can be particularly loud.

#### **Operating fluids/materials**

The used operating fluids and materials can cause adverse health effects. Suitable safety measures must be taken in order to prevent injuries.

- Strictly forbid fire, open flame and smoking.
- Follow safety regulations when dealing with oils, lubricants and chemical substances.
- Avoid contact with skin and eyes.
- Do not inhale oil mist and vapors.
- Do not eat or drink while handling cooling and lubricating fluids.
- Keep suitable fire extinguishing agents ready for use.
- Use only KAESER approved operating materials.

#### **Unsuitable spare parts**

Unsuitable spare parts compromise the safety of the machine.

- Use only spare parts approved by the manufacturer for use in this machine.
- Use only genuine KAESER pressure components.

#### **Conversion or modification of the machine**

Modifications, additions to and conversions of the machine or the controller can result in unpredictable dangers.

- Do not convert or modify the machine!
- Obtain written approval by the manufacturer prior to any technical modification or expansion of the machine, the controller, or the control programs.

#### **Extending or modifying the nitrogen station**

If dimensioned appropriately, safety relief valves reliably prevent an impermissible rise in pressure. New dangers may arise if you modify or extend the nitrogen station.

- When extending or modifying the nitrogen system.  
Check the blow-off capacity of safety relief valves on receivers and nitrogen lines before installing a new machine.
- If the blow-off capacity is insufficient:  
Install safety relief valves with larger blow-off capacity.



### 3.5.2 Safe machine operation

The following is information supporting you in the safe handling of the machine during individual product life phases.

#### Personal protective equipment

When working on the machine you may be exposed to dangers that can result in accidents with severe adverse health effects.

- Wear protective clothing as necessary.

Suitable protective clothing (examples):

- Safety work wear
- Protective gloves
- Safety boots
- Eye protection
- Ear protection

#### Transport

The weight and size of the machine require safety measures during its transport to prevent accidents.

- Use suitable lifting gear that conforms to local safety regulations.
- Allow transportation only by personnel trained in the safe movement of loads.
- Attach lifting gear only to suitable lifting points.
- Be aware of the center of gravity to avoid tipping.
- Make sure the danger zone is clear of personnel.
- Do not step onto machine components to climb up the machine.

#### Assembly

- Use only electrical cables that are suitable and approved for the surroundings and electrical loads applied.
- Never dismantle compressed air pipes until they are fully vented.
- Only use pressure lines that are suitable and approved for the maximum working pressure and the intended medium.
- Do not allow connection pipes to be placed under mechanical stress.
- Do not induce any forces into the machine via the connections, so that the compressive forces must be balanced by bracing.

#### Positioning

A suitable installation location for the machine prevents accidents and faults.

- Install the machine in a suitable compressor room.
- Install and regularly check the nitrogen warning system for correct function.
- Ensure sufficient and suitable lighting such that the display can be read and work carried out comfortably and safely.
- Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.

- If installed outdoors, the machine must be protected from frost, direct sunlight, dust, rain and splashing water.
- Do not operate in areas in which specific requirements with regard to explosion protection are in force.
- Ensure adequate ventilation.
- Place the machine in such a manner that the working conditions in its environment are not impaired.
- Comply with limit values for ambient temperature and humidity.
- The intake air must not contain any damaging contaminants, Damaging contaminants are for instance: explosive or chemically instable gases and vapors, acid or base forming substances such as ammonia, chlorine or hydrogen sulfide.
- Do not position the machine in the warm exhaust air flow from other machines.
- Keep suitable fire extinguishing agents ready for use.

#### **Commissioning, operation and maintenance**

During commissioning, operation and maintenance you may be exposed to dangers resulting from, e.g., electricity, pressure and temperature. Careless actions can cause accidents with severe adverse effects for your health.

- Allow maintenance work to be carried out only by authorized personnel.
- Wear close-fitting, flame-resistant clothing. Wear protective clothing as necessary.
- Switch off and lock out the power supply disconnecting device and verify the absence of any voltage.
- Check that there is no voltage on floating relay contacts.
- Close shut-off valves or otherwise isolate the machine from the distribution network to ensure that no nitrogen can flow back into the machine.
- Depressurize all pressurized components and enclosures.
- Allow the machine to cool down.
- Do not open the cabinet while the machine is switched on.
- Do not open or dismantle any valves.
- Use only spare parts approved by KAESER for use in this machine.
- Carry out regular inspections:
  - for visible damages,
  - of safety installations,
  - of the EMERGENCY STOP push button,
  - of any components requiring monitoring.
- Pay particular attention to cleanliness during all maintenance and repair work. Cover components and openings with clean cloths, paper or tape to keep them clean.
- Do not leave any loose components, tools or cleaning rags on or in the machine.
- Components removed from the machine can still be dangerous.  
Do not attempt to open or destroy any components taken from the machine.

#### **Decommissioning, storage and disposal**

Improper handling of old operating fluids and components represent a danger for the environment.

- Drain off fluids and dispose of them according to environmental regulations.  
These include, for example, compressor oil and cooling water.

- Have refrigerant disposed of by authorized bodies only.
- Dispose of the machine in accordance with local environmental regulations.

#### 3.5.3 Organizational Measures

- Designate personnel and their responsibilities.
- Give clear instructions on reporting faults and damage to the machine.
- Give instructions on fire reporting and fire-fighting measures.

#### 3.5.4 Danger areas

The table gives information on areas dangerous to personnel.

Only authorized personnel may enter these areas.

Function	Danger area	Authorized personnel
Transport	Within a 10 ft. radius around the machine	Installation personnel for transport preparation No personnel during transport
	Beneath the lifted machine	No personnel!
Installation	Within the machine Within a 3 ft. radius of the machine and its power supply cables	Installation personnel
Operation	Within a 3 ft. radius around the machine	Operating personnel
Maintenance	Within the machine	Maintenance personnel
	Within a 3 ft. radius around the machine	

Tab. 29 Danger areas

### 3.6 Safety devices

Various safety devices ensure safe working with the machine.

- Do not change, bypass or disable safety devices.
- Check safety devices for correct function regularly.
- Do not remove or damage labels and notices.
- Ensure that labels and notices are clearly legible.

Further information More information on safety devices is contained in chapter 4, section 4.3.

### 3.7 Service life of safety functions

Pursuant to ISO 13849-1: 2015, the Category and Performance Level (PL) of the machine's safety functions have been analyzed and assessed:

Safety function	Category	Performance Level
EMERGENCY STOP push button	1; 3	c
Check safety shutdown when opening the machine (door limit switch)	1; 3	c

Safety function	Category	Performance Level
Cooler nitrogen inlet temperature switch	1; 3	c

Tab. 30 Category and Performance Level

The safety-relevant components of the safety functions are designed for a working life of 20 years. The service life starts with the commissioning, and is not extended by times during which the machine was not in use.

The following components are affected:

- EMERGENCY STOP push button
- Main contactor
- Door interlock switch
- Cooler nitrogen inlet temperature switch

1. Have the components of the safety functions replaced after a service life of 20 years by an authorized KAESER service representative.
2. Have the reliability of the safety functions checked by an authorized KAESER service representative.

### 3.8 Safety signs

The diagram shows the position of the safety signs on the machine. The table lists the various safety signs used and their meanings.























Fig. 4 Location of safety signs




Item	Symbol	Meaning
1		<p>Hot surface can cause burns!</p> <ul style="list-style-type: none"> <li>➤ Let the machine cool down.</li> <li>➤ Work carefully.</li> <li>➤ Wear long-sleeved garments (not synthetics such as polyester) and protective gloves.</li> </ul>
2		<p>HAZARDOUS VOLTAGE!</p> <p>Touching electrically live components can cause serious injury or death.</p> <ul style="list-style-type: none"> <li>➤ Isolate completely from the power supply (all conductors) and ensure the supply cannot be switched on again (lock out).</li> <li>➤ Check that no voltage is present.</li> </ul>
5		<p>Flying debris!</p> <p>Severe injury, especially of the eyes, could result while the fan is rotating.</p> <ul style="list-style-type: none"> <li>➤ Prevent all materials from falling into the fan guard.</li> <li>➤ Never work over the running machine.</li> <li>➤ Isolate completely from the power supply (all conductors) and ensure the supply cannot be switched on again (lock out).</li> </ul>
8		<p>Danger of falling or damage to the machine!</p> <ul style="list-style-type: none"> <li>➤ Do not sit or walk on the enclosure.</li> <li>➤ Do not place or store any load on the enclosure.</li> </ul>
12		<p>Injury and/or machine defects caused by improper use!</p> <ul style="list-style-type: none"> <li>➤ Maintenance should be performed by properly trained personnel only.</li> <li>➤ Read and understand manual and all safety labels before switching the machine on.</li> <li>➤ Never remove or cover safety labels.</li> </ul>
		<p>Machine starts automatically!</p> <p>Severe injury could result from rotating components, electrical voltage and air pressure.</p> <ul style="list-style-type: none"> <li>➤ Isolate completely from the power supply (all conductors) and ensure the supply cannot be switched on again (lock out).</li> <li>➤ Check that no voltage is present.</li> </ul>
13	 	<p>Severe injury could result from touching the fan blades while it is rotating!</p> <ul style="list-style-type: none"> <li>➤ Never switch the machine on without guard in place over the fan blade.</li> <li>➤ Isolate completely from the power supply (all conductors) and ensure the supply cannot be switched on again (lock out).</li> </ul>
14		<p>Injury and/or contamination can result from breathing nitrogen!</p> <p>Contamination of food can result from using untreated nitrogen for food processing!</p> <ul style="list-style-type: none"> <li>➤ Never breathe untreated nitrogen.</li> <li>➤ Air from this compressor must meet OSHA 29 CFR1910.134 and FDA 21 CFR178.3570 standards, if used for breathing or food processing.</li> <li>➤ Use proper nitrogen treatment.</li> </ul> <p>Food grade coolant must be used for food processing.</p>

Item	Symbol	Meaning
15		Loud noise when safety relief valve opens! Ear damage and burns can occur. <ul style="list-style-type: none"> <li>➤ Wear ear protection and protective clothing.</li> <li>➤ Close all maintenance doors and cover panels.</li> </ul>
16		Serious injury or death can result from loosening or opening component under pressure! <ul style="list-style-type: none"> <li>➤ Isolate the machine from the nitrogen system.</li> <li>➤ Depressurize all pressurized components and enclosures.</li> <li>➤ Ensure that the machine remains depressurized.</li> <li>➤ Check that machine is depressurized.</li> </ul>
18		Bearing damage due to re-greasing in standstill! <ul style="list-style-type: none"> <li>➤ Re-grease the bearings only with the motor running.</li> <li>➤ Use only ESSO UNIREX N3 bearing grease.</li> <li>➤ For lubrication interval and volume required, please refer to service manual.</li> </ul>
24		Risk of hand injury without safety guard! <ul style="list-style-type: none"> <li>➤ Never switch the machine on without guard in place over the fan blade.</li> </ul>
27		Risk of fire or electric shock! If the interrupter has tripped, current-carrying components of the controller should be examined and replaced if damaged to reduce the risk of fire or electric shock.
28		Risk of fire or electric shock! To maintain overcurrent, short-circuit and ground-fault protection, the manufacturer's instructions for setting the interrupter must be followed to reduce the risk of fire or electric shock.
32		<b>EXTERNAL VOLTAGE!</b> Touching electrically live components can cause serious injury or death. <ul style="list-style-type: none"> <li>➤ Isolate completely from the power supply (all conductors) and ensure the supply cannot be switched on again (lock out).</li> <li>➤ Check that no voltage is present.</li> </ul>
34		Serious injury can result from compressed nitrogen. <ul style="list-style-type: none"> <li>➤ Do not direct nitrogen stream at body.</li> </ul>
38	 	Risk of hand injury during machine run-on! <ul style="list-style-type: none"> <li>➤ Wait at least 1 minute following machine shutdown before opening enclosure.</li> </ul>

Tab. 31 Safety signs

### 3.9 Information signs

The table lists the various information signs used and their meanings.

Sign	Meaning
	Maintain the air filter regularly.
	Condensate drainage Check the function of the condensate drainage at regular intervals.
	Check the oil level regularly and change the oil at the correct intervals.

Tab. 32 Information signs

## 3.10 Emergency situations

### 3.10.1 Correct fire fighting

#### Suitable measures

Calm and prudent action can save lives in the event of a fire.

- Keep calm.
- Give the alarm.
- Shut off supply lines if possible.  
Power supply disconnecting device (all phases)  
Cooling water (if present)
- Warn and move endangered personnel to safety.
- Help incapacitated persons.
- Close the doors.
- When trained accordingly: Attempt to extinguish the fire.

#### Extinguishing substances

- Suitable extinguishing media:  
Foam  
Carbon dioxide  
Sand or soil
- Unsuitable extinguishing media:  
Strong jet of water

### 3.10.2 Treating injuries from handling cooling oil

#### Eye contact:

Compressor oil can cause irritation.

- Rinse open eyes thoroughly for a few minutes under running water.
- Seek medical help if irritation persists.

#### Skin contact:

Compressor oil may irritate after prolonged contact.

- Wash thoroughly with skin cleaner, then with soap and water.
- Contaminated clothing should be dry-cleaned before reuse.

**Inhalation:**

Oil mist may make breathing difficult.

- Clear air passages of oil mist.
- Seek medical help if difficulty with respiration continues.

**Ingestion:**

- Wash out the mouth immediately.
- Do not induce vomiting.
- Seek medical aid.

## 3.11 Warranty

This operator manual contains no independent warranty commitment. Our general terms and conditions of business apply with regard to warranty.

A condition of our warranty is that the machine is used for the purpose for which it is intended under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

In addition, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- unauthorized modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of original spare parts and operating materials.

- Obtain confirmation from KAESER that your specific operating conditions are suitable.

## 3.12 Environmental protection

The operation of this machine may cause dangers for the environment.

- Do not allow compressor oil to escape into the environment or into the sewage system.
- Store and dispose of operating materials and replaced parts in accordance with local environmental protection regulations.
- Observe national regulations.  
This applies particularly to parts contaminated with compressor oil.



## 4 Design and Function

### 4.1 Enclosure




Fig. 5 Enclosure overview

- |   |                      |   |                   |
|---|----------------------|---|-------------------|
| ① | Control cabinet door | ③ | Access door       |
| ② | Latch                | ④ | Panel (removable) |

The enclosure, when closed, serves various functions:

- Sound insulation
- Protection against contact with components
- Cooling air flow

The enclosure is not suitable for the following uses:

- Walking on, standing or sitting on.
- As resting place or storage of any kind of load.

Safe and reliable operation is only assured with the enclosure closed.

Access doors are hinged to swing open, removable panel must be lifted off.

Latches are released by a key supplied with the machine.

### 4.2 Machine function

The description uses an air-cooled machine as an example.




Fig. 6 Machine overview

- |   |   |   |                    |
|---|---|---|--------------------|
| ① | Compressor block                        | ⑥ | Air cooler         |
| ② | Compressor motor                        | ⑦ | Nitrogen inlet     |
| ③ | Fan motor                               | ⑧ | Nitrogen discharge |
| ④ | Network pressure gauge (inlet pressure) | ⑨ | Control cabinet    |
| ⑤ | Network pressure gauge (final pressure) |   |                    |

### 4.2.1 Description

The compressor block is driven by an electric motor via V-belts.

The block has three cylinders.

The cooling fins at the cylinder and the cylinder head dissipate the heat which is driven by a fan out of the machine's interior.

Under LOAD, the inlet valve is opened and the safety relief valve is closed.

The pre-compressed nitrogen is sent through opened inlet valve into the compressor block and transported into the high-pressure system through the opened check valve and the cooler.

During this process, the cooler cools the compressed nitrogen.

### 4.3 Safety devices

The following safety devices are provided and may not be modified in any way.

- **EMERGENCY STOP control device:**  
Stops the machine immediately in an emergency situation. The motor is stopped. The pressure system is vented.
- **Safety relief valve:**  
The safety relief valve protects the system against excessive pressure. It is factory set.
- **Door interlock switch:**  
The machine will stop automatically if a safety interlocked door or panel is opened or removed.
- **Housing and covers for moving parts and electrical connections:**  
Protect against accidental contact.
- **Temperature sensors:**  
Triggers machine shut down if impermissible high temperatures occur.
- **Pressure transducer:**  
Monitors the pressure conditions at various locations in the machine.

The operator is responsible for the provision of the following safety equipment:

- Nitrogen warning system:  
Monitors the breathing air in the machine room and to warn of low oxygen content.
- Safety signs nitrogen:  
Identifies the installation room with "Nitrogen" safety sign at the outside.

## 4.4 Operating panel SIGMA CONTROL 2

### Keys




Fig. 7 Keys – overview

Item	Name	Function
1	«OFF»	Switches the machine off.
2	«ON»	Switches the machine on.
3	«Escape»	Returns to the next higher menu option level. Exits the edit mode without saving.
4	«Enter»	Jumps to the selected menu option. Exits the edit mode and saves.
5	«Down»	Scrolls down the menu options. Reduces a parameter value.
6	«Right»	Jumps to the right. Moves the cursor position to the next right field.
7	«Left»	Jumps to the left. Moves the cursor position to the next left field.
8	«Up»	Scrolls up the menu options. Increases a parameter value.

Item	Name	Function
9	«Events & Information»	Operating mode: Displays the event memory.
10	«Acknowledgement»	Confirms/acknowledges alarms and warning messages. If permissible: Resets the fault counter (RESET).
11	«LOAD/IDLE»	Toggles between the LOAD and IDLE operating modes.
12	«Remote control»	Switches the remote control on and off.
13	«Timer control»	Switches the timer control on and off.

Tab. 33 Keys

**LEDs**




Fig. 8 Indicators – overview

Item	Name	Function
14	Indicator field or display	Graphic display with 8 lines and 30 characters per line.
15	<i>Fault</i>	Flashes red to indicate a machine fault. Continuous red light after acknowledgement.
16	<i>Communication</i>	Continuous red illumination if a communication connection (Ethernet, USS, COM modules) has a fault.
17	<i>Warning</i>	Flashes in yellow in the following events: <ul style="list-style-type: none"> <li>■ Maintenance work due</li> <li>■ Warning message</li> </ul> Lights yellow continuously when acknowledged.
18	<i>Control voltage</i>	Lights green when the power supply is switched on.
19	<i>LOAD</i>	Lights green when the compressor is running under LOAD.

Item	Name	Function
20	<i>IDLE</i>	Lights green when the compressor is running in IDLE. Flashes when the «LOAD/IDLE» toggle key is pressed.
21	<i>Remote control</i>	The LED lights when the machine is in remote control.
22	<i>Timer control</i>	The LED lights when the machine is in clock control (timer).
23	<i>Machine ON</i>	Lights green when the machine switched on.

Tab. 34 Indicators

**RFID sensor field**

RFID is the abbreviation for “Radio Frequency Identification” and makes possible to identify persons and objects.

Placing a suitable transponder in front of the RFID sensor field of the controller will automatically activate the communication between transponder and SIGMA CONTROL 2.

A suitable transponder is the KAESER RFID Equipment Card. Two of them have been provided with the machine.

Typical application:

- Users log on to the machine.  
(no manual input of the password required.)




Fig. 9 RFID sensor field

Item	Name	Function
24	RFID	RFID sensor field for the communication with a suitable RFID transponder.

Tab. 35 RFID sensor field

Further information More information about the use of RFID technology is provided in the SIGMA CONTROL 2 operating manual.

**4.5 Operating modes and control modes**

**4.5.1 Machine operating modes**

**STOP**

The machine is connected to the power supply.  
The *Controller voltage* LED lights green.  
The machine is switched off. The *ON* LED is extinguished.

**READY**

The machine has been activated with «ON»:

- The *ON*LED lights green.
- The drive motor is stopped.
- The inlet valve is closed.
- The inlet control valve is closed.
- The venting valve is open.
- The return valve is closed.
- The check valve upstream of the cooler prevent the compressed nitrogen from flowing back from the high-pressure side into the compression stage.

The compressor motor starts as soon as system pressure is lower than the setpoint pressure (cut-out pressure).

In addition, timing and/or remote control may affect the start of the motor.

**LOAD**

The compressor motor runs under load.

- The inlet valve is open.
- The venting valve is closed.
- The return valve is closed.
- The airend delivers compressed nitrogen to the distribution network.

**IDLE**

The compressor motor runs unloaded with low power consumption.

- The inlet valve is closed.
- The inlet control valve is closed.
- The venting valve is closed.
- The return valve is open.

Upon expiration of a defined time, the return valve is closed and the machine switches to LOAD.

**4.5.2 Control modes**

Using the selected control mode, the controller switches the machine between its various operational states in order to compensate for nitrogen being drawn off by consumers and maintain system pressure between the set minimum and maximum values. The control mode also rules the degree of energy efficiency of the machine.

The machine-dependant venting phase between the LOAD and READY operating modes ensures load changes at minimum material stresses.

The controller SIGMA CONTROL 2 can operate in the following modes:

- DUAL
- QUADRO
- DYNAMIC
- VARIO

Energy-efficient control modes for various applications:

Application	Recommended control mode
Nitrogen station with one machine or several machines with comparable delivery	VARIO
Machine for peak load in a nitrogen station	VARIO
Machine for intermediate load in a nitrogen station	DYNAMIC*
Machine for basic load in a nitrogen station	DYNAMIC*

\* At exceedingly high pressure fluctuations or frequent drive motor starts (current peaks), switch from DYNAMIC to VARIO.

Tab. 36 Energy-efficient control modes

The SIGMA CONTROL 2 controller is factory set to DYNAMIC control mode unless specifically ordered otherwise.

### DUAL

In the DUAL control mode, the machine is switched back and forth between LOAD and IDLE to maintain the machine working pressure between the preset minimum and maximum values. When maximum pressure is reached, the machine switches to IDLE. When the preset *idling time* has elapsed, the machine switches to READY.

The *idling time* is factory preset according to the maximum starting frequency of the compressor motor. The shorter the *idling time* setting, the sooner (and more frequently) the drive motor is stopped.

### QUADRO

In contrast to the DUAL regulating mode, the machine will switch from LOAD to READY in QUADRO mode after periods with low nitrogen consumption.

After periods with a high nitrogen consumption, the machine will switch from LOAD to READY after passing through IDLE.

In this control mode, the controller requires two specified times: The *running time* and the *idle/standstill time*.

The shorter these times are set, the sooner (and more frequently) the motor is stopped.

### DYNAMIC

In contrast to the DUAL regulating mode, the machine will switch from LOAD to READY in DYNAMIC mode at low drive motor temperature.

And from LOAD via IDLE to READY at a high drive motor temperature.

The lower the drive motor temperature, the sooner (and, therefore, more often and longer) it is stopped.

### VARIO

The VARIO mode is based on the DUAL control mode. The difference to DUAL is that the *idling time* is automatically lengthened or shortened to compensate for higher or lower machine starting frequencies.

## 4.6 Oil level monitoring

SIGMA CONTROL 2 will issue a warning when the oil level is too low.




Fig. 10 Oil level monitoring

- ① Compressor block
- ② Oil level sensor
- ③ Oil sight glass

➤ Regular visual check of the oil level is necessary despite oil level monitoring.

## 4.7 Floating relay contacts

Floating relay contacts for the transmission of messages are provided. Information on location, loading capacity, and message type is found in the electrical wiring diagram.



If the floating relay contacts are connected to an external power source, they may be under power even when the machine is isolated from the power supply.

## 4.8 Options

The options available for your machine are described below.

### 4.8.1 Option F15 KAESER FILTER KD

- KAESER FILTER KD removes solid particles from the intake nitrogen.

The manual condensate drain serves only for the purposes of monitoring, since no liquid is removed from the nitrogen stream. Only in the event of a fault will oil or an oil-water mixture be discharged.






Fig. 11 Option F15 KAESER FILTER KD

- ① KAESER FILTER KD
- ② Manual condensate drain (shut-off valve)

Further information A description of the option codes can be found in chapter 2.3.

### 4.8.2 Option H1 Machine mountings

These mountings allow the machine to be anchored firmly to the floor.




Fig. 12 Machine mountings

### 4.8.3 Option H4 Oil collection tray

Any leaks occurring at the machine are captured by the oil collection tray.




Fig. 13 Oil collection tray

- ① Oil collection tray

#### 4.8.4 Option K9 Water-cooling

Bundled-pipe heat exchangers are used in water-cooled machines.



Fig. 14 Water cooling (Option K9)

① Air cooler (water-cooled)

## 5 Installation and Operating Conditions

### 5.1 Ensuring safety

The conditions in which the machine is installed and operated have a decisive effect on safety. Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

#### Complying with safety warnings

Disregard of safety warnings can cause unforeseeable dangers!

- Strictly forbid fire, open flame and smoking.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting oil vapors or parts of the machine.
- Do not store inflammable material in the vicinity of the machine.
- The machine is not explosion-proof:  
Do not operate in areas in which specific requirements with regard to explosion protection are in force.
- Ensure sufficient and suitable lighting such that the display can be read and work carried out comfortably and safely.
- Use a duct to discharge the machine exhaust air to the outside. Exhaust air openings must not be closed.
- Ensure that a nitrogen warning system is installed in the installation location of the nitrogen compressor to alert when oxygen levels are insufficient and to prevent a risk of asphyxiation.
- Keep suitable fire extinguishing agents ready for use.
- Ensure that required ambient conditions are maintained.

Required ambient conditions may be:

- Maintain ambient temperature and humidity
- Ensure the appropriate composition of the air within the machine room:
  - clean with no damaging contaminants (e.g., dust, fibers, fine sand)
  - free of explosive or chemically unstable gases or vapors
  - free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulfide

### 5.2 Installation conditions

#### 5.2.1 Determining the installation location and clearances

The machine is intended for installation in a suitable machine room. Information on wall clearances and ventilation is given below.



The clearances specified are recommended clearances and ensure unhindered access to all machine parts.

- In the event that these cannot be complied with, please consult an authorized KAESER service representative for further advice.

**Precondition** The floor must be level, firm and capable of bearing the weight of the machine.




Fig. 15 Recommended installation, distances [in.]

- (A) Exhaust fan
- (B) Exhaust air duct
- (Z) Ventilation inlet air opening

1. **NOTICE** *Ambient temperature too low!*  
Frozen condensate and highly viscous compressor oil can cause damage when starting the machine.
  - Ensure that the temperature of the machine is at least +37°F before switching it on.
  - Heat the machine room sufficiently or install a auxiliary heater.
2. Ensure accessibility and adequate lighting so that all work on the machine can be carried out without danger or hindrance.
3. Ensure that the indicators can be read without glare and that the controller display cannot be damaged by direct sunlight (UV radiation).
4. Ensure that all air inlet and exhaust air openings in the enclosure remain open.
5. Observe additional clearances in accordance with local occupational safety and building regulations, so as to ensure that escape and rescue routes can be reached safely even when the machine housing is open.



If the machine is installed in a location containing other equipment (compressors, refrigerated dryers, etc.), then **under no circumstances** may hot exhaust air be directed towards the cooling air inlet side of the machine.  
Hot exhaust air can cause damage to the machine.

### 5.2.2 Ensuring adequate machine room ventilation

In the absence of an exhaust air duct, a high-performance exhaust fan must be installed at the user-end (see chapter 2.7).

Adequate ventilation of the machine room fulfils several functions:

- It conveys exhaust heat away from the machine, thus ensuring the necessary operating conditions.



➤ In the event that conditions for adequate ventilation of the machine room cannot be guaranteed, please consult an authorized KAESER service representative for further advice.

1. Ensure that the volume of air flowing into the machine room is at least equivalent to that being removed from it by the machine and exhaust fan.
2. Ensure that the machine and exhaust fan can only be operated when the air inlet opening is open.
3. Keep the inlet and exhaust openings free from obstructions so that the cooling air can flow freely through the machine room.
4. Ensure clean air so as to support the proper functioning of the machine.

Further information See chapter 13.2 for dimensions of air inlet and exhaust air openings.

### 5.2.3 Installing a nitrogen warning system

The operator must ensure that a nitrogen warning system is installed in the machine room containing the nitrogen compressor, in order to raise the alarm should oxygen levels become insufficient and thereby prevent any risk of asphyxiation.

➤ Check the nitrogen warning system regularly to ensure reliable operation.

### 5.2.4 Exhaust air ducting design

The exhaust air duct serves to convey away the cooling air, which results in the room heating up less than it would otherwise (lower air inlet requirement).

On the air inlet and exhaust air side, the machine can only overcome the air resistance stipulated within its design specifications. Any additional air resistance will reduce the airflow and negatively affect cooling of the machine.

Consult an authorized KAESER service representative before determining:

- Design of the exhaust air ducting
- Junction between machine and exhaust air ducting
- Length of the ducting
- Number of bends in the ducting
- Design of flaps or shutters

➤ Consult an authorized KAESER service representative for advice.

## 5.3 Operating the machine in a nitrogen network

When the machine is connected to a nitrogen system, the network working pressure may not exceed the permissible final pressure of the machine.

When charging a fully vented nitrogen network there is generally a very flow speed through the nitrogen treatment devices. These conditions are detrimental to correct air treatment. Nitrogen quality suffers.

To ensure the desired nitrogen quality when charging a vented air network, we recommend the installation of a main charging system to fill the empty nitrogen network under controlled conditions.

➤ Consult an authorized KAESER service representative for advice on this subject.

## 6 Installation

### 6.1 Ensuring safety

Follow the instructions below for safe installation.

Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

#### Complying with safety warnings

Disregard of safety warnings can cause unforeseeable dangers!

- Follow the instructions in chapter 3 "Safety and Responsibility".
- Installation work may only be carried out by authorized personnel.
- Make sure that no one is working on the machine.
- Ensure that all service doors and panels are locked.

#### Working on live components

Touching voltage carrying components can result in electric shocks, burns or death.

- Work on electrical equipment may only be carried out by authorized electricians.
- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Check that the floating relay contacts are voltage-free.

#### Working on the compressed air system

Compressed nitrogen is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following safety concerns relate to any work on components that could be under pressure.

- Isolate the machine from the nitrogen network by closing the user's nitrogen inlet and discharge shut-off valves.
- Depressurize all pressurized components and enclosures (see chapter 10.12).
- Do not open or dismantle any valves.

#### When working on the drive system

Touching voltage carrying components can result in electric shocks, burns or death.

Touching the fan while the machine is running can result in serious injury.

- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Do not open the cabinet while the machine is switched on.

Further information Details of authorized personnel are found in chapter 3.4.2.  
Details of dangers and their avoidance are found in chapter 3.5.

## 6.2 Reporting transport damage

1. Check the machine for visible and hidden transport damage.
2. Inform the carrier and the manufacturer in writing of any damage without delay.

## 6.3 Connecting the machine to the nitrogen network

Install flexible pressure lines that run as directly as possible to the low-pressure and high-pressure sides of the machine. If the lines are directed upwards, 90 ° bends may be required.

Use a swan neck pipe to connect to the low-pressure and high-pressure networks.



Condensate in the nitrogen network can damage the piping:

- Only use corrosion-resistant piping.
- Use fluoroelastomers as the material for the seals.
- Take the electrochemical series into account.
- Consult KAESER regarding suitable materials for the nitrogen network.
- Do not introduce or discharge any forces to/from the machine for which the compressive forces must be compensated by bracing.

Precondition Fully vent the nitrogen network (see chapter 10.12).

### **⚠ WARNING**

*High pressure!*

*High, pulsating and swelling pressures.*

- *Avoid compressive forces entering/exiting the machine by using appropriate bracing (fixed point) for the compressed air lines.*

### 6.3.1 Connecting the machine to the low-pressure network




Fig. 16 Low-pressure network connection

- |                        |   |
|------------------------|---|
| ① Nitrogen line        | ④ Flexible pressure line                |
| ② Low-pressure network | ⑤ Machine (low-pressure nitrogen inlet) |
| ③ KAESER FILTER KD     | ⑥ User-end shut-off valve               |

- Install a KAESER FILTER KD to ensure reliable operation of the machine (when Option F15 is selected, a KAESER FILTER KD is not required at the user-end).

1. **⚠ WARNING** *Serious injury can result from loosening or opening components under pressure!*
  - Fully vent all pressurized components and enclosures.
  - A shut-off valve must be installed by the user in the connecting line.
2. Connect the machine to the low-pressure network using a flexible compressed air line.

### 6.3.2 Connecting the machine to the high-pressure network




Fig. 17 High-pressure network connection

- |                             |                           |
|-----------------------------|---------------------------|
| ① Machine (nitrogen outlet) | ③ Flexible pressure line  |
| ② Machine (nitrogen inlet)  | ④ User-end shut-off valve |

- Install an electronic condensate drain to prevent condensate from flowing back into the machine.
1. **⚠ WARNING** *Serious injury can result from loosening or opening components under pressure!*
    - Fully vent all pressurized components and enclosures.
  2. A shut-off valve must be installed by the user in the connecting line.
  - Connect the machine to the high-pressure network using a flexible compressed air line.

Further information For the size and positions of the nitrogen connections, see the dimensional drawing in chapter 13.2.



**Piping example**




Fig. 18 Piping example

- |   |                       |   |   |
|---|-----------------------|---|---|
| ① | Booster               | ⑤ | KAESER FILTER KD                            |
| ② | High-pressure network | ⑥ | Fixed point                                 |
| ③ | Low-pressure network  | ⑦ | Electronic condensate drain (high pressure) |
| ④ | Condensate line       |   |   |

- A shut-off valve must be installed by the user in the condensate line.
- Install the electronic condensate drain (high pressure) as a water trap in the nitrogen outlet line.



When Option F15 is selected, a KAESER FILTER KD is not required at the user-end.

**6.4 Installation example**

The following installation example is a suggestion only and does not relate to an actual application.




Fig. 19 Installation example (suggestion)

- |                               |                                    |
|-------------------------------|------------------------------------|
| (A) Low-pressure network      | (6) KAESER FILTER KD               |
| (B) High-pressure network     | (7) Booster                        |
| (1) Rotary screw compressor   | (8) Air-main charging system       |
| (2) Air receiver              | (9) Condensate drain               |
| (3) Refrigerated dryer        | (10) Condensate treatment system   |
| (4) KAESER FILTER, e.g. KE/KA | (11) High-pressure venting chamber |
| (5) KAESER FILTER KC (Option) |                                    |

## 6.5 Connecting the condensate drain

A threaded connection is provided for attaching a condensate line.



The condensate must be able to drain off freely.

- Only a condensate collection line with a minimum permissible gauge working pressure of 910 psi may be connected to the machine.

Fig. 20 illustrates a recommended installation.

Condensate flows downwards into the condensate collection line. This prevents condensate from flowing back into the machine.

If condensate flows into the condensate collection line at several points, shut-off valves must be installed in the condensate lines so as to be able to shut off the lines before commencing any maintenance work.

**Condensate line**

Characteristic	Value
Max. length <sup>1)</sup> [ft]	50
Max. delivery head [ft]	16
Material (pressure-resistant, corrosion-proof)	Copper Stainless steel Hose line

<sup>1)</sup> For longer lengths, please contact the manufacturer before installation.

Tab. 37 Condensate line

**Condensate collection line**

Characteristic	Value
Gradient [%]	≥3
Max. length <sup>1)</sup> [ft]	65
Material (pressure-resistant, corrosion-proof)	Copper Stainless steel Hose line

<sup>1)</sup> For longer lengths, please contact an authorized KAESER service representative before installation

Tab. 38 Condensate collection line

Nitrogen flow rate <sup>1)</sup> [cfm]	Line cross-section ["]
<350	3/4
350 – 700	1
701 – 1400	1 1/2
>1400	2

<sup>1)</sup> Use the nitrogen flow rate as a guide for the expected condensate volume

Tab. 39 Condensate collection line: Line cross-section




Fig. 20 Connecting the condensate drain

- |   |                            |   |                                      |
|---|----------------------------|---|--------------------------------------|
| ① | Threaded connection        | ⑤ | Shut-off valve                       |
| ② | Condensate line            | Ⓐ | Delivery head                        |
| ③ | Condensate collection line | Ⓑ | Length of condensate collection line |
| ④ | Screw plug                 |   |                                      |

Depending on the version of the machine, you may require multiple condensate drains.

➤ Connect each condensate drain directly to the condensate collection line.



➤ Collect the condensate in a suitable collection container and dispose of it in accordance with applicable environmental regulations.

Further information The dimensional drawing in chapter 13.2 provides the size and position of the connection port.

## 6.6 Connecting the machine to a power supply network

**Precondition** The power supply disconnecting device is switched off, lock out / tag out the device, the absence of any voltage has been verified.

The tolerance limits of the power supply network are within the permissible tolerance limits of the rated machine voltage.


1. The power supply must only be established by authorized installation personnel or authorized, certified electricians.
2. Observe required safety measures as stipulated in the applicable regulations and in national accident prevention regulations. Also observe the regulations of the local electricity supplier.
3. Select supply cable cross-sections and overcurrent protective devices (backup fuses) in accordance with local regulations.
4. Test the overload protective device to ensure that the time it takes to disconnect in response to a fault is within the permitted limit.
5. The user is required to fit the machine with a lockable power supply disconnecting device in accordance with local regulations.  
This could be, for example, a load disconnecting switch with fused input. If a circuit breaker is used, it must be suitable for the applicable motor starting characteristics.
6. Check that the control voltage transformer connections are in accordance with the power supply.  
If necessary, reconnect the control transformer to suit the power supply.

7. **⚠ DANGER** *Danger of fatal injury from electric shock!*
  - *Switch off and lock out / tag out the power supply disconnecting device and verify the absence of any voltage.*
8. Connect the machine to the power supply.

Further information The wiring diagram in chapter 13.3 contains further details regarding the electrical connection.

## 6.7 Options

### 6.7.1 Option H1 Anchoring the Machine



04-P0023

Fig. 21 Machine mountings

- Use appropriate fixing bolts to anchor the machine.

Further information Details of the fixing holes are contained in the dimensional drawing in chapter 13.2.

### 6.7.2 Option H4 Oil collection tray



Any leaks occurring at the machine are captured by the oil collection tray.

Precondition Installation site is level  
Sufficient space for the assembly  
Suitable hoisting gear




Fig. 22 Oil collection tray

- |                       |                                   |
|-----------------------|-----------------------------------|
| ① Oil collection tray | ③ Support plate for mounting feet |
| ② Fixing points       | ④ Mounting feet                   |

- Horizontally align the oil collection tray on the ground and fasten at the fixing points.
- Use suitable hoisting gear to place the machine on the oil collection tray in such a manner that the mounting feet stand securely on the support plates.
- Screw the mounting feet onto the support plates.

### 6.7.3 Option K9 Connecting the cooling water



- Take the electrochemical series into consideration and choose suitable materials for water connections.
- Keep the effect of pressure surge on the heat exchanger as low as possible.
- Install an expansion tank to act as a pulsation dampener if pressure surges cannot be avoided.
- Avoid a low inlet temperature for the cooling water as it can cause condensation. If required, contact an authorized KAESER service representative for suitable insulation measures.

Temperature-controlled cooling water supply systems, to which numerous machines are connected, regulate water volumetric flow rate according to the difference in temperature between the supply and the return water. Individual machines may not receive an adequate volumetric flow under this system. Breakdowns are the result.



- KAESER can advise on how to ensure the cooling water supply via suitable control valves.



Fig. 23 Connecting the cooling water

- |      |                      |      |                           |
|------|----------------------|------|---------------------------|
| (A)  | Cooling water outlet | (12) | Connection port with plug |
| (B)  | Cooling water inlet  | (17) | Safety relief valve       |
| (10) | Shut-off valve       |      |                           |

1. The user is to provide the following fittings:
  - Dirt traps (grid size according to permissible particle size).
  - Shut-off valves (10) and connection ports (12) for maintenance and venting.
  - Safety relief valve (17) to prevent build-up of excessive pressure.  
Actuating pressure and blow-off capacity of the safety valve are governed by the user's installation design. The technical specification of the cooler and the machine must be taken into consideration.
2. Connect the cooling water lines to the fittings.
3. Open the shut-off valve on the cooling water outlet (A).
4. Slowly open the cooling water inlet shut-off valve (B) to gradually fill the cooler with water.
5. Bleed air from the water lines.

Further information The dimensional drawing in chapter 13.2 gives the flow direction, size and position of the connection ports.

## 7 Initial Start-up

### 7.1 Ensuring safety

Here you will find instructions for a safe commissioning of the machine. Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

#### Complying with safety warnings

Disregard of safety warnings can cause unforeseeable dangers!

- Follow the instructions in chapter 3 "Safety and Responsibility".
- Installation work may only be carried out by authorized personnel.
- Make sure that no one is working on the machine.
- Ensure that all service doors and panels are locked.

#### Working on live components

Touching voltage carrying components can result in electric shocks, burns or death.

- Work on electrical equipment may only be carried out by authorized electricians.
- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Check that there is no voltage on floating relay contacts.

#### Working on the compressed air system

Compressed nitrogen is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following safety concerns relate to any work on components that could be under pressure.

- Isolate the machine from the nitrogen network by closing the user's nitrogen inlet and discharge shut-off valves.
- Depressurize all pressurized components and enclosures (see chapter 10.12).
- Do not open or dismantle any valves.

#### Working on the drive system

Touching voltage carrying components can result in electric shocks, burns or death.

Touching the fan while the machine is running can result in serious injury.

- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Do not open the cabinet while the machine is switched on.

Further information Details of authorized personnel are found in chapter 3.4.2.  
Details of dangers and their avoidance are found in chapter 3.5.

### 7.2 Instructions to be observed before commissioning

Incorrect or improper commissioning can cause injury to persons and damage to the machine.



## 7 Initial Start-up

### 7.3 Checking installation and operating conditions

- Commissioning may be carried out only by authorized installation and service personnel who have been trained on this machine.

#### Special measures for re-commissioning after storage/standstill

Storage period/ standstill longer than	Measure
12 months	➤ Change the compressor oil.
36 months	➤ Have the overall technical condition checked by an authorized KAESER service representative.

Tab. 40 Re-commissioning after storage/standstill

### 7.3 Checking installation and operating conditions

- Check and confirm all the items on the checklist before commissioning the machine:

Check:	See chapter	Confirmed?
➤ Are the operators completely familiar with the applicable safety regulations?	–	
➤ Have all of the installation conditions been fulfilled?	5	
➤ Has a lockable power supply disconnecting device been installed at the user-end?	6.6	
➤ Are the tolerance limits of the power supply network within the permissible tolerance limits of the rated machine voltage? (See nameplate in the control cabinet)	2.1	
➤ Are the cable cross-sections and fuse ratings sufficient?	2.15.1	
➤ Is the compressor motor overload relay appropriate for the power supply voltage?	7.4	
➤ Is the fan motor protection switch appropriate for the power supply voltage?	7.4	
➤ Have all electrical connections been checked for tightness?	–	
➤ Has the inspection been repeated after 50 operating hours following the initial commissioning?	–	
➤ Have the connections to the low-pressure network and high-pressure network been established using a shut-off valve and flexible pressure line?	6.3	
➤ Has the belt tension been checked?	10.23	
➤ Has it been rechecked after 24 operating hours following initial commissioning?	–	
➤ Is there sufficient oil in the compressor block housing? (With the machine switched off, the oil level should be 0.2 – 0.3 inches above the red zone on the oil sight glass)	10.13	
➤ Has an external condensate line been connected?	–	
➤ Has it been verified that no other nitrogen components are located in the hot exhaust air flow exiting the machine?	5.2.4	

Check:	See chapter	Confirmed?
➤ Is the machine firmly anchored to the floor without stress? (Option H1)	6.7.1	
➤ Is there a guaranteed supply of cooling water? (Option K9)	6.7.3	
➤ Has the door limit switch been aligned and its function checked?	7.8	
➤ Are all maintenance doors closed and all removable panels secured in place?	–	

Tab. 41 Checklist for installation conditions

## 7.4 Setting the overload protection relay

Electrical diagram 13.3 gives the location of the overload relay.

With star-delta starting, the phase current is fed via the overload protection relay. This phase current is 0.58-times the rated motor current.

To prevent the overload relay being triggered by voltage fluctuations, temperature influences or component tolerances, the setting can be higher than the arithmetical phase current.

- Check the overload protection relay setting.



The overload protection relay shuts the machine down despite being correctly set?

- Contact an authorized KAESER service representative.

## 7.5 Checking the motor protection switch settings

Electrical diagram in chapter 13.3 gives the setting values for the motor overload protection switch.

In direct on-line starting, the current for the fan motor is fed via the motor overload protection switch.



To prevent the motor overload protection switch from being triggered by voltage fluctuations, temperature influences or component tolerances, the setting can be higher than the rated motor current.

- Check the motor overload protection switch setting.



The overload protection switch shuts the machine down despite being correctly set?

- Contact an authorized KAESER service representative.

## 7.6 Starting the machine for the first time

Precondition No personnel are working on the machine.  
All access doors are closed.  
All removable panels in place and secured.

1. Open the shut-off valve to the nitrogen network.
2. Switch on the power supply disconnecting device.

After the controller has carried out a self-test, the green *Controller on* LED is lit continuously.

3. If required:  
Change the display language as described in chapter 7.9.
4. Press the «ON» key.  
The compressor motor runs up and after a short time the machine switches to LOAD and delivers nitrogen.



- Watch for any faults occurring in the first hour of operation.
- After the first 50 operating hours, check all electrical connections and tighten where necessary.



- Does the machine stop when the compressor motor rotates in the wrong direction?
- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
  - Changeover phase lines L1 and L2.
  - Acknowledge any existing alarm messages and switch the machine on again.

## 7.7 Inlet and discharge pressure

Inlet and discharge pressure are factory set.

An adjustment is possible to suit other individual operating conditions.



Do not set the machine's maximum working pressure higher than the maximum working pressure of the nitrogen system connected.

The machine may not switch more than twice per minute between LOAD and IDLE.

To improve the switching frequency:

- Increase the difference between cut-in and cut-out pressure.
  - Add a larger receiver downstream to increase buffer capacity.
- Set the target pressure as described in the SIGMA CONTROL 2 service manual.

## 7.8 Checking the door interlock switch

The interlock switch stops the machine as soon as the panel is opened.

Check the interlock switch function when commissioning or re-commissioning the machine.



The door interlock switch is an important safety device.  
The machine may only be operated with a correctly functioning interlock switch.




Fig. 24 Position of the door interlock switch

- ① Door interlock switch
- ② Removable panel

1. Open the access panel ② after switching on the machine.  
The machine shuts down automatically. The controller displays an alarm message.
2. Close the panel and acknowledge the alarm.



The machine does not shut down?

- Have the interlock switch checked by an authorized KAESER service representative.

## 7.9 Setting the display language

The controller can display text messages in several languages.

You can set the language for texts on the display. This setting will be retained even when the machine is switched off.

1. In operating mode, switch to the main menu with the «Return» key.
2. Press the «UP» or «DOWN» keys until the current language is shown as active line (inverse):

145 psig	176.0 °F	505 psig
EN English		
▶1	xxxxxxxxxx	
▶2	xxxxxxxxxx	
▶3	xxxxxxxxxx	
▶4	xxxxxxxxxx	
▶5	xxxxxxxxxx	
▶6	xxxxxxxxxx	

Current language (active line)

Submenu

Submenu

Submenu

Submenu

Submenu

Submenu

3. Use the «Return» key to switch to setting mode.  
The language display flashes.
4. Move to the required language with «UP» or «DOWN».
5. Confirm the setting with the «Enter» key.
6. Press «Escape» repeatedly to return to the main menu.

Result The display texts are now in the selected language.

Further information Detailed information can be found in the SIGMA CONTROL 2 service manual.

## 8 Operation

### 8.1 Switching on and off

Always switch the machine on with the «ON» key and off with the «OFF» key.

A power supply disconnecting device has been installed by the user.




Fig. 25 Switching on and off

- |   |                        |   |                        |
|---|------------------------|---|------------------------|
| ① | Machine ON LED         | ⑪ | «LOAD/IDLE» toggle key |
| ② | «ON» key               | ⑲ | LOAD LED               |
| ③ | «OFF» key              | ⑳ | IDLE LED               |
| ⑧ | Controller voltage LED |   |                        |

#### 8.1.1 Switching on

**Precondition** No personnel are working on the machine.  
All access doors and panels are closed and secure.

1. Switch on the power supply disconnecting device.  
The *Controller voltage* LED lights green.
2. Press the «ON» key.  
The *ON* LED lights green.



If a power failure occurs, the machine is **not** prevented from re-starting automatically when power is resumed.  
It can re-start automatically as soon as power is restored.

**Result** The compressor motor starts as soon as system pressure is lower than the setpoint pressure (cut-off pressure).

#### 8.1.2 Switching off

1. Press the «OFF» key.  
The machine switches to IDLE and the *IDLE* LED flashes. The SIGMA CONTROL 2 displays *Stopping*. The *ON* LED extinguishes as soon as the automatic shut-off action is completed.
2. Switch off and lock out the power supply disconnecting device.

**Result** The *Controller voltage* LED extinguishes. The machine is switched off and disconnected from the power supply.



In rare cases, you may want to shut down the machine immediately and cannot wait until the automatic shut-down process is finished.

- Press «OFF» once again.

## 8.2 Switching off in an emergency and switching on again

The EMERGENCY STOP push-button is located below the control panel.




Fig. 26 Switching off in an emergency

⑨ EMERGENCY STOP push button

### Switching off

- EMERGENCY STOP push button actuated.

**Result** The EMERGENCY STOP device remains latched after actuation. The compressor's pressure system is vented and the machine is prevented from automatically re-starting.

### Switching on

**Precondition** The fault has been rectified

1. Turn the EMERGENCY STOP push button in the direction of the arrow to unlatch it.
2. Acknowledge any existing alarm messages.

**Result** The machine can now be started again.

## 8.3 Using the remote control for switching on and off

**Precondition** A link to the remote control center exists.




Fig. 27 Using the remote control for switching on and off

- ① «Remote control» key
- ② *Remote control* LED

1. Attach an easily seen notice to the machine that warns of remote operation.

**⚠ WARNING**

Remote control: Risk of injury caused by unexpected starting!

- Make sure that the power supply disconnecting device is switched off before commencing any work on the machine.

Tab. 42 Machine identification

2. Label the starting device in the remote control center as follows:

**⚠ WARNING**

Remote control: Risk of injury caused by unexpected starting!

- Before starting, make sure that no one is working on the machine and that it can be safely started.

Tab. 43 Remote control identification

3. Press the «Remote control» key.  
The *remote control*/LED lights. The machine can be remotely controlled.

## 8.4 Switching on and off with the clock

Precondition The clock is programmed.




Fig. 28 Switching on and off with the clock

- ① «Clock» key
- ② *Clock* LED



1. Attach an easily seen notice warning of time-controlled operation:

**⚠ WARNING**

Clock control: danger of unexpected starting!

- Make sure that the power supply disconnecting device is switched off before commencing any work on the machine.

Tab. 44 Machine identification

2. Press the «clock» key.  
The *clock* LED lights. The machine is switched on and off by the clock.

## 8.5 Interpreting operation messages

The controller will automatically display operation messages informing you about the current operational state of the machine.

Operating messages are identified with the letter B.

Further information Detailed information can be found in the SIGMA CONTROL 2 operating manual.

## 8.6 Acknowledging alarm and warning messages

Messages are displayed on the "new value" principle:

- Message coming: LED flashes
- Message acknowledged: LED illuminates
- Message going: LED off

or

- Message coming: LED flashes
- Message going: LED flashes
- Message acknowledged: LED off




Fig. 29 Acknowledging messages

- 10 *Warning* LED (yellow)
- 11 *Alarm* LED (red)
- 12 Key «Acknowledge»

**Alarm message**

An alarm shuts the machine down automatically. The red *alarm* LED flashes. The system displays the appropriate message.

Precondition The fault has been rectified

- Acknowledge the message with the «acknowledge» key.  
*Alarm* LED extinguishes.  
The machine is again ready for operation.



If the machine was switched off with the EMERGENCY STOP push button:

- Unlatch the EMERGENCY STOP push button (turn in direction of the arrow) before acknowledging the alarm message.

Further information A list of possible alarm messages occurring during operation can be found in the service manual SIGMA CONTROL 2.

**Warning message**

If maintenance work is to be carried out or if the warning is displayed before an alarm, the yellow *warning* LED flashes.

The system displays the appropriate message.

Precondition The danger of an alarm is passed, maintenance has been carried out.

- Acknowledge the message with the «Acknowledge» key.  
The *warning* LED extinguishes.

Further information A list of possible alarm messages occurring during operation can be found in the service manual SIGMA CONTROL 2.

## 9 Fault Recognition and Rectification

### 9.1 Basic instructions

There are 3 types of fault:

- Warning:
  - Warning messages *W*
- Fault (with indication):
  - Alarm messages *S*
  - System messages *Y*
  - Diagnostic messages *D*
- Other faults (without indication): See chapter 9.2

The messages valid for your machine are dependent on how the individual machine is equipped.

1. Do not attempt fault rectification measures other than those given in this manual!
2. In all other cases:  
Have the fault rectified by an authorized KAESER service representative.

Further information Detailed information for the various messages can be found in the service manual SIGMA CONTROL 2.

### 9.2 Other faults

Fault	Possible cause	Remedy
Machine runs but does not produce nitrogen.	Inlet valve not opening or only opening partially.	Contact authorized KAESER Service representative.
	Venting valve not closing.	Contact authorized KAESER Service representative.
	Leaks in the pressure system.	Check pipework and connections for leaks and tighten any loose connections.
	Nitrogen consumption is greater than the capacity of the compressor.	Check for nitrogen leaks. Shut down consumer(s).
Compressor switches between LOAD and IDLE more than twice per minute.	Receiver too small.	Increase size of receiver.
	Flow into the nitrogen network restricted.	Increase the nitrogen line diameters. Checking the filter elements.
	The differential between cut-in and cut-out pressure too is small.	Check switching differential.

<b>Fault</b>	<b>Possible cause</b>	<b>Remedy</b>
Cooling oil into the machine.	Hose coupling or maintenance hose still plugged into the quick-release coupling on the compressor block. Ball valve at the compressor block is not closed.	Remove the hose coupling/ maintenance hose. Close the ball valve.
	Oil pump leaking.	Contact authorized KAESER Service representative.
	Leaking pipe joints.	Tighten pipe joints. Replace seals.
Cooling oil consumption too high.	Unsuitable compressor oil	Use recommended compressor oils.
	Piston rings worn or broken.	Contact authorized KAESER Service representative.
	Micro-filter element in the crankcase venting contaminated.	Renew the micro-filter element in the crankcase venting.

Tab. 45 Other faults and remedies

# 10 Maintenance

## 10.1 Ensuring safety

Follow the instructions below to ensure safe machine maintenance.  
 Warning instructions are located before a potentially dangerous task.





Disregard of warning instructions can cause serious injuries!

### Complying with safety warnings

Disregard of safety warnings can cause unforeseeable dangers!

- Follow the instructions in chapter 3 "Safety and Responsibility".
- Maintenance work may only be carried out by authorized personnel.
- Use one of the safety signs below to advise others that the machine is currently being serviced:

Sign	Meaning
	Don't activate the machine.
	Warning: The machine is being serviced.

Tab. 46 Advise others that the machine is being serviced.

- Before switching on, make sure that nobody is working on the machine and all access doors and panels are closed.

### Working on live components

Touching voltage carrying components can result in electric shocks, burns or death.

- Work on electrical equipment may only be carried out by authorized electricians.
- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Check that there is no voltage on floating relay contacts.

### Working on the compressed air system

Compressed nitrogen is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following safety concerns relate to any work on components that could be under pressure.

- Isolate the machine from the nitrogen network by closing the user's nitrogen inlet and discharge shut-off valves.
- Depressurize all pressurized components and enclosures (see chapter 10.12).
- Do not open or dismantle any valves.

**Working on the drive system**

Touching voltage carrying components can result in electric shocks, burns or death. Touching the fan wheel, the coupling or the belt drive while the machine is switched on can result in serious injury.

- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Do not open the cabinet while the machine is switched on.

Further information Details of authorized personnel are found in chapter 3.4.2.  
Details of dangers and their avoidance are found in chapter 3.5.

## 10.2 Following the maintenance plan

### 10.2.1 Logging maintenance work



The maintenance intervals given are those recommended for KAESER original components with average operating conditions.

- In adverse conditions, perform maintenance work at shorter intervals.

Adverse conditions are, e.g.:

- high temperatures
- much dust
- high number of load changes
- low load

- Adjust the maintenance intervals with regard to local installation and operating conditions.

- Document all maintenance and service work.

This enables the frequency of individual maintenance tasks and deviations from our recommendations to be determined.

Further information A list is given in chapter 10.25.

### 10.2.2 Resetting maintenance interval counters

According to the way a machine is equipped, sensors and/or maintenance interval counters monitor the operational state of important functional devices. Required maintenance work is shown on SIGMA CONTROL 2.

Precondition Maintenance performed and maintenance message acknowledged.

- Reset the maintenance interval counter as described in the SIGMA CONTROL 2 operating manual.

### 10.2.3 Regular maintenance and service work

The following table provides an overview of the various maintenance intervals for the machine. Selected maintenance intervals for the machine can be displayed via the SIGMA CONTROL 2 controller.

Maintenance interval	Short description
Weekly	Week
Yearly	Year
SIGMA CONTROL 2: Maintenance package A (Every 1000 operating hours; at least every 1 years)	Package A
SIGMA CONTROL 2: Maintenance package B (Every 2000 operating hours; at least every 2 years)	Package B
SIGMA CONTROL 2: Maintenance package C (Every 12000 operating hours; at least every 6 years)	Package C
SIGMA CONTROL 2: Maintenance package D (Every 24000 operating hours; at least every 12 years)	Package D
SIGMA CONTROL 2: Belt inspection (Every 500 operating hours)	Belt
SIGMA CONTROL 2: Hose lines (Every 24000 operating hours; Interval dependent on the number of load changes for the machine)	Lines
SIGMA CONTROL 2: Air cooler (Interval dependent on the number of load changes for the machine)	Cooler
SIGMA CONTROL 2: Electrical system (Every 9000 operating hours)	Electrical system
At least after 20 years	20 years

Tab. 47 Maintenance intervals, regular maintenance and service work

The following table gives an overview of the regular maintenance and service work required.

1. Maintenance and service work should be carried out in a timely manner, taking local ambient and operating conditions into account.
2. Replace maintenance parts and operating fluids in accordance with their respective service lives.

### 10.2.3.1 Machine maintenance and service schedule

- Tasks indicated with "KS" may only be carried out by an authorized KAESER service representative.
- Carry out maintenance and service work in accordance with the following table and at the times specified:

Task	Week	Year	Package A	Package B	Package C	Package D	Belt	Lines	Cooler	Electrical system	20 years	See Chapter	Note
------	------	------	-----------	-----------	-----------	-----------	------	-------	--------	-------------------	----------	-------------	------

#### Safety functions:

KS = Contact KAESER SERVICE; CE = Contact certified electrician

1) Adjust interval as necessary, see Table 49.

2) Interval dependent on the number of load changes for the machine.

Task	Week	Year	Package A	Package B	Package C	Package D	Belt	Lines	Cooler	Electrical system	20 years	See Chapter	Note
Check the safety shutdown function for when the machine is opened.		X										7.8	
Check the safety relief valve.		X										10.8	
Check the excess temperature safety shutdown function.		X										10.9	
Check the EMERGENCY STOP push button.		X										10.10	
Check the temperature shut-down function on the cooler nitrogen inlet.		X										10.11	
Replace safety-relevant components for safety functions.										X		—	KS
<b>Filter:</b>													
Clean or replace the filter mat.			X	X	X	X						10.3	
<b>Compressor block:</b>													
Check the compressor oil level.	X											10.13	
Change the compressor oil <sup>1)</sup> .				X	X	X						10.15	
Replace the oil filter.				X	X	X						10.17	
Service the dirt trap.			X	X	X	X						10.18	
Crankcase ventilation: Replace the filter element.				X	X	X						10.16	
Replace the hydraulic bearing.						X						—	KS
<b>Motor and bearings:</b>													
Service the motor anti-friction bearing.				X	X	X						10.7	
Check the drive belt tension.							X					10.23	
Replace the drive belt.					X	X						—	KS
Replace the fan motor.						X						—	KS
<b>Valves:</b>													
Service the housing ventilation check valve.				X	X	X						10.19.1	
Service the relief check valve.				X	X	X						10.19.2	
Replace the solenoid valve.				X	X	X						10.20	
Replace the relief valve.				X	X	X						—	KS

KS = Contact KAESER SERVICE; CE = Contact certified electrician

<sup>1)</sup> Adjust interval as necessary, see Table 49.

<sup>2)</sup> Interval dependent on the number of load changes for the machine.



Task	Week	Year	Package A	Package B	Package C	Package D	Belt	Lines	Cooler	Electrical system	20 years	See Chapter	Note
Service the control valve.				X	X	X						—	KS
Service the inlet valve.				X	X	X						—	KS
Service the venting valve.					X	X						—	KS
Venting line: Replace the filter element.					X	X						—	KS
<b>Heat exchanger:</b>													
Option K1: Check the cooler for leaks.		X										10.4	
Option K9: Check the water-cooler for leaks.		X										10.6	
Option K1: Replace the cooler <sup>2)</sup> .								X				10.5	KS
<b>Pipe and hose lines:</b>													
Replace the hose lines <sup>2)</sup> .					X	X		X				—	KS
Replace the control lines <sup>2)</sup> .					X	X		X				—	KS
<b>Electrical connections:</b>													
Check that all electrical and screw connections are sufficiently tightened.		X							X			—	KS; CE
<b>Options:</b>													
Option F15: Check the filter for condensate.	X											10.21	
Option F15: Replace the filter element.			X	X	X	X						10.22	

KS = Contact KAESER SERVICE; CE = Contact certified electrician

<sup>1)</sup> Adjust interval as necessary, see Table 49.

<sup>2)</sup> Interval dependent on the number of load changes for the machine.

Tab. 48 Regular machine maintenance and service work

### 10.2.3.2 Compressor oil: Change interval

Duty cycles and ambient conditions are important factors influencing the number and length of the oil change intervals.



Advice can be obtained from an authorized KAESER service representative regarding suitable oil change intervals.

- Check operating conditions and adjust intervals as necessary; log the results in table 49 for future reference.

Compressor oil	Maximum permissible oil change interval [operating hours/years]	
	Favorable operating conditions <sup>1)</sup>	My operating conditions
ISO320N	2000/1	
—	—	

<sup>1)</sup> Cool to moderate ambient temperatures, low humidity, moderate to high duty cycle.

Tab. 49 Compressor oil: Change intervals

### 10.3 Control cabinet: Clean or renew the filter mat

A filter mat is placed behind every ventilation grille. Filter mats protect the control cabinet from ingress of dirt. If the filter mats are clogged, adequate cooling of the components is no longer ensured. In such a case, clean or replace the filter mats.

**Material** Warm water and household detergent  
Spare parts (as required)

**Precondition** The power supply disconnecting device is switched off,  
the device is locked off,  
the absence of any voltage has been verified.  
The machine has cooled down.




Fig. 30 Switching cabinet ventilation

- ① Ventilation grill
- ② Filter mat

- Carefully remove the ventilation grill and take out the filter mat.
- Beat the mat or use a vacuum cleaner to remove loose dirt. If necessary, wash with lukewarm water and household detergent.
- Change the filter mat if cleaning is not possible or if the change interval has expired.
- Lay the filter mat in the frame and latch in the ventilation grill.

## 10.4 Option K1 Cooler maintenance

Regularly clean the cooler. This ensures reliable cooling of the machine and the nitrogen. The frequency is mainly dependent on local operating conditions.

A leaking cooler causes nitrogen loss.



Clogged coolers are indicative of unfavorable ambient conditions. Such ambient conditions clog the cooling air ducts in the machine's interior and the motors resulting in increased wear and tear.

- Have an authorized KAESER service representative clean the cooling air ducts.

**Material** Brush and vacuum cleaner  
Face mask (as required)

**Precondition** The power supply disconnecting device is switched off,  
the device is locked off,  
the absence of any voltage has been verified.  
The machine has cooled down.




Fig. 31 Cleaning the cooler

- ① Cooler
- ② Brush

### Cleaning the cooler

Do not use sharp objects to clean the cooler. It could be damaged.

Avoid creating clouds of dust.

- Dry brush the air cooler and use a vacuum cleaner to suck up the dirt.



The cooler can't be cleaned thoroughly?

- Have stubborn clogging removed by an authorized KAESER service representative.

### Check the cooler for leaks

- Carry out visual inspection: Did condensate escape?



Is the cooler leaking?

- Have the defective cooler repaired immediately by an authorized KAESER service representative.

## 10.5 Option K1 Changing the cooler

The maintenance interval for replacement of the air-cooled nitrogen aftercooler is dependent on the number of load changes for the machine.

1. **⚠ WARNING** *Danger of serious injury from the nitrogen aftercooler bursting!*
  - *Observe maintenance intervals for the nitrogen aftercooler!*
2. Replacement intervals will be displayed by the controller.
3. Arrange for the nitrogen aftercooler to be replaced without delay by an authorized KAESER service representative.

## 10.6 Option K9 Water-cooling Maintenance



Cooler clogging causes overheating and machine damage.

- Observe the block discharge temperature to detect any tendency to rise.

Check the cooler regularly for leaks and contamination. Frequency of checking is dependant on the characteristics of the cooling water.

**Precondition** The power supply disconnecting device is switched off, the device is locked off, the absence of any voltage has been verified.

### Checking for leaks

Special attention must be paid to aging and corrosion of the cooler materials under long term operating conditions. If a leak occurs, condensate will run into the cooling water.

1. Check the cooler visually for leaks.
2. Have an authorized KAESER service representative check the cooler for internal leaks at least once a year.

### Cleaning

- An authorized KAESER service representative should clean the cooler when the block discharge temperature is 50 °F above the annual average.

## 10.7 Motor maintenance

In motors with bearings with re-lubricating facility, the lubricating fittings are located at the outside of the machine. The grease lines are filled at the factory.



Use only the high temperature grease UNIREX N3 for the motor bearings. Damage to bearings caused by the use of other brands of grease is excluded from the warranty.

Material Grease gun with UNIREX N3  
Cleaning cloths




Fig. 32 Motor maintenance

- |                                    |                        |
|------------------------------------|------------------------|
| ① Grease fittings compressor motor | Ⓐ A-side motor bearing |
| ② Grease fittings fan motor        | Ⓑ B-side motor bearing |

**Compressor motor:**



The required quantity of grease is stated on the compressor drive motor nameplate or see chapter 2.13.1

Precondition Compressor motor running

1. Clean the grease fittings with a cleaning cloth.
2. Grease both motor bearings with a grease gun.
3. Reset the maintenance counter.

**Fan motor:**



The required quantity of grease is stated on the fan motor nameplate or see chapter 2.13.2

Precondition Fan motor running

1. Clean the grease fittings with a cleaning cloth.
2. Grease both motor bearings with a grease gun.
3. Reset the maintenance counter.

## 10.8 Testing the safety relief valve

The safety relief valve test consists of two steps:

1. Testing the safety relief valve on the cooler.
2. Testing the safety relief valve on the distribution tank.

### 10.8.1 Cooler safety relief valve

To test the safety relief valve, raise the gauge working pressure of the machine above the opening pressure differential of the safety relief valve.

Network pressure monitoring is switched off during the test. In normal operation, the blow-off protection will switch the machine off before the safety relief valve is actuated. During the test, the blow-off protection will switch the machine off only when the opening pressure differential of the safety relief valve has been exceeded by 14.5 psi.



- Follow the detailed description of this procedure in the SIGMA CONTROL 2 operating manual
- Never operate the machine without a properly functioning safety relief valve.
- Arrange for defective safety relief valves to be replaced immediately.

#### **⚠ WARNING**

*Risk of hearing damage when safety relief valve blows off!*

- *Close all maintenance doors, replace and secure all removable panels.*
- *Always wear ear protection.*

Precondition The machine is switched off.

1. Close the user-end shut-off valve at the nitrogen outlet.
2. Read off the actuating pressure on the safety relief valve.  
(The actuating pressure is usually to be found at the end of the part identification label)
3. Log in to the SIGMA CONTROL 2 with access level 2.
4. Observe the pressure display in the SIGMA CONTROL 2 and call up the test function.
5. **⚠ WARNING** *Risk of burning from nitrogen when the safety relief valve blows off!*
  - *Close all maintenance doors, replace and secure all removable panels.*
  - *Wear eye protection.*
6. End the test as soon as the safety relief valve blows off or the gauge working pressure exceeds the opening pressure differential of the safety relief valve by almost 14.5 psi.
7. If necessary, vent the machine and replace the defective safety relief valve.
8. Deactivate the test function.
9. Open the user-end shut-off valve on the nitrogen outlet.

#### 10.8.2 Distribution tank safety relief valve

- To check the actuating pressure of the safety relief valve, it must be removed from the machine by an authorized KAESER service representative and installed on a test rig.

Further information For the actuating pressure of the safety relief valve, see chapter 2.8.


#### **Activating the safety relief valve**

In order to prevent the seat of the safety relief valve from sticking, it must be actuated at regular intervals: once per year at a minimum.



- In the event that the permissible working pressure is exceeded, the safety relief valve will open to protect the machine.
  - Never operate the machine without a properly functioning safety relief valve.
  - Do **not** adjust the safety relief valve.

Precondition Machine is running under LOAD.



10-P0762-002

Fig. 33 Testing the safety relief valve

- ① Distribution tank safety relief valve
- ② Knurled screw

1. **⚠ WARNING** *safety relief valve blowing off!*  
*Excessive noise when the safety relief valve blows off.*  
*Risk of injury from bursting components and compressed fluid.*
  - *Wear ear and eye protection.*
2. Turn the knurled screw counter-clockwise until compressed fluid blows off.
3. Turn the knurled screw back to its original position.



- Do not turn the knurled screw too far.
  - Arrange for defective safety relief valves to be replaced by KAESER SERVICE.

## 10.9 Checking the overheating safety shutdown function


The machine should shut down if the block discharge temperature (ADT) reaches a maximum of 425°F.

- Check the safety shutdown function as described in the SIGMA CONTROL 2 operating manual.



- The machine does not shut down?
  - Have the safety shut-down function checked by an authorized KAESER service representative.

## 10.10 Checking the EMERGENCY STOP push button



10-P2166

Fig. 34 Checking the EMERGENCY STOP push button

⑨ EMERGENCY STOP push button

Precondition Compressor motor running

1. EMERGENCY STOP push button actuated.

The compressor motor stops, the pressure system is vented, and the machine is prevented from automatically re-starting.



The compressor motor does not stop?

The safety function of the EMERGENCY STOP push button is no longer ensured.

➤ Shut down the machine immediately and call an authorized KAESER service representative.

2. Turn the EMERGENCY STOP push button in the direction of the arrow to unlatch it.

3. Acknowledge the alarm message.

## 10.11 Cooler nitrogen inlet temperature switch

Should the machine exceed the nitrogen inlet temperature at the cooler (Option K1  $\geq$  311 °F, Option K9  $\geq$  311 °F), an alarm message will be displayed on the SIGMA CONTROL 2 (see SIGMA CONTROL 2 operating manual).



Arrange for the shutdown function of the temperature switch to be checked by an authorized KAESER service representative.






Fig. 35 Nitrogen inlet temperature switch

- |     |                                  |     |                    |
|-----|----------------------------------|-----|--------------------|
| (A) | Cooler option K1 – Air-cooling   | (1) | Temperature switch |
| (B) | Cooler option K9 – Water-cooling | (2) | Temperature sensor |

➤ The temperature switch is non-adjustable.

**Unlocking the temperature switch**

Should the nitrogen inlet temperature fall below the set value, the temperature switch must be unlocked manually.




Fig. 36 Unlocking the temperature switch

- (1) Temperature switch

1. Open the cover.
2. Unlock the snap-action switch by pulling it upwards.
3. Close the cover.
4. Acknowledge the alarm message.

## 10.12 Venting the machine (depressurizing)

Venting takes place in three stages:

- Isolating the machine from the nitrogen system.
- Venting the cooler.
- Manually discharge compressed nitrogen behind the network pressure gauge (inlet pressure) (rear left access door).



The machine must be isolated from the nitrogen network and completely vented before undertaking any work on the pressure system.

**Precondition** The power supply disconnecting device is switched off (all poles), lock out and tag out the device, the absence of any voltage has been verified.

### CAUTION

*Compressed nitrogen!*

*Compressed nitrogen and devices under gas pressure can injure or cause death if the contained energy of the gas is released suddenly or uncontrolled.*

- *Fully depressurize all pressurized components and enclosures.*

## Isolating the machine from the nitrogen system




Fig. 37 Mount the user's shut-off valves.

- ① User's shut-off valve (inlet pressure)
- ② User's shut-off valve (high pressure)

➤ Close the user's shut-off valves (inlet and final pressure).



If no shut-off valves are provided by the user, the complete air network must be vented.

**Venting the cooler**

Precondition Panel removed (see chapter 4.1).




Fig. 38 Venting the cooler.

- |  |                                  |
|--|----------------------------------|
| ① Shut-off valve                         | Ⓐ Cooler option K1-air cooling   |
| ② Nitrogen inlet                         | Ⓑ Cooler option K9-water cooling |
| ③ Network pressure gauge (high pressure) |                                  |

- Slowly open the shut-off valve ① and check that the network pressure gauge ③ (final pressure) reads 0 psig.



The network pressure gauge (final pressure) does not read 0 psig after automatic venting?

- Ensure that the shut-off valve ① is open or that the entire nitrogen system is depressurized.
- Slowly open the shut-off valve ① to release pressure.
- If manual venting does **not** attain depressurization: Contact an authorized KAESER service representative.

**Venting the inlet pressure side**

Precondition Left-hand access door opened (see chapter 4.1).




Fig. 39 Venting the inlet pressure side

- |   |   |
|---|---|
| ① Shut-off valve                          | ③ Network pressure gauge (final pressure) |
| ② Network pressure gauge (inlet pressure) | ④ Control pressure control valve          |

- Slowly open the shut-off valve and check that the network pressure gauge ② (inlet pressure) reads 0 psig.



The control pressure control valve **cannot** be adjusted.



The network pressure gauge (inlet pressure) does not read 0 psig after automatic venting?

- Ensure that the shut-off valve is open or that the entire nitrogen system is depressurized.
- Slowly open the shut-off valve ① to release pressure.
- If manual venting does **not** attain depressurization: Contact an authorized KAESER service representative.

## 10.13 Checking the oil level

The oil level can be read off on the oil sight glass.

Precondition The machine is running under LOAD.




Fig. 40 Checking the oil level

- ① Oil filler plug
- ② Oil sight glass

1. **⚠ CAUTION**

*Danger of burning - hot surfaces!*

- *Wear long-sleeved clothing and protective gloves.*

2. Check the compressor cooling oil level with machine running under LOAD.

Result Top off when the compressor oil level falls to the minimum mark. Top off the oil

## 10.14 Topping off the compressor oil

Material Compressor oil

Precondition The power supply disconnecting device is switched off, lockout and tagout the device, the absence of voltage has been verified.

Vent all pressurized components and enclosures (see chapter 10.12).




Fig. 41 Topping off the compressor oil

- ① Screw plug
- ② O-ring
- ③ Oil sight glass

1. **NOTICE** *The machine can be damaged by unsuitable oil.*
  - *Never mix different types of oil.*
  - *Never top off with a different type of oil to that already used in the machine.*
2. Slowly unscrew the filler plug.
3. Top off to bring the oil to the correct level.
4. If necessary, replace the O-ring of the screw plug and screw the plug into the filler port.

**Starting the machine and performing a trial run**

1. Close all access doors, replace, and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valves at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device.
5. Switch on the machine, after approx. 2 minutes of operation: Check the cooling oil level and top off if necessary.
6. Switch off the machine and visually check for leaks.

**10.15 Changing the compressor oil**

Change the initial charge of oil as specified in table 49.  
Always drain the oil completely from the compressor block.



Change the oil immediately if it becomes milky.  
This indicates a high condensate content.  
Contact an authorized KAESER service representative if condensate is detected in the compressor oil. It is necessary to adapt the block discharge temperature to individual ambient conditions.



The machine must be isolated from the nitrogen network and completely vented before undertaking any work on the pressure system.

Material Compressor oil  
Oil receptacle

The maintenance hose with hose coupling and shut-off valve is stowed behind the left access door.

Precondition The machine has been running at least 5 minutes in LOAD mode. The power supply disconnecting device is switched off, lockout and tagout the device, the absence of any voltage has been verified.  
Vent all pressurized components and enclosures (see chapter 10.12).

**⚠ CAUTION**

*Danger of burning from hot components and scalding from escaping oil.*

➤ *Wear long-sleeved clothing and gloves.*





Fig. 42 Changing the compressor oil

- |                              |                         |
|------------------------------|-------------------------|
| ① Screw plug                 | ⑤ Shut-off valve        |
| ② Shut-off valve (oil drain) | Ⓐ Shut-off valve open   |
| ③ Hose coupling              | Ⓑ Shut-off valve closed |
| ④ Male plug-in hose fitting  | ⑥ Maintenance hose      |

1. Prepare an oil receptacle.
2. With the shut-off valve closed, insert the male plug-in hose fitting ④ into the hose coupling ③.
3. Place the end of the maintenance hose ⑥ in the oil receptacle and secure it in place.
4. Open shut-off valve ②.
5. Slowly open the shut-off valve ⑤ in the maintenance hose and allow the condensate to drain completely.
6. Close the shut-off valve ② and remove the male plug-in hose fitting ④ from the coupling.

Result The cooling oil is drained from the compressor block.

**Filling with compressor oil**

1. Open the filler plug  (Fig. 42) slowly.
2. Filling with compressor oil
3. Check the filler plug and o-ring for damage and screw the plug back in again.

**Starting the machine and performing a trial run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance interval counter.
5. Start the machine and check the oil level again after about 2 minutes operation and topping up again, if necessary.
6. Switch off the machine and visually check for leaks.



- Dispose of the old oil in accordance with valid environmental protection regulations.

**10.16 Changing the micro-filter element in the crankcase vent**

Material Micro-filter element

Precondition The power supply disconnecting device is switched off, lockout and tagout the device, the absence of any voltage has been verified.  
The machine has cooled down.

Vent all pressurized components and enclosures (see chapter 10.12).

** CAUTION**

*Danger of burning from hot components and scalding from escaping oil.*

- *Wear long-sleeved clothing and gloves.*



Do not use the machine without a vent cap.






Fig. 43 Changing the micro-filter element in the crankcase vent

- |   |                      |   |             |
|---|----------------------|---|-------------|
| ① | Crankcase venting    | ③ | O-ring      |
| ② | Micro-filter element | ④ | Venting cap |

1. Unscrew the vent cap from the crankcase vent.
2. **⚠ CAUTION** *Escaping oil mist is damaging to health.*
  - *Do not inhale oil mist and vapors.*
  - *Avoid contact with skin and eyes.*
3. Pull out the micro-filter element.



Dispose of micro-filter element in accordance with environmental protection regulations.

4. Insert a new micro-filter element.
5. Replace the cap in the crankcase vent and check that the O-ring is properly seated.

**Starting the machine and performing a trial run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check for leaks.

**10.17 Changing the crankcase oil filter**

Material Oil filter  
Oil receptacle  
Cleaning cloth

Precondition The power supply disconnecting device is switched off, lock out and tag out the device, the absence of any voltage has been verified.  
The machine has cooled down.  
Vent all pressurized components and enclosures (see chapter 10.12).

1. **⚠ CAUTION** *Danger of burns from hot components and compressor oil.*
  - *Wear long-sleeved clothing and protective gloves.*
2. Change the oil filter when indicated on SIGMA CONTROL 2.




Fig. 44 Changing the crankcase oil filter

- ① Oil filter
- ② Direction of rotation to unscrew the filter

1. **⚠ CAUTION** *Escaping oil mist is damaging to health.*
  - *Do not inhale oil mist and vapors.*
  - *Avoid contact with skin and eyes.*
2. Unscrew the oil filter counter-clockwise; catch oil spillage and dispose of according to environmental regulations.
3. Clean sealing faces with a clean cloth.
4. Lightly oil the gasket of the new filter.
5. Manually turn the oil filter clockwise to tighten. Do not use any tool.
6. Check the oil level.

#### Starting the machine and performing a test run

1. Close all maintenance doors, replace and secure all removable panels.
2. Open the user-end nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve on the cooler and network pressure gauge (initial pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine on and run it for around 2 minutes, then shut it down and perform a visual inspection.

## 10.18 Dirt trap maintenance



The machine must be isolated from the nitrogen network and completely vented before undertaking any work on the pressure system.

**Material** Compressed air for blowing out  
Cleaning agent

**Precondition** The power supply disconnecting device is switched off, lock out and tag out the device, the absence of any voltage has been verified.  
The machine has cooled down.  
Fully vent all pressurized components and enclosures (see chapter 10.12).

### 10.18.1 Dirt trap in the inlet line



When a fault occurs in IDLE.  
➤ Clean the dirt trap strainer.




Fig. 45 Dirt trap in the inlet line

- |   |                    |   |             |
|---|--------------------|---|-------------|
| ① | Dirt trap          | ④ | Screw plug  |
| ② | Gasket or O-ring   | ⑤ | Cover plate |
| ③ | Dirt trap strainer |   |             |

1. **⚠ CAUTION** *Fatal injury caused by components under high pressure!*
  - Isolate the machine from the nitrogen system.
  - Vent (depressurize) the machine completely.
  - Verify the absence of pressure.
2. Remove the cover plate.
3. Remove the plug and clean the gasket or O-ring.
4. Remove the dirt trap strainer and blow clean.
5. Reassemble all parts with gasket or O-ring.
6. Install the cover plate.

**Starting the machine and performing a trial run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valves at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check for leaks.

**10.18.2 Dirt trap in the crankcase**



If a fault occurs because of insufficient oil pressure.

- Clean the dirt trap strainer.




Fig. 46 Dirt trap in the crankcase

- |   |                    |   |            |
|---|--------------------|---|------------|
| ① | Dirt trap          | ③ | O-ring     |
| ② | Dirt trap strainer | ④ | Screw plug |

1. **⚠ CAUTION** *Danger of burns from hot components!*  
➤ *Wear long-sleeved clothing and protective gloves.*
2. Remove the plug and clean the O-ring.
3. Remove the dirt trap strainer and blow clean.
4. Reassemble the dirt trap and plug with the O-ring.

**Starting the machine and performing a trial run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valves at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check for leaks.

10.18.3 Dirt trap in the filter




Fig. 47 Dirt trap in the filter

- |   |                                |   |                 |
|---|--------------------------------|---|-----------------|
| ① | Filter housing                 | ⑤ | Seal            |
| ② | Double-ended male stud fitting | ⑥ | Silencer insert |
| ③ | Condensate drain hose          | ⑦ | Nut             |
| ④ | Dirt trap with double fitting  |   |                 |

1. **⚠ CAUTION** *Fatal injury caused by components under high pressure!*
  - Isolate the machine from the nitrogen system.
  - Vent (depressurize) the machine completely.
  - Verify the absence of pressure.
2. Loosen the condensate hose
3. Unscrew the double fitting with dirt trap strainer from the filter housing.
4. Unscrew the filter housing and rinse with warm water.
5. Blow out the dirt trap strainer and filter housing to clean the units.
6. Remove the retaining nut and the silencer insert.
7. Blow the silencer insert clean from inside to outside.
8. Reassemble in reverse order.

**Starting the machine and performing a test run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check for leaks.

10.18.4 Dirt trap in the return line




Fig. 48 Dirt trap in the return line

- |   |                  |   |                    |
|---|------------------|---|--------------------|
| ① | Dirt trap        | ③ | Dirt trap strainer |
| ② | Gasket or O-ring | ④ | Screw plug         |

1. **⚠ CAUTION** *Fatal injury caused by components under high pressure!*
  - Isolate the machine from the nitrogen system.
  - Vent (depressurize) the machine completely.
  - Verify the absence of pressure.
2. Remove the plug and clean the gasket or O-ring.
3. Remove the dirt trap strainer and blow clean.
4. Reassemble all parts with gasket or O-ring.

**Starting the machine and performing a test run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check for leaks.

10.19 Check valve maintenance



The machine must be isolated from the nitrogen network and completely vented before undertaking any work that entails opening the pressure system. Both network pressure gauges (initial and final pressure) read 0 psig.

- Material** Compressed air for blowing out  
Cleaning cloth  
Service KIT (if required)
- Precondition** The power supply disconnecting device is switched off, lock out and tag out the device, the absence of any voltage has been verified.  
The machine has cooled down.  
Vent all pressurized components and enclosures (see chapter 10.12).

### 10.19.1 Housing ventilation check valve

The check valve is fitted to the housing vent. It protects the housing from excessive internal pressure while the machine is operating. When the machine is shut down, the check valve prevents air from entering the interior of the housing.




Fig. 49 Housing ventilation check valve

- |   |             |   |            |
|---|-------------|---|------------|
| ① | Check valve | ⓐ | Valve cone |
| ② | Screw plug  | ⓑ | Spring     |
| ③ | Valve seat  | ⓒ | O-ring     |
| ④ | Service KIT |   |            |

1. **⚠ WARNING** Risk of fatal injury from components under high pressure!
    - Isolate the machine from the nitrogen network.
    - Vent the machine completely.
    - Verify the absence of pressure.
  2. Open the screw plug.
  3. Clean the valve seat and valve cone with a cleaning cloth or blow out with dry compressed air (<30 psig!).
- I** Should the valve seat show severe wear or damage, the check valve must be replaced by an authorized KAESER service representative.  
If required, replace the valve cone, spring and O-ring (Service KIT).
4. Insert the O-ring into the groove on the screw plug.
  5. Insert the valve cone with spring into the screw plug.
  6. Close the check valve using the screw plug.

**Starting the machine and performing a test run**

1. Close all maintenance doors, replace and secure all removable panels.
2. Open the user-end nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve on the cooler and network pressure gauge (initial pressure).
4. Switch on the power supply disconnecting device.
5. Switch the machine on and run it for around 2 minutes, then shut it down and visually check for leaks.

**10.19.2 Unloading the check valve**

The check valve is fitted downstream of the safety relief valve. It prevents air from entering the machine after the machine has been vented or shut down.




Fig. 50 Relieving the check valve

- |   |             |   |            |
|---|-------------|---|------------|
| ① | Check valve | a | Valve cone |
| ② | Screw plug  | b | Spring     |
| ③ | Valve seat  | c | O-ring     |
| ④ | Service KIT |   |            |

1. **⚠ WARNING** Risk of fatal injury from components under high pressure!
  - Isolate the machine from the nitrogen network.
  - Vent the machine completely.
  - Verify the absence of pressure.
2. Open the screw plug.
3. Clean the valve seat and valve cone with a cleaning cloth or blow out with dry compressed air (<30 psig!).
- i** Should the valve seat show severe wear or damage, the check valve must be replaced by an authorized KAESER service representative.  
If required, replace the valve cone, spring and O-ring (Service KIT).
4. Insert the O-ring into the groove on the screw plug.
5. Insert the valve cone and spring into the housing.
6. Close the check valve using the screw plug.



#### Starting the machine and performing a test run

1. Close all maintenance doors, replace and secure all removable panels.
2. Open the user-end nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve on the cooler and network pressure gauge (initial pressure).
4. Switch on the power supply disconnecting device.
5. Switch the machine on and run it for around 2 minutes, then shut it down and visually check for leaks.

## 10.20 Replacing the condensate drain solenoid valve

Ingress of dirt during operation can prevent the condensate drain solenoid valve from sealing. For reasons of operational safety, replace the condensate drain solenoid valve as soon as SIGMA CONTROL 2 displays a corresponding message.

Material Spare part

Precondition The machine is switched off.

The power supply disconnecting device is switched off, the device is locked off, the absence of any voltage has been verified.

Depressurize all pressurized components and enclosures (see chapter 10.12).



10-P2464

Fig. 51 Replacing the condensate drain solenoid valve

- |                                   |                                   |
|-----------------------------------|-----------------------------------|
| ① Union fittings                  | ③ Connecting socket               |
| ② Condensate drain solenoid valve | ④ Pressure line condensate outlet |

1. **⚠ WARNING** *Danger of fatal injury because of pressurized components.*
  - *Isolate the machine from the nitrogen system.*
  - *Vent the machine completely to atmospheric.*
  - *Check for zero psig.*
2. Remove the connecting socket from the solenoid valve.
3. Remove the union fittings from the filter.
4. Remove the hose from the condensate outlet.
5. Remove the pressure lines from the condensate drain solenoid valve.

6. Mount the new condensate drain solenoid valve and fix the pressure lines.
7. Fix the connecting socket.

#### Starting the machine and carrying out a trial run

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply and reset the maintenance interval counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check for leaks.

## 10.21 Option K15 Checking the filter for condensate

**Precondition** The filter housing is pressurized.  
Wear safety glasses.




Fig. 52 Checking the filter for condensate

- ① Shut-off valve
- ② Male hose coupling

1. Place a suitable receptacle beneath the condensate drain.
2. Attach a sufficiently long, transparent, and pressure-resistant hose line to the male hose coupling and the receptacle.
3. Carefully open the shut-off valve and close it again immediately as soon as only condensed fluid escapes.



In the event that oil or an oil-water mixture is discharged first:  
 ➤ Rectify the cause of this fault.

## 10.22 Option F15 Replacing the filter element



➤ To avoid damage, handle all components with care and install without the use of tools. This is particularly important when it comes to the frontal sealing surfaces.



The machine must be isolated from the nitrogen network and completely vented before undertaking any work that entails opening the pressure system. Both network pressure gauges (initial and final pressure) read 0 psi.

**Material** KAESER filter element (including silicone-free sealing grease and O-ring)

**Precondition** The power supply disconnecting device is switched off, lock out and tag out the device, the absence of any voltage has been verified.  
The machine has cooled down.  
Fully vent all pressurized components and enclosures (see chapter 10.12).

### 10.22.1 Removing the filter element




Fig. 53 Removing the filter element

- |  |   |
|--|---|
| ① Filter housing                                   | ④ Installation mark on the filter housing |
| ② Filter element                                   | ⑤ Installation mark on the filter head    |
| ③ Locking screw (secured against complete removal) | ⑥ Filter head                             |

1. **⚠ WARNING** Risk of fatal injury from components under high pressure!
  - Isolate the machine from the nitrogen network.
  - Vent the machine completely.
  - Verify the absence of pressure.
2. Loosen the locking screw ③ by hand until you can feel resistance again.  
If the filter was pressurized, the residual nitrogen will escape.



If you can hear a continuous whistling sound:  
The filter remains under pressure!  
➤ Disconnect the filter from the nitrogen network, or vent the entire network.

3. Jiggle the filter housing ① gently and then rotate by 90° until the installation marks on the filter housing ④ and the filter head ⑤ are facing one another.
4. Remove the filter housing together with the screwed-in filter element vertically downwards.
5. Unscrew the filter element ② from the filter housing (approx. 1 1/2 rotations required).

6. If required: Drain and dispose of any condensate.
7. Check the filter housing for corrosion.



If the filter housing is noticeably corroded:

- Determine the cause (e.g. composition of the nitrogen, prevailing operating conditions)
- Completely replace the filter.



Dispose of the contaminated filter element in accordance with environmental regulations.

### 10.22.2 Installing the filter element



- Do not touch the surface of the filter material with your hand.

Precondition The inner surfaces of the filter head and the filter housing are clean.




Fig. 54 Installing the filter element

- |   |                    |   |                       |
|---|--------------------|---|-----------------------|
| ① | Filter housing     | ④ | O-ring                |
| ② | Filter element     | ⑤ | O-ring                |
| ③ | Installation marks | ⑥ | Surface to be greased |

1. Grease the thread, front surface and bayonet catch of the filter housing (Pos. ⑥).
2. Push the filter element ② into the filter housing ① so that the installation marks ③ are aligned with one another.
3. Screw the filter element into the filter housing (one rotation required).
4. Fully grease the O-ring ⑤ and insert between the filter element and the filter housing.
5. Grease the O-ring ④.

10.22.3 Installing the filter housing




Fig. 55 Installing the filter housing

- |   |                                 |
|---|---------------------------------|
| ① Surface to be greased                   | ④ Limit stop on the filter head |
| ② Installation mark on the filter housing | ⑤ Locking screw                 |
| ③ Installation mark on the filter head    |                                 |

1. Grease the inner surface of the filter head (Pos. ①).
2. Align the installation marks (②) and (③) on the filter housing and head with one another.
3. Insert the filter housing into the filter head.
4. Rotate the filter housing through 90° as far as the limit stop (④).
5. Manually tighten the locking screw (⑤).



If the locking screw cannot be tightened:  
The bayonet catch on the filter housing is not fully closed.  
➤ Rotate the filter housing as far as the limit stop.




Fig. 56 Filling out the maintenance sticker

- |                               |
|-------------------------------|
| ① Maintenance sticker         |
| ② Service contact information |

6. Fill out the maintenance sticker with the year in which the next maintenance falls due.
7. Attach the maintenance sticker so that the *max* mark is pointing to the month in which the next maintenance falls due.

10.22.4 Pressurizing the filter

A high fluid flow rate may damage the filter material.

1. Check that the locking screw has been tightened properly by hand.
2. Slowly open the user-end shut-off valve (initial pressure).
3. Slowly open the user-end shut-off valve (final pressure).

10.23 Drive belt maintenance



Use only KAESER drive belts. Each belt set has the same length and the belts are fully oil-resistant.

- V-belts must be changed as a set.

Material V-belt belt set


Precondition The power supply disconnecting device is switched off, lockout and tagout the device the absence of any voltage has been verified. The machine has cooled down. Fully vent all pressurized components and enclosures (see chapter 10.12).

**⚠ WARNING**

*Hand injury due to the machine running on!*

- *Wait for at least one minute after switching off before you open the panel.*

Visually check for damage



10-P0778

Fig. 57 Visually check for damage

- ① Removable access panel
- ② Motor pulley

1. Remove the panel.

2. Turn the drive belt at the motor pulley by hand so that all of the belts can be inspected for damage.
3. In case of damage: Immediately have the drive belt replaced by an authorized KAESER service representative.

**Checking and adjusting belt tension**

- Check the position of the locking pin.



The drive belt need re-tensioning if the locking pin **3a** is at the lower end of the slot.




Fig. 58 Re-tighten the drive belt

- |  |  |
|--|--|
| <ul style="list-style-type: none"> <li>① Hexagon nut</li> <li>② Hexagon nut</li> </ul> | <ul style="list-style-type: none"> <li>③a Locking pin (lower end)</li> <li>③b Locking pin (upper end)</li> </ul> |
|--|--|

1. Loosen the hexagon nut ①.
2. Screw down the hexagonal nut ② until the pin ③b is located at the upper end of the slot again.
3. Tighten the hexagonal locking nut ①.

**Starting the machine and performing a test run**

1. Close all access doors, replace and secure all removable panels.
2. Open the user's nitrogen inlet and outlet shut-off valves.
3. Close the shut-off valve at the cooler and network pressure gauge (inlet pressure).
4. Switch on the power supply disconnecting device and reset the maintenance counter.
5. Start the machine and run it for 2 minutes, then stop it and visually check it.

**10.24 Cylinder head and valves**

- Maintenance and service work on the cylinder head and valves should be performed *only* by an authorized KAESER service representative.





# 11 Spares, Operating Materials, Service

## 11.1 Note the nameplate

The nameplate contains all information to identify your machine. This information is essential to us in order to provide you with optimal service.

- Please give the information from the nameplate with every inquiry and order for spares.

## 11.2 Ordering consumable parts and operating fluids/materials

KAESER consumable parts and operating fluids/materials are genuine parts. They are specifically designed for use in KAESER machines.

Unsuitable or poor-quality consumable parts and operating fluids/materials may result in damage to the machine or significantly impair its proper function.

Damage can result in injury to personnel.

### **⚠ WARNING**

*Risk of personal injury or damage to the machine resulting from the use of unsuitable spare parts or operating fluids/materials!*

- *Only use genuine parts and operating fluids/materials.*
- *Arrange for an authorized KAESER service representative to carry out regular maintenance.*

#### Machine

Designation	Number
Oil filter	1200
Housing ventilation filter	1570
Drive belt	1800
Filter mat (control cabinet bottom)	1100
Filter mat (control cabinet top)	1102
Compressor oil	1600
Filter element (Option F15)	1550

Tab. 51 Machine maintenance parts

## 11.3 KAESER AIR SERVICE

KAESER AIR SERVICE offers:

- Authorized KAESER service representatives with KAESER factory training,
- Increased operational reliability ensured by preventive maintenance,
- Energy savings achieved by avoidance of pressure losses,
- Optimum conditions for operation of the nitrogen system,
- The security of genuine KAESER spare parts,
- Increased legal certainty as all regulations are kept to.

- Why not sign a KAESER AIR SERVICE maintenance agreement!  
Your advantage:  
Lower costs and higher nitrogen availability.


## **11.4 Replacement parts for service and repair**

Use these parts lists to plan your material requirement according to operating conditions and to order the required spare parts.



- Make sure that any service or repair tasks not described in this manual are carried out by an authorized KAESER service representative.


### **11.4.1 Spare parts option K1 (air cooling)**



Prospekt für den Kunden: Bitte bei Bestellung auf die Bestellnummer, die Originalnummer und die Seriennummer des Kompressors achten.  
 Die Zeichnung zeigt nur ein Beispiel für die Ersatzteile. Die Zeichnung ist nicht verbindlich. Die Zeichnung ist nur ein Beispiel für die Ersatzteile.  
 Wenn die Zeichnung nicht mit der Zeichnung des Herstellers übereinstimmt, ist die Zeichnung des Herstellers maßgebend.  
 Copyright Kaeser Kompressoren AG, alle Rechte vorbehalten.

Kaeser-Kompressoren		Original		Ersatzteil	
Zeichnungs-Nr.	Dokument-Nr.	Original-Nr.	Name	Original-Nr.	Ersatzteil-Nr.
1025 - Drive / Antrieb		13.05.219	1025	13.05.219	1025
SEGA-Nummer		13.05.219	1025	13.05.219	1025
SEGA-Nummer		13.05.219	1025	13.05.219	1025
SEGA-Nummer		13.05.219	1025	13.05.219	1025

(Service-Kit) (Option) (Subassembly) (Untergruppe)  
 Blatt 1 von 1



**KAESER**  
KOMPRESSOREN

**1089 - Valve plate - cylinder-head / Ventilplatte-Zylinder-Kopf**


Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1  
 Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1  
 Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1

Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1

Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1

Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1

Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungszahl: 1089\_24.05.2019 Part1



**KAESER KOMPRESSOREN**


1090-Oil circuit - slide ring / Ölkreislauf - Gleitring

**Benennung:** 1090-Oil circuit - slide ring / Ölkreislauf - Gleitring


Zeichnungsgruppe		Dokument-Nr.		Erstellt mit:	
Original	Alt	Datum	Name	Original	Alt
		24.05.2019	Pfaffl		
SEGA-Nummer		Version		Solid Edge	
SEC-10156_01		14.05.2019		R002	
Service-Kit (Option) / Subassembli / Untergruppe			Skizze / Zeichnung		

Bitte beachten Sie, dass die Ersatzteile, die in diesem Katalog aufgeführt sind, nur für den originalen oder für einen identischen Kompressor geeignet sind. Die Zeichnungen sind als Ersatzteile für den originalen Kompressor vorgesehen. Die Zeichnungen sind nur für den originalen Kompressor geeignet. Die Zeichnungen sind nicht für andere Kompressoren geeignet. Die Zeichnungen sind nicht für andere Kompressoren geeignet. Die Zeichnungen sind nicht für andere Kompressoren geeignet. Die Zeichnungen sind nicht für andere Kompressoren geeignet.

1 von 1



2744




2710

**KAESER**  
KOMPRESSOREN

Bitte beachten Sie, dass die Ersatzteile nur für die Original-Compressoren vorgesehen sind. Die Verwendung von Ersatzteilen anderer Hersteller kann zu Schäden an der Maschine und an den Bauteilen führen. Die Verantwortung für die Sicherheit der Maschine liegt bei der Verwendung von Ersatzteilen anderer Hersteller. Die Verwendung von Ersatzteilen anderer Hersteller ist nicht zulässig. Die Verantwortung für die Sicherheit der Maschine liegt bei der Verwendung von Ersatzteilen anderer Hersteller.

Benennung		2740 - Zylinder/Piston-Kit / Zylinder/Kolben Kit	
Zusammengehörig	Dokument-Nr.	Original	Erstellt mit:
Service spare part drawing / Service Ersatzteil Zeichnung	K000XXXX D 01	Alt	Solid Edge
SECA-Nummer	Version	14.03.2017	Benutzer
SEC-8605_21	Subassembly / Untergruppe	Benutzer	1 von 1




**KAESER KOMPRESSOREN**

**1038 - Sound enclosure / Schalldämmhaube**

Original Name Datum  
 Zeichnungsart: Original Name: 24.04.2019  
 Skizze: 24.04.2019  
 Fertigkeit: Fertigkeit: 24.04.2019  
 Fertigung: Fertigung: 24.04.2019  
 Zeichnung: Zeichnung: 24.04.2019

SEGA-Nummer: (Service-Kit) / Subassembly / Untergruppe  
 SED-1009\_01

Blatt 1 von 1



**KAESER KOMPRESSOREN**


**8013 - Set sheet metal parts / Satz Blechteile**

Blattgruppe: 8013  
 Zeichnungsart: Service-Ensemble-Zeichnung  
 Dokument-Nr.:  
 Original: Datum: 25.08.2019  
 Art: Part1  
 Version: 25.08.2019  
 Blatt: Part1  
 Anzahl: 1 von 1

Original-Datei: C:\Programme\Kaeser\KOMPRESSOREN\8013\8013.dwg  
 Original-Datei: C:\Programme\Kaeser\KOMPRESSOREN\8013\8013.dwg

Die Zeichnung ist ein Ersatzteil. Bitte beachten Sie die folgenden Hinweise: Dieses Ersatzteil ist ein Ersatzteil für ein bestimmtes Modell. Es ist nicht für andere Modelle geeignet. Die Zeichnung ist ein Ersatzteil. Bitte beachten Sie die folgenden Hinweise: Dieses Ersatzteil ist ein Ersatzteil für ein bestimmtes Modell. Es ist nicht für andere Modelle geeignet. Die Zeichnung ist ein Ersatzteil. Bitte beachten Sie die folgenden Hinweise: Dieses Ersatzteil ist ein Ersatzteil für ein bestimmtes Modell. Es ist nicht für andere Modelle geeignet.






**KAESER KOMPRESSOREN**

Bezeichnung: 1065 - Inlet-/Pressure range / Ansaug-/Druckbereich  
 Datum: 30.04.2019  
 Zeichnungszustand: Original  
 Name: Erhellung  
 Zeichnungsart: 3D-Modell  
 Datum: 25.05.2019  
 Name: R001  
 Blatt: 1 von 1


SECC-10102\_01  
 (Service-Kit) (Option) (Subassembly) (Untergruppe)

Bitte beachten Sie, dass die Ersatzteile nur für die Reparatur von Druckluftkompressoren vorgesehen sind. Die Verwendung dieser Ersatzteile für andere Zwecke ist nicht zulässig. Die Haftung für Schäden an Personen oder Sachwerten ist ausgeschlossen. Die Ersatzteile sind nur für die Reparatur von Druckluftkompressoren vorgesehen. Die Verwendung dieser Ersatzteile für andere Zwecke ist nicht zulässig. Die Haftung für Schäden an Personen oder Sachwerten ist ausgeschlossen.



**KAESER KOMPRESSOREN**

Original Name: Erteilt mit:  
 Datum: 08.05.2019 Part: Solid Edge  
 Zeichnung: 20.05.2019 Part: Bsp  
 Dokument Nr.: Ad  
 Original: (Service-Kit) / Subassembly / Untergruppe  
 Zeichnungsgruppe: 7006 - Control lines / Steuerleitungen  
 Zeichnungsgruppe: 7006 - Control lines / Steuerleitungen  
 Original Name: Erteilt mit:  
 Datum: 08.05.2019 Part: Solid Edge  
 Zeichnung: 20.05.2019 Part: Bsp  
 Dokument Nr.: Ad  
 Original: (Service-Kit) / Subassembly / Untergruppe  
 Zeichnungsgruppe: 7006 - Control lines / Steuerleitungen



**KAESER KOMPRESSOREN**

Bezeichnung: 2D09 - Fan assembly / Baugruppe Ventilator

Zeichnungsgrupp: Dokument-Nr.

Original: Datum: Name: Erstellt von:



Alt: 24.04.2019: Part1: Solid Edge:

Modifiziert: 24.04.2019: Part1: Bsp2:

Standard: (Service-Kit) (Option) (Subassembly) / Untergruppe








SEC-Nr: 0109\_01


Blatt: 1 von 1



Die Zeichnung ist eine Exploded View. Sie ist nicht als Montageanleitung zu verstehen. Sie ist nur zur Identifizierung der Ersatzteile geeignet.  
 This is an exploded view drawing. It is not a manual for assembly. It is only suitable for identifying spare parts.  
 Die Zeichnung ist eine Exploded View. Sie ist nicht als Montageanleitung zu verstehen. Sie ist nur zur Identifizierung der Ersatzteile geeignet.  
 This is an exploded view drawing. It is not a manual for assembly. It is only suitable for identifying spare parts.

Bezeichnung		Original		Ersatzteil	
Zachungsgruppe	Dokument Nr.	Art	Name	Skizze	Skizze
960-000-000	960-000-000	960-000-000	ECO-Drain 12	960-000-000	960-000-000
Service-Kit / Subassembly / Untergruppe			Blatt		
960-000-000			1 von 1		





Original for identification

Original for identification

Kaeser-Teil-Nr.		Original		Name	
Doc-Nr.	Part-Nr.	Doc-Nr.	Part-Nr.	Original	English
5007	5007	20.05.2119	20.05.2119	Drain valve	Drain valve
2072	2072	20.05.2119	20.05.2119	Oil separator	Oil separator
6446	6446	20.05.2119	20.05.2119	Return line	Return line
6470	6470	20.05.2119	20.05.2119	Service kit	Service kit
2140	2140	20.05.2119	20.05.2119	Oil separator	Oil separator
6510	6510	20.05.2119	20.05.2119	Return line	Return line
2008	2008	20.05.2119	20.05.2119	Drain valve	Drain valve

Drain valve  
Oil separator  
Return line  
Service kit

5000 - Compressed-air cooling / Druckluftkühlung

Zeichnungstyp: Einzelteil

Strichliste: 10.05.2119, 10.05.2119


SFCA-Nr.: 10.05.2119

Original für Identifikation: 10.05.2119

Original für Identifikation: 10.05.2119

Original für Identifikation: 10.05.2119

Original für Identifikation: 10.05.2119



**KAESER KOMPRESSOREN**

Original Name: Erweitert: 1 von 1  
 Datum: 20.05.2019  
 Zeichnungs-Nr.: 1056  
 Original: 1056  
 Datum: 20.05.2019  
 Zeichnungs-Nr.: 1056  
 Original: 1056  
 Datum: 20.05.2019  
 Zeichnungs-Nr.: 1056


**5000 - Compressed-air cooling / Druckluftkühlung**

Zeichnungsgruppe: 5000  
 Original: 1056  
 Datum: 20.05.2019  
 Zeichnungs-Nr.: 1056  
 Original: 1056  
 Datum: 20.05.2019  
 Zeichnungs-Nr.: 1056

**Service-Kit (Option) / Subassembly / Untergruppe**

Original: 1056  
 Datum: 20.05.2019  
 Zeichnungs-Nr.: 1056

### 11.4 Replacement parts for service and repair



Bitte beachten Sie, dass die Ersatzteile, die in dieser Zeichnung dargestellt sind, nur für den originalen Hersteller und für den originalen Hersteller vorgesehen sind. Die Zeichnung ist nur ein Beispiel für die Darstellung der Ersatzteile. Die Zeichnung ist nicht verbindlich. Die Zeichnung ist nur ein Beispiel für die Darstellung der Ersatzteile. Die Zeichnung ist nicht verbindlich. Die Zeichnung ist nur ein Beispiel für die Darstellung der Ersatzteile. Die Zeichnung ist nicht verbindlich.

Original: 21.05.2019  
 Zeichnung: 21.05.2019  
 Blatt: 1 von 1


Original	Name	Erstellt mit
21.05.2019	Part1	Solid Edge
21.05.2019	Part1	Blatt
21.05.2019	Part1	Blatt

5007 - Cooler HP w. attach parts / Kühler-HD mit Anbauteilen

Zeichnungsgruppe: Original

Service-Kit (Option) / Subassembly / Untergruppe

SEGA-Nummer: 5007-10128-01



**KAESER KOMPRESSOREN**

Original Name: 1056 - Venting / Entlüftung  
 Original Datum: 18.04.2019  
 Original Ad: 1056  
 Original Stückzahl: 1056-10118\_01


Service-Kit (Option) / Subassembly / Untergruppe  
 Service-Kit (Option) / Subassembly / Untergruppe

1 von 1




Die Zeichnung zeigt die Montage eines Ersatzteils an einer Maschine. Die Zeichnung ist als Explosionszeichnung dargestellt. Die Zeichnung zeigt die Montage eines Ersatzteils an einer Maschine. Die Zeichnung ist als Explosionszeichnung dargestellt.

<b>KAESER</b> KOMPRESSOREN		Erstellt mit:	
Zeichnungs-Nr.	Dokument-Nr.	Original	Alt
1505 - Control air filter / Steuerluftfilter			
SEGA-Nummer	(Service-Kit) / Subassembly / Untergruppe	1505	1505
SEGA-11122_01			
		Blatt 1	von 1








**KAESER KOMPRESSOREN**


**2040 - Inlet valve / Einlassventil**

Bezeichnung	Original	Name	Erstellt mit
Zeichnungsgrupp	1000XXXX D 01	13.08.2017	13.08.2017
Service spare part drawing / Service Ersatzteil Zeichnung	At	Heinze	Solid Edge
SECA Number	13.08.2017	Heinze	Blatt
SEC-6508.01	(Service-Kit) / Subassembly / Untergruppe	Blatt	1 von 1

Bitte beachten Sie, dass die Ersatzteile nur für den originalen Hersteller und für den originalen Hersteller vorgesehen sind. Die Verwendung von Ersatzteilen anderer Hersteller kann zu Schäden an der Maschine und an den Bauteilen führen. Die Zeichnung ist eine schematische Darstellung und ist nicht maßstabgetreu. Die Zeichnung ist eine schematische Darstellung und ist nicht maßstabgetreu. Die Zeichnung ist eine schematische Darstellung und ist nicht maßstabgetreu.




**11.4.2 Spare parts option K9 (water cooling: tube heat exchanger)**



Prosimplem, ki je namenjen samo za uporabo pri vzdrževanju. Če želite več informacij, se obrnite na našo službo za pomoč pri iskanju delovnih delov. Če želite več informacij, se obrnite na našo službo za pomoč pri iskanju delovnih delov. Če želite več informacij, se obrnite na našo službo za pomoč pri iskanju delovnih delov.

KAESER KOMPRESSOREN		Original	
Zeichnungs-Nr.	Dokument-Nr.	Name	Erstellt am:
1025 - Drive / Antrieb			
SEGA-Nummer	SEGA-10098_01	Original	13.05.2019
SEGA-Gruppe	(Service-Kit) (Option) (Subassembly) (Untergruppe)	Alt	13.05.2019
		Neu	
		Blatt	1 von 1



**KAESER**  
KOMPRESSOREN


Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungs-Nr.: 24.05.213 Part1  
 Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungs-Nr.: 24.05.213 Part1  
 Original Name: Original Datum: Erstellt mit: Solid Edge  
 Zeichnungs-Nr.: 24.05.213 Part1

1089 - Valve plate - cylinder-head / Ventilplatte-Zylinder-Kopf

SEGA Number: SEC-10158\_01


(Service-Kit) (Option) (Subassembly) (Untergruppe)

Blatt 1 von 1




Benennung: 1090 - Oil circuit - slide ring - Ölkreislauf - Gleitring  
 Zeichnungsgruppe: Service spare parts drawing / Service Ersatzteil-Zeichnung  
 Dokument-Nr.:  
 Original: 24.05.2019  
 Name: Part1  
 Erstellt mit: Solid Edge  
 Datum: 24.05.2019  
 Part1  
 Modifiziert: 24.05.2019  
 Part1  
 Blatt: 1 von 1  
 (Service-Kit) (Option) / Subassembly / Untergruppe

Bitte beachten Sie, dass die Ersatzteile nur für die Reparatur von Originalgeräten vorgesehen sind. Die Verwendung von Ersatzteilen anderer Hersteller kann zu Schäden an den Originalgeräten führen. Die Zeichnung ist eine technische Zeichnung und ist nicht als Ersatzteilzeichnung zu verwenden. Die Zeichnung ist eine technische Zeichnung und ist nicht als Ersatzteilzeichnung zu verwenden. Die Zeichnung ist eine technische Zeichnung und ist nicht als Ersatzteilzeichnung zu verwenden. Die Zeichnung ist eine technische Zeichnung und ist nicht als Ersatzteilzeichnung zu verwenden.



2744



2710


**KAESER**  
KOMPRESSOREN

Bitte beachten Sie, dass alle Ersatzteile bei KAESER nur als Originalteile gefertigt werden. Die Ersatzteile sind nur für die Reparatur von KAESER-Kompressoren geeignet. Die Ersatzteile sind nur für die Reparatur von KAESER-Kompressoren geeignet. Die Ersatzteile sind nur für die Reparatur von KAESER-Kompressoren geeignet.

Original	Original	Original
Document No.	Part No.	Serial No.
XXXXXX D 01	A4	14.03.2017
Service-Kit	Option	Subassembly / Untergruppe
SEC-4805-D1	14.03.2017	14.03.2017
1 von 1		

**2740 - Cylinder/Piston-Kit / Zylinder/Kolben Kit**





**KAESER KOMPRESSOREN**


Original Name Datum  
 Zeichnungs-Nr. 24.04.2019  
 Original Name Datum  
 Zeichnungs-Nr. 24.04.2019  
 Original Name Datum  
 Zeichnungs-Nr. 24.04.2019

10038 - Sound enclosure / Schalldämmhaube

SEGA Nummer: SEC-10038\_01

(Service-Kit) / Subassembly / Untergruppe

Blatt 1 von 1



**KAESER KOMPRESSOREN**

Original Name: 8013  
 Original Datum: 25.08.2019  
 Original Ad: Part1  
 Original Version: 25.08.2019  
 Original Status: Part1

Erstellt mit: Solid Edge

8013 - Set sheet metal parts / Satz Blecheile


Zeichnungsart: Dokument Nr. 8013

Skizze: skizze.ppt  
 Zeichnung: 8013.dwg  
 Untergruppe: (Service-Kit) / Subassembly / Untergruppe

SECA Nummer: SEC0-10318\_01

Blattgruppe: 1 von 1

Die Zeichnung ist ein technisches Dokument. Sie ist urheberrechtlich geschützt und darf nicht kopiert, verbreitet oder sonstwie öffentlich zugänglich gemacht werden. Jeder unbefugte Zugriff ist untersagt. Die Zeichnung ist ein geistiges Eigentum der Kaeser Compressoren AG. Die Weitergabe an Dritte ist ohne schriftliche Genehmigung der Kaeser Compressoren AG. Die Zeichnung ist ein geistiges Eigentum der Kaeser Compressoren AG. Die Weitergabe an Dritte ist ohne schriftliche Genehmigung der Kaeser Compressoren AG.




**KAESER  
KOMPRESSOREN**

Original Name Datum Erstellt von  
 Zeichnungs-Nr. 18.05.2019 P1611 Solid Edge  
 Service spare part drawing / Service Ersatzteil-Zeichnung Maschen 24.05.2019 P1611 BMBZ  
 (Service-Kit) (Option) / Subassembly / Untergruppe  
 SE-10105\_01  
 (Kaufgruppe) (Kaufgruppe) (Kaufgruppe)  
 1 von 1

1055 - Inlet-/Pressure range / Ansaug-/Druckbereich

Bitte beachten Sie, dass die Ersatzteile hier nur als Illustration dargestellt sind und nicht als Ersatz für den Originalteil vorgesehen sind. Die Zeichnung ist keine Garantie für die Richtigkeit der Angaben. Die Zeichnung ist eine Illustration, die die Identifizierung der Ersatzteile erleichtert. Die Verantwortung für die Richtigkeit der Angaben liegt bei den Kunden. Die Zeichnung ist eine Illustration, die die Identifizierung der Ersatzteile erleichtert. Die Verantwortung für die Richtigkeit der Angaben liegt bei den Kunden. Die Zeichnung ist eine Illustration, die die Identifizierung der Ersatzteile erleichtert. Die Verantwortung für die Richtigkeit der Angaben liegt bei den Kunden.




**KAESER KOMPRESSOREN**

**7006 - Control lines / Steuerleitungen**

Original Name Datum Erteilt von  
 Zeichnungs-Nr. 18.05.2019 Part1 Solid Edge  
 Original Name Datum Erteilt von  
 Zeichnungs-Nr. 18.05.2019 Part1 Solid Edge

SEGA-Nummer: 7006-10109\_01  
 SEGA-Gruppe: (Service-Kit) (Option) (Subassembly) (Untergruppe)

Blatt: 1 von 1



**KAESER KOMPRESSOREN**

**Bezeichnung:** 2D09 - Fan assembly / Baugruppe Ventilator

**Zuordnung:** Original: Datum: Name: Erstellte Nr.:  
 Skizze: 24.04.2019 P-011  
 1/1

**SEGA-Nummer:** 1/2009 24.04.2019 P-011  
 1/1



**SEGA-Info:** (Service-Kit) (Option) (Subassembly / Untergruppe)

**Original-Teil-Nr. / Original-Datei:**








**Original-Teil-Nr. / Original-Datei:**


**Original-Teil-Nr. / Original-Datei:**

**Original-Teil-Nr. / Original-Datei:**



Zeichnungstyp: ECO-Drain 12  
 Original Name: Ersatzteil  
 Dokument Nr.: 138.02.2135  
 Zeichnung Nr.: 138.02.2135  
 Datum: 18.02.2015  
 Zeichnung: 138.02.2135  
 Blatt: 1 von 1  
 (Service-Kit) | Subassembly | Untergruppe






Bitte beachten Sie die folgenden Hinweise: Gebrauchte oder verschlissene Originalteile werden nicht empfohlen. Bei der Montage von Ersatzteilen ist die Verwendung von Originalteilen zu empfehlen. Die Zeichnung bildet nur ein Ersatzteil dar. Es ist nicht zulässig, die Zeichnung zu kopieren, zu reproduzieren oder in irgendeiner Weise zu verbreiten. Die Zeichnung ist Eigentum der KAESER KOMPRESSOREN. Die Weitergabe an Dritte ist ohne schriftliche Genehmigung der KAESER KOMPRESSOREN. Die KAESER KOMPRESSOREN sind für die Herstellung von Druckluftkompressoren und Druckluftsystemen bekannt. Die KAESER KOMPRESSOREN sind für die Herstellung von Druckluftkompressoren und Druckluftsystemen bekannt. Die KAESER KOMPRESSOREN sind für die Herstellung von Druckluftkompressoren und Druckluftsystemen bekannt.

KAESER KOMPRESSOREN		Original		Ersatzteil	
Zeichnungs-Nr.	Dokument-Nr.	Name	Datum	Erstellt mit	Seit
5007		5007	20.05.2019	10/11	10/11
SECC-Nr.		SECC-Nr.	20.05.2019	10/11	10/11
SECC-Nr.		SECC-Nr.	20.05.2019	10/11	10/11

5000 - Compressed-air cooling / Druckluftkühlung  
 Zeichnungs-Nr. 5007  
 SECC-Nr. 5007  
 SECC-Nr. 5007



Originalteilnummer: 901771 27 USE


Originalteilname: 5000 - Compressed-air cooling / Druckluftkühlung

Originalteilgruppe: (Service-Kit) / Subassembly / Untergruppe

KAESER KOMPRESSOREN	
Zeichnungsgrupp	Dokument-Nr.
Original-Nr.	Erstellt in:
Ad.	Rev.
20.05.2019	Part1
20.05.2019	Part1
20.05.2019	Part1
20.05.2019	Part1
20.05.2019	Part1
20.05.2019	Part1
20.05.2019	Part1
20.05.2019	Part1

1 von 1





**KAESER KOMPRESSOREN**


Original Name Datum  
 Zeichnungs-Nr. 21.05.2019  
 Original Nr. 21.05.2019  
 Original Name 21.05.2019  
 Original Name 21.05.2019

5007 - Cooler HP w. attach parts / Kühler-HD mit Anbauteilen

SEGA-Nummer: 5007-01/22\_01


(Service-Kit) (Option) / Subassembly / Untergruppe

Blatt 1 von 1



Die Zeichnung ist eine Exploded View. Die Teile sind nicht in ihrer natürlichen Reihenfolge dargestellt. Die Zeichnung ist eine Exploded View. Die Teile sind nicht in ihrer natürlichen Reihenfolge dargestellt. Die Zeichnung ist eine Exploded View. Die Teile sind nicht in ihrer natürlichen Reihenfolge dargestellt.

<b>KAESER KOMPRESSOREN</b>		Original Name		Erstellt mit	
5007 - Cooler HP w. atftech parts / Kühler-HD mit Anbauteilen		Dokument-Nr.		A4	
Zeichnungsgruppe		Datum		Solid Edge	
Schnitznummer		Reviz.		Blatt	
SEC-Nr. 01/28_01		11.05.2019		1 von 1	
(Service-Kit) (Option) (Subassembli) (Untergruppe)		Blatt		Blatt	




**KAESER KOMPRESSOREN**

Bitte beachten Sie die folgenden Hinweise: Gebrauch der Ersatzteile ist nur zulässig, wenn es sich um die originalen Ersatzteile handelt. Die Verwendung von Ersatzteilen anderer Herkunft kann zu Schäden an der Maschine und an der Umwelt führen.  
 Die Zeichnung ist ein technisches Dokument und ist als solche zu behandeln. Die Zeichnung ist nicht als Ersatz für die Originalzeichnung zu verwenden. Die Zeichnung ist als technisches Dokument zu betrachten. Die Zeichnung ist als technisches Dokument zu betrachten. Die Zeichnung ist als technisches Dokument zu betrachten. Die Zeichnung ist als technisches Dokument zu betrachten.

Original-Teilenummer: 9864  
 Ersatzteil-Nr.: 9864  
 Original-Name: Ersatzteil  
 Original-Datum: 26.02.2019  
 Original-Alt: Alt  
 Original-Teilenummer: 9864  
 Original-Name: Ersatzteil  
 Original-Datum: 26.02.2019  
 Original-Alt: Alt

Bezeichnung: 1056 - Venting / Entlüftung  
 Zeichnungsgruppe:   
 SMDL-Nummer: 9864  
 SMDL-Teilenummer: 9864  
 (Service-Kit) (Option) (Subassembly) (Untergruppe)  
 Blatt 1 von 1



Produktionszeichnungen sind nur als Orientierungshilfe zu verstehen. Sie ersetzen nicht den Originalhersteller. Änderungen sind vorbehalten. Die Zeichnung ist als technische Zeichnung anzusehen. Die Ausführung ist davon abhängig, wie die Zeichnung in der Ausführung gezeichnet ist. Die Zeichnung ist als technische Zeichnung anzusehen. Die Ausführung ist davon abhängig, wie die Zeichnung in der Ausführung gezeichnet ist.

Lesen Sie die Zeichnung sorgfältig durch. Die Zeichnung ist als technische Zeichnung anzusehen. Die Ausführung ist davon abhängig, wie die Zeichnung in der Ausführung gezeichnet ist.


**1505 - Control air filter / Steuerluftfilter**

Zeichnungsgrupp	Dokument-Nr.	Original	Name	Erstellt am:
SECA-11122_01		Alt		30.04.2019
SECA-11122_01		Neu		30.04.2019

**(Service-Kit) | Subassembly / Untergruppe**

Blatt 1 von 1






2042


2044

6442 9874



9875 6428 9869 6429

3795



<b>KAESER KOMPRESSOREN</b>		Name		Erstellt am	
Benennung		Datum		Solid Edge	
2040 - Inlet valve / Einlassventil		13.08.2017		Heing2	
Zeichnungsyp		Original		Bsp	
Sonderform für: Einleitung / Service Einlassventil		K0000000.D 01		13.08.2017	
SECA Nummer		Option / Subassembly / Untergruppe		1 von 1	
SEC-6508_21		Revised		1 von 1	

## 12 Decommissioning, Storage and Transport

### 12.1 Decommissioning

Decommissioning is necessary, for example, under the following circumstances:

- the machine is temporarily not needed,
- the machine is to be moved to another location,
- The machine is to be scrapped.

#### Temporary decommissioning

Precondition The machine can be started at regular intervals.

- Run the machine once a week under load for at least 30 minutes to ensure sufficient corrosion protection.

#### Long-term decommissioning

- In this case, please contact an authorized KAESER service representative.

### 12.2 Packing

A wooden crate is required for overland transport to protect the machine from mechanical damage. Other measures must be taken for the transport of machines by sea or air. Please contact an authorized KAESER service representative for more information.

Material Desiccant  
Plastic sheeting  
Wooden crate

Precondition The machine is decommissioned.  
Machine is dry and cooled down.

1. Wrap the machine fully in plastic sheeting.
2. Place sufficient desiccant (e.g. silica gel) inside the plastic sheeting.
3. Protect the machine in a wooden crate against mechanical damages.

### 12.3 Storage

Moisture can lead to corrosion, particularly on the surfaces of the compressor block.

Frozen moisture can damage components, valve diaphragms, and gaskets.



Please consult with KAESER if you have questions to the appropriate storage and commissioning.

1. **NOTICE** *Moisture and frost can damage the machine!*
  - *Prevent ingress of moisture and formation of condensation.*
  - *Maintain a storage temperature of >32°F.*
2. Store the machine in a dry, frost-proof room.

## 12.4 Transport

### 12.4.1 Safety

Weight and center of gravity determine the most suitable method of transportation.



Please consult with KAESER if you intend to transport the machine in freezing temperatures.

**Precondition** Transport only by forklift truck or suitable lifting gear and only by personnel trained in the safe transportation of loads.

- Ensure the danger area is clear of personnel.

### 12.4.2 Transport with a forklift truck

**Precondition** The whole machine is over the forks.



Fig. 59 Transporting with a forklift truck

1. Take note of the center of gravity.
2. Drive the forks completely under the machine or pallet and lift carefully.

### 12.4.3 Transport with a hoist

Only suitable and approved load-carrying and attachment devices ensure proper transport of the machine with a hoist (e.g., crane). Suitable crossbeams ensure sufficient distance of the attachment resources from the machine housing to prevent damage.

The machine is not equipped with fastening points.

Examples of unsuitable fastening points:

- Pipe sockets
- Attached components such as cyclone separators, condensate drains or compressed air filters.



➤ Consult with KAESER if you require suitable load-carrying and attachment devices or have questions regarding the correct use.

**Precondition** Load-carrying and attachment devices meet the local safety regulations.

The hoist, load-carrying and attachment devices or the lifted machine do not endanger personnel.






Fig. 60 Transport with a crane

- ① Load carrying devices
- ② Attachment resources
- ③ Crossbeam

1. **⚠ WARNING** Risk of accident caused by incorrect use of load-carrying and attachment devices!
  - Comply with permissible load limits.
  - Comply with specific safety information of used load-carrying and attachment devices.
2. Properly use load-carrying and attachment devices:
  - Ensure proper distribution of the fastening points relative to the centre of gravity position (symmetrical load distribution).
  - Ensure equal slope angles of 15° to 45° for attachment devices with multiple strands.
    - Slope angles between 45° and 60° may be unsuitable.
    - Slope angles larger than 60° are prohibited.
  - Ensure the maximum incline of 6° of the machine to the horizontal.
  - Ensure sufficient distance of the attachment devices to the machine.
  - Ensure a positive stability height: Dimension B > Dimension A
  - Do not attach the attachment devices to any machine component.
3. Carry out a lifting test:  
Slightly lift the machine to check whether machine remains in horizontal position and does not teeter.
4. Transport the machine only after a successful lifting test.

## 12.5 Disposal

When disposing of a machine, drain out all liquids and remove dirty filters.

Precondition The machine is decommissioned.

1. Completely drain the cooling oil from the machine.
2. Remove used filters.
3. Hand the machine over to an authorized disposal expert.



- Components contaminated with oil must be disposed of in accordance with local environmental protection regulations.

### 12.5.1 Battery disposal

Batteries contain substances that are harmful to living beings and the environment. For this reason, batteries must not be disposed of with unsorted residential waste. They must be disposed of in accordance with local environmental regulations. This procedure facilitates the handling and recycling of batteries.





Fig. 61 Battery disposal

- ① Do not dispose of batteries with residential waste
- ② Battery contains lead (if applicable)

- Dispose of batteries in accordance with local environmental regulations.

## **13 Annex**

### **13.1 Pipeline and instrument flow diagram (P+I diagram)**



\* Not with option F15


P&I diagram		Sheet	
Booster		1	
FKKDNCN2-20212.00		FKKDNCN2-00212.01	
DNC Nitrogen		USE	
c	Name	Date	Name
b	Plau	11.11.2020	Schäfer
a	Schäfer	11.11.2020	Schäfer
Revision	Date	Name	

1	Compressor block	24	Inlet valve
1.3	Oil filter	24.1	Inlet control valve
1.6	Oil pump	24.2	Shut-off valve Ventilation (Suction side)
1.8	Bypass valve	24.3	Hose line (Suction side)
1.10	Dirt trap (Compressor block)	24.4	Silencer
1.11	Crankcase	25	Unloading valve
1.12	Filter (Crankcase venting)	25.1	Silencer (Pressure relief)
1.13	Check valve (Compressor block)	25.2	Dirt trap
1.20	Oil level sensor (switching)	25.3	Filter (Pressure relief)
1.21	Nozzle	25.4	Check valve (Pressure relief)
3	Compressor motor	25.5	Unloading control valve
3.2	Temperature Compressor motor [T3]	25.6	Hose line (PN145)
4	V-belt pulley	25.9	Automatic condensate drain: Solenoid valve
10	Fan motor	25.10	Hose line (PN75)
13	Compressed air aftercooler	27	PT100 temperature sensor - Air/rend discharge temperature (Cylinder 1, 2, 3) [T1.1, T1.2, T1.3]
13.1	Shut-off valve (Condensate outlet Compressed air aftercooler)	27.1	PT100 temperature sensor - Nitrogen outlet [T2]
13.2	Dirt trap (Return line)	39	Pressure regulating valve
13.3	Recovery valve	48	Pressure transducer - Nitrogen inlet [p1]
13.4	Silencer	48.1	Pressure transducer - Nitrogen outlet [p4]
13.6	Temperature switch	48.2	Pressure transducer - Oil pressure [p5]
13.15	Hose line (Discharge side)	48.3	Pressure transducer - Suction side [p2]
13.17	Check valve (Discharge side)	48.4	Pressure transducer - Discharge side [p3]
13.18	Nozzle Pulsation dampening (Discharge side)	Option	
13.20	Control valve for return valve	F15	KAESER FILTER KD
14	KAESER FILTER KD	K1	Air cooling
17	Pressure gauge Network pressure (Initial pressure)	K9	Water cooling: bundled-tube heat exchanger
17.2	Pressure gauge Network pressure (Final pressure)		
19*	Dirt trap (Suction side)		
22.1	Safety relief valve (Suction side)		
22.2	Safety relief valve (Nitrogen outlet)		

\* Not with option F15


c		Date	Name	P+I diagram	Sheet
b		Drawn	Plau	FKKDNCN2-00212.00	2
a		Released	Schäfer	Booster	USE
				DNC Nitrogen	FKKDNCN2-00212.01

## 13.2 Dimensional drawing






Change number	Projection	Scale	Date	Name
Document TZM 10505210 USE 00	Original	1:25	16.12.2020	KOCH4
Document T2D 10505210 D 00	A3	A3	17.12.2020	KOCH4
Status Released	Designation	DNC.2 K1 Dimension and connection dim.		

Change number	Date	Name	Language	Sheet
H4	16.12.2020	KOCH4	USE	1 / 2
K5/K6	17.12.2020	KOCH4	USE	1 / 2
H1	17.12.2020	HOLLAUER1	USE	1 / 2
K1	17.12.2020	HOLLAUER1	USE	1 / 2
F14	17.12.2020	HOLLAUER1	USE	1 / 2



Position marginally dependent on design  
ID: Internal thread  
Transport opening ≥ machine width + 3.9 inch




Subject to development-related changes.  
Drawing may be altered only via CAD.

Drawings remain our exclusive property.  
They are suitable only for the agreed upon purpose.  
Copies or any other reproductions, including storage, treatment and distribution by use of electronic systems is not allowed for any other than the agreed upon purpose.  
Neither originals nor reproductions may be given to or made available to third parties.




Change number		Projection	Scale	Date	Name	KAESER KOMPRESSOREN	
H4	Oil collection tray		1:25	Drawn 16.12.2020	KOCH4	Language	USE
K5/K6	electronic condensate drain		Original	Edited 17.12.2020	KOCH4	Sheet	2 / 2
H1	Machine mountings	Document TZD	A3	Released 17.12.2020	HOLLAUER1	Designation	
K1	Air cooling	10505210 D 00	DNC.2 K1		Dimension and connection dim.		
F14	KAESER FILTER KB / ECO-DRAIN	Status	Released				

Stand 13.02.2016





Drawings remain our exclusive property. Neither originals nor reproductions may be given to or made available to third parties. Copies of any other reproductions, including storage, treatment and distribution by use of electronic systems is not allowed for any other than the agreed upon purpose. The file is intended only for the agreed upon purpose.



Subject to development-related changes.  
Drawing may be altered only via CAD.

Drawings remain our exclusive property.  
They are intended only for the agreed upon purpose.  
Copies or any other reproductions, including storage, treatment and distribution by use of electronic systems is not allowed for any other than the agreed upon purpose.  
Neither originals nor reproductions may be given to or made available to third parties.

Change number		Projection	Scale	Date	Name	KAESER KOMPRESSOREN	
H4	Oil collection tray	1st angle projection	1:25	16.12.2020	KOCH4	Language	USE
K5/K6	electronic condensate drain		Original	Drawn	17.12.2020	KOCH4	Sheet
K9	Water cool. bundled-pipe exch.	Document TZM	A3	Released	HOLLAUER1	Designation	
H1	Machine mountings	Document TZD	DNC.2 K9		Dimension and connection dim.		
F14	KAESER FILTER KB / ECO-DRAIN	10505295 USE 00	Status		Released		
		10505295 D 00	Released				

Stand 13.02.2016


## 13.3 Electrical Diagram

1	2	3	4	5	6	7	8																																
<p><b>Wiring Diagram</b></p> <p>booster compressor DN22C/DN30C/DN37C/DN37CXL/DN45C</p> <p>air cooled or water cooled</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">208V±10% 3ph 60Hz</td> <td style="width: 50%;">230V±10% 3ph 60Hz</td> </tr> <tr> <td>380V±10% 3ph 60Hz</td> <td>460V±10% 3ph 60Hz</td> </tr> <tr> <td>575V±10% 3ph 60Hz</td> <td></td> </tr> </table> <p>Power supply: WYE system with center point solidly grounded</p>								208V±10% 3ph 60Hz	230V±10% 3ph 60Hz	380V±10% 3ph 60Hz	460V±10% 3ph 60Hz	575V±10% 3ph 60Hz																											
208V±10% 3ph 60Hz	230V±10% 3ph 60Hz																																						
380V±10% 3ph 60Hz	460V±10% 3ph 60Hz																																						
575V±10% 3ph 60Hz																																							
<p style="text-align: center;"><b>ATTENTION !!!</b></p> <p>The document gives collective information on power supply voltages and frequencies for all machines. The voltage and frequency and local conditions under which any particular machine may be used are given on the nameplate of the machine and in the accompanying service manual.</p>																																							
<p>The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p>																																							
<p style="text-align: center;"><b>manufacturer: KAESER COMPRESSORS</b> 96450 Coburg GERMANY</p>																																							
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; text-align: center;">c</td> <td style="width: 10%;"></td> <td style="width: 10%; text-align: center;">Date</td> <td style="width: 10%; text-align: center;">22.01.21</td> <td style="width: 10%; text-align: center;">USE</td> <td style="width: 10%;"></td> <td style="width: 10%;"></td> <td style="width: 10%;"></td> </tr> <tr> <td style="text-align: center;">b</td> <td></td> <td style="text-align: center;">Drawn</td> <td style="text-align: center;">Siller</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">a</td> <td></td> <td style="text-align: center;">Released</td> <td style="text-align: center;">Büchner</td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;">A</td> <td style="text-align: center;">Change</td> <td style="text-align: center;">Date</td> <td style="text-align: center;">Name</td> <td></td> <td></td> <td></td> <td></td> </tr> </table>								c		Date	22.01.21	USE				b		Drawn	Siller					a		Released	Büchner					A	Change	Date	Name				
c		Date	22.01.21	USE																																			
b		Drawn	Siller																																				
a		Released	Büchner																																				
A	Change	Date	Name																																				
				SC2 MCS		DKK-U3010.07																																	
cover page booster compressor				=		+																																	
				page		1																																	
				1		Sht.																																	

Lfd. Nr. No.	Benennung Name	Zeichnungsnummer (Kunde) Drawing No. (customer)	Zeichnungsnummer (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	cover page		DKK-U3010.07	1	
2	list of contents		ZKK-U3010.07	1	
3	general instructions		UKK-U3010.07	1	
4	electrical equipment identification		UKK-U3010.07	2	
5	electrical component parts list		UKK-U3010.07	3	
6	electrical component parts list		UKK-U3010.07	4	
7	electrical component parts list		UKK-U3010.07	5	
8	electrical component parts list		UKK-U3010.07	6	
9	electrical component parts list		UKK-U3010.07	7	
10	electrical component parts list		UKK-U3010.07	8	
11	wiring diagram	power supply/power unit	SKK-U3010.07	1	
12	wiring diagram	compressor motor	SKK-U3010.07	2	
13	wiring diagram	vent motor	SKK-U3010.07	3	
14	wiring diagram	control voltage tapping	SKK-U3010.07	4	
15	wiring diagram	safety chain	SKK-U3010.07	5	
16	wiring diagram	power supply unit	SKK-U3010.07	6	
17	wiring diagram	IO-module/configuration	SKK-U3010.07	7	
18	wiring diagram	sensors/actuators	SKK-U3010.07	8	
19	wiring diagram	sensors/actuators	SKK-U3010.07	9	
20	wiring diagram	sensors/actuators	SKK-U3010.07	10	
21	wiring diagram	volt-free contacts	SKK-U3010.07	11	
22	wiring diagram	inputs/outputs IOM3	SKK-U3010.07	12	
23	wiring diagram	digital inputs - option C40	SKK-U3010.07	13	
24	wiring diagram	inputs/outputs - option C40	SKK-U3010.07	14	
25	wiring diagram	transformer diagrams	SKK-U3010.07	15	
26	wiring diagram	Handling: Terminals	SKK-U3010.07	16	
27	wiring diagram	Feed line connection	SKK-U3010.07	17	
28	wiring diagram	Feed line connection	SKK-U3010.07	18	
29	wiring diagram	Feed line connection	SKK-U3010.07	19	
30	terminal connection	terminal strip-X0-X11-X12	KKK-U3010.07	1	
31	lay-out	Switchboard	AKK-U3010.07	1	
32	lay-out	Switchboard	AKK-U3010.07	2	

Date		22.01.21	=		
a	Drawn	Siller	+		
b	Released	Büchner			
B. Change			SC2 MCS	ZKK-U3010.07	page 1 1 SHL
list of contents			booster compressor		
<b>KAESER</b> KOMPRESSOREN					

1	2	3	4	5	6	7	8																		
<p><b>general instructions</b></p> <p><b>ATTENTION !!!</b> Install supplies, grounding and shock protection to local safety regulations. Do not make or break live plug-in connectors.</p>																									
<p>control cabinet wiring for non-designated conductors</p> <table border="0"> <tr> <td>primary circuits ungrounded:</td> <td>black, UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>primary circuits grounded:</td> <td>grey, UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>control voltage AC 115V ungrounded:</td> <td>red, 18AWG UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>control voltage AC 115V grounded:</td> <td>white, 18AWG UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>control voltage DC ungrounded:</td> <td>blue, 18AWG UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>control voltage DC grounded:</td> <td>white/blue, 18AWG UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>external voltage:</td> <td>orange, 16AWG UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>measuring circuits:</td> <td>violet, 18AWG UL-Style 1015, CSA-TEW</td> </tr> <tr> <td>ground conductor:</td> <td>green/yellow, UL-Style 1015, CSA-TEW</td> </tr> </table>								primary circuits ungrounded:	black, UL-Style 1015, CSA-TEW	primary circuits grounded:	grey, UL-Style 1015, CSA-TEW	control voltage AC 115V ungrounded:	red, 18AWG UL-Style 1015, CSA-TEW	control voltage AC 115V grounded:	white, 18AWG UL-Style 1015, CSA-TEW	control voltage DC ungrounded:	blue, 18AWG UL-Style 1015, CSA-TEW	control voltage DC grounded:	white/blue, 18AWG UL-Style 1015, CSA-TEW	external voltage:	orange, 16AWG UL-Style 1015, CSA-TEW	measuring circuits:	violet, 18AWG UL-Style 1015, CSA-TEW	ground conductor:	green/yellow, UL-Style 1015, CSA-TEW
primary circuits ungrounded:	black, UL-Style 1015, CSA-TEW																								
primary circuits grounded:	grey, UL-Style 1015, CSA-TEW																								
control voltage AC 115V ungrounded:	red, 18AWG UL-Style 1015, CSA-TEW																								
control voltage AC 115V grounded:	white, 18AWG UL-Style 1015, CSA-TEW																								
control voltage DC ungrounded:	blue, 18AWG UL-Style 1015, CSA-TEW																								
control voltage DC grounded:	white/blue, 18AWG UL-Style 1015, CSA-TEW																								
external voltage:	orange, 16AWG UL-Style 1015, CSA-TEW																								
measuring circuits:	violet, 18AWG UL-Style 1015, CSA-TEW																								
ground conductor:	green/yellow, UL-Style 1015, CSA-TEW																								
<p>option C40 = Nitrogen version</p> <p>option K6 = Electronic condensate drain</p> <p>option F14 = KAESER FILTER KB</p>																									
<p style="text-align: center;">general instructions booster compressor</p>																									
																									
						SC2 MCS	UKK-U3010.07																		
						=	+																		
						page	1																		
						8 SHL																			

1		2		3		4		5		6		7		8	
<b>electrical equipment identification</b>															
<b>general components</b>				<b>control</b>				<b>sensors/actuators</b>							
-B25	overload relay,	-K20	Main Control System SC2/MCS	-B1	pressure transducer,	-B2	Compressed air outlet	-B3	pressure transducer,	-B4	oil pressure	-B5	Pressure side return circuit	-B40.1	intake side return circuit
-K50	compressor motor	-X1	Ethernet	-K21	IO-module SC2/IO-M-3	-X1	inside	-X2	IO-Bus, input	-X3	IO-Bus, output	-X4	analog input, Pt100	-B40.2	air end discharge temperature 1
-F4	coupling relay,	-X2	RS485-FC (USS)	-X5, -X9	power supply unit, digital outputs	-X5	Relay outputs	-X6	analog input, analog output 4-20mA	-X8	digital inputs	-X11...-X14	external analog inputs, 4-20mA	-B40.3	air end discharge temperature 2
-1FU,-2FU,-3FU	temperature Compressed air aftercooler	-X3	communication module (Bus)	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-K22	IO-module SC2/IO-M-1	-B42	air end discharge temperature 3
-M1	circuit breaker,	-X4	SD card slot	-X3,-X8	digital inputs	-X4	power supply unit, digital outputs	-X5,-X9	Relay outputs	-X6	analog input, analog output 4-20mA	-X7	analog input, Pt100	-B50	compressed air outlet temperature
-M4	vent motor	-X5	ground connection	-X6	analog input, Pt100	-X7	analog input, Pt100	-X8	digital inputs	-X9	external	-X10	analog inputs, 4-20mA	-B60	temperature switch
-M7	primary control fuse	-X6		-X11...-X14	external analog inputs, 4-20mA	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-B70	Compressed air aftercooler
-Q1	secondary control fuse	-X7		-X3,-X8	digital inputs	-X4	power supply unit, digital outputs	-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-K1	compressor motor
-Q2	compressor motor	-X8		-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-X8	external	-X9	external	-K2	oil level switch
-Q3	vent motor	-X9		-X11...-X14	external analog inputs, 4-20mA	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-K3	Inlet control valve
-Q4	controller ventilator	-X10		-X3,-X8	digital inputs	-X4	power supply unit, digital outputs	-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-K10	Return valve
-Q3	main contactor	-X11		-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-X8	external	-X9	external	-K11	Relief control valve
-Q2	delta contactor	-X12		-X11...-X14	external analog inputs, 4-20mA	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-K12	condensate drain filter
-Q3	wye contactor	-X13		-X3,-X8	digital inputs	-X4	power supply unit, digital outputs	-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-K11	condensate drain
-Q4	starter vent motor	-X14		-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-X8	external	-X9	external	-K12	Compressed air outlet
-S1	EMERGENCY STOP pushbutton	-X15		-X11...-X14	external analog inputs, 4-20mA	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-K12	condensate drain Prefilter
-S5	door safety interlock switch	-X16		-X3,-X8	digital inputs	-X4	power supply unit, digital outputs	-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-K12	Compressed air outlet
-T11	control transformer	-X17		-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-X8	external	-X9	external	-K12	Compressed air outlet
-T21,-T22	power unit	-X18		-X11...-X14	external analog inputs, 4-20mA	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-K12	Compressed air outlet
<b>terminal strips</b>															
-X0	terminal strip, power supply	-X1		-X3,-X8	digital inputs	-X4	power supply unit, digital outputs	-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-K12	Compressed air outlet
-X11	terminal strip, control	-X2		-X5,-X9	Relay outputs	-X6	analog input, 4-20mA	-X7	analog input, Pt100	-X8	external	-X9	external	-K12	Compressed air outlet
-X12	terminal strip, control 24VDC	-X3		-X11...-X14	external analog inputs, 4-20mA	-X15	analog output	-X18,-X19	digital inputs	-X20,-X21	digital outputs	-X22...-X32	analog inputs, Pt100	-K12	Compressed air outlet

Date		22.01.21		electrical equipment identification		=		UKK-U3010.07		page		2	
Drawn		Siller		booster compressor		+				page		8 SHL	
Released		Büchner						SC2 MCS					
C/Change		Date		Name									

model	electrical component parts list				page 3 8 Sht.
	DN 22 C	DN 30 C	DN37C / DN37CXL	DN 45 C	
machine power supply	208 V ±10 %, 60 Hz	208 V ±10 %, 60 Hz	208 V ±10 %, 60 Hz	208 V ±10 %, 60 Hz	= + UKK-U3010.07
motor -M1	30 hp	40 hp	50 hp	60 hp	
motor -M4	2 hp	2 hp	2 hp	2 hp	SC2 MCS
lay-out	page 2	page 2	page 2	page 2	
supply terminals -X0:U1/V1/W1	3x 894385.0 285-195 (WAGO) --- Torque Stripped length Handling GRD rail IHI Torque Stripped length	3x 895545.0 285-1185 (WAGO) --- 42 mm fig. 2, Sht. 16 7.8952.00010 S300-41-44 fig. 21, Sht. 19 minimal 26 mm	3x 895545.0 285-1185 (WAGO) --- 42 mm fig. 2, Sht. 16 7.8952.00010 S300-41-44 fig. 21, Sht. 19 minimal 26 mm	3x 895545.0 285-1185 (WAGO) --- 42 mm fig. 2, Sht. 16 7.8952.00010 S300-41-44 fig. 21, Sht. 19 minimal 26 mm	electrical component parts list booster compressor
supply connection	fig. 12+ 13, Sht. 18	fig. 12+ 13, Sht. 18	fig. 12+ 13, Sht. 18	fig. 12+ 13, Sht. 18	
terminal strip -X11	7.7113.00101 Wieland Handling fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	KAESER KOMPRESSOREN
contactor -Q1/-Q2	7.3140.02140 3RT1054-1AF36 7.3140.02020 Siemens 3RT1956-1CC00	7.3140.02140 3RT1054-1AF36 7.3140.02020 3RT1956-1CC00	7.3140.02140 3RT1054-1AF36 7.3140.02020 3RT1956-1CC00	7.3140.02140 3RT1054-1AF36 7.3140.02020 3RT1956-1CC00	
interference suppressor	7.8740.00440 3RT2045-1AK60 7.8740.05170 Siemens 3RT2946-1CC00	7.8740.00440 3RT2045-1AK60 7.8740.05170 3RT2946-1CC00	7.8740.00440 3RT2045-1AK60 7.8740.05170 3RT2946-1CC00	7.8740.00440 3RT2045-1AK60 7.8740.05170 3RT2946-1CC00	electrical component parts list booster compressor
contactor -Q3	7.8740.00440 3RT2045-1AK60 7.8740.05170 Siemens 3RT2946-1CC00	7.8740.00440 3RT2045-1AK60 7.8740.05170 3RT2946-1CC00	7.8740.00440 3RT2045-1AK60 7.8740.05170 3RT2946-1CC00	7.8740.00440 3RT2045-1AK60 7.8740.05170 3RT2946-1CC00	
interference suppressor	7.8740.00340 3RT2023-1AK60 7.8740.05140 Siemens 3RT2926-1CC00	7.8740.00340 3RT2023-1AK60 7.8740.05140 3RT2926-1CC00	7.8740.00340 3RT2023-1AK60 7.8740.05140 3RT2926-1CC00	7.8740.00340 3RT2023-1AK60 7.8740.05140 3RT2926-1CC00	electrical component parts list booster compressor
contactor -Q4	7.8740.00340 3RT2023-1AK60 7.8740.05140 Siemens 3RT2926-1CC00	7.8740.00340 3RT2023-1AK60 7.8740.05140 3RT2926-1CC00	7.8740.00340 3RT2023-1AK60 7.8740.05140 3RT2926-1CC00	7.8740.00340 3RT2023-1AK60 7.8740.05140 3RT2926-1CC00	
coupling relay -K50	7.3149.01670 Wieland flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	electrical component parts list booster compressor
overload relay -B25	7.8741.00140 Siemens 3RB3046-1XB0 (32-115 A) setting: 47 A	7.6873.00230 3RB2056-1FC2 (50-200 A) setting: 61 A	7.6873.00230 3RB2056-1FC2 (50-200 A) setting: 72 A	7.6873.00230 3RB2056-1FC2 (50-200 A) setting: 89 A	
motor -M1	7.9991.10040	setting: 64 A			electrical component parts list booster compressor
motor -M1	7.9991.00140	setting: 64 A			
motor -M1	7.9991.10040	setting: 68 A			electrical component parts list booster compressor
motor -M1	7.9991.00140	setting: 71 A			
fuses -1FU/-2FU/-3FU	7.3313.1 Ferraz ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	electrical component parts list booster compressor
fuse socket -1FU...-3FU	7.3320.00060 Wöhner AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	
circuit breaker -F4	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.9 A NEC 430.32(C) incremental setting: 6.6 A	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.9 A NEC 430.32(C) incremental setting: 6.6 A	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.9 A NEC 430.32(C) incremental setting: 6.6 A	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.9 A NEC 430.32(C) incremental setting: 6.6 A	electrical component parts list booster compressor
terminal block	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	
auxiliary switch	7.8742.05000 Siemens 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	electrical component parts list booster compressor
transformer -T11	7.7569.0 B0601024 (250 VA) Block diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	
power supply -T21/-T22	7.7605P0 Prodrive PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	electrical component parts list booster compressor
connection -W11	1 AWG black 600 V, 90°C	1 AWG black 600 V, 90°C	1 AWG black 600 V, 90°C	1 AWG black 600 V, 90°C	
connection -W13	4 AWG black 600 V, 90°C	3/0 AWG black 600 V, 90°C	3/0 AWG black 600 V, 90°C	3/0 AWG black 600 V, 90°C	electrical component parts list booster compressor
connection -W14	4 AWG black 600 V, 90°C	4 AWG black 600 V, 90°C	4 AWG black 600 V, 90°C	4 AWG black 600 V, 90°C	
cables -W19.1/2	4 AWG 600 V, 90°C	1 AWG 600 V, 90°C	1 AWG 600 V, 90°C	1 AWG 600 V, 90°C	electrical component parts list booster compressor
controller ventilator -M7	7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	
outlet filter RübSamen&Herr	7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	electrical component parts list booster compressor




model	electrical component parts list				page 4 8 Sht.
	DN 22 C	DN 30 C	DN37C / DN37CXL	DN 45 C	
machine power supply	230 V ±10 %, 60 Hz	230 V ±10 %, 60 Hz	230 V ±10 %, 60 Hz	230 V ±10 %, 60 Hz	= + UKK-U3010.07
motor -M1	30 hp	40 hp	50 hp	60 hp	
motor -M4	2 hp	2 hp	2 hp	2 hp	SC2 MCS
lay-out	page 2	page 2	page 2	page 2	
supply terminals	-X0:U1/V1/W1 3x 894385.0 285-195 (WAGO) --- Torque Stripped length Handling GRD rail IHI Torque Stripped length	3x 895545.0 285-1185 (WAGO) --- 42 mm fig. 2, Sht. 16 7.8952.00010 S300-41-44 fig. 21, Sht. 19 minimal 26 mm	3x 895545.0 285-1185 (WAGO) --- 42 mm fig. 2, Sht. 16 7.8952.00010 S300-41-44 fig. 21, Sht. 19 minimal 26 mm	3x 895545.0 285-1185 (WAGO) --- 42 mm fig. 2, Sht. 16 7.8952.00010 S300-41-44 fig. 21, Sht. 19 minimal 26 mm	electrical component parts list booster compressor
supply connection	fig. 12+ 13, Sht. 18	fig. 12+ 13, Sht. 18	fig. 12+ 13, Sht. 18	fig. 12+ 13, Sht. 18	
terminal strip	-X11 Handling 7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	KAESER KOMPRESSOREN
contactor	-Q1/-Q2 7.3140.02140 3RT1054-1AF36	7.3140.02140 3RT1054-1AF36	7.3140.02140 3RT1054-1AF36	7.3140.02140 3RT1054-1AF36	
interference suppressor	7.3140.02020 Siemens 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	electrical component parts list booster compressor
contactor	-Q3 7.8740.00440 3RT2045-1AK60	7.8740.00440 3RT2045-1AK60	7.8740.00440 3RT2045-1AK60	7.8740.00440 3RT2045-1AK60	
interference suppressor	7.8740.05170 Siemens 3RT2946-1CC00	7.8740.05170 3RT2946-1CC00	7.8740.05170 3RT2946-1CC00	7.8740.05170 3RT2946-1CC00	KAESER KOMPRESSOREN
contactor	-Q4 7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	
interference suppressor	7.8740.05140 Siemens 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	electrical component parts list booster compressor
coupling relay	-K50 Wieland 7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	
overload relay	-B25 Siemens 7.8741.00140 3RB3046-1XB0 (32-115 A) setting: 49 A	7.6873.00230 3RB2056-1FC2 (50-200 A) setting: 56 A	7.6873.00230 3RB2056-1FC2 (50-200 A) setting: 66 A	7.6873.00230 3RB2056-1FC2 (50-200 A) setting: 81 A	KAESER KOMPRESSOREN
motor -M1	7.9991.10040	setting: 65 A			
motor -M1	7.9991.00140	setting: 65 A			electrical component parts list booster compressor
motor -M1	7.9991.10040	setting: 62 A			
motor -M1	7.9991.00140	setting: 73 A			
fuses	-1FU/-2FU/-3FU Ferraz 7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	Date 22.01.21
fuse socket	-1FU...-3FU Wöhner 7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	
circuit breaker	-F4 7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.7 A	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.7 A	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.7 A	7.8742.01180 3RV2021-1HA10 (5.5-8 A) setting: 5.7 A	Date 22.01.21
terminal block	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	
auxiliary switch	7.8742.05000 Siemens 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	Date 22.01.21
transformer	-T11 7.7569.0 B0601024 (250 VA) Block diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	
power supply	-T21/-T22 Prodrive 7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	Date 22.01.21
connection	-W11 1 AWG black 600 V, 90°C	1 AWG black 600 V, 90°C	1 AWG black 600 V, 90°C	1 AWG black 600 V, 90°C	
connection	-W13 4 AWG black 600 V, 90°C	3/0 AWG black 600 V, 90°C	3/0 AWG black 600 V, 90°C	3/0 AWG black 600 V, 90°C	Date 22.01.21
connection	-W14 4 AWG black 600 V, 90°C	4 AWG black 600 V, 90°C	4 AWG black 600 V, 90°C	4 AWG black 600 V, 90°C	
cables	-W19.1/2 4 AWG 600 V, 90°C	2 AWG 600 V, 90°C	2 AWG 600 V, 90°C	1 AWG 600 V, 90°C	Date 22.01.21
controller ventilator	-M7 7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	
outlet filter	Rübsamen&Herr 7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	Date 22.01.21

model	electrical component parts list				page 5 8 Sht
	DN 22 C	DN 30 C	DN37C / DN37CXL	DN 45 C	
machine power supply	380 V ±10 %, 60 Hz	380 V ±10 %, 60 Hz	380 V ±10 %, 60 Hz	380 V ±10 %, 60 Hz	+ UKK-U3010.07
motor -M1	30 hp	40 hp	50 hp	60 hp	
motor -M4	2 hp	2 hp	2 hp	2 hp	SC2 MCS
lay-out	page 1	page 1	page 1	page 1	
supply terminals	-X0:U1/W1/W1 7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	3x 7.3140.05360 3RA2943-3L (Siemens) 89 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	3x 7.3140.05360 3RA2943-3L (Siemens) 89 lb-in Torque Stripped length 25 mm	electrical component parts list booster compressor
GRD rail	7.8952.0 S2/O-34-44 IHI Torque Stripped length minimal 16 mm	7.8952.0 S2/O-34-44 IHI Torque Stripped length minimal 16 mm	7.8952.0 S2/O-34-44 IHI Torque Stripped length minimal 16 mm	7.8952.0 S2/O-34-44 IHI Torque Stripped length minimal 16 mm	
supply connection	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	KAESER KOMPRESSOREN
terminal strip	-X11 7.7113.00101 Wieland Handling fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	
contactor	-Q1/-Q2 7.8740.00410 3RT2036-1AK60	7.8740.00440 3RT2045-1AK60	7.8740.00420 3RT2037-1AK60	7.8740.00440 3RT2045-1AK60	+ UKK-U3010.07
interference suppressor	7.8740.05150 Siemens 3RT2936-1CC00	7.8740.05170 3RT2946-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05170 3RT2946-1CC00	
auxiliary switch	-Q1 7.8740.05010 Siemens 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	electrical component parts list booster compressor
contactor	-Q3 7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	
interference suppressor	7.8740.05150 Siemens 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	KAESER KOMPRESSOREN
contactor	-Q4 7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	
interference suppressor	7.8740.05140 Siemens 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	electrical component parts list booster compressor
coupling relay	-K50 7.3149.01670 Wieland flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	
overload relay	-B25 7.8741.00090 Siemens 3RB3036-1UB0 (12-50 A) setting: 24 A	7.8741.00140 3RB3046-1XB0 (32-115 A)	7.8741.00100 3RB3036-1WB0 (20-80 A) setting: 40 A	7.8741.00140 3RB3046-1XB0 (32-115 A) setting: 49 A	KAESER KOMPRESSOREN
motor -M1	7.9991.10020	setting: 34 A			
motor -M1	7.9991.00120	setting: 51 A			electrical component parts list booster compressor
motor -M1	7.9991.10020	setting: 38 A			
motor -M1	7.9991.00120	setting: 57 A			KAESER KOMPRESSOREN
fuses	-1FU/-2FU 7.3316.1 Ferraz ATQR 1 1/2 (1.5 A, 600 V)	7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	
fuses	-3FU 7.3313.1 Ferraz ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	electrical component parts list booster compressor
fuse socket	-1FU...3FU 7.3320.00060 Wöhner AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	
circuit breaker	-F4 7.8742.01160 3RV2021-1FA10 (3.5-5 A) setting: 3.5 A	7.8742.01160 3RV2021-1FA10 (3.5-5 A) setting: 3.5 A	7.8742.01160 3RV2021-1FA10 (3.5-5 A) setting: 3.5 A	7.8742.01160 3RV2021-1FA10 (3.5-5 A) setting: 3.5 A	electrical component parts list booster compressor
terminal block	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	
auxiliary switch	7.8742.05000 Siemens 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	electrical component parts list booster compressor
transformer	-T11 7.2239.20080 Block diagram 2, Sht. 15	7.2239.20080 USTE250 (250 VA) diagram 2, Sht. 15	7.2239.20080 USTE250 (250 VA) diagram 2, Sht. 15	7.2239.20080 USTE250 (250 VA) diagram 2, Sht. 15	
power supply	-T21/-T22 7.7605P0 Prodrive PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	22.01.21 Siller Büchner
connection	-W13 7.3140.05270 3RA2933-3FA00	7.3140.05370 3RA2943-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05370 3RA2943-3FA00	
connection	-W14 7.3140.05270 3RA2933-3FA00	6 AWG black 600 V, 90°C	7.3140.05270 3RA2933-3FA00	6 AWG black 600 V, 90°C	Date Drawn Released
cables	-W19.1/2 8 AWG 600 V, 90°C	6 AWG 600 V, 90°C	4 AWG 600 V, 90°C	2 AWG 600 V, 90°C	
controller ventilator	-M7 7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	Name Date
outlet filter	Rübsamen&Herr 7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	
					C Change


model	electrical component parts list				page 6 8 Sht.
	DN 22 C	DN 30 C	DN37C / DN37CXL	DN 45 C	
machine power supply	460 V ±10 %, 60 Hz	460 V ±10 %, 60 Hz	460 V ±10 %, 60 Hz	460 V ±10 %, 60 Hz	= +
motor -M1	30 hp	40 hp	50 hp	60 hp	
motor -M4	2 hp	2 hp	2 hp	2 hp	UKK-U3010.07
lay-out	page 1	page 1	page 1	page 1	
supply terminals	-X0:U1/V1/W1 7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	SC2 MCS
	GRD rail IHI S2/O-34-44 Torque Stripped length fig. 20, Sht. 19 minimal 16 mm	7.8952.0 S2/O-34-44 fig. 20, Sht. 19 minimal 16 mm	7.8952.0 S2/O-34-44 fig. 20, Sht. 19 minimal 16 mm	7.8952.0 S2/O-34-44 fig. 20, Sht. 19 minimal 16 mm	
supply connection	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	electrical component parts list booster compressor
terminal strip	-X11 7.7113.00101 Wieland Handling fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	
contactor	-Q1/-Q2 7.8740.00410 3RT2036-1AK60	7.8740.00420 3RT2037-1AK60	7.8740.00410 3RT2036-1AK60	7.8740.00420 3RT2037-1AK60	KAESER KOMPRESSOREN
interference suppressor	Siemens 7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	
auxiliary switch	-Q1 Siemens 7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	electrical component parts list booster compressor
contactor	-Q3 7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	
interference suppressor	Siemens 7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	KAESER KOMPRESSOREN
contactor	-Q4 7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	
interference suppressor	Siemens 7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	electrical component parts list booster compressor
coupling relay	-K50 7.3149.01670 Wieland flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	
overload relay	-B25 Siemens 7.8741.00090 3RB3036-1UB0 (12-50 A) setting: 21 A	7.8741.00100 3RB3036-1WB0 (20-80 A) setting: 28 A	7.8741.00090 3RB3036-1UB0 (12-50 A) setting: 33 A	7.8741.00100 3RB3036-1WB0 (20-80 A) setting: 41 A	KAESER KOMPRESSOREN
motor -M1	7.9991.1	setting: 37 A			
motor -M1	7.9991.00100	setting: 31 A			electrical component parts list booster compressor
motor -M1	7.9991.1	setting: 41 A			
motor -M1	7.9991.00100	setting: 41 A			KAESER KOMPRESSOREN
motor -M1	7.9991.00100	setting: 45 A			
fuses	-1FU/-2FU 7.3313.1 Ferraz ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	Date 22.01.21 Siller Büchner
fuses	-3FU 7.3313.1 Ferraz ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	
fuse socket	-1FU...3FU 7.3320.00060 Wöhner AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	Date Drawn Released
circuit breaker	-F4 7.8742.01150 3RV2021-1EA10 (2.8-4 A) setting: 2.9 A	7.8742.01150 3RV2021-1EA10 (2.8-4 A) setting: 2.9 A	7.8742.01150 3RV2021-1EA10 (2.8-4 A) setting: 2.9 A	7.8742.01150 3RV2021-1EA10 (2.8-4 A) setting: 2.9 A	
terminal block	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	Date Name
auxiliary switch	Siemens 7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	
transformer	-T11 7.7569.0 B0601024 (250 VA) Block diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	7.7569.0 B0601024 (250 VA) diagram 1, Sht. 15	Date Name
power supply	-T21/-T22 7.7605P0 Prodrive PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	
connection	-W13 7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	Date Name
connection	-W14 7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	
cables	-W19.1/2 10 AWG 600 V, 90°C	6 AWG 600 V, 90°C	6 AWG 600 V, 90°C	6 AWG 600 V, 90°C	Date Name
controller ventilator	-M7 7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	
outlet filter	Rübsamen&Herr 7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	Date Name

model	electrical component parts list				page 7 8 Sht
	DN 22 C	DN 30 C	DN37C / DN37CXL	DN 45 C	
machine power supply	575 V ±10 %, 60 Hz	575 V ±10 %, 60 Hz	575 V ±10 %, 60 Hz	575 V ±10 %, 60 Hz	= +
motor -M1	30 hp	40 hp	50 hp	60 hp	
motor -M4	2 hp	2 hp	2 hp	2 hp	UKK-U3010.07
lay-out	page 1	page 1	page 1	page 1	
supply terminals	-X0:U1/V1/W1 7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	7.3140.05070 3RV2935-5E (Siemens) 53 lb-in Torque Stripped length 25 mm	SC2 MCS
	GRD rail IHI S2/O-34-44 Torque Stripped length fig. 20, Sht. 19 minimal 16 mm	7.8952.0 S2/O-34-44 fig. 20, Sht. 19 minimal 16 mm	7.8952.0 S2/O-34-44 fig. 20, Sht. 19 minimal 16 mm	7.8952.0 S2/O-34-44 fig. 20, Sht. 19 minimal 16 mm	
supply connection	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	fig. 10+ 11, Sht. 17	electrical component parts list booster compressor
terminal strip	-X11 Handling 7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	7.7113.00101 Wieland fig. 1, Sht. 16	
contactor	-Q1/-Q2 7.8740.00410 3RT2036-1AK60	7.8740.00410 3RT2036-1AK60	7.8740.00410 3RT2036-1AK60	7.8740.00410 3RT2036-1AK60	KAESER KOMPRESSOREN
interference suppressor	Siemens 7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	
auxiliary switch	-Q1 Siemens 7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	7.8740.05010 3RH2911-1HA11	electrical component parts list booster compressor
contactor	-Q3 7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	7.8740.00400 3RT2035-1AK60	
interference suppressor	Siemens 7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	7.8740.05150 3RT2936-1CC00	KAESER KOMPRESSOREN
contactor	-Q4 7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	7.8740.00340 3RT2023-1AK60	
interference suppressor	Siemens 7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	7.8740.05140 3RT2926-1CC00	electrical component parts list booster compressor
coupling relay	-K50 Wieland 7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	7.3149.01670 flare 110 V-1W-250 V6 A-F	
overload relay	-B25 Siemens 7.8741.00090 3RB3036-1UB0 (12-50 A) setting: 16 A	7.8741.00090 3RB3036-1UB0 (12-50 A) setting: 16 A	7.8741.00090 3RB3036-1UB0 (12-50 A) setting: 26 A	7.8741.00090 3RB3036-1UB0 (12-50 A) setting: 32 A	KAESER KOMPRESSOREN
motor -M1	7.9991.10030	setting: 22 A			
motor -M1	7.9991.00130	setting: 29 A			
motor -M1	7.9991.10030	NEC 430.32(C) incremental setting: 18 A	NEC 430.32(C) incremental setting: 30 A	NEC 430.32(C) incremental setting: 36 A	electrical component parts list booster compressor
motor -M1	7.9991.00130	setting: 25 A			
fuses	-1FU/-2FU Ferraz 7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	7.3316.1 ATQR 1 1/2 (1.5 A, 600 V)	Date 22.01.21 Siller Büchner
fuses	-3FU Ferraz 7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	7.3313.1 ATQR 2 1/2 (2.5 A, 600 V)	
fuse socket	-1FU...3FU Wöhner 7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	7.3320.00060 AMBUS EASYSWITCH	Date Drawn Released
circuit breaker	-F4 7.8742.01140 3RV2021-1DA10 (2.2-3.2 A) setting: 2.3 A	7.8742.01140 3RV2021-1DA10 (2.2-3.2 A) setting: 2.3 A	7.8742.01140 3RV2021-1DA10 (2.2-3.2 A) setting: 2.3 A	7.8742.01140 3RV2021-1DA10 (2.2-3.2 A) setting: 2.3 A	
terminal block	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	7.3140.05090 3RV2928-1H	Date Name
auxiliary switch	Siemens 7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	7.8742.05000 3RV2901-1E	
transformer	-T11 7.2239.20080 USTE250 (250 VA) Block diagram 2, Sht. 15	7.2239.20080 USTE250 (250 VA) diagram 2, Sht. 15	7.2239.20080 USTE250 (250 VA) diagram 2, Sht. 15	7.2239.20080 USTE250 (250 VA) diagram 2, Sht. 15	Date Name
power supply	-T21/-T22 7.7605P0 PSDC24/2.5 Prodrive	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	7.7605P0 PSDC24/2.5	
connection	-W13 7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	Date Name
connection	-W14 7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	7.3140.05270 3RA2933-3FA00	
cables	-W19.1/2 10 AWG 600 V, 90°C	6 AWG 600 V, 90°C	6 AWG 600 V, 90°C	6 AWG 600 V, 90°C	Date Name
controller ventilator	-M7 7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	7.3146.00660 / LV300	
outlet filter	Rübsam&Herr 7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	7.2752.00010 / GV300	Date Name







Function: Group of function:		input voltage		compressor motor power unit	
c	Date	22.01.21			
b	Drawn	Siller			
a	Released	Büchner			
D	Change	Date	Name		
			SC2 MCS	SKK-U3010-07	page 1 19 Str.




Function: controller ventilator		compressor motor	
Group of function:		weye-delta changeover	
c	Date	22.01.21	
b	Drawn	Siller	
a	Released	Büchner	
D	Change		
	Date		
	Name		
		SC2 MCS	SKK-U3010-07
			page 2
			19 Str.










\*\*\*\* performance-related components, see: electrical component parts list.

Function:		temperature switch Compressed air aftercooler		door safety interlock switch/EMERGENCY STOP	
Group of function:		Compressed air aftercooler		safety chain	
c	Date	22.01.21			
b	Drawn	Siller			
a	Released	Büchner			
d	Date				
		writing diagram		=	
		booster compressor		+	
		safety chain		SKK-U3010.07	
		SC2 MCS		page 5	
				19 Str.	



Function:		24V DC	
Group of function:		control voltage	
c	Date	22.01.21	
b	Drawn	Siller	
a	Released	Büchner	
d	Change	Date	Name


wiring diagram  
booster compressor  
power supply unit




SC2 MCS

SKK-U3010.07

page 6  
19 Str.





Function:		Group of function:	
c	Date	22.01.21	
b	Drawn	Siller	
a	Released	Büchner	
D	Change	Date	Name


wiring diagram  
booster compressor  
sensors/actuators




SKK-U3010-07


SC2 MCS

page 8  
19 SHL







Function:		condensate drain Compressed air outlet		condensate drain Prefilter	
Group of function:					
c	Date	22.01.21			
b	Drawn	Siller			
a	Released	Büchner			
D	Change	Date	Name	SC2 MCS	SKK-U3010-07
				page 10	19 Str.











Function:		wiring diagram	
Group of function:		booster compressor	
		digital inputs - option C40	
		SC2 MCS	SKK-U3010.07
		page 13	
		19 Str.	





wiring diagram  
booster compressor  
transformer diagrams



1	2	3	4	5	6	7	8
<p><b>fig. 1: Handling: Control line terminal</b></p>							
<p><b>fig. 2: Handling: Supply terminal Wago</b></p>							
<p><b>KAESER</b> KOMPRESSOREN</p>							
<p>wiring diagram booster compressor Handling: Terminals</p>							
<p>SC2 MCS      SKK-U3010-07</p>							
<p>= +      page 16 19 Str.</p>							
c	Date	22.01.21	Drawn	Siller	Released	Büchner	
b							
a							
D	Change	Date	Name				

8  
7  
6  
5  
4  
3  
2  
1

fig. 11: Feed line connection





fig. 10: Feed line connection



c	Date	22.01.21	wiring diagram		=	
b	Drawn	Siller	booster compressor		+	
a	Released	Büchner	Feed line connection		SKK-U3010-07	
D	Change	Date	Name	SC2 MCS	page	17
					19	Str.




fig. 12: Feed line connection

fig. 13: Feed line connection

c	Date	22.01.21	wiring diagram	=			
b	Drawn	Siller	booster compressor	+			
a	Released	Büchner	Feed line connection				page 18
D	Change						19 Str.
			KAESER KOMPRESSOREN	SC2 MCS	SKK-U3010-07		

1 2 3 4 5 6 7 8

fig. 20: Feed line connection

GRD

terminal model	Wire Size Copper (solid to semirigid stranded) AWG / MCM	Wire Size Copper flexible * AWG / MCM	Torque lb - in
S2/0	---	1/0 - 1	75
S2/0	---	1 - 4	55
S2/0	2/0 - 3	4 - 8	50
S2/0	4 - 6	8 - 10	45
S2/0	8	10 - 14	40
S2/0	10 - 14	---	35

\* Stranding classes G, H, J/DLO, Metric class 5 and K/M/TW

fig. 21: Feed line connection

GRD

terminal model	Wire Size Copper (solid to semirigid stranded) AWG / MCM	Wire Size Copper flexible * AWG / MCM	Torque lb - in
S300	300 - 2	4/0 - 2	375
S300	2 - 6	2 - 6	275

\* Stranding classes G, H, J/DLO, Metric class 5 and K/M/TW

fig. 22: Feed line connection

GRD

terminal model	Wire Size Copper (solid to semirigid stranded) AWG / MCM	Wire Size Copper flexible * AWG / MCM	Torque lb - in
S500	500 - 4	350 - 4	500

\* Stranding classes G, H, J/DLO, Metric class 5 and K/M/TW


c	Date	22.01.21	wiring diagram		=	+	SKK-U3010-07	page 19
b	Drawn	Siller	booster compressor					
a	Released	Büchner	Feed line connection		SC2 MCS			19 Str.
D	Change	Date	Name					






* supply line cross-section see operating manual s.b.c. = supplied by customer		voltage-free contacts, User's connection 1) compressor motor running		option C40 2) option C40 3) Class 2 control circuit		option K6 5) option K6 6) option F14 7) option K6 + F14 GNYE = green/yellow	
cable-no.	external destination	terminal strip: -X0 total 3 terminals		terminal strip: -X11 total 24 terminals		terminal strip: -X12 total 14 terminals	
	terminal strip	connection	name of device	location	jumper wire	terminal legend	link
destination inside	connection	name of device	terminal-no.	terminal-no.	terminal-no.	terminal-no.	terminal-no.
cable-no.	external destination	terminal strip: -X0 total 3 terminals		terminal strip: -X11 total 24 terminals		terminal strip: -X12 total 14 terminals	
	terminal strip	connection	name of device	location	jumper wire	terminal legend	link
destination inside	connection	name of device	terminal-no.	terminal-no.	terminal-no.	terminal-no.	terminal-no.
cable-no.	external destination	terminal strip: -X0 total 3 terminals		terminal strip: -X11 total 24 terminals		terminal strip: -X12 total 14 terminals	
	terminal strip	connection	name of device	location	jumper wire	terminal legend	link
destination inside	connection	name of device	terminal-no.	terminal-no.	terminal-no.	terminal-no.	terminal-no.
cable-no.	external destination	terminal strip: -X0 total 3 terminals		terminal strip: -X11 total 24 terminals		terminal strip: -X12 total 14 terminals	
	terminal strip	connection	name of device	location	jumper wire	terminal legend	link
destination inside	connection	name of device	terminal-no.	terminal-no.	terminal-no.	terminal-no.	terminal-no.

c	Date	22.01.21	terminal connection		SC2 MCS	KKK-U3010.07	page 1
b	Drawn	Siller	booster compressor				1
a	Released	Büchner	terminal strip -X0, -X11, -X12				1
H	Change	Date	Name				1



c	Date	22.01.21	=	AKK-U3010.07	page 1	
	Drawn	Siller				SC2 MCS
	Released	Büchner				
I. Change		Date	Name			



c	Date	22.01.21	+		=	
b	Drawn	Siller				
a	Released	Büchner				
l	Change					
		Name				
		Date				
			SC2 MCS		AKK-U3010.07	
						page 2
						2 SHL


## 13.4 Determining the permissible initial pressure



Use the following diagrams to determine the permissible initial pressure.


The following data can be found in the diagrams:

- Model
- Airend
- Main system frequency
- Unit of pressure
- Block RPM
- $i_{min}$  = Minimally permissible compression ratio of the machine
- $i_{max}$  = Maximally permissible compression ratio of the machine
- $T_o$  = Intake temperature
- $T_u$  = Ambient temperature
- $p_1$  = Initial pressure
- $p_4$  = Discharge pressure




Version 1

TB/Hollauer




Version 1

TB/Hollauer



Version 1


TB/Hollauer



Version 1


TB/Hollauer






Version 1

TB/Hollauer



Version 1

TB/Hollauer



**13.5 Safety relief valve data sheet**

**13.5.1 Data Sheet 1 of 4**

# Safety valves

Type SVW/SVWN/SVWC	DN 8	PN 50	-25 to 180 °C	type tested CE 0036
-----------------------	------	-------	---------------	------------------------

**Use area:**

- ⇒ for compressed air and other gases of the fluid group 2;
- ⇒ blow-off freely, therefore not suitable for fluids and steam.


**Models**

- SVW ⇒ 2.0401 (brass)
- SVWC ⇒ 1.4104 (stainless steel)
- SVWN ⇒ 1.4571 (stainless steel)

**Characteristics:**


open types +++ elastic valve seat seal (Viton) +++ compression spring stainless steel +++ ventilate with knurled thumb screw +++ connection with spigot +++ product-mark TÜV and GL +++ TÜV- and GL-individual inspection +++ certificates according to EN 10204 possible.

connectio n-tap (d <sub>1</sub> )	area of differential test pressure [bar]	d <sub>2</sub> [mm]	l <sub>1</sub> [mm]	l <sub>2</sub> [mm]	SW	
					SVW	SVWN SVWC
M16x1,5	0,2 – 14,20	20	12	63	20	22
	14,21 – 39,90			75		
	39,91 – 50,00			82		
G1/4 A	0,2 – 14,20	18	10	63	20	22
	14,21 – 39,90			75		
	39,91 – 50,00			82		
G3/8 A	0,2 – 14,20	20	12	63	24	24
	14,21 – 39,90			75		
	39,91 – 50,00			82		
G1/2 A	0,2 – 14,20	24	14	63	24	24
	14,21 – 39,90			75		
	39,91 – 50,00			82		



**Order description:**

(Please pay attention to the indication on the back sheet)



Changes in the sense of the technical progress reserve.



**Armaturen- und Metallwerke Zöblitz GmbH**  
 Bahnhofstraße 16, 09496 Marienberg Tel. 037363 480-0 / Fax 037363 480-90  
 Internet: [www.armaturen-zoebnitz.de](http://www.armaturen-zoebnitz.de) e-mail: [info@armaturen-zoebnitz.de](mailto:info@armaturen-zoebnitz.de)  
 TDB-8.0308.0-D\_03E

page  
1/2

## Safety valves

<b>Type</b> SVW/SVWN/SVWC	<b>DN 8</b>	<b>PN 50</b>	<b>-25 to 180 °C</b>	<b>type tested</b> <b>CE 0036</b>
------------------------------	-------------	--------------	----------------------	--------------------------------------

### blow-off value

<b>p<sub>e</sub></b> <b>[bar]</b>	<b>qm [m<sup>3</sup>/h]</b> <b>at 0°C/760 Torr</b>
0,2	13,6
0,8	19,3
0,9	37,6
1,4	48,1
1,9	58,6
2	69,2
2,5	81,2
3	93,2
3,5	105,1
4	117,1
5	141,0
6	165,0
7	188,9
8	212,8
9	236,4
10	260,7
11	284,6
12	308,6
13	332,5

<b>p<sub>e</sub></b> <b>[bar]</b>	<b>qm [m<sup>3</sup>/h]</b> <b>at 0°C/760 Torr</b>
14	356,4
15	380,4
16	404,3
17	428,2
18	452,2
19	476,1
20	500,0
21	524,0
22	547,9
23	571,8
24	595,8
25	619,7
26	643,6
27	667,6
28	691,5
29	715,4
30	739,4
31	763,3
32	787,2

<b>p<sub>e</sub></b> <b>[bar]</b>	<b>qm [m<sup>3</sup>/h]</b> <b>at 0°C/760 Torr</b>
33	811,2
34	835,1
35	859,0
36	883,0
37	906,9
38	930,8
39	954,8
40	978,7
41	1.002,6
42	1.026,6
43	1.050,5
44	1.074,4
45	1.098,4
46	1.122,3
47	1.146,3
48	1.170,2
49	1.194,1
50	1.218,1

The showed blow-off values will be reached at an increase of pressure of 10% above the differential test pressure.

#### Indication:

Safety valves of model SVWC are only suitable for temperatures between -10 and 180°C .

Valves are adjusted and supplied leaded. Special variants (other spigot, nickel plated or similar) on request.

Delivery with knurled thumb screw is possible.

We ask for indication of the medium and the operating temperature in order

Please find safety references and the guidance of maintenance on the back sheet of our inspection certificate or on inquiry.

Changes in the sense of the technical progress reserve.



**Armaturen- und Metallwerke Zöblitz GmbH**  
 Bahnhofstraße 16, 09496 Marienberg Tel. 037363 480-0 / Fax 037363 480-90  
 Internet: [www.armaturen-zoebnitz.de](http://www.armaturen-zoebnitz.de) e-mail: [info@armaturen-zoebnitz.de](mailto:info@armaturen-zoebnitz.de)


page  
2/2

TDB-8.0308.0-D\_03E

13.5.2 Data Sheet 2 of 4

# Safety valves

Type SVW/SVWN/SVWC	DN 10	PN 50	-25 till 180 °C	type tested CE 0036
-----------------------	-------	-------	-----------------	------------------------



**Use area:**

- ⇒ for compressed air other gases of the fluid group 2;
- ⇒ blow-off freely,
- ⇒ therefore not suitable for fluids and steam

**Models**


- SVW ⇒ 2.0401 / C38500 (brass)
- SVWC ⇒ 1.4401 / A316 (stainless steel)
- SVWN ⇒ 1.4571 / A316Ti (stainless steel)

**Characteristics:**

open type +++ elastic valve seat seal (Viton) +++  
 compression spring of stainless steel +++  
 ventilate with knurled thumb screw +++  
 connection with spigot +++ product-mark TÜV and GL +++  
 TÜV- and GL - individual inspection +++  
 certificates according to EN 10204 possible

connection tap (d <sub>1</sub> )	area of differential test pressure [bar]	d <sub>2</sub> [mm]	l <sub>1</sub> [mm]	l <sub>2</sub> [mm]	SW
G3/8 A	0,20 - 8,50	22	12	75	27
	08,51 - 40,00			95	
	40,01 - 50,00			120	
G1/2 A	0,20 - 8,50	26	14	75	
	08,51 - 40,00			95	
	40,01 - 50,00			120	
G3/4 A	0,20 - 8,50	32	16	75	32
	08,51 - 40,00			95	
	40,01 - 50,00			120	

**Order description:**



(Please pay attention to the indication on the back-sheet.)

Changes in the sense of the technical progress reserve.



**Armaturen- und Metallwerke Zöblitz GmbH**  
 Bahnhofstraße 16, 09496 Marienberg Tel. 037363 480-0 / Fax 037363 480-90  
 Internet: [www.armaturen-zoebnitz.de](http://www.armaturen-zoebnitz.de) e-mail: [info@armaturen-zoebnitz.de](mailto:info@armaturen-zoebnitz.de)

page  
1/2

TDB-8.0313.0-D\_03E



## Safety valves

<b>Type</b> SVW/SVWN/SVWC	<b>DN 10</b>	<b>PN 50</b>	<b>-25 till 180 °C</b>	<b>type tested</b> <b>CE 0036</b>
------------------------------	--------------	--------------	------------------------	--------------------------------------

### Blow-off value

p <sub>e</sub> [bar]	qm [m <sup>3</sup> /h] at 0°C/760 Torr		p <sub>e</sub> [bar]	qm [m <sup>3</sup> /h] at 0°C/760 Torr		p <sub>e</sub> [bar]	qm [m <sup>3</sup> /h] at 0°C/760 Torr
0,2	24,0		15	649,2		34	1.425,3
0,8	59,4		16	690,0		35	1.466,2
1,3	76,9		17	730,8		36	1.507,0
1,8	94,5		18	771,7		37	1.547,8
2,3	112,1		19	812,6		38	1.588,7
2,8	129,5		20	853,4		39	1.629,5
3,3	147,1		21	894,3		40	1.670,4
3,8	164,1		22	935,1		41	1.711,3
4	199,8		23	975,9		42	1.752,1
5	240,7		24	1.016,8		43	1.792,9
6	281,5		25	1.057,7		44	1.833,8
7	322,4		26	1.098,5		45	1.874,6
8	363,3		27	1.139,4		46	1.919,5
9	404,0		28	1.180,2		47	1.956,4
10	444,9		29	1.221,1		48	1.997,2
11	485,8		30	1.261,9		49	2.038,1
12	526,6		31	1.302,7		50	2.078,9
13	567,5		32	1.343,6			
14	608,3		33	1.384,5			

The showed blow-off values will be reached at an increase of pressure of 10% above the differential test pressure.

#### **Indication:**

Valves are adjusted and supplied leaded. Special variants (other spigot, nickel-plated or similar) on request. Delivery with jet deflection ring is possible.

We ask for indication of the medium and the operating temperature in order.

Please find safety references and the guidance of maintenance on the back sheet of our inspection certificate or on inquiry.

Changes in the sense of the technical progress reserve.



#### Armaturen- und Metallwerke Zöblitz GmbH

Bahnhofstraße 16, 09496 Marienberg Tel. 037363 480-0 / Fax 037363 480-90  
 Internet: [www.armaturen-zoebnitz.de](http://www.armaturen-zoebnitz.de) e-mail: [info@armaturen-zoebnitz.de](mailto:info@armaturen-zoebnitz.de)

page  
2/2

TDB-8.0313.0-D\_03E

13.5.3 Data Sheet 3 of 4

TÜV/CE atmospheric discharge safety valves  
for industrial applications

→ **Series 810**

4.2

**810**

Safety valves made of brass,  
atmospheric discharge,  
with threaded connections



■ MATERIAL



■ SPECIFICATION



1/4" – 1"



– 60°C to + 270°C  
depending on version



0,2 – 50 bar

■ SUITABLE FOR

Air, gases and vapours      neutral



■ EXAMPLES OF USE

For the protection of:

- pressure tanks and
- pressure systems

for air and other neutral, non-poisonous and non-flammable gases which can be freely discharged into the environment.

Please observe plant-specific regulations and use of appropriate valve version and sealing material.

- compressors
- pressure booster plants air-side
- paint spray shops
- pneumatic control units
- transport- and railway applications

**Safety valves are set and sealed at the factory.**

■ APPROVALS

TÜV Type test approval 2055	D/G
ASME	G
EC type examination	S/G
TSG ZF001-2006	D/G (S/G)
KGS	G
TR ZU 032/2013 - TR ZU 010/2011	D/G (S/G)

Type approval Deutsche Bahn

Requirements

AD 2000 Data sheet A2	ASME-Code Sec. VIII Div. 1
DIN EN ISO 4126-1	KGS AA 319
PED 2014/68/EU	

Classification society

Germanischer Lloyd	GL
Lloyd's Register EMEA	LR EMEA
Bureau Veritas	BV
American Bureau of Shipping	ABS
Det Norske Veritas	DNV
Russian Maritime Register of Shipping	RS

■ MATERIALS

Component	Material	DIN EN	ASME
Inlet body	Brass	CW617N	CW617N
Outlet body	Brass	CW617N	CW617N
Internal parts	Brass	CW617N	CW617N
Spring	Stainless steel	1.4568	631



TDB-8.3789.0-DAT\_01E

Version 2017 / 08 (K)

www.goetze-armaturen.de | info@goetze-armaturen.de | Phone: +49(0)7141.48894-60

**Series 810 ■ VALVE VERSION**

<b>s</b>	Standard	cylindrical form, atmospheric discharge, for air and similar neutral, non-toxic and non-flammable gases that can be freely discharged into the atmosphere.
----------	----------	--

**■ MEDIUM**

<b>G</b>	gaseous	Air and similar neutral gases
----------	---------	-------------------------------

**■ TYPE OF LIFTING MECHANISM**

<b>K</b>	Standard with twist-type lifting mechanism	
----------	--	--

**■ AVAILABLE NOMINAL DIAMETERS AND CONNECTION SIZES**

Nominal diameter DN	8	10	15	20	25
Inlet	1/4" (8)	3/8" (10)	1/2" (15)	3/4" (20)	1" (25)
Atmospheric discharge via outlet apertures	■	■	■	■	■

**■ TYPE OF CONNECTION INLET / OUTLET THREADED CONNECTIONS**

<b>m / -</b>	Standard	Male thread BSP-P / -	DIN EN ISO 228-1 / -
<b>Against surcharge</b>			
<b>BSP-Tm / -</b>	On request	Male thread BSP-T / -	DIN EN 10226, ISO 7-1 / -
<b>NPT-m / -</b>	On request	Male thread NPT-m / -	ANSI B1.20.1 / -

**■ SEALS**

<b>FKM</b>	Fluorocarbon	Elastomere flat seal 0,2 – 25 bar	-20°C to +200°C
<b>FKM VI</b>	Fluorocarbon	Elastomere flat seal	-46°C up to +230°C in case of blowing of up to +270°C
<b>PTFE</b>	Polytetrafluoroethylene	Flat seal 25,1 – 50 bar	-60°C to +225°C
<b>Against surcharge</b>			
<b>PTFE</b>	Polytetrafluoroethylene	Flat seal 0,2 – 25 bar	-60°C to +225°C


**■ OPTIONS**

Special versions on request.	
------------------------------	--

■ NOMINAL DIAMETERS, CONNECTIONS, INSTALLATION DIMENSIONS

Series 810: Connection, installation dimensions, ranges of adjustment									
Nominal diameter	DN	8	10	15	20	25			
Connection DIN EN ISO 228	G	1/4" (8)	3/8" (10)	1/2" (15)	3/4" (20)	1" (25)			
Installation dimensions in mm	H	60	65	78	66	79	94	104	111
	h	10	10	10	12	12	12	12	14
	SW	19	24	24	27	27	34	34	41
	do	7,5	10	10	11	11	16	16	20
Weight	kg	0,1	0,14	0,16	0,17	0,19	0,35	0,4	0,6
Range of adjustment	bar	0,2-50	0,2-9	9,1-50	0,2-7	7,1-50	0,2-9	9,1-50	0,2-50
Range of adjustment ASME	psi	15-725	15-130	131-725	15-102	103-725	15-130	131-725	15-725

■ MAIN DIMENSIONS, INSTALLATION DIMENSIONS



■ INDIVIDUAL SELECTION / VALVE CONFIGURATION

Series	Valve version	Medium	Lifting device	Nominal diameter DN	Connection type		Connection size		Seal	Options	Set pressure	Quantity
					Inlet	Outlet	Inlet	Outlet				
810	s	G	K	10	m	-	10	-	FKM		11,5	50
810	s	G	K			-		-				
810	s	G	K			-		-				
810	s	G	K			-		-				

In this table you can configure a valve according to your individual requirements (similar to the *example* shown, which should be deleted before you enter your own data). Please complete the table by hand using the abbreviations in this datasheet and then fax it to: +49(0)7141.4889488  
Please do not forget to add your personal data so that our sales team can contact you.

Name \_\_\_\_\_

First Name \_\_\_\_\_

Company \_\_\_\_\_

Telephone \_\_\_\_\_

E-Mail \_\_\_\_\_



TDB-8.3789.0-DAT\_01E

Version 2017 / 08 (K)

www.goetze-armaturen.de | info@goetze-armaturen.de | Phone: +49(0)7141.48894-60

**■ CAPACITY TABLE**

Series 810: Blowing-off rates at 10% above set pressure						
Nominal diameter DN		8	10	15	20	25
Set pressure bar						
Air Nm <sup>3</sup> /h	0,2	20	35	46	100	133
	0,3	25	45	54	119	144
	0,4	29	52	67	137	167
	0,5	32	58	74	158	185
	0,6	35	64	82	172	211
	0,7	37	70	87	187	235
	0,8	41	74	95	200	260
	0,9	43	80	101	213	282
	1	46	85	107	227	305
	1,5	60	108	137	286	408
	2	73	132	166	346	506
	3	100	182	222	465	699
	4	125	228	279	584	889
	5	151	274	336	703	1070
	6	176	321	393	821	1251
	7	201	367	450	940	1432
	8	227	414	507	1059	1613
	9	252	460	564	1178	1794
	10	278	507	621	1297	1975
	11	303	553	678	1416	2156
	12	329	599	735	1535	2337
	13	354	646	791	1654	2518
	14	380	692	848	1773	2700
	15	405	739	905	1891	2881
	16	431	785	962	2010	3062
	17	456	832	1019	2129	3243
	18	482	878	1076	2248	3424
	19	507	925	1133	2367	3605
	20	533	971	1190	2486	3786
	21	558	1017	1247	2605	3967
22	584	1064	1304	2724	4148	
23	609	1110	1361	2843	4329	
24	635	1157	1417	2961	4510	
25	660	1203	1474	3080	4691	
26	685	1250	1531	3199	4872	
27	711	1296	1588	3318	5053	
28	736	1342	1645	3437	5234	
29	762	1389	1702	3556	5415	
30	787	1435	1759	3675	5597	
31	813	1482	1816	3794	5778	
32	838	1528	1873	3913	5959	
33	864	1575	1930	4031	6140	
34	889	1621	1986	4150	6321	
35	915	1667	2043	4269	6502	
36	940	1714	2100	4388	6683	
37	966	1760	2157	4507	6864	
38	991	1807	2214	4626	7045	
39	1017	1853	2271	4745	7226	
40	1042	1900	2328	4864	7407	
41	1068	1946	2385	4983	7588	
42	1093	1993	2442	5101	7769	
43	1119	2039	2499	5220	7950	
44	1144	2085	2556	5339	8131	
45	1170	2132	2612	5458	8313	
46	1195	2178	2669	5577	8494	
47	1220	2225	2726	5696	8675	
48	1246	2271	2783	5815	8856	
49	1271	2318	2840	5934	9037	
50	1297	2364	2897	6053	9218	



Version 2017 / 08 (K)

TDB-8.3789.0-DAT\_01E

[www.goetze-armaturen.de](http://www.goetze-armaturen.de) | [info@goetze-armaturen.de](mailto:info@goetze-armaturen.de) | Phone: +49(0)7141.48894-60

■ CAPACITY TABLE ASME

Series 810: Blowing-off rates at 10% above set pressure						
Nominal diameter DN		8	10	15	20	25
Set pressure bar psi(g)						
Air	15	31	55	67	142	221
	30	45	81	98	207	323
SCFM	40	56	99	120	254	397
	50	66	118	143	302	472
	60	77	137	165	350	546
	70	87	155	188	397	621
	87	105	187	226	478	747
	90	108	192	233	493	770
	100	119	211	255	540	844
	110	129	230	278	588	919
	120	140	248	300	636	993
	130	150	267	323	683	1068
	140	161	286	345	731	1142
	150	171	304	368	779	1217
	160	182	323	391	826	1291
	170	192	341	413	874	1366
	180	203	360	436	922	1440
	190	213	379	458	969	1515
	200	223	397	481	1017	1589
	210	234	416	503	1065	1663
	220	244	434	526	1112	1738
	230	255	453	548	1160	1812
	240	265	472	571	1208	1887
	250	276	490	593	1255	1961
	260	286	509	616	1303	2036
	270	297	528	638	1351	2110
	280	307	546	661	1398	2185
	290	318	565	683	1446	2259
	300	328	583	706	1494	2334
	320	349	621	751	1589	2483
	340	370	658	796	1684	2632
	360	391	695	841	1780	2781
	380	412	732	886	1875	2929
	400	433	770	931	1970	3078
	420	454	807	976	2066	3227
	440	475	844	1021	2161	3376
	460	496	881	1066	2256	3525
	480	517	919	1111	2351	3674
	500	538	956	1157	2447	3823
	520	559	993	1202	2542	3972
	540	580	1030	1247	2637	4121
	560	600	1067	1292	2733	4270
	580	621	1105	1337	2828	4419
	600	642	1142	1382	2923	4568
	620	663	1179	1427	3019	4717
	640	684	1216	1472	3114	4866
	660	705	1254	1517	3209	5015
	680	726	1291	1562	3305	5164
	700	747	1328	1607	3400	5313
	725	773	1375	1663	3519	5499



TDB-8.3789.0-DAT\_01E

Version 2017 / 08 (K)

www.goetze-armaturen.de | info@goetze-armaturen.de | Phone: +49(0)7141.48894-60

13.5.4 Data Sheet 4 of 4



TÜV/CE atmospheric discharge safety valves  
for industrial applications

→ **Series 812**

4.4

**812**

Safety valves made of brass,  
atmospheric discharge,  
with threaded connections



■ MATERIAL



■ SPECIFICATION



1/2" – 2"



– 60°C to + 270°C  
depending on version



0,2 – 50 bar  
depending on version

■ SUITABLE FOR

Air, gases and vapours neutral



■ EXAMPLES OF USE

For the protection of:

- pressure tanks and
- pressure systems

for air and other neutral, non-poisonous and non-flammable gases which can be freely discharged into the environment.

Please observe plant-specific regulations and use of appropriate valve version and sealing material.

- pneumatic control units
- pressure booster plants air-side
- paint spray shops
- transport- and railway applications
- pneumatic braking systems

**Safety valves are set and sealed at the factory.**

■ APPROVALS

TÜV Type test approval 2003	D/G
ASME	G
EC type examination	S/G
TSG ZF001-2006	D/G (S/G)
KGS	G
TR ZU 032/2013 - TR ZU 010/2011	D/G (S/G)
<b>Type approval Deutsche Bahn</b>	
<b>Requirements</b>	
AD 2000 Data sheet A2	ASME-Code Sec. VIII Div. 1
DIN EN ISO 4126-1	KGS AA 319
PED 2014/68/EU	

■ Classification society

Germanischer Lloyd	GL
Lloyd's Register EMEA	LR EMEA
American Bureau of Shipping	ABS
Det Norske Veritas	DNV
Bureau Veritas	BV
Russian Maritime Register of Shipping	RS

■ MATERIALS

Component	Material	DIN EN	ASME
Inlet body	Brass	CW617N	CW617N
Outlet body	Brass	CW617N	CW617N
Internal parts	Brass / Stainless steel	CW617N / 1.4404	CW617N / 316 L
Spring	Stainless steel	1.4310 / 1.4568	302 / 631
Sealing cap	Stainless steel	1.4301	304



TDB-8.5061.0-DAT\_01E

Version 2017 / 08 (K)

www.goetze-armaturen.de | info@goetze-armaturen.de | Phone: +49(0)7141.48894-60

**Series 812 ■ VALVE VERSION**

<b>s</b>	Standard	cylindrical form, atmospheric discharge, for air and similar neutral, non-toxic and non-flammable gases that can be freely discharged into the atmosphere.
----------	----------	--

**■ MEDIUM**

<b>G</b>	gaseous	Air and similar neutral gases
----------	---------	-------------------------------

**■ TYPE OF LIFTING MECHANISM**

<b>K</b>	Standard with twist-type lifting mechanism	
----------	--	--

**■ AVAILABLE NOMINAL DIAMETERS AND CONNECTION SIZES**

Nominal diameter DN	15	20	25	32	40	50
Inlet	1/2" (15)	3/4" (20)	1" (25)	1 1/4" (32)	1 1/2" (40)	2" (50)
Atmospheric discharge via outlet apertures	■	■	■	■	■	■

**■ TYPE OF CONNECTION INLET / OUTLET THREADED CONNECTIONS**

<b>m / -</b>	Standard	Male thread BSP-P / -	DIN EN ISO 228-1 / -
<b>Against surcharge</b>			
<b>BSP-Tm / -</b>		Male thread BSP-T	DIN EN 10226, ISO 7-1 / -
<b>NPT-m / -</b>		Male thread NPT / -	ANSI B1.20.1 / -
<b>Further connection types available on request</b>			

**■ SEALS**

<b>NBR</b>	Nitrile rubber	Elastomere flat seal	-30°C to +130°C
<b>Against surcharge</b>			
<b>FKM</b>	Fluorocarbon	Elastomere flat seal	-20°C to +200°C
<b>FKM VI</b>	Fluorocarbon	Elastomere flat seal	-46°C up to +270°C after the seal has been subjected to temperatures of more than +230°C slight leakages are possible
<b>PTFE</b>	Polytetrafluoroethylene	Flat seal from 1 bar	-60°C to +225°C
<b>EPDM</b>	Ethylene propylene diene	Elastomere flat seal	-40°C to +170°C

**■ OPTIONS**


<b>SHORT</b>	short version for DN 32 and DN 40	
<b>Against surcharge</b>		
Deflector made of stainless steel	Order code: <b>812 ABS-DN..</b>	
Special versions on request.		

■ **NOMINAL DIAMETERS, CONNECTIONS, INSTALLATION DIMENSIONS**

Series 812: Connection, installation dimensions, ranges of adjustment							
Nominal diameter	DN	15	20	25	32	40	50
Connection DIN EN ISO 228	G	1/2" (15)	3/4" (20)	1" (25)	1 1/4" (32)	1 1/2" (40)	2" (50)
Installation dimensions in mm	H (H1)	144	177	177	215 (177 <sup>1</sup> )	215 (177 <sup>1</sup> )	282
	h	12	15	15	22,5	22,5	26
	SW	32	41	41	55	55	80
	do	14	20	24	31	31	48
Weight	kg	0,6	1,3	1,3	2,6	2,6	5,4
Range of adjustment	bar	0,2-50	0,2-50	0,2-50	0,2-50	0,2-50	0,2-30
Range of adjustment ASME	psi	15-725	15-725	15-725	15-725	15-725	15-435

<sup>1</sup>type 812 with the option SHORT for the pressure range 0,2 to 6 bar also available as short version

■ **MAIN DIMENSIONS, INSTALLATION DIMENSIONS**



■ **INDIVIDUAL SELECTION / VALVE CONFIGURATION**

Series	Valve version	Medium	Lifting device	Nominal diameter DN	Connection type		Connection size		Seal	Options	Set pressure	Quantity
					Inlet	Outlet	Inlet	Outlet				
812	s	G	K	40	m	–	40	–	FKM		5,0	3
812	s	G	K	32	m	–	32	–	NBR	SHORT	3,5	2
812	s	G	K			–		–				
812	s	G	K			–		–				

In this table you can configure a valve according to your individual requirements (similar to the *example* shown, which should be deleted before you enter your own data). Please complete the table by hand using the abbreviations in this datasheet and then fax it to: +49(0)7141.4889488  
Please do not forget to add your personal data so that our sales team can contact you.

Name \_\_\_\_\_

First Name \_\_\_\_\_

Company \_\_\_\_\_

Telephone \_\_\_\_\_

E-Mail \_\_\_\_\_



TDB-8.5061.0-DAT\_01E

Version 2017 / 08 (K)

www.goetze-armaturen.de | info@goetze-armaturen.de | Phone: +49(0)7141.48894-60

**■ CAPACITY TABLE**

Series 812: Blowing-off rates at 10% above set pressure							
Nominal diameter DN	15	20	25	32	40	50	
Set pressure bar							
Air Nm <sup>3</sup> /h	0,2	61	167	240	401	401	768
	0,3	76	189	272	453	453	827
	0,4	88	205	296	493	493	887
	0,5	99	222	320	534	534	946
	0,6	110	240	345	576	576	1005
	0,7	121	262	377	629	629	1064
	0,8	129	280	404	673	673	1123
	0,9	138	299	431	719	719	1182
	1	147	319	459	766	766	1370
	1,5	194	419	604	1007	1007	1827
	2	245	520	749	1249	1249	2325
	3	338	717	1032	1723	1723	3177
	4	436	923	1330	2219	2219	4056
	5	524	1112	1601	2671	2671	4962
	6	613	1300	1872	3123	3123	5802
	7	702	1488	2143	3575	3575	6642
	8	790	1676	2413	4027	4027	6034
	9	879	1864	2684	4478	4478	6711
	10	968	2052	2955	4930	4930	7388
	11	1057	2240	3226	5382	5382	8065
	12	1145	2428	3497	5834	5834	8742
	13	1234	2617	3768	6286	6286	9420
	14	1323	2805	4039	6738	6738	10097
	15	1412	2993	4310	7190	7190	10774
	16	1500	3181	4581	7642	7642	11451
	17	1589	3369	4851	8094	8094	12129
	18	1678	3557	5122	8546	8546	12806
	19	1766	3745	5393	8998	8998	13483
	20	1855	3933	5664	9450	9450	14160
	21	1944	4122	5935	9902	9902	14838
22	2033	4310	6206	10354	10354	15515	
23	2121	4498	6477	10806	10806	16192	
24	2210	4686	6748	11258	11258	16869	
25	2299	4874	7019	11710	11710	17546	
26	2387	5062	7289	12162	12162	18224	
27	2476	5250	7560	12614	12614	18901	
28	2565	5438	7831	13066	13066	19578	
29	2654	5626	8102	13518	13518	20255	
30	2742	5815	8373	13970	13970	20933	
31	2831	6003	8644	14422	14422	-	
32	2920	6191	8915	14874	14874	-	
33	3009	6379	9186	15325	15325	-	
34	3097	6567	9457	15777	15777	-	
35	3186	6755	9727	16229	16229	-	
36	3275	6943	9998	16681	16681	-	
37	3363	7131	10269	17133	17133	-	
38	3452	7320	10540	17585	17585	-	
39	3541	7508	10811	18037	18037	-	
40	3630	7696	11082	18489	18489	-	
41	3718	7884	11353	18941	18941	-	
42	3807	8072	11624	19393	19393	-	
43	3896	8260	11895	19845	19845	-	
44	3984	8448	12166	20297	20297	-	
45	4073	8636	12436	20749	20749	-	
46	4162	8825	12707	21201	21201	-	
47	4251	9013	12978	21653	21653	-	
48	4339	9201	13249	22105	22105	-	
49	4428	9389	13520	22557	22557	-	
50	4517	9577	13791	23009	23009	-	



Version 2017 / 08 (K)

TDB-8.5061.0-DAT\_01E

[www.goetze-armaturen.de](http://www.goetze-armaturen.de) | [info@goetze-armaturen.de](mailto:info@goetze-armaturen.de) | Phone: +49(0)7141.48894-60

■ CAPACITY TABLE ASME

Series 812: Blowing-off rates at 10% above set pressure							
Nominal diameter DN		15	20	25	32	40	50
Set pressure psi(g)							
Air	15	111	226	326	543	543	985
	30	162	330	475	792	792	1437
SCFM	40	199	406	584	975	975	1768
	50	236	482	694	1158	1158	2099
	60	273	558	803	1340	1340	2430
	70	311	634	913	1523	1523	2762
	87	374	763	1099	1834	1834	3325
	90	385	786	1132	1888	1888	3424
	100	422	862	1241	2071	2071	3755
	110	460	938	1351	2254	2254	4087
	120	497	1014	1460	2437	2437	4418
	130	534	1090	1570	2619	2619	4749
	140	571	1166	1679	2802	2802	5081
	150	609	1242	1789	2985	2985	5412
	160	646	1318	1898	3167	3167	5743
	170	683	1394	2008	3350	3350	6074
	180	721	1470	2117	3533	3533	6406
	190	758	1546	2227	3715	3715	6737
	200	795	1623	2336	3898	3898	7068
	210	832	1699	2446	4081	4081	7400
	220	870	1775	2555	4263	4263	7731
	230	907	1851	2665	4446	4446	8062
	240	944	1927	2774	4629	4629	8393
	250	981	2003	2884	4812	4812	8725
	260	1019	2079	2993	4994	4994	9056
	270	1056	2155	3103	5177	5177	9387
	280	1093	2231	3212	5360	5360	9718
	290	1130	2307	3322	5542	5542	10050
	300	1168	2383	3431	5725	5725	10381
	320	1242	2535	3650	6090	6090	11044
	340	1317	2687	3869	6456	6456	11706
	360	1391	2839	4088	6821	6821	12369
	380	1466	2991	4307	7187	7187	13031
	400	1540	3143	4527	7552	7552	13694
	420	1615	3295	4746	7917	7917	14356
	435	1671	3410	4910	8191	8191	14853
	460	1764	3600	5184	8648	8648	-
	480	1838	3752	5403	9014	9014	-
	500	1913	3904	5622	9379	9379	-
	550	2099	4284	6169	10292	10292	-
	600	2286	4664	6717	11206	11206	-
	650	2472	5045	7264	12119	12119	-
	700	2658	5425	7812	13033	13033	-
	725	2751	5615	8085	13490	13490	-



TDB-8.5061.0-DAT\_01E

Version 2017 / 08 (K)

www.goetze-armaturen.de | info@goetze-armaturen.de | Phone: +49(0)7141.48894-60

