

Operator manual

Portable Rotary Screw Compressor

MOBILAIR M250E / M255E SIGMA CONTROL SMART

No.: 902482_00 USE

Read this manual before using this product.

Failure to follow the instructions and safety precautions in this manual can result in serious injury or death.

Manufacturer:

KAESER KOMPRESSOREN SE

96410 Coburg • PO Box 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

www.kaeser.com

Original instructions
/KKW/M250 2.13 en Z1 SBA-E-MOBILAIR-USCA

20220809 112146

1	Regarding this Document	
1.1	Using this document	1
1.2	Further documents	1
1.3	Copyright	1
1.4	Symbols and labels	1
1.4.1	Warnings	1
1.4.2	Potential damage warnings	2
1.4.3	Other alert notes and their symbols	2
2	Technical Data	
2.1	Nameplate	4
2.2	Options	4
2.2.1	Compressed air distributor	5
2.2.2	Air treatment	5
2.2.3	Low temperature equipment	5
2.2.4	Automatic start/stop	6
2.2.5	DUAL Control	6
2.2.6	GSM/GPS modem	6
2.3	Machine (without options)	6
2.3.1	Sound pressure level [dB(A)]	6
2.3.2	Tightening torque	6
2.3.3	Ambient conditions	7
2.3.4	Additional specifications	8
2.4	Compressor	8
2.4.1	Gauge working pressure and flow rate	8
2.4.2	Safety relief valve	9
2.4.3	Temperature	9
2.4.4	Compressor air filter maintenance switch	10
2.4.5	Compressed air outlet	10
2.4.6	Compressed air quality	10
2.4.7	Cooling oil recommendation	11
2.4.8	Cooling oil charge	11
2.4.9	Checking the filling volume of the condensate collection tank	11
2.5	Drive motor	12
2.5.1	Make	12
2.5.2	Drive motor rated power	12
2.5.3	Maximum rated current	13
2.6	Electrical connection	14
2.6.1	Power Supply	14
2.6.2	Power supply specifications	15
2.7	Fan motor	16
2.7.1	Fan motor rated power	16
2.8	Options	16
2.8.1	Low-temperature equipment	16
2.8.2	Measuring point connection	16
		16
3	Safety and Responsibility	
3.1	Basic instructions	17
3.2	Specified use	17
3.3	Incorrect Use	17
3.4	Operator responsibilities	17
3.4.1	Observe statutory and accepted rules and regulations	17
3.4.2	Determining suitable personnel	18
3.4.3	Complying with inspection schedules and accident prevention regulations	18
3.5	Dangers	19

3.5.1	Safely dealing with sources of danger	19
3.5.2	Organizational Measures	21
3.5.3	Danger areas	22
3.6	Safety devices	22
3.7	Service life of safety functions	22
3.8	Safety signs	23
3.9	Noise control requirements	27
3.10	Emergencies	27
3.10.1	Correct actions in the event of a fire	27
3.10.2	Treating injuries from handling operating fluids/materials	28
3.11	Warranty	29
3.11.1	Noise emissions warranty	29
3.12	Identifying the effects of improper modifications	29
3.13	Environmental protection	30
4	Design and Function	
4.1	Bodywork	31
4.2	Machine layout	33
4.3	Machine function	33
4.4	Operating modes and control modes	35
4.4.1	Machine operating modes	35
4.4.2	PROPORTIONAL control mode	35
4.5	Safety devices	36
4.5.1	Monitoring functions with shut-down	36
4.5.2	Further safety devices	36
4.6	SIGMA CONTROL SMART control panel	36
4.7	Draining the cooling oil and condensate	37
4.8	Draining condensate according to operating conditions	38
4.9	Options	38
4.9.1	Air treatment	39
4.9.2	Auxiliary heater	39
4.9.3	Automatic operating modes	40
4.9.4	GSM/GPS unit	42
4.9.5	Document bag	42
5	Installation and Operating Conditions	
5.1	Ensuring safety	44
5.2	Installation conditions	44
5.2.1	Note the conditions for stationary installation	45
5.2.2	Comply with the specified ambient temperature	47
6	Installation	
6.1	Ensuring safety	48
6.2	Reporting Transport Damage	48
6.3	Securing the parked machine	48
6.3.1	Fitting the machine feet	49
6.4	Electrical connection	50
6.4.1	Network Conditions	50
6.4.2	Power supply disconnecting device	50
6.5	Using the external condensate collection tank	50
7	Initial Start-up	
7.1	Ensuring safety	52
7.2	Before initial start-up (or recommissioning)	53
7.2.1	Instructions to be observed before commissioning or recommissioning	53
7.3	After storing the machine for a long period	53

7.4	Setting the overload relay	54
7.5	Setting the motor overload protection switch	54
7.6	Setting the voltage measuring relay	54
7.7	Draining condensate according to operating conditions	54
7.8	Low-temperature operation (winter)	56
7.8.1	Following the pre-heating time of the auxiliary heater	56
7.9	Note the automatic operating modes	57
7.9.1	Note the automatic start/stop	57
7.9.2	Note the DUAL control	57
8	Operation	
8.1	Ensuring safety	59
8.2	Observing environmental impacts	60
8.2.1	Environmental impact: thunderstorm	60
8.2.2	Environmental impact: low temperature	60
8.3	Switching on the machine	61
8.3.1	Connecting the power supply cable	61
8.3.2	Overview of fittings	62
8.3.3	Preparing the machine to start	64
8.3.4	Switching on the drive motor	64
8.3.5	Running up the machine to operating temperature	64
8.3.6	Switching the machine to LOAD operation	65
8.4	Setting the compressed air discharge pressure	65
8.5	Switching off	67
8.5.1	Switching off	67
8.5.2	Observing the back pressure indicator	68
8.5.3	Switching off the controller voltage	68
8.5.4	Switching off the on-site power supply disconnecting device	68
8.5.5	Disconnecting the CAM-LOK plug-in connection system	68
8.6	Shutting down machine in the event of an emergency	68
8.7	Checking the ambient temperature	70
8.8	Confirming alarm and warning messages	70
8.8.1	Confirming and acknowledging alarm messages	70
8.8.2	Confirming and acknowledging warning messages	70
8.9	Checking the level of the condensate collection tank	71
8.9.1	Checking the internal condensate collection tank	71
8.9.2	Checking the external condensate collection tank	71
8.10	Cleaning the machine after operation	71
8.10.1	Cleaning the exterior of the machine	72
8.10.2	Cleaning the interior of the machine	73
8.11	Operating the options	74
8.11.1	Note the automatic operating modes	74
9	Fault Recognition and Rectification	
9.1	Basic instructions	76
9.2	Analyzing SIGMA CONTROL SMART messages	76
9.2.1	Alarm message on the controller (machine off)	76
9.2.2	Warning message on the controller	78
9.3	Drive motor faults and alarms	79
9.3.1	Drive motor refuses to start or stops	79
9.4	Compressor faults and alarms	80
9.4.1	Working pressure too high	80
9.4.2	Working pressure too low.	81
9.4.3	Safety relief valve blowing off	81
9.4.4	Machine overheating	81

9.4.5	Too much oil residue in the compressed air	82
9.4.6	Oil flows from the compressor air filter after shutdown	83
10	Maintenance	
10.1	Ensuring safety	84
10.2	Adhere to the maintenance messages on the controller	85
10.2.1	Evaluating the maintenance message	85
10.2.2	Completing the maintenance	86
10.3	Following the maintenance plans	87
10.3.1	Logging maintenance work	87
10.3.2	Regular maintenance tasks	87
10.4	Motor maintenance	91
10.4.1	Servicing the motor bearings on the drive motor	91
10.4.2	Fan motor maintenance	93
10.5	Compressor Maintenance	94
10.5.1	Checking the cooling oil level	94
10.5.2	Filling and replenishing with cooling oil	95
10.5.3	Changing the cooling oil	96
10.5.4	Replacing the compressor oil filter	99
10.5.5	Servicing the control valve dirt trap	101
10.5.6	Changing the oil separator cartridge	103
10.5.7	Servicing the compressor air filter	108
10.5.8	Cleaning the compressed air aftercooler	110
10.5.9	Servicing the dirt trap on the centrifugal separator	113
10.5.10	Checking safety relief valves	115
10.5.11	Checking the excessive temperature shut-down function	115
10.5.12	Check the EMERGENCY STOP push button	115
10.6	Cleaning the oil cooler	116
10.6.1	Cleaning the oil cooler	117
10.7	Checking/emptying the condensate collection tank	119
10.7.1	Emptying the condensate collection tank	120
10.7.2	Checking the condensate drain line	120
10.8	Checking the screw connections	121
10.8.1	General guideline values for tightening torques	121
10.8.2	Specific guideline values for tightening torques	121
10.8.3	Sealed screw connections	121
10.9	Check sound insulation material	123
10.10	Checking the doors	124
10.10.1	Service rubber sealing strips	124
10.10.2	Checking function of closed doors	124
10.10.3	Checking connection elements of doors	125
10.11	Checking/replacing hose lines	125
10.11.1	Replace the pressure hoses of the compressor	125
10.12	Draining accumulated liquid inside the machine	125
10.13	Have the main contactor replaced	127
10.14	Maintenance for Optional Items	127
10.14.1	Servicing the filter combination	127
10.15	Documenting maintenance and service work	133
11	Spares, Operating Materials, Service	
11.1	Note the nameplate	134
11.2	Ordering spare parts and operating fluids/materials	134
11.3	KAESER AIR SERVICE	134
11.4	Replacement parts for service and repair	135
11.4.1	Spare parts overview	135

12	Decommissioning, Storage and Transport	
12.1	Decommissioning	203
12.1.1	Temporary decommissioning	203
12.1.2	Long-term decommissioning	203
12.2	Transport	204
12.2.1	Safety	205
12.2.2	Transporting the machine by crane	205
12.2.3	Transporting the machine with a forklift truck	206
12.2.4	Transporting the machine locally on site	209
12.2.5	Transporting the machine as load	210
12.3	Storage	211
12.4	Disposal	212
12.4.1	Draining operating fluids	212
12.4.2	Draining the condensate	213
12.4.3	Removing filters/filter elements	213
12.4.4	Disposing of the machine	213
13	Annex	
13.1	Labeling	214
13.2	Pipeline and instrument diagram (P&I diagram)	214
13.3	Dimensional Drawing	217
13.4	Electrical Diagram	219
13.5	Operator manual for compressed air filter combination	249
13.6	Installing CAM-LOK	277

Fig. 1	Option label MOBILAIR M250E / M255E with options	5
Fig. 2	Three-phase star (wye system); 4 wire; center point solidly grounded	14
Fig. 3	Three-phase star (wye system); 3 wire; grounded center point solidly grounded	15
Fig. 4	Locations of safety signs on the outside of the machine	23
Fig. 5	Locations of safety signs on the inside of the machine	25
Fig. 6	Locations of safety signs on the inside of the machine (top view)	26
Fig. 7	Position of safety signs on the control cabinet	27
Fig. 8	Overview of bodywork	32
Fig. 9	Example M250E, 175 hp, 400V/50Hz, Sigma 37.1	33
Fig. 10	Example M250E, 132 kW, 400V/50Hz, Sigma 37.1	34
Fig. 11	Overview of SIGMA CONTROL SMART control panel	36
Fig. 12	Drain device - symbols and arrangement of shut-off valves	38
Fig. 13	Filter combination	39
Fig. 14	Electric auxiliary heater	40
Fig. 15	Measuring point connection	42
Fig. 16	Location of the GSM/GPS unit inside the machine	42
Fig. 17	Document bag option	43
Fig. 18	Minimum distances from excavations/slopes/walls	45
Fig. 19	Flow of cooling air inside the machine	46
Fig. 20	Minimum distance if several machines are set up	46
Fig. 21	Mounting machine foot/rubber pad	49
Fig. 22	Drain device - symbols and arrangement of shut-off valves	51
Fig. 23	Draining condensate internally/externally	55
Fig. 24	Machine cable shaft	61
Fig. 25	Connecting the plug-in connection system	62
Fig. 26	Arrangement of SIGMA CONTROL SMART operating unit and fittings	63
Fig. 27	SIGMA CONTROL SMART operating unit keys and displays	63
Fig. 28	Ready indicator display	64
Fig. 29	Quick access adjustment compressed air output pressure	66
Fig. 30	Setting the compressed air discharge pressure	66
Fig. 31	Switching off in an emergency	69
Fig. 32	Closed floor pan bung	72
Fig. 33	Measuring point information sign	75
Fig. 34	Positions of the grease nipples	92
Fig. 35	Lubricating the drive motor bearings	93
Fig. 36	Checking the cooling oil level	94
Fig. 37	Drain device - symbols and arrangement of shut-off valves	98
Fig. 38	Replacing the oil filter	100
Fig. 39	Servicing the dirt trap on the oil separator tank	102
Fig. 40	Changing the oil separator cartridge	105
Fig. 41	Removing wearing parts	106
Fig. 42	Servicing the compressor air filter	109
Fig. 43	Cleaning the filter element	110
Fig. 44	Cleaning the compressed air aftercooler	112
Fig. 45	Cleaning the dirt trap	114
Fig. 46	Check the EMERGENCY STOP push button	116
Fig. 47	Cleaning the oil cooler	117
Fig. 48	Unlocking the venting coupling	119
Fig. 49	Closed floor pan plug	126
Fig. 50	Compressed air filter combination	128
Fig. 51	Draining the condensate	128
Fig. 52	Changing the filter elements	130
Fig. 53	Crane lifting eye information sign	206
Fig. 54	Prepare for transport using a forklift truck	207

Fig. 55	Lifting the machine with a forklift truck	208
Fig. 56	Transporting the machine with a forklift truck	209
Fig. 57	Improperly lashed down across bodywork	210
Fig. 58	Properly lashed down using lashing points on support frame	211
Fig. 59	Labeling M250E/M255E/60Hz	214

Tab. 1	Danger levels and their definition (personal injury)	1
Tab. 2	Danger levels and their definition (damage to property)	2
Tab. 3	Nameplate	4
Tab. 4	Compressed air distributor option	5
Tab. 5	Air treatment options	5
Tab. 6	Low temperature equipment option	5
Tab. 7	Automatic start/stop	6
Tab. 8	DUAL control	6
Tab. 9	GSM/GPS modem	6
Tab. 10	Guaranteed sound pressure level [dB(A)]	6
Tab. 11	Torques for M4–M8 screws	7
Tab. 12	Torques for M10–M24 screws	7
Tab. 13	Torque cover fixing screws oil separator tank	7
Tab. 14	Torques for lifting eye screws	7
Tab. 15	Ambient conditions	7
Tab. 16	Gauge working pressure and flow rate, M250E / 460 V / 60 Hz	8
Tab. 17	Gauge working pressure and flow rate, M255E / 460 V / 60 Hz	8
Tab. 18	Gauge working pressure and flow rate, M250E / 575 V / 60 Hz	8
Tab. 19	Gauge working pressure and flow rate, M255E / 575 V / 60 Hz	9
Tab. 20	Safety relief valve actuating pressure	9
Tab. 21	Machine temperature	9
Tab. 22	Switching to LOAD mode	9
Tab. 23	Machine temperature	9
Tab. 24	Maintenance switch switching point	10
Tab. 25	Compressed air outlet butterfly valve	10
Tab. 26	Ambient temperature	10
Tab. 27	Interrelation between compressed air treatment and compressed air quality	10
Tab. 28	Cooling oil recommendation	11
Tab. 29	Cooling oil charge	11
Tab. 30	Filling volume of internal condensate collection tank	11
Tab. 31	Drive motors by rated power 175 hp	12
Tab. 32	Drive motors by rated power 214.6 hp	12
Tab. 33	Technical specifications for M250E drive motors	12
Tab. 34	Technical specifications for M255E drive motors	13
Tab. 35	Maximum rated current M250E	13
Tab. 36	Maximum rated current M255E	13
Tab. 37	Maximum rated current M250E	13
Tab. 38	Maximum rated current M255E	14
Tab. 39	Connection type for rated voltage 460V/575V/M250E	15
Tab. 40	SConnection type for rated voltage 460V/575V/M255E	15
Tab. 41	Fan motor rated power 60 Hz	16
Tab. 42	Ambient conditions, low-temperature equipment	16
Tab. 43	Auxiliary heater power	16
Tab. 44	Measuring point connection	16
Tab. 45	Inspection intervals according to Ordinance on Industrial Health and Safety	19
Tab. 46	Danger areas	22
Tab. 47	Category and Performance Level	22
Tab. 48	Safety signs	24
Tab. 49	Safety signs	26
Tab. 50	Control unit keys and indicators	36
Tab. 51	Temperature set-point value	39
Tab. 52	Set the measuring point using the directional control valve	41
Tab. 53	Maximum inclined position	45
Tab. 54	On-site power supply disconnecting device	50

Tab. 55	Measures for re-commissioning the compressor after a long period of storage	53
Tab. 56	Example of pre-heat time for the electrical auxiliary heater	56
Tab. 57	"Do not start the machine" information sign	56
Tab. 58	Safety sign for automatic starting	57
Tab. 59	Safety sign for automatic starting	57
Tab. 60	Color coding L1, L2, L3, GRD	62
Tab. 61	Suitable compressed air range for cleaning	73
Tab. 62	Alarm messages and troubleshooting concerning the drive motor	76
Tab. 63	Alarm messages and troubleshooting concerning "compressor fault"	77
Tab. 64	Alarm messages and troubleshooting concerning "controller fault"	77
Tab. 65	Alarm messages and troubleshooting concerning "General faults"	78
Tab. 66	Warning messages and measures relating to the compressor	79
Tab. 67	General warning messages and measures	79
Tab. 68	Fault: "Drive motor refuses to start or stops"	79
Tab. 69	Fault: working pressure too high	80
Tab. 70	Fault: working pressure too low	81
Tab. 71	Fault: safety relief valve blowing off	81
Tab. 72	Fault: machine overheating	81
Tab. 73	Alarm: "Too much oil residue in the compressed air"	82
Tab. 74	Alarm: "Oil flows from the compressor air filter after shutdown"	83
Tab. 75	Advise others that the machine is being serviced.	84
Tab. 76	Maintenance messages and required measures	85
Tab. 77	Maintenance intervals and regular maintenance tasks	87
Tab. 78	Regular machine maintenance tasks	88
Tab. 79	Regular maintenance task options	90
Tab. 80	Specific message code for "Service motor bearings"	91
Tab. 81	Specific message code for "Change cooling oil"	96
Tab. 82	Specific message code for "Replace oil filter"	99
Tab. 83	Specific message code for "Service air filter"	108
Tab. 84	Suitable compressed air range for cleaning	111
Tab. 85	Shut-down at excessive temperature	115
Tab. 86	Suitable compressed air range for cleaning	117
Tab. 87	Specific message code for "Service main contactor"	127
Tab. 88	Replacing the filter elements	131
Tab. 89	Maintenance log	133
Tab. 90	Compressor spare parts	134
Tab. 91	Drive motor spare parts	134
Tab. 92	"Temporarily decommissioned" information notice	203
Tab. 93	Definition of long-term decommissioning	203
Tab. 94	Long-term decommissioning checklist	204
Tab. 95	"Long-term decommissioning" information sign	204
Tab. 96	Maximum load force of lashing eye	209
Tab. 97	Maximum load force of lashing eye	210
Tab. 98	Machine fluids	212
Tab. 99	Machine filters/filter elements	213
Tab. 100	Machine option filters/filter elements	213

1 Regarding this Document

1.1 Using this document

The operating manual is a component of the product. It describes the machine as it was at the time of first delivery after manufacture.

- Keep the operating manual in a safe place throughout the life of the machine.
- Supply any successive owner or user with this operating manual.
- Please insert any amendment or revision of the operating manual sent to you.
- Enter details from the machine nameplate and individual items of equipment in the table in chapter 2.

1.2 Further documents

Further documents included with this operating manual are:

- Certificate of acceptance / operating instructions for the pressure vessel
- Declaration of Conformity in accordance with applicable directives

Missing documents can be requested from KAESER.

- Make sure all documents are complete and observe the instructions contained in them.
- Make sure you provide the data from the nameplate when ordering documents.

1.3 Copyright

This operator manual is copyright protected. Queries regarding use or duplication of the documentation should be referred to KAESER. Correct use of information will be fully supported.

1.4 Symbols and labels

- Please note the symbols and labels used in this document.

1.4.1 Warnings

Warning notices indicate risks potentially resulting in personal injury, if the measures specified are not taken.

Warning notices indicate three levels of danger identified by the corresponding signal word:

Signal word	Meaning	Consequences of ignoring the warning
DANGER	Warns of an imminent danger	Will very likely result in death or severe injury
WARNING	Warns of a potentially imminent danger	May result in death or severe injury
CAUTION	Warns of a potentially dangerous situation	May result in a moderate physical injury

Tab. 1 Danger levels and their definition (personal injury)

1 Regarding this Document

1.4 Symbols and labels

Some warning notes may precede a chapter. They apply to the entire chapter including all subsections.

Example:

DANGER

The type and source of the imminent danger is shown here!

The possible consequences of ignoring a warning are shown here.

The word "DANGER" indicates that death or severe injury can very likely result from ignoring the warning.

► *The measures required to protect yourself from danger are shown here.*

Warning notes referring to a subsection or the subsequent action are integrated into the procedure and numbered as an action.

Example:

1. **DANGER** *The type and source of the imminent danger is shown here!*

The possible consequences of ignoring a warning are shown here.

The word "WARNING" indicates that death or severe injury may result from ignoring the warning.

► *The measures required to protect yourself from danger are shown here.*

2. Always read and comply with warning instructions.

1.4.2 Potential damage warnings

Contrary to the warnings shown above, damage warnings do not indicate a potential personal injury.

Damage warnings have only one danger level, identified with this signal word:

Signal word	Meaning	Consequences of non-compliance
NOTE	Warns of a potentially dangerous situation	Damage to property is possible

Tab. 2 Danger levels and their definition (damage to property)

Example:

NOTICE

The type and source of the imminent danger is shown here!

Potential effects when ignoring the warning are indicated here.

► *The protective measures against the damages are shown here.*

► Carefully read and fully comply with warnings against damages.

1.4.3 Other alert notes and their symbols



This symbol indicates particular important information.

Material Here you will find details on special tools, operating materials or spare parts.

Precondition Here you will find conditional requirements necessary to carry out the task.
The conditions relevant to safety shown here will help you to avoid dangerous situations.

➤ This symbol is placed by lists of actions comprising one step of a task.

1. In process instructions with several steps ...
2. ... the sequence of steps is numbered.

Result Shows the expected conclusion of the previous action.

Option da ➤ Information relating to one option only is marked with an option code (e.g., "option da" means that this section is only valid for machines with the air treatment components "aftercooler and centrifugal separator"). Option codes used in this operating manual are explained in chapter 2.2.



Information referring to potential problems is identified by a question mark.

The cause is named in the help text ...

- ... and a remedy given.



This symbol refers to important information or measures concerning environmental protection.

Further information Further topics are introduced here.

2 Technical Data

2.1 Nameplate

The machine's nameplate provides the type and important technical information.

The nameplate is located on the outside of the machine (see illustration in chapter 13.1).

► Enter here the nameplate data as a reference:

Feature	Value
Portable screw compressor	
Part No.	
Serial No.	
Actual total weight	
Lifting point load capacity	
Rated power	
Rated motor speed	
Max. working pressure	

Tab. 3 Nameplate

2.2 Options

A list of the options built into your machine helps to correlate the information in this Operating Manual.

Available options are listed on the options label (option: code letters).


This label can be found:

- On the outside of the machine.
- See chapter 13.1.



The following tables list all possible options.
Only the codes for those options fitted appear on the label!

Options fitted:



02-M3524

Fig. 1 Option label MOBILAIR M250E / M255E with options

- Take a list of available options from the options label and enter these options as reference in the overviews below.

2.2.1 Option fa Compressed air distributor

Option	Option code	Available?
Non-separated compressed air distribution line	fa	

Tab. 4 Compressed air distributor option

2.2.2 Option dd Air treatment

Option	Option code	Available?
Filter combination	dd	
-	-	

Tab. 5 Air treatment options

2.2.3 Option ba Low temperature equipment

Option	Option code	Available?
Insulated control air lines	ba	
-	-	

Tab. 6 Low temperature equipment option

2.2.4 Option ob
Automatic start/stop

Option	Option code	Available?
Automatic start/stop	ob	

Tab. 7 Automatic start/stop

2.2.5 Option cd
DUAL Control

Option	Option code	Available?
DUAL control	cd	

Tab. 8 DUAL control

2.2.6 Option oc
GSM/GPS modem

Option	Option code	Available?
GSM/GPS modem	oc	

Tab. 9 GSM/GPS modem

2.3 Machine (without options)
2.3.1 Sound pressure level [dB(A)]

The sound pressure level conforms to the US EPA Standard.
Measuring distance: 23 ft

Sound Pressure Level	M250E / M255E
Sound pressure level [dB(A)]	76

Tab. 10 Guaranteed sound pressure level [dB(A)]

2.3.2 Tightening torque
2.3.2.1 Tightening torques for screws

Overview:

- Standard values for M4–M8 screws
 - Surface finish: zinc plated (bright)
 - Standard values for M10–M24 screws
 - Surface finish: zinc flake coating (matte).
- Set the torque as appropriate for the surface finish and friction coefficient.

2 Technical Data

2.3 Machine (without options)

Standard values for M4–M8 screws with steel grade 8.8:

Thread	M4	M5	M6	M8
Torque [lbf-in]	26.6	52.2	88.5	216.8

Surface finish: zinc plated (bright)
Standards based on VDI 2230.

Tab. 11 Torques for M4–M8 screws

Standard values for M10–M24 screws with steel grade 8.8:

Thread	M10	M12	M14	M16	M20	M24
Torque [lbf-in]	354	620	929	1416	2832	4868

Surface finish: zinc flake coating (matte).
Standards based on VDI 2230.

Tab. 12 Torques for M10–M24 screws

2.3.2.2 Torque cover fixing screws oil separator tank

Recommended values for screws corresponding to the strength category:

Screws	Strength category	Thread	Torque [lbf in]
Hex-head screw	8.8	M20	1770

Tab. 13 Torque cover fixing screws oil separator tank

2.3.2.3 Torques for lifting eye

Recommended values for screws corresponding to the strength category:

Screws	Strength category	Thread	Torque [lbf in]
Hex-head bolt	8.8	M16	1770
Hex-head bolt	8.8	M20	3540

Tab. 14 Torques for lifting eye screws

2.3.3 Ambient conditions

Positioning	Limit value
Maximum altitude amsl* [ft]	3000
Minimum ambient temperature [°F]	14
Maximum ambient temperature [°F]	104

* Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 15 Ambient conditions

2.3.4 Additional specifications

Specifications according to the machine's operating license, such as:

- Dimensions,
- Footprint

can be found in the dimensional drawing, chapter 13.3.



The dimensional drawing also shows the position of the following inlets and outlets relevant to the machine's function:

- Cooling air inlet
- Cooling air outlet
- Compressed air outlet

2.4 Compressor

2.4.1 Gauge working pressure and flow rate



Definition of flow rate: Continuous delivery volume relative to intake conditions

460 V / 60 Hz

Type	M250E			
Maximum gauge working pressure [psig]	125	-	175	203
SIGMA airend	36.1	-	33.1	32.1
Flow rate [cfm]	885	-	705	565

Flow rate as per ISO 1217:2009. Annex C

Tab. 16 Gauge working pressure and flow rate, M250E / 460 V / 60 Hz

Type	M255E			
Maximum gauge working pressure [psig]	125	145	-	203
SIGMA airend	37.1	36.1	-	33.1
Flow rate [cfm]	990	870	-	690

Flow rate as per ISO 1217:2009. Annex C

Tab. 17 Gauge working pressure and flow rate, M255E / 460 V / 60 Hz

575 V / 60 Hz

Type	M250E			
Maximum gauge working pressure [psig]	125	-	175	203
SIGMA airend	36.1	-	33.1	32.1
Flow rate [cfm]	885	-	705	565

Flow rate as per ISO 1217:2009. Annex C

Tab. 18 Gauge working pressure and flow rate, M250E / 575 V / 60 Hz

Type	M255E			
Maximum gauge working pressure [psig]	125	145	-	203
SIGMA airend	37.1	36.1	-	33.1
Flow rate [cfm]	990	870	-	690
Flow rate as per ISO 1217:2009, Annex C				

Tab. 19 Gauge working pressure and flow rate, M255E / 575 V / 60 Hz

2.4.2 Safety relief valve

Maximum working pressure: see machine nameplate

Maximum working pressure [psig]	125	145	175	203
Safety relief valve actuating pressure* [psig]	160	175	203	230

*The safety relief valve is fitted to the oil separator tank

Tab. 20 Safety relief valve actuating pressure

2.4.3 Temperature

Overview:

- Typical airend discharge temperature during operation
- LOAD operation with required airend discharge temperature
- Safety shut-down at maximum discharge temperature

2.4.3.1 Typical airend discharge temperature during operation

A conventionally thermostatic valve regulates the compressor temperature accordingly.

Machine temperature	Value
Typical discharge temperature [°F] during operation	185 230

Tab. 21 Machine temperature

2.4.3.2 LOAD operation with required airend discharge temperature

Airend discharge temperature for LOAD mode	Value
Required airend discharge temperature [°F] for switching to LOAD mode	68

Tab. 22 Switching to LOAD mode

2.4.3.3 Safety shut-down at maximum airend discharge temperature

Machine temperature	Value
Maximum airend discharge temperature [°F] automatic safety shut-down	243

Tab. 23 Machine temperature

2.4.4 Compressor air filter maintenance switch

Maintenance switch	Value
Switching point at vacuum [psi]	0.8

Tab. 24 Maintenance switch switching point

2.4.5 Compressed air outlet

Type of butterfly valve	
Quantity	1
Nominal width DN [mm]	80
Number of holes, flange	8
Thread	M16
Actuation of butterfly valve	Hand wheel with gear

Tab. 25 Compressed air outlet butterfly valve

2.4.6 Compressed air quality

2.4.6.1 Ambient temperature

The quality of the treated compressed air depends on the ambient temperature.

Ambient temperature	Limit value
Minimum ambient temperature [°F]	14
Maximum ambient temperature [°F]	104

Tab. 26 Ambient temperature

2.4.6.2 Compressed air quality at the compressed air outlet



The compressed air outlet is marked with the identifiers of compressed air quality.

Interrelation between compressed air treatment and compressed air quality:

Compressed air treatment		Compressed air quality	
Standard design / option code	Components	Characteristics	Code
Standard design	<ul style="list-style-type: none"> ▪ Compressed air aftercooler ▪ Centrifugal separator 	Cool and condensate-free	A

Compressed air treatment		Compressed air quality	
Standard design / option code	Components	Characteristics	Code
Standard design + dd	<ul style="list-style-type: none"> ■ Compressed air aftercooler ■ Centrifugal separator ■ Filter combination 	Dry and technically oil-free	F

Tab. 27 Interrelation between compressed air treatment and compressed air quality

2.4.7 Cooling oil recommendation

A sticker showing the type of oil used is located near the oil separator tank filler.

Information on ordering cooling oil is found in chapter 11.

	SIGMA FLUID
	S-570
Description	Synthetic oil
Application	Special oil for ambient conditions with high temperatures and humidity. Standard oil for all applications except in connection with foodstuffs. Particularly suitable for machines with a high duty cycle.
Viscosity at 104°F	0.08 in ² /s (ASTM D445)
Viscosity at 212 °F	0.01 in ² /s (ASTM D445)
Flash point	497°F (ASTM D92)
Density at 59 °F	54.2 lb/ft ³ (ASTM D1298)
Pour point:	-65°F (ASTM D97)

Tab. 28 Cooling oil recommendation

2.4.8 Cooling oil charge

Cooling oil	Fluid volume [qt]
Machine	69

Tab. 29 Cooling oil charge

2.4.9 Checking the filling volume of the condensate collection tank

Internal condensate collection tank	Value
Filling volume [gal]	6.6

Internal condensate collection tank	Value
–	–

Tab. 30 Filling volume of internal condensate collection tank

2.5 Drive motor

2.5.1 Make

Type	M250E	
Rated power [hp]	175	
Rated voltage [V]	460 / 3 ~	575 / 3 ~
Frequency [Hz]	60	60
Manufacturer	Siemens	Siemens
Model	1PC30053AB200MAO	1PC30053AB200MA2

Tab. 31 Drive motors by rated power 175 hp

Type	M255E	
Rated power [hp]	214.6	
Rated voltage [V]	460 / 3 ~	575 / 3 ~
Frequency [Hz]	60	60
Manufacturer	Siemens	Siemens
Model	1PC30053AB400MAO	1PC30053AB400MAO

Tab. 32 Drive motors by rated power 214.6 hp

2.5.2 Drive motor rated power

Type	M250E	
Rated power [hp]	175	
Rated voltage [V]	460 / 3 ~	575 / 3 ~
Frequency [Hz]	60	60
Rated voltage tolerance [%]	±10	±10
Rated speed [rpm]	1793	1793
Energy-efficiency class	IE4	IE4
Protection class	IP55	IP55

Tab. 33 Technical specifications for M250E drive motors

Type	M255E		
Rated power [hp]	214.6		
Rated voltage [V]	460 / 3 ~		575 / 3 ~
Frequency [Hz]	60		60
Rated voltage tolerance [%]	±10		±10
Rated speed [rpm]	1793		1793
Energy-efficiency class	IE4		IE4
Protection class	IP55		IP55

Tab. 34 Technical specifications for M255E drive motors

2.5.3 Maximum rated current

Type	M250E			
Rated power [hp]	175			
Rated voltage [V]	460 / 3 ~			
Frequency [Hz]	60			
Working pressure [psig]	125	–	175	203
Maximum rated current (I _N) [A]	235	–	238	232

Tab. 35 Maximum rated current M250E

Type	M255E			
Rated power [hp]	214.6			
Rated voltage [V]	460 / 3 ~			
Frequency [Hz]	60			
Working pressure [psig]	125	145	–	203
Maximum rated current (I _N) [A]	284	268	–	267

Tab. 36 Maximum rated current M255E

Type	M250E			
Rated power [hp]	175			
Rated voltage [V]	575 / 3 ~			
Frequency [Hz]	60			
Working pressure [psig]	125	–	175	203
Maximum rated current (I _N) [A]	189	–	191	187

Tab. 37 Maximum rated current M250E

Type	M255E			
Rated power [hp]	214.6			
Rated voltage [V]	575 / 3 ~			
Frequency [Hz]	60			
Working pressure [psig]	125	145	-	203
Maximum rated current (I _N) [A]	232	218	-	218

Tab. 38 Maximum rated current M255E

2.6 Electrical connection

2.6.1 Power Supply

Basic requirements

The machine is designed for an electrical supply according to National Electric Code (NEC), edition 2020, particularly article 670 and NFPA 79, edition 2018, particularly section 4.4. In the absence of any user-specified alternatives, the limits given in these standards must be adhered to. Consult manufacturer for any other specific power supply.

The incoming line within the control panel should be as short as possible. Observe the max. distance from the fuse disconnect switch to the bodywork from 6.6 ft.


If external sensors or communication lines are to be connected to the machine, use shielded cables and insert the same through EMC fittings into the control panel.

Three-phase

Do **NOT** operate package on any unsymmetrical power supply. Also do **NOT** operate package on power supplies such as a three-phase WYE system with the center point not solidly grounded or three-phase (open) delta.


The machine requires a symmetrical three-phase power supply transformer with a WYE configuration output as shown in Figure 2 and Figure 3. In a symmetrical three phase supply the phase angles and voltages are all the same.

Other power supplies are not suitable.



03-S0235

Fig. 2 Three-phase star (wye system); 4 wire; center point solidly grounded



03-S0236

Fig. 3 Three-phase star (wye system); 3 wire; grounded center point solidly grounded

Further information Please contact an authorized KAESER service representative for options.
The electrical diagram 13.4 contains further specifications for electrical connection.

2.6.2 Power supply specifications

The following multi-strand copper core wires are given according to 2020 NEC 310.14, 310.15, 310.16 and table 310.16 adjusted for 104 °F ambient temperature.

If other local conditions prevail, like for example high temperature, the cross section should be checked and adjusted according to 2020 NEC 110.14(C), 220.3, 310.14, 310.15, 310.16, table 310.15(B)(1), table 310.15(C)(1), 430.6, 430.22, 430.24, 670.4(A) and other local codes.

Dual element time delay fuses should be selected according to 2020 NEC 240.6, 430.52 and tables 430.52, 430.248 and 430.250.

It is recommended to use a ground conductor the same size as the current carrying conductors, if local codes allow. Neither the minimum ground wire size as pointed out in 2020 NEC table 250.122 nor using conduit as the sole ground connection is recommended.

Further information The electrical diagram in chapter 13.4 contains further specifications for electrical connection.

Type	M250E	
Rated voltage [V]	460 V	575 V
Supply per phase and ground (167°F)	2xAWG3/0	2xAWG2/0
Fuse protection [A] as per Class J	300	250
Max. voltage, backup fusing [V]	600	600

Tab. 39 Connection type for rated voltage 460V/575V/M250E

Type	M255E	
Rated voltage [V]	460 V	575 V
Supply per phase and ground (167°F)	2xAWG4/0	2xAWG3/0
Fuse protection [A] as per Class J	350	300
Max. voltage, backup fusing [V]	600	600

Tab. 40 Connection type for rated voltage 460V/575V/M255E

2.7 Fan motor

2.7.1 Fan motor rated power

Rated voltage [V]	460 / 3 ~	575 / 3 ~
Rated power [hp]	8	8
Maximum speed [rpm]	1250	1250
Protection class	Type rating 3	Type rating 3

Tab. 41 Fan motor rated power 60 Hz

2.8 Options

2.8.1 Option ba

Low-temperature equipment

2.8.1.1 Ambient conditions

Installation	Limit value
Maximum elevation ASL* [ft]	3000
Minimum ambient temperature [°F]	14
Maximum ambient temperature [°F]	104

* Higher altitudes are permissible only after consultation with the manufacturer

Tab. 42 Ambient conditions, low-temperature equipment

2.8.1.2 Auxiliary heater

Standstill heater	Value
Number of radiators	3
Total power of the radiators [W]	1500
Switching point, thermostat [°F]	41
Protection rating	—

Tab. 43 Auxiliary heater power

2.8.2 Option cd

Measuring point connection

Name	Value
Hose coupling ["]	G 1/4
Pressure transducer [psi / mA]	0–16 / 4–20

Tab. 44 Measuring point connection

3 Safety and Responsibility

3.1 Basic instructions

The machine is manufactured to the latest engineering standards and acknowledged safety regulations. Nevertheless, dangers can arise through its operation:

- Danger to life and limb of the operator or third parties,
- Impairments to the machine and other material assets.



Disregard of warning or safety instructions can cause serious injuries!

- Use this machine only if it is in a technically perfect condition and only for the purpose for which it is intended; observe all safety measures and the instructions in the service manual!
- Immediately rectify (have rectified) any faults that could be detrimental to safety!

3.2 Specified use

The machine is intended solely for generating compressed air for industrial use. Any other use is considered incorrect. The manufacturer is not liable for any damages that may result from incorrect use. The user alone is liable for any risks incurred.

- Comply with the specifications listed in this service manual.
- Operate the machine only within its performance limits and under the permitted ambient conditions.
- Do not use compressed air for breathing purposes unless it is specifically treated.
- Do not use compressed air for any application that will bring it into direct contact with food products unless it is specifically treated.

3.3 Incorrect Use

Improper usage can cause damage to property and/or (severe) injuries.

- Only use the machine as intended.
- Never direct compressed air at persons or animals.
- Do not use untreated compressed air for breathing purposes.
- Do not allow the machine to take in toxic, acidic, flammable, or explosive gases or vapors.
- Do not operate the machine in areas in which specific requirements with regard to explosion protection are in effect.

3.4 Operator responsibilities

3.4.1 Observe statutory and accepted rules and regulations

Examples of these include nationally implemented directives and/or applicable national legislation, safety and accident prevention regulations.

1. **⚠ DANGER** *Risk of fatal injury caused by contact with live components!*
 - *Only certified electricians may work on the installation, maintenance and repair of the machine's electrical assemblies. This includes work on live components!*

3 Safety and Responsibility

3.4 Operator responsibilities

2. Observe relevant statutory regulations and accepted technical rules during transport, operation, and maintenance of the machine.

3.4.2 Determining suitable personnel

Suitable personnel are experts who, by virtue of their training, knowledge and experience, as well as their knowledge of relevant regulations, can assess the work to be undertaken and recognize the possible dangers involved.

Authorized operating personnel possess the following qualifications:

- they are of legal age,
- are familiar with and adhere to the safety instructions and sections of the Operating Manual relevant to operation,
- they have received adequate training and authorization to operate electrical and compressed air devices,

Authorized maintenance personnel possess the following qualifications:

- they are of legal age,
- are familiar with and adhere to the safety instructions and sections of the Operating Manual relevant to maintenance,
- are fully familiar with the safety concepts and regulations of electrical and compressed air engineering,
- are able to recognize the possible dangers of electrical and compressed air devices and take appropriate measures to safeguard persons and property,
- have received adequate training in and authorization for the safe installation and maintenance of this machine.

Authorized transport personnel possess the following qualifications:

- they are of legal age,
 - are familiar with and adhere to the safety instructions and sections of the Operating Manual relevant to transporting,
 - are familiar with the safety regulations relating to handling transport goods,
- Ensure that personnel entrusted with transport, operation, and maintenance are qualified and authorized to carry out their tasks.

3.4.3 Complying with inspection schedules and accident prevention regulations

The machine is subject to local inspection schedules.

- Have the pre-commissioning inspection carried out according to the Ordinance on Industrial Safety and Health, §15.
- Carry out recurring inspections:
The user must ensure that the machine's safety devices are checked for function as required or at least annually.
- Carry out oil changes:
The user must ensure that the cooling oil is changed as required or at least annually and the oil change must be documented. Intervals may be varied if an analysis proves that the oil is still usable.

3 Safety and Responsibility

3.5 Dangers

- Keep to inspection intervals in accordance with the Ordinance on Industrial Health and Safety with maximum intervals as laid down in §16:

Inspection	Inspection interval	Inspection authority
Equipment inspection	Before commissioning	Approved supervisory body.
Internal inspection	Every 5 years after commissioning or the last inspection	Contact an authorized KAESER service representative.
Strength test	Every 10 years after commissioning or the last inspection	Contact an authorized KAESER service representative.

Tab. 45 Inspection intervals according to Ordinance on Industrial Health and Safety

Checking the lifting point

The user is responsible for ensuring that the machine's lifting point and fixings are inspected according to national regulations for wear and damage.

- Have lifting point checked.

Lifting point is not in order: The machine must not be transported by crane. Have the machine repaired immediately.

3.5 Dangers

Basic instructions

The following describes the various forms of danger that can occur during machine operation.

Basic safety instructions are found in this service manual at the beginning of each chapter in the section entitled 'Safety'.

Warning instructions are found before a potentially dangerous task.

3.5.1 Safely dealing with sources of danger

The information provided here explains how to counter the various types of danger that can arise during machine operation.

Electricity

Touching voltage-carrying components can result in electric shocks, burns or even death.

- Allow only qualified and authorized electricians or trained personnel under the supervision of a qualified and authorized electrician to carry out work on electrical equipment according to electrical engineering regulations.
- Before commissioning or re-commissioning the machine, the user must ensure adequate protection against electric shock from direct or indirect contact.
- Before starting any work on electrical equipment:
Switch off and lock out / tag out the user's power supply disconnecting device and verify the absence of voltage.
- Switch off all other external power sources.
These could be connections to floating contacts for example.
- Use fuses corresponding to machine power.
- Regularly check that all electrical connections are tight and in perfect condition.

Fire and explosion

Spontaneous ignition and combustion of cooling oil can result in serious injury or death.

- Allow no open flames or sparks at the place of use.
- Make sure that the ambient temperature at the machine's place of use is within permissible limits.
- Never refill cooling oil when the machine is running.
- Wipe up spilled cooling oil immediately.
- Provide a fire extinguisher in the immediate vicinity.

Forces of compression

Escaping compressed air can cause serious injury. The following information concerns work on components that could be under pressure.

- Wait until the compressor has automatically vented (the pressure gauge must read 0 psig!).
- Then open an outlet valve carefully to ensure that the line between the minimum pressure / check valve and the compressed air outlet is vented.
- Do not carry out welding, heat treatment or mechanical modifications to pressurized components (e.g. pipes and vessels) as this influences the component's resistance to pressure.
The safety of the machine is then no longer ensured.

Spring forces

Sudden release of springs under tension can cause serious injuries.

Minimum pressure / check valves, safety relief valves and inlet valves are powerfully spring-loaded.

- Do not open or dismantle any valves.

Compressed air quality

The composition of the compressed air must be suitable for the actual application in order to preclude health and life-threatening dangers.

- Use appropriate systems for air treatment before using the compressed air from this machine as breathing air and/or for the processing of foodstuffs.
- Use food grade cooling oil whenever compressed air is to come into contact with foodstuffs.

Rotating components

Touching the fan wheel, the coupling or the belt drive while the machine is running can result in serious injury.

- Operate the machine only with canopy, safety guards, access doors and panels closed.
- Shut down the machine before opening a door or canopy.
- Wear close-fitting clothes and a hair net if necessary.
- Properly install all safety devices and panels before restarting the machine.

Temperature

- Avoid contact with hot components.

These include, for example, drive motor, compressor airend, oil and compressed air lines, coolers and oil separator tank.

- Wear protective clothing.

- Wear protective gloves when connecting or disconnecting compressed air hoses.
- Allow the machine to cool down before commencing any maintenance work.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting oil vapors or parts of the machine.

Noise

The enclosure absorbs the machine noise to a tolerable level. This function will be effective only if the body is closed.

- Operate the machine only with closed body.
- Check machines that are lined with sound proofing material for perfect condition of the sound proofing material.
- Wear hearing protection if necessary.
Safety relief valve blow-off results in high noise emission.
- Never generate compressed air without consumers being connected.

Operating fluids/materials

The used operating fluids and materials can cause adverse health effects. Suitable safety measures must be taken in order to prevent injuries.

- Strictly forbid fire, open flame and smoking.
- Follow safety regulations when dealing with oils, lubricants and chemical substances.
- Avoid contact with skin and eyes.
- Do not inhale oil mist and oil vapors.
- Do not eat or drink while handling oil, cooling and lubricating fluids.
- Keep suitable fire extinguishing agents ready for use.
- Use only KAESER approved operating materials.

Unsuitable spare parts

Unsuitable spare parts compromise the safety of the machine.

- Use only spare parts approved by the manufacturer for use in this machine. Unsuitable spare parts compromise the safety of the machine.
- Use only genuine KAESER replacement parts on pressure bearing parts.

Conversion or modification of the machine

Modifications, additions or conversions to or of the machine can result in unpredictable hazards.

- Do not convert or modify the machine!
- Do not install any non-approved additional components.
- Do not make any changes to the machine that will increase its weight beyond the permissible limit and/or endanger its safe use or transportation. Any such changes invalidate the approval to use the machine or tow it on the road.
- Prior to any technical modification and expansions of the machine, obtain the written approval of the manufacturer.

3.5.2 Organizational Measures

- Designate personnel and their responsibilities.

3 Safety and Responsibility

3.6 Safety devices

- Give clear instructions on reporting faults and damage to the machine.
- Give instructions on fire reporting and fire-fighting measures.

3.5.3 Danger areas

The table gives information on areas dangerous to personnel.

Only authorized personnel may enter these areas.

Task	Danger area	Authorized personnel
Transport	Within a 10 ft radius of the machine.	Operating personnel to prepare for transport. No personnel during transport.
	Beneath the lifted machine.	No personnel!
Commissioning	Within the machine.	Maintenance personnel
	Within a 3 ft radius of the machine.	
Operation	Within a 3 ft radius of the machine.	Operating personnel
Maintenance	Within the machine.	Maintenance personnel
	Within a 3 ft radius of the machine.	

Tab. 46 Danger areas

3.6 Safety devices

Safety devices ensure safe working with the machine.

- Do not change, bypass or disable safety devices.
- Regularly check safety devices for their correct function.
- Do not remove or obliterate labels and notices.
- Ensure that labels and notices are clearly legible.

Further information More information on safety devices is contained in chapter 4.5.

3.7 Service life of safety functions

Pursuant to ISO 13849-1:2015, Category and Performance Level (PL) of the machine's safety functions have been analyzed and assessed:

Safety function	Category	Performance Level
Safety shut-down due to excessive airend discharge temperature	2	b
EMERGENCY STOP push button	1	c

Tab. 47 Category and Performance Level

The safety-relevant components of the safety functions are designed for a working life of 20 years. The working life starts with the commissioning, and is not extended by times during which the machine was not in use.

3 Safety and Responsibility

3.8 Safety signs

The following components are affected:

- Resistance thermometer (Pt100 sensor with signal transducer for measuring the discharge temperature)
 - EMERGENCY STOP push button
 - Main contactor
1. The components of the safety functions must be replaced by an authorized KAESER service representative after a working life of 20 years.
 2. Have an authorized KAESER service representative check the reliability of the safety functions.

3.8 Safety signs

The graphics show the locations of the safety signs on the outside and inside of the machine. The table lists the various safety signs used and their meanings.

Safety signs outside




Fig. 4 Locations of safety signs on the outside of the machine

3 Safety and Responsibility

3.8 Safety signs

Location	Sign	Meaning
245	A yellow triangle containing a lightning bolt symbol.	<p>Electric voltage! Danger of fatal injury from contact with live electrical components.</p> <ul style="list-style-type: none"> ➢ Switch off the power supply at all poles. ➢ Lock out / tag out to secure them against being switched on again. ➢ Verify the absence of all voltage.
265	A yellow circle containing a silhouette of a person operating a machine.	<p>Personal injury or damage to the machine due to incorrect operation!</p> <ul style="list-style-type: none"> ➢ Read and understand the operating manual and all safety signs before switching on this machine.
310 311	A yellow circle containing a silhouette of a machine with a warning symbol over it.	<p>Injury or damage from open machine!</p> <ul style="list-style-type: none"> ➢ Operate the machine only when closed. ➢ Transport the machine only when closed.
330 331 332	A yellow triangle containing a wavy line symbol indicating heat.	<p>Hot surface can cause burns!</p> <ul style="list-style-type: none"> ➢ Let the machine cool down. ➢ Work carefully. ➢ Wear protective clothing and protective gloves. ➢ Do not inhale dangerous gases.
390 391	Two yellow triangles stacked vertically. The top one shows a person near rotating blades, and the bottom one shows a hand near a V-belt drive.	<p>Warning! Rotating fan blades and V-belt drive!</p> <p>Severe injury could result from touching the fan blades and V-belt drive while it is rotating.</p> <ul style="list-style-type: none"> ➢ Never switch the machine on without guard in place over the fan blade. ➢ Isolate completely from the power supply and ensure the supply cannot be switched on again.
430	A yellow circle containing an exclamation mark.	<p>Connect air hoses only in full compliance with OSHA standard 29 CFR 1926.302 (bX7)!</p> <p>The required safety devices should be tested in accordance with their manufacturer's recommendations to verify that they reduce pressure in case of hose failure and will not nuisance trip with the hose and tool combinations in use.</p>
440	A yellow circle containing a silhouette of a person breathing through a stethoscope.	<p>Compressed air quality!</p> <p>Injury and/or contamination can result from breathing compressed air. Contamination of food can result from using untreated compressed air for food processing.</p> <ul style="list-style-type: none"> ➢ Never breathe untreated compressed air! ➢ Air from this compressor must meet OSHA 29 CFR1910.134 and FDA 21 CFR178.3570 standards, if used for breathing or food processing. Use proper compressed air treatment. ➢ Food grade coolant must be used for food processing.

3 Safety and Responsibility

3.8 Safety signs

Location	Sign	Meaning
450		Loud noise and compressed air blast! Damage to hearing and injury if ball valve is opened without a compressed air hose being connected. ► Connect a suitable compressed air hose. ► Open the ball valve.
620		Pinch point hazard!
621		► Keep hands clear when opening the canopy.
1710 1711		Risk of injury caused by an automatic machine start! ► Switch off and lock out / tag out the «load isolating switch» of the machine and secure against unintentional reactivation before opening any doors.

Tab. 48 Safety signs

Safety signs inside




Fig. 5 Locations of safety signs on the inside of the machine




Fig. 6 Locations of safety signs on the inside of the machine (top view)

Location	Sign	Meaning
190		<p>Wrong cooling oil level! Risk of machine defects or rising oil consumption (oil content for pure air).</p> <ul style="list-style-type: none"> ➢ Check cooling-oil level. ➢ Run the machine only with proper cooling-oil level.
238		<p>Electric arc! Risk of fatal injury when disconnecting network supply line under load.</p> <ul style="list-style-type: none"> ➢ Switch off the machine. ➢ Wait until the drive motor stands still. ➢ Remove the plug connection.
240/241/242/243 244/245/246/247		<p>Electric voltage! Danger of fatal injury from contact with live electrical components.</p> <ul style="list-style-type: none"> ➢ Switch off the power supply at all poles. ➢ Lock out / tag out to secure them against being switched on again. ➢ Verify the absence of all voltage.
320		<p>Loud noise and oil mist when the safety relief valve opens! Ear damage and burns can result.</p> <ul style="list-style-type: none"> ➢ Wear ear protection and protective clothing. ➢ Close all maintenance doors and cover panels. ➢ Work carefully.
600 601		<p>Pressure and spring force! Risk of fatal injury caused by loosening, opening, or dismantling valves or other components that are under pressure or heavy spring loading.</p> <ul style="list-style-type: none"> ➢ Do not open or dismantle valves. ➢ Contact an authorized KAESER service representative in the event of a fault.

Tab. 49 Safety signs

3 Safety and Responsibility

3.9 Noise control requirements




Fig. 7 Position of safety signs on the control cabinet

- ① Manufacturer's safety sign
- ② Manufacturer's safety sign

3.9 Noise control requirements



Tampering with the noise control system is prohibited!

Federal law prohibits the following acts or causing thereof:

- The removal or rendering inoperative by any persons, other than for purposes of maintenance, repair, or replacement, of any devices or element of design incorporated into any new compressor for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use; or
- the use of the compressor after such device or element of design has been removed or rendered inoperative by any person.

Among those acts included in the prohibition against tampering are the acts listed below:

- Removing any facing (doors, hood, service panels).
- Modifying the air inlet and outlet louvers.
- Modifying the air intake channels or hoses (if applicable).
- Modifying the air filter enclosure.
- Modifying the exhaust air silencer.
- Manipulating the machine's control and regulation system.

3.10 Emergencies

3.10.1 Correct actions in the event of a fire

Suitable measures

Calm and prudent action can save lives in the event of a fire.

- Keep calm.
- Give the alarm.
- Switch off the machine from the instrument panel if possible.

3 Safety and Responsibility

3.10 Emergencies

- Make machine volt-free (disconnect from main) if possible.
- Warn and move endangered persons to safety.
- Help incapacitated persons.
- Close doors and covers.
- When trained accordingly: Attempt to extinguish the fire.

Extinguishing media

- Suitable extinguishing media:
Foam
Carbon dioxide
Sand or soil
- Avoid unsuitable extinguishing media:
Strong jet of water

3.10.2 Treating injuries from handling operating fluids/materials

The following operating fluids/materials are in the machine:

- Cooling oil
- Lubricating oils
- Lubricating greases

Eye contact:

Oil, greases and other fluids/materials can cause irritation.

- Rinse open eyes thoroughly for a few minutes under running water.
- Seek immediate medical advice for persistent irritation.

Skin contact:

Oil, greases and other fluids/materials may irritate after prolonged contact.

- Wash thoroughly with skin cleanser, then with soap and water.
- Contaminated clothing should be intensively cleaned before reuse.

Inhalation:

Oil mist may make breathing difficult.

- Clear air passages of oil mist.
- Seek immediate medical help if difficulty with respiration continues.

Ingestion:

- Wash out the mouth immediately.
- Do not induce vomiting.
- Seek medical aid.

3.11 Warranty

This operator manual contains no independent warranty commitment. Our general terms and conditions of business apply with regard to warranty.

A condition of our warranty is that the machine is used for the purpose for which it is intended under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

In addition, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- unauthorized modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of original spare parts and operating materials.

- Obtain confirmation from KAESER that your specific operating conditions are suitable.

3.11.1 Noise emissions warranty

The manufacturer warrants to the ultimate purchaser and each subsequent purchaser that this air compressor was designed, built, and equipped to conform, at the time of sale to the first retail purchaser, with all applicable American EPA noise control regulations.

This warranty is not limited to any particular part, component, or system of the air compressor.

Defects in the design, assembly, or in any part, component, or system of the compressor which, at the time of sale to the first retail purchaser, caused noise emissions to exceed Federal standards are covered by this warranty for the life of the air compressor.

3.12 Identifying the effects of improper modifications

The machine and various assemblies are designed according to applicable regulations and are submitted for approval procedures by the relevant authorities (where applicable).

Concerned assemblies include:

- Drive motor
- Compressor
- Pressure-bearing components (e.g., valves, vessels, piping)

Remodelling or modifications can have the result that the interaction of the individual assemblies according to regulations is no longer ensured. Thus, the prerequisites required for approval by authorities may no longer be given.

Examples of directives and regulations that may be applicable:

- Machine Directive
- Pressure Equipment Directive
- EMC Directive
- Directive on Noise Emission

Remodelling or modifications restrict the service work that can be performed for you (examples):

- Warranty (if directly and originally affected by the remodelling or modification)
- Reduced spare part supply (scope, delivery times)
- SIGMA CONTROL SMART:
Program changes result in a reduced capability of software updating.

3.13 Environmental protection

The operation of this machine may cause dangers for the environment.

- Do not allow operating materials/condensate to escape into the environment or into the sewage system!
- Store and dispose of all operating materials, condensate and replacement parts in accordance with applicable environmental regulations.
This applies particularly to cooling oil and parts contaminated with cooling oil or other fluids/materials.
- Observe relevant national regulations.

4 Design and Function

4.1 Bodywork

Bodywork is understood to be the exterior machine enclosure above the line of the base frame / skids.

The bodywork has several functions when it is closed:

- Weather protection
- Sound insulation
- Protection against touching
- Cooling air flow

Safe and reliable operation is ensured only when the bodywork is closed.

⚠ CAUTION

Pinch hazard!

Risk of injuries to fingers when closing doors and covers.

- *Work with caution.*
- *Always wear protective gloves.*




Fig. 8 Overview of bodywork

- | | |
|--|--|
| ① View of machine, left front side and front side
② View of machine, left front side and rear
③ Control panel cover for SIGMA CONTROL SMART
④ Door / cooling air inlet
⑤ Grill / cooling air
⑥ Skid
⑦ Door
⑧ Door
⑨ Step
⑩ Door / cooling air inlet | ⑪ Door
⑫ Door / cooling air outlet
⑬ Service cover
⑭ Crane lifting eye cover
⑮ Door
⑯ Door
⑰ Door
⑱ Door
⑲ Cable shaft |
|--|--|

The door locks must be unlocked with the control cabinet key fixed to the inside of the step. After unlocking, the doors can be swung open.

The bodywork is absolutely not suitable for the following uses:

- Persons walking, standing or sitting on the machine.
- Use as a resting place or storage of any kind of load.


4.2 Machine layout


Fig. 9 Example M250E, 175 hp, 400V/50Hz, Sigma 37.1

- | | |
|---|----------------------------------|
| [1] Lifting eye | [9] Minimum pressure check valve |
| [2] Oil separator tank | [10] Centrifugal separator |
| [3] Internal condensate collection tank | [11] Airend |
| [4] Connector box | [12] Oil filter |
| [5] Air filter | [13] Compressed air aftercooler |
| [6] Control cabinet | [14] Oil cooler |
| [7] Drive motor | [15] Safety relief valve |
| [8] Compressed air outlet butterfly valve | [16] Inlet valve |

4.3 Machine function

Machine function (without options).

Item numbers correspond to the pipe and instrument flow diagram (P&I diagram) in chapter 13.2.




Fig. 10 Example M250E, 132 kW, 400V/50Hz, Sigma 37.1

①	Air filter	⑯	Drive motor
③	Inlet valve	⑰	Oil cooler
④	Airend	㉑	Oil filter
⑤	Oil separator tank	㉒	Compressed air aftercooler
⑦	Oil separator cartridge	㉓	Centrifugal separator
⑩	Compressed air outlet butterfly valve	㉘	Fan wheel
⑬	Safety relief valve	㉗	Minimum pressure check valve

Air is drawn in from the surroundings via the two air filters ① and cleaned.

The air is then compressed in the airend ④.

The airend is driven by the electric drive motor ⑯.

Cooling oil is injected into the airend. It lubricates moving parts and forms a seal between the rotors and between the rotors and the housing. This direct cooling in the compression chamber ensures a very low airend discharge temperature.

Cooling oil separated from the compressed air in the oil separator tank ⑤ is cooled in the oil cooler ⑳. The cooling oil then flows through the oil filter ㉑ and back to the point of injection. The internal machine pressure keeps the oil circulating. A separate pump is not necessary. A thermostatic valve ⑲ regulates and optimizes the cooling oil temperature.

The oil-free compressed air subsequently reaches the compressed air treatment. The compressed air treatment consists of one compressed air aftercooler and one centrifugal separator.

The compressed air is cooled in the compressed air aftercooler to approximately 9°F to 18°F above the ambient temperature. Most of the moisture carried in the air is removed in the after-cooler.

The centrifugal separator sets the compressed air that still contains moisture into centrifugal motion via a swirl vane. The compressed air loses a significant proportion of its residual moisture load as a result of these centrifugal forces. The accumulating condensate falls to the bottom of the centrifugal separator.

A dirt trap with a condensate hose line is installed beneath the centrifugal separator. While the condensate flows through the dirt trap, existing dirt particles are retained. Subsequently, the condensate flows into the condensate hose line which leads to the condensate collection tank.

The moisture-reduced compressed air passes through the minimum pressure check valve (37) to the butterfly valve of the compressed air outlet. The minimum pressure check valve ensures that there is always a minimum internal pressure sufficient to maintain cooling oil circulation within the machine.

A separate electric fan motor supplies the drive power for the fan wheel (28). The flow direction of the fan wheel and arrangement of the cooling air inlet and outlet determine the cooling air flow of the machine within the enclosure. The cooling air continuously flows through the oil cooler. The heated cooling air returns through the cooling air outlet back into the surroundings.

4.4 Operating modes and control modes

4.4.1 Machine operating modes

The machine operates in the following modes:

- WARM-UP
 - Discharge temperature cold.
 - Switching the machine to LOAD mode blocked.
- IDLE
 - Discharge temperature warm.
 - Switching the machine to LOAD mode enabled.
- LOAD
 - The inlet valve is open.
 - The airend delivers compressed air.
- RUN-ON
 - Forced IDLE mode after switching off the motor from LOAD mode.
 - Run-on time is shown on the display of SIGMA CONTROL SMART.
- STANDSTILL
 - The inlet valve closes.
 - The venting valve opens to de-pressurize the machine.
 - The drive motor comes to a standstill.

4.4.2 PROPORTIONAL control mode

The control system regulates the volume of air generated to match the actual demand. The machine keeps the working pressure constant by continuously varying the volumetric flow rate within the machine's regulating range, independent of the air demand.

With the help of an electrical control valve (the proportional controller), the opening and closing of the inlet valve is continuously varied in response to the actual air demand. The airend provides compressed air for connected consumers.

This continuous delivery regulation minimizes the power consumption of the drive motor. The load and power consumption of the drive motor rise and fall with the air demand.

4.5 Safety devices

4.5.1 Monitoring functions with shut-down

SIGMA CONTROL SMART monitors important machine parameters. The machine is automatically shut down if an alarm occurs.

SIGMA CONTROL SMART saves the alarm message in the message memory.

Further information Further information on alarm messages at SIGMA CONTROL SMART is provided in chapter 9.2.1.

4.5.2 Further safety devices

The following safety devices are provided and may not be modified in any way.

- «EMERGENCY STOP» push button:
The «EMERGENCY STOP» push button is used for immediate shutdown of the machine. The drive motor comes to an immediate stop. The pressure system is vented.
- Safety relief valves:
Safety relief valves protect the system against unacceptable pressure rise. They are factory set.
- Enclosure and covers for moving parts and electrical connections:
Protect against accidental contact.

4.6 SIGMA CONTROL SMART control panel




Fig. 11 Overview of SIGMA CONTROL SMART control panel

04-M2847

Item	Symbol	Designation	Function	Indicator
1	-	Indicator field or display	Graphic display.	-
2		«Up» key and «Down» key	<ul style="list-style-type: none">■ Scroll upwards or downwards through the menu options.■ Enter settings.■ Change values.■ Switch between menu pages.	-

Item	Symbol	Designation	Function	Indicator
3		«Enter» key	<ul style="list-style-type: none"> ■ Opens the selected submenu. ■ Finishes an entry. ■ Activates an input. ■ Acknowledges/resets maintenance tasks. ■ Returns to the superordinate menu item (press quickly) ■ Exits the menu (press for at least 2 seconds) 	—
4		«LOAD/IDLE» key	Switches the compressor between LOAD and IDLE operating modes and vice versa.	Flashes when ready to switch to LOAD. Illuminates continuously when the machine is running in LOAD.
5		«STOP» key	<ul style="list-style-type: none"> ■ Stops the machine. ■ Acknowledges/resets maintenance tasks. 	
6		«START» key	Starts the machine.	Flashes when ready to start. Illuminates continuously when the drive motor is running.

Tab. 50 Control unit keys and indicators

Further information For more information about the functionality of the controller, please see the separate SIGMA CONTROL SMART operating manual.

4.7 Draining the cooling oil and condensate

A central drain device for cooling oil and condensate is attached to the front side of the machine. The drain device is easily accessible for service personnel.

All shut-off valves of the drain device are clearly arranged in one row:

- Condensate (external)
- Cooling oil of the machine

In addition, each shut-off valve is marked with a specific symbol, see Fig. 12.

4 Design and Function

4.8 Draining condensate according to operating conditions




Fig. 12 Drain device - symbols and arrangement of shut-off valves

- | | | | |
|-----|-----------------------|-----|-------------|
| [1] | Drain device | [4] | Cooling oil |
| [2] | Condensate (external) | [5] | Cooling oil |
| [3] | Cooling oil | [6] | Cooling oil |

4.8 Draining condensate according to operating conditions

When you operate the machine, especially if the ambient air is very humid, significant amounts of condensate will precipitate.

Depending on operating conditions, the accumulated condensate can be drained off in an environmentally compliant way by manually operating a directional control valve:

- Short-term operation
 - Using the internal condensate collection tank with small capacity
 - Lever of directional control valve set to “/”
- Continuous operation
 - Using the external condensate collection tank with large capacity
 - Lever of directional control valve set to “//”

Position “/” for short-term operation and position “//” for continuous operation, see chapter 7.7, Fig. 23.



A drain device for condensate (external drainage) and cooling oil is installed on the front side of the machine, see Fig. 12. All shut-off valves are marked with specific symbols.

Use the corresponding hose to connect to an external condensate collection tank with a large capacity.

Further information Install components for the external condensate drain device, see chapter 6.5.

4.9 Options

The options available for your machine are described below.

4.9.1 Air treatment

4.9.1.1 Option dd Filter combination

To obtain oil-free compressed air, the dried compressed air passes through a pre-filter and micro-filter combination and emerges oil-free and free from solid particles.




Fig. 13 Filter combination

- | | |
|-------------------------|---|
| ① Centrifugal separator | ⑤ Condensate drain shut-off valves |
| ② Filter combination | ⑥ Minimum pressure check valve |
| ③ Prefilter | ⑦ Compressed air outlet butterfly valve |
| ④ Fine filter | |

4.9.2 Option ba Auxiliary heater

An electric auxiliary heater is installed in the machine to prevent damages to the airend when the machine is started at low ambient temperatures. The electric auxiliary heater preheats the interior of the machine while the drive motor is in standstill mode. The auxiliary heater consists of several radiators that are switched on and off by means of thermostats.

Application cases for the auxiliary heater:

- Pre-heating the machine's interior during start-up.
- Continuous temperature set-point value in the machine's interior during automatic operating modes, e.g. automatic start/stop.

The machine's interior is continuously kept at a temperature set-point value, see Table 51.

Machine interior	Value
Temperature set-point value [°F]	41

Tab. 51 Temperature set-point value

NOTICE

Damage to the airend caused by cold start of machine

- *Pre-heat the machine's interior by means of the auxiliary heater in times of low ambient temperatures.*
- *Only start the machine when the machine's interior has sufficiently pre-heated.*




Fig. 14 Electric auxiliary heater

- ① Auxiliary heater
- ② Radiator

4.9.3 Automatic operating modes

Overview:

- Automatic start/stop option
 - Floating contacts
- DUAL control option
 - Measuring point connection

4.9.3.1 Option ob Start/stop control



The start/stop control is an automatic operating mode in which a master control system with remote contact demands compressed air from the machine controller.

After the start signal from the master controller has been received, the machine starts automatically. The machine runs through the warm-up phase and automatically switches to LOAD operation.

Further information For setting the start/stop control at the machine controller, see the SIGMA CONTROL SMART operating manual.

Option ob Floating contacts

Floating contacts are provided for the transfer of signals/messages. Information on location, loading capacity and type of message or signal can be found in the wiring diagram.

4.9.3.2 Option cd

DUAL Control



DUAL control is a control mode that automatically starts the machine and controls the flow rate. When no consumer demands air, the machine is automatically shut down.

When DUAL control is activated and the pressure falls below the cut-in pressure, the SIGMA CONTROL SMART starts the machine. As soon as the specified airend discharge pressure is attained, SIGMA CONTROL SMART switches the machine to LOAD.

SIGMA CONTROL SMART starts the run-on time when the specified cut-out pressure is reached. In run-on time, the machine continues to run in LOAD mode to level the compressed air demand for the application.

Upon expiration of the run-on time, SIGMA CONTROL SMART switches the machine to IDLE. The machine cools down during unloaded IDLE operation. If, during this time, the compressed air pressure lies above the cut-in pressure, SIGMA CONTROL SMART switches the machine to READY (the drive motor stands still).

As soon as the internal machine pressure is reduced and the time set for the restart inhibitor is expired (in consideration of the maximum starting frequency of the drive motor), SIGMA CONTROL SMART again allows restarting. If, after allowing a restart, the compressed air pressure drops below the cut-in pressure, the machine immediately switches to LOAD.

Further information For setting the DUAL control at the machine controller, see the SIGMA CONTROL SMART operating manual.

Option cd Measuring point connection

An additional hose coupling has been installed at the machine enabling measurement of the network pressure of the external compressed air system. This hose coupling is fitted with a directional control valve and a pressure transducer at the machine end.


The hose coupling is located on the right next to the butterfly valve of the compressed air outlet, see Fig. 15.

An information sign ② indicates the meaning of the two different positions of the directional control valve.

Selecting the measuring point using the directional control valve:

Measurement point	Machine pressure at compressed air outlet	Network pressure
Directional control valve	Position p5	Position pN

Tab. 52 Set the measuring point using the directional control valve



Fig. 15 Measuring point connection

- | | |
|---|--|
| <input type="checkbox"/> ① Compressed air outlet butterfly valve
<input type="checkbox"/> ② Directional control valve information sign
<input type="checkbox"/> ③ Directional control valve | <input type="checkbox"/> ④ Pressure transducer
<input type="checkbox"/> ⑤ Hose coupling |
|---|--|

4.9.4 Option oc GSM/GPS unit

The machine is equipped with a GSM/GPS unit. This can be equipped with a SIM card and serves for connection to the MOBILAIR fleet management system.

The GSM/GPS unit has only indicating functions.


Fig. 16 Location of the GSM/GPS unit inside the machine

- | |
|---|
| <input type="checkbox"/> ① Modem
<input type="checkbox"/> ② Antenna
<input type="checkbox"/> ③ Signal cable |
|---|

4.9.5 Document bag

The document bag is used to store important accompanying documents for the machine safely (and to keep them clean) within the machine. This ensures that operating personnel always, and at any location, has access to the accompanying documents of the portable machine.



The document bag is not part of the standard equipment. It can be optionally selected!

Example for accompanying documents of machine:

- Machine's Operating Manual.
- User Manual of SIGMA CONTROL SMART.

Position the document bag inside the machine, see the below figure.




Fig. 17 Document bag option

- ① Document bag
- ② Rear of the machine
- ③ Location of document bag within the machine

5 Installation and Operating Conditions

5.1 Ensuring safety

The conditions in which the machine is installed and operated effect the safety of personnel and surroundings.

Warning instructions are located directly at a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

Compliance with safety instructions

Ignoring safety warnings can cause unforeseeable dangers!

- Strictly forbid fire, open flame and smoking.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting oil vapors or parts of the machine.
- Do not store flammable material in the vicinity of the machine.
- The machine is not explosion-proof:
Do not operate in areas in which specific requirements with regard to explosion protection are in force.
- Keep suitable fire extinguishing agents on hand and ready for use.
- Ensure that required ambient conditions are maintained.

Required ambient conditions may be:

- Ambient temperature
- Air composition at the installation site:
 - clean with no damaging contaminants (e.g., dust, fibers, fine sand)
 - free of explosive or chemically unstable gases or vapors
 - free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulfide

5.2 Installation conditions

Comply with the corresponding installation conditions at each installation location to ensure safe operation of the machine.



This machine is designed for a stationary installation.

⚠ CAUTION

Fire hazard because of heat build-up!

Insufficient distance to walls may well cause heat build-up that could damage the machine.

- *Do not position the machine directly against a wall.*
- *Check that there sufficient space around the machine for inlet and exhaust air.*

- Comply with all instructions!

5.2.1 Note the conditions for stationary installation

Overview:

- Installation location and condition of floor
- Preconditions for sufficient flow of cooling air
- Comply with the minimum distance to other machines

Installation location and condition of floor

Precondition A level surface must be available at the installation location
The ground must be firm and capable of bearing the corresponding weight of the machine.




Fig. 18 Minimum distances from excavations/slopes/walls

- ① Excavations
- ② Slope

1. Keep sufficient distance (at least 5 feet) from the edges of excavations and slopes, see Fig. 18.
2. Ensure that the machine is as level as possible.

Temporarily, the machine may also be operated in an inclined position, see table 53.

Setting up the machine	Value
Maximum inclined position [degree]	15

Tab. 53 Maximum inclined position

3. Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.

5.2 Installation conditions

Preconditions for sufficient flow of cooling air




Fig. 19 Flow of cooling air inside the machine

- | | | | |
|---|--|---|-------------------------|
| ① | View of machine; left front side / front side | ④ | Cooling air grill |
| ② | View of machine; right front side / front side | ⑤ | Cooling air inlet door |
| ③ | Cooling air inlet door | ⑥ | Cooling air outlet door |

1. Keep cooling air inlet and outlet openings free of obstructions so that the cooling air can flow freely through the machine.
2. Keep sufficient distance (at least 5 ft) from the walls.
3. Do not allow wind to blow into the cooling air outlet.
4. Heated cooling air must not be drawn into the machine.

Comply with the minimum distance to other machines



When you set up several machines it is particularly important to ensure that heated cooling air from one machine is not drawn in to another machine. The cooling air outlet of one machine must never be positioned in front of the cooling air inlet opening of another machine.




Fig. 20 Minimum distance if several machines are set up

- | | | | |
|---|------------------------|---|------------------------|
| ① | Cooling air grill | ③ | Cooling air inlet door |
| ② | Cooling air inlet door | ④ | Minimum distance |

1. Align the rear of the machine to be set up parallel to the front side of the machine that has already been set up.

2. Keep the minimum distance to the machine that has already been set up, see Figure 20.
The fan wheel of the machine can draw in sufficient quantities of cool ambient air through all cooling air inlet openings.
The fan wheel of the machine can blow out the heated cooling air from the machine's interior through the cooling air outlet without any obstructions.

5.2.2 Comply with the specified ambient temperature

1. **NOTICE** *Ambient temperature too low!*
Frozen condensate and highly viscous compressor oil can cause damage when starting the machine.
➤ *Use low viscosity compressor oil.*
2. At ambient temperatures below 32 °F, follow the instructions in chapter 7.8.

6 Installation

6.1 Ensuring safety

Here you will find instructions for a safe installation of the machine.

Warning instructions are located directly at a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

Compliance with safety warnings

Ignoring safety warnings can cause unforeseeable dangers!

- Follow the instructions in chapter 3 'Safety and Responsibility'.
- Installation work may only be carried out by authorized personnel.

When working on live components

Touching voltage carrying components can result in electric shocks, burns or death.

- Installation work on electrical equipment may be carried out by authorized electricians only.
- Switch off and lock out / tag out the power supply disconnecting device.
- Verify the absence of any voltage.
- Check that the floating relay contacts are voltage-free.

Further information Details of authorized personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

6.2 Reporting Transport Damage

1. Check the machine for visible and hidden transport damage.
2. Inform the carrier and the manufacturer in writing of any damage found.

6.3 Securing the parked machine



Bolt-down machine feet and rubber pads are **not** part of the standard equipment. These items can be optionally selected!

For safe footing, the machine can be secured with bolt-down machine feet.

6 Installation

6.3 Securing the parked machine

Material	Bolt-down machine feet (anti-vibration elements) Fastening screws Wrench
Precondition	The machine is switched off. «Load isolating switch» of the machine set to position <i>OFF</i> , «Load isolating switch» is locked off, «Controller ON/OFF» switch set to position <i>OFF</i> , Absence of voltage has been verified. The machine is installed on level ground, the machine has cooled down. The butterfly valve at the compressed air outlet is open, the machine is fully vented, pressure gauge reads 0 psig!

6.3.1 Fitting the machine feet

The support frame of the machine is provided with holes for fitting bolt-down machine feet (see dimensional drawing in chapter 13.3 for the location of these holes).

You may use rubber pads instead of the machine feet if the machine is placed on or bolted to surfaces not subject to acceleration.




Fig. 21 Mounting machine foot/rubber pad

- | | | | |
|-----|---|-----|---|
| [1] | Machine's support frame (skid) | [4] | Washer |
| [2] | Machine foot/rubber pad installation detail | [5] | Bolt-down machine foot (anti-vibration element) |
| [3] | Hexagon bolt | [6] | Rubber pad (for static installation only) |

1. Position the bolt-down machine feet underneath the corresponding drilled hole of the skid.
2. Fit the washer to the hexagon bolt.
3. Insert the hexagon bolt through the drilled hole of the longitudinal support.
4. Install the hexagon bolt in the thread of the machine foot.
5. Tighten the hexagon bolt.
6. Install and tighten the other machine feet analogously.

6.4 Electrical connection

6.4.1 Network Conditions

This machine is designed for the operation in an industrial environment with proprietary power supply network separated from the public supply by a transformer or generator. The operator must ensure that this machine is connected only to a power supply network that meets these conditions.

- Ensure that the power supply network meets these requirements.

6.4.2 Power supply disconnecting device



The power supply disconnecting device and its correct on-site installation is not part of the delivery scope of the machine. Accordingly the manufacturer of the machine is not responsible for the correct installation of a suitable power supply disconnecting device; rather, it is the responsibility of the machine operator.

1. Determine technical data for the design of an on-site power supply disconnecting device according to applicable country-specific regulations and guidelines.

Scope of application	Country-specific regulations and guidelines
Europe	EN60204-1: 2018. 5.3
USA/Canada	NFPA 79

Tab. 54 On-site power supply disconnecting device

2. The suitable on-site power supply disconnecting device must be installed by authorized installation personnel or authorized certified electricians only.

Further information An authorized KAESER service representative can provide you with detailed information concerning the design or installation of a suitable power supply disconnecting device for your machine.

6.5 Using the external condensate collection tank

To avoid interruptions during operation it is recommended to use an external condensate collection tank with a large capacity when running the machine in continuous operation.

The machine is already prepared with a condensate drain device:

- Directional control valve inside the machine.
- The shut-off valve for condensate on the drain device is installed on the front of the machine.



The following components must be provided by the customer:

- External condensate collection tank with large capacity
- Male hose coupling with suitable hose

6 Installation

6.5 Using the external condensate collection tank




Fig. 22 Drain device - symbols and arrangement of shut-off valves

1. Position external condensate collection tank next to the machine.
2. Loosen and remove the screw plug ②.
3. Install the male hose coupling with a suitable hose on the shut-off valve ② on the drain device.
4. Route the open end of the hose into the external condensate collection tank and secure it in place.

Result The machine is prepared for continuous operation with an external condensate collection tank.

Further information Set the directional control valve and shut-off valve of the drain device, see chapter 7.7.

7 Initial Start-up

7.1 Ensuring safety

Here you will find instructions for safe commissioning of the machine.

Warning instructions are given prior to a potentially dangerous task.



Disregard of warning instructions can result in life-threatening injuries!

Observing safety warnings

Ignoring safety warnings can cause unforeseeable dangers.

- Follow the instructions in chapter 3 "Safety and Responsibility".
- Commissioning tasks may only be carried out by authorized installation personnel!
- Make sure that no one is working on the machine.
- Ensure that the enclosure and all panels are closed.

When working on live components

Touching voltage carrying components can result in electric shocks, burns or death.

- Work on electrical equipment may only be carried out by authorized certified electricians.
- Switch off and lock out / tag out the on-site / customer's power supply disconnecting device and verify the absence of voltage.
- Check that there is no voltage on floating contacts.

Working on the pressure system (the machine provides compressed air for connected consumers)

Compressed air is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following safety instructions relate to any work on components that could be under pressure.

- Close shut-off valves or otherwise isolate the machine from the compressed air network to ensure that no compressed air can flow back into the machine.
- Disconnect the compressed air consumers.
- Fully vent all pressurized components and enclosures.
- Check that individual components are in vented state.
- Do not open or dismantle any valves.

Working on the pressure system (the machine provides compressed in the compressed air system)

Compressed air is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following safety instructions relate to any work on components that could be under pressure.

- Close shut-off valves or otherwise isolate the machine from the compressed air network to ensure that no compressed air can flow back into the machine.
- Fully vent all pressurized components and enclosures.
- Check that individual components are in vented state.
- Do not open or dismantle any valves.

When working on the drive system

Touching voltage carrying components can result in electric shocks, burns or death. Touching the fan wheel, the coupling or the belt drive while the machine is switched on can result in serious injury.

- Switch off and lock out / tag out the on-site / customer's power supply disconnecting device and verify the absence of voltage.
- Do not open the enclosure while the machine is switched on.

Further information Information regarding authorized personnel can be found in chapter 3.4.2.
Information regarding dangers and their avoidance can be found in chapter 3.5.

7.2 Before initial start-up (or recommissioning)

Incorrect or improper commissioning can cause injury to persons and damage to the machine.

7.2.1 Instructions to be observed before commissioning or recommissioning



The initial start-up of every machine takes place at the factory. Every machine is also given a trial run and passes a careful check.

- Commissioning may only be carried out by authorized installation and service personnel who have been trained on this machine.
- Remove all packing materials on and in the machine.
- Observe the machine during the first few hours of operation to ensure that it is operating correctly.

7.3 After storing the machine for a long period

- Carry out the following before every re-commissioning after a long period of storage.

Storage period longer than:	Action
5 months	<ul style="list-style-type: none"> ➢ Remove the desiccant from the openings in the air intake filters. ➢ Check the air and oil filters. ➢ Drain the preserving oil from the separator tank. ➢ Fill with cooling oil. ➢ Check all compressor oil lines for leaks, loose connections, wear and damage. ➢ Clean the bodywork with a grease and dirt dissolving agent.
12 months	<ul style="list-style-type: none"> ➢ Change motor bearings. ➢ Change the bearing grease.
36 months	<ul style="list-style-type: none"> ➢ Have the overall technical condition checked by an authorized KAESER service representative.

Tab. 55 Measures for re-commissioning the compressor after a long period of storage

7.4 Setting the overload relay

See Wiring Diagram, chapter 13.4 for information on set points for the overload relay.

During the system operation, the phase current is fed via the overload relay. This phase current is 0.58-times the rated drive motor current in the delta configuration.

To prevent the overload relay being triggered by voltage fluctuations, temperature influences or component tolerances, the setting can be higher than the arithmetical phase current.

- Check the settings of the overload relay.



The overload relay shuts the machine down despite being correctly set?

- Contact an authorized KAESER service representative.

7.5 Setting the motor overload protection switch

See Electrical Diagram, Chapter 13.4 for information on setting values for the motor overload protection switch.



To prevent the motor overload protection switch from being triggered by voltage fluctuations, temperature influences or component tolerances, the setting can be higher than the rated motor current.

- Check the motor overload protection switch setting.



The overload protection switch shuts the machine down despite being correctly set?

- Contact an authorized KAESER service representative.

7.6 Setting the voltage measuring relay

See Wiring Diagram, chapter 13.4 for information on set points for the voltage measuring relay.

The voltage measuring relay monitors a three-phase network for the following faults:

- Low voltage
- High voltage
- Phase loss
- Phase sequence

In the event of one or several of these faults, SIGMA CONTROL SMART creates a fault message.

- If necessary, have a certified electrician check the connection on site.



The voltage measuring relay shuts the machine down despite being correctly set?

- Contact an authorized KAESER service representative.

7.7 Draining condensate according to operating conditions

Prior to starting the machine, the directional control valve of the condensate drain must be set according to operating conditions.

Overview:

- Short-term operation
 - Lever of directional control valve set to “I”
 - Shut-off valve in the area of the drain device is closed
 - The condensate drains into the internal condensate collection tank
- Continuous operation
 - External hose connection is installed
 - Lever of directional control valve set to “II”
 - Shut-off valve in the area of the drain device is open
 - The condensate drains into the external condensate collection tank



The following figure shows the machine without the side door at the cooling air inlet.




Fig. 23 Draining condensate internally/externally

- | | |
|--|--|
| [1] Machine | [5] Lever |
| [2] Compressed air aftercooler | [I] Position for draining condensate internally |
| [3] Directional control valve position | [II] Position for draining condensate externally |
| [4] Directional control valve | |

- Make decision according to operating conditions!

Draining condensate internally	Draining condensate externally
<ol style="list-style-type: none"> 1. Open the door. 2. Set lever of directional control valve set to “I”. 3. Check to ensure that the shut-off valve in the area of the drain device is closed. 4. If required, close the shut-off valve in the area of the drain device. 5. Close the door. 	<ol style="list-style-type: none"> 1. Open the door. 2. Set lever of directional control valve set to “II”. 3. Check to ensure that the shut-off valve in the area of the drain device is open. 4. If required, open the shut-off valve in the area of the drain device. 5. Close the door.

7.8 Low-temperature operation (winter)

During times of low ambient temperatures, low viscosity compressor oil facilitates the machine start. Short compressed air hoses reduce the risk of freezing of air tools.

1. Use low viscosity compressor oil.
2. Use short compressed air hoses.

7.8.1 Option ba

Following the pre-heating time of the auxiliary heater



To reach a suitable temperature set-point value in the machine's interior when the ambient temperature is low, the machine requires a certain time to pre-heat.

Examples for the minimum pre-heat times of the electrical auxiliary heater:

Ambient temperature [°F]	Temperature set-point value Airend [°F]	Minimum pre-heat time tempera- ture [h]
-13	14	2.5
	23	4.5

Tab. 56 Example of pre-heat time for the electrical auxiliary heater

NOTICE

Damage to the airend caused by cold start of machine

- Pre-heat the machine's interior by means of the auxiliary heater in times of low ambient temperatures.
- Only start the machine when the machine's interior has sufficiently pre-heated.

Pre-heating the machine's interior

1. Switch on the «load isolating switch».

The auxiliary heater is switched on if the «load isolating switch» is switched on.

2. Do **not** start the machine.

3. Mark the machine clearly with the following information sign:

Machine is energized.

The «load isolating device» is switched on.

The machine's interior is pre-heated by means of the auxiliary heater.

Do **not** start the machine.

Tab. 57 “Do not start the machine” information sign

4. The auxiliary heater is switched on by complying with the minimum pre-heat time.

Initiating the starting procedure

Precondition The minimum pre-heat time has been reached,
The machine's interior is sufficiently pre-heated.

1. Remove the information sign "Do not start machine" after the minimum pre-heat time has been reached.
2. Initiate the starting procedure, see chapter 8.3.

7.9 Note the automatic operating modes

Overview:

- Start/stop/automatic option
 - DUAL control option
- Follow all instructions.

7.9.1 Option ob

Note the automatic start/stop

If your machine is connected to a master control system and is equipped with the automatic start/stop option, this machine can be operated in the start/stop automatic operation mode.

A safety sign on the machine points out the automatic starting of the machine, see illustration in Table 58. Position of the safety sign on the machine, see Chapter 3.8.

Option	Safety sign
Start/stop automatic	
—	—

Tab. 58 Safety sign for automatic starting

1. Check whether there is a safety sign for automatic starting on the machine.
2. Inform operators regarding automatic starting of machine.

Further information Observe start procedure for machine with automatic start/stop option, see Chapter 8.11.1.
Operate machine with automatic start/stop or in manual mode, see operating manual for SIGMA CONTROL SMART.

7.9.2 Option cd

Note the DUAL control

If your machine is equipped with the DUAL control option, you can operate this machine in automatic DUAL control mode.

A safety sign on the machine points out the automatic starting of the machine, see illustration in Table 59. Position of the safety sign on the machine, see Chapter 3.8.

Option	Safety sign
DUAL control	
—	—

Tab. 59 Safety sign for automatic starting

1. Check whether there is a safety sign for automatic starting on the machine.
2. Inform operators regarding automatic starting of machine.

Further information

Observe the start procedure for a machine with DUAL option, see Chapter 8.11.1.

Operate the machine with DUAL control or in manual mode, see the SIGMA CONTROL SMART operating manual.

8 Operation

8.1 Ensuring safety

Follow the instructions below for safe operation.

Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

Complying with safety warnings

Disregard of safety warnings can cause unforeseeable dangers!

- Follow the instructions in chapter 3 "Safety and Responsibility".
- Make sure that no one is working on the machine.
- Ensure that all service doors and panels are closed and secured.

Preventing accidental contact

Intensely heated, rotating, or electrically-live components can cause severe injuries.

- Ensure that all doors, canopy and panels are closed.
- Do not carry out any checks or settings while the machine is running.
- Shut down the machine before opening any doors/canopy.

When working on live components

Touching voltage-carrying components can result in electric shocks, burns or death.

- Work on electrical equipment may only be carried out by authorized electricians.

Safe working with compressed air tools and hoses

Open pressurized compressed air hoses move erratically and can cause serious injury to people.

- Pressurize compressed air hoses only after the tool has been connected.
- Do not pressurize open compressed air hoses.
- Detach compressed air hoses only after the hose has been purged of compressed air.
- At working pressures >100 psig, compressed air hoses should be secured by a cable to their respective outlet valves.

Condensate formation in compressed air hoses

Use the shortest possible compressed air hoses to minimize the temperature difference between the machine's compressed air outlet and the air tool. The hose length represents a cooling section. With increasing cooling, the compressed air gives off moisture capable of damaging the air tool.

- Use short compressed air hoses.

Condensate formation in compressed air receivers

Compressed air stored in a containers will cool down. The compressed air precipitates moisture that collects at the container's bottom. Corrosion may damage the container.

- Regularly drain the condensate.

Further information	Details of authorized personnel are found in chapter 3.4.2. Details of dangers and their avoidance are found in chapter 3.5.
---------------------	---

8.2 Observing environmental impacts

To ensure safety on the building site, the following environmental impacts must be observed separately:

- Thunderstorms
- Low ambient temperatures
- Comply with all instructions!

8.2.1 Environmental impact: thunderstorm

Due to its metallic design, the machine is particularly at risk for lightning strike during a thunderstorm. It is absolutely necessary that any persons avoid the immediate danger area around the machine when a thunderstorm is imminent.

Appropriate protection is provided by vehicles with a roof (Faraday cage).

1. **⚠ WARNING** *Lightning strike during thunderstorm*
 - *Avoid the danger area around the machine.*
 - *Get into suitable vehicles.*
2. Enter buildings with lightning conductor.

8.2.2 Environmental impact: low temperature

Overview:

- Remove snow and/or ice from the machine.
- Check the function of the «EMERGENCY STOP» push button.

Considerable snow or ice may build up on the machine under low temperature conditions.

- Remove any snow and ice from the machine before operating.

The mechanical function of the «EMERGENCY STOP» push button may be impaired under low temperatures.

1. **⚠ WARNING** *«EMERGENCY STOP» push button jammed!*
The machine cannot be stopped quickly in an emergency.
 - *Check the function of the «EMERGENCY STOP» push button.*
 - *Do not operate the machine if the «EMERGENCY STOP» push button does not work.*
2. Push the «EMERGENCY STOP» push button.
The «EMERGENCY STOP» push button cannot be pressed or does not engage.
The «EMERGENCY STOP» push button is frozen.
3. Defrost the «EMERGENCY STOP» push button.

4. Disengage «EMERGENCY STOP» key.



The «EMERGENCY STOP» push button still does not function after defrosting.

- Have an authorized KAESER service representative replace the «EMERGENCY STOP» push button.

8.3 Switching on the machine

Overview:

- Connect the power supply cable
- Overview of fittings:
 - SIGMA CONTROL SMART operating unit
 - Compressed air outlet pressure gauge
 - «EMERGENCY STOP» push button
- Prepare the machine to start
- Switch on the drive motor
- Allow the machine to warm up
- Switch the machine to LOAD operation

- Follow all instructions carefully.

8.3.1 Connecting the power supply cable

There are two plug-in connections in the same color variant for each phase and GRD. Always connect both plug-in connections of the same color variant for each phase and GRD.

Precondition	Local power supply is available. On-site CAM-LOK plug-in connection system is professionally designed and installed, see chapter 13.6. On-site power supply disconnecting device is professionally installed. The electrical connection has been inspected (clockwise rotation), see Commissioning. The «Load isolating switch» of the on-site power supply disconnecting device is switched off at all poles.
--------------	--




Fig. 24 Machine cable shaft

- ① Left end side of machine
② Cable shaft

- ③ CAM-LOK plug-in connection system
④ Rear side of machine

1. Insert power supply cable through the cable shaft.
2. Open the door/s.
3. Pull the power supply cable into the machine's interior.




Fig. 25 Connecting the plug-in connection system

- ① CAM-LOK plug-in connection system inside the machine
- ② Compatible customer-provided plug-in connection system
- ③ Dual implementation for each phase and GRD

1. Connect all customer-provided plugs to the CAM-LOK plug-in connection system inside the machine.


Color coding	
Color	Phase/GRD
Yellow	L3
Black	L2
Brown	L1
Green	GRD

Tab. 60 Color coding L1, L2, L3, GRD

2. Close the door/s.

8.3.2 Overview of fittings


Compressed air outlet pressure gauge, SIGMA CONTROL SMART operating unit and «Controller ON/OFF» switch are located behind the control panel cover.



08-M2843-25xE

Fig. 26 Arrangement of SIGMA CONTROL SMART operating unit and fittings

- | | |
|---|--|
| [1] Control panel cover closed | [6] SIGMA CONTROL SMART operating unit |
| [2] Control panel cover open | [7] SIGMA CONTROL SMART display |
| [3] SIGMA CONTROL SMART control panel cover | [8] «Menu bar navigation» keys |
| [4] «EMERGENCY STOP» push button | [9] «Operating mode» keys |
| [5] Compressed air outlet pressure gauge | [10] «Controller ON/OFF» switch |



08-M2854

Fig. 27 SIGMA CONTROL SMART operating unit keys and displays

- | | |
|---------------------------|-------------------------------------|
| [10] «Up» and «Down» keys | [a] Controller voltage ON indicator |
| [11] «Enter» key | [b] READY indicator (flashes) |
| [12] «LOAD/IDLE» key | [16] Menu bar |
| [13] «OFF» key | [c] Settings menu indicator |
| [14] «START» key | [17] Navigation menu indicator |
| [15] Status bar | |

➤ Memorise this information.


8.3.3 Preparing the machine to start

1. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
2. Open the control panel cover of the SIGMA CONTROL SMART.
3. Turn the «Controller ON/OFF» switch to the “ON” position.

The controller voltage for the SIGMA CONTROL SMART is switched on.

If there is no error message, the following operating data/states are indicated on the SIGMA CONTROL SMART display:

- Operating data
 - Airend discharge temperature
 - Operating hours
- Operating states
 - Drive motor *Ready* symbol
 - The *READY* indicator flashes green.



08-M2921

Fig. 28 Ready indicator display

- | | | | |
|---|------------------------------|---|------------------------------|
| ① | SIGMA CONTROL SMART display | ④ | Ready symbol |
| ② | Airend discharge temperature | ⑤ | Controller voltage ON status |
| ③ | Operating hours | ⑥ | READY status (flashes green) |

4. Check if the status *Ready* is indicated on the status bar of the SIGMA CONTROL SMART.

The machine is ready to start.



The machine is not ready to start / error messages are indicated on the SIGMA CONTROL SMART display.

- Read error messages.
- Rectify cause while observing operational safety.

8.3.4 Switching on the drive motor

Precondition Nobody is working on the machine

All doors/covers are closed

- Press «START» key on the SIGMA CONTROL SMART operating panel.
The machine's drive motor starts up.
The *READY* indicator on the SIGMA CONTROL SMART display (status bar) illuminates continuously in green.

8.3.5 Running up the machine to operating temperature

After the drive motor has started, the machine initially runs through the WARM-UP PHASE. In the WARM-UP PHASE, the machine is brought to the working temperature in an unloaded state.

1. Allow the machine to run in the WARM-UP PHASE.
The machine warms up unloaded.
2. Wait until the setpoint for the airend discharge temperature has been reached.

Result The machine switches to IDLE operation.

Result The machine has warmed up unloaded and is ready to switch to LOAD operation.

8.3.6 Switching the machine to LOAD operation

Precondition A compressed air hose is connected to the butterfly valve on the compressed air outlet.

1. Press the «LOAD/IDLE» key on the operating panel of the SIGMA CONTROL SMART.
The machine switches to LOAD operation.
2. Open the butterfly valve on the compressed air outlet.

Result The machine delivers compressed air.

8.4 Setting the compressed air discharge pressure

The compressed air discharge pressure can be modified only when this option is activated in the machine controller.

(See also the separate user manual for SIGMA CONTROL SMART.)

The compressed air discharge pressure (nominal pressure) can be set when the drive motor is in standstill (SIGMA CONTROL SMART switched on) or during operation (with the machine running).

- The pressure can only be set lower than the nominal working pressure of the machine.
- You can adjust the settings in increments of 0.1 bar or 1 psi.
- The adjustment is displayed.

CAUTION

Danger from incorrectly set pressure!

Danger from malfunctioning or not functioning compressed air tools when the machine's discharge pressure is set incorrectly.

- *Use connected compressed air tools only with the pressure appropriate for its purpose (tool working pressure).*
- *Comply with the information and notes provided in the compressed air tool's operating instruction.*

The Settings menu for the compressed air discharge pressure can be reached in two ways:

- Quick access from the main menu
- Access via menu structure

Precondition Controller (SIGMA CONTROL SMART) is switched on

The pressure adjustment option is enabled

- Select the access type.

Quick access from the main menu:




Fig. 29 Quick access adjustment compressed air output pressure

- ① Compressed air discharge pressure setting symbol
- ② Setting value

1. Press «UP» or «DOWN» key for more than two seconds and release.
The display immediately jumps to the line for "Setting the compressed air discharge pressure".
The Settings menu has a flashing frame.
2. Press the «UP» and/or «DOWN» keys to select the required pressure.
The set value for the compressed air discharge pressure is immediately active and remains saved.
3. Press «Enter».
The frame disappears.
4. Press «Enter».
Jump back to the menu bar, the "Main menu" symbol receives a black background.

Access via menu structure:

Precondition The Settings menu (hand symbol) is selected.




Fig. 30 Setting the compressed air discharge pressure

- ① Adjustment compressed air discharge pressure
- ② Setting value

1. Press «down» for a short time.
The "Setting compressed air discharge pressure" line is framed.
2. Press «Enter».
The frame flashes and thus signals that input is possible.
You can set the required compressed air discharge pressure.
3. Press the «UP» and/or «DOWN» keys to select the required pressure.
The set value for the compressed air discharge pressure is immediately active and remains saved.

4. Press «Enter».

The frame stops flashing.

5. Press «Enter» for at least two seconds.

Jump back to the menu bar, the "Settings menu" symbol receives a black background.

or:

1. Press «UP» or «DOWN» until all lines of the Settings menu no longer have a frame.

2. Press «Enter» for just a moment.

Jump back to the menu bar, the "Settings menu" symbol receives a black background.



The modification of the pressure setting at the display can be blocked upon the entry of the Customer password (password level 1). The last setting of the compressed air discharge pressure is retained.

8.5 Switching off

Overview:

- Switching the machine off
 - Switching the machine to the run-on phase
 - Switching the machine off after the cool-down phase
- Switch off the controller voltage for the SIGMA CONTROL SMART
- Switch off the on-site power supply disconnecting device
- Disconnect the plug-in connection system

► Follow all instructions carefully.

8.5.1 Switching off

The machine may only be switched off via the operating panel of the SIGMA CONTROL SMART

⚠ DANGER

Death or serious injury can result from pulling out the plug-in connection during operation

► *Only switch the machine off via the operating panel of the SIGMA CONTROL SMART.*

Switch the machine to the run-on phase	Switching the machine off after the cool-down phase
<ol style="list-style-type: none">1. Open the control panel cover.2. Press the «LOAD/IDLE» key. The drive motor runs in IDLE operation. The oil separator tank is vented. The inlet valve closes.  0.5 - 3 minutes (drive motor can be switched off).3. Press and hold the «STOP» key for more than 1 second. The drive motor shuts down.	<ol style="list-style-type: none">1. Wait for the cool-down phase.2. Press and hold the «OFF» key for more than one second. The machine switches to <i>unloaded run-on</i>. The drive motor runs in IDLE operation. The oil separator tank is vented. The inlet valve closes. The drive motor switches off, controlled by a timer.

8.5.2 Observing the back pressure indicator



- The SIGMA CONTROL SMART display indicates *back pressure* if the pressure in the oil separator tank (OST) remains > 14.5 psig.
- When the machine is fully vented, the indicator changes from *back pressure* to *READY*.
- If the OST is fully vented after shutdown, the “restart inhibitor” is activated and indicated by a timer counting down on the display.

➤ Follow all instructions

8.5.3 Switching off the controller voltage

To switch off the SIGMA CONTROL SMART, the «Controller ON/OFF» switch must be set to the *OFF* position.

Precondition

The oil separator tank has been fully vented,
the *back pressure* symbol is no longer illuminated.

The *READY* symbol is indicated.

- Turn the «Controller ON/OFF» switch to the *OFF* position.
All the SIGMA CONTROL SMART indicators switch off.

8.5.4 Switching off the on-site power supply disconnecting device

1. Switch off the on-site «Load isolating switch» on the power supply disconnecting device.
2. Secure the on-site «Load isolating switch» on the power supply disconnecting device against switching on again.

8.5.5 Disconnecting the CAM-LOK plug-in connection system

1. Open the door/s.
2. Disconnect all customer-provided plugs to the CAM-LOK plug-in connection system inside the machine.
3. Remove the power supply cable.
4. Close the door/s.


8.6 Shutting down machine in the event of an emergency



The «EMERGENCY STOP» push button may be used only in case of an **emergency** in order to shut down the machine.

The «EMERGENCY STOP» push button is located beneath the control panel cover of SIGMA CONTROL SMART, see Fig. 31.

In the event of an emergency around or relating to the machine, it must be shut down immediately.



08-M2922-M25xE

Fig. 31 Switching off in an emergency

- ① Control panel cover of SIGMA CONTROL SMART (closed)
- ② «EMERGENCY STOP» push button
- ③ Direction of arrow

Shut down machine in the event of an emergency

- Press the «EMERGENCY STOP» push button.

Result Drive motor switches off, the machine stands still.
«EMERGENCY STOP» push button is locked.
Pressure system is vented.
Machine is secured against an automatic restart.

Remove the fault on the machine

Precondition Operational safety at the machine and its environment is ensured.

1. Determine the cause of the fault.
2. Rectify the fault.

Unlocking the «EMERGENCY STOP» push button

The «EMERGENCY STOP» push button remains locked after shutting down in the event of an emergency.

The «EMERGENCY STOP» push button must be unlocked manually.

- Turn the «EMERGENCY STOP» push button in the direction of the arrow until it automatically unlocks.

Putting the machine back into operation

When the fault has been cleared, the machine must be unlocked.

Precondition «EMERGENCY STOP» push button is unlocked.

1. Press the «Enter» key on the SIGMA CONTROL SMART control panel to confirm the fault message.
2. Turn the «Controller ON/OFF» switch to the *OFF* position.
3. Turn the «Controller ON/OFF» switch to the *ON* position.

Result The machine is ready to start again.

8.7 Checking the ambient temperature

- Check to ensure that the ambient temperature for air treatment is within the required limit values.



The moisture content of the transported air is too high.

The ambient temperature has fallen below or exceeds the permissible limit value.

- Shut down the machine.

Further information See chapter 2.4.6 for air treatment limit values.

8.8 Confirming alarm and warning messages

- The information evaluated by SIGMA CONTROL SMART is stored in the event memory.
- The warning and alarm messages are shown on the display of SIGMA CONTROL SMART.
- The message is stored in the event memory of SIGMA CONTROL SMART at the same time.

8.8.1 Confirming and acknowledging alarm messages

An alarm message is displayed and

- The machine is shut down and cannot be restarted.
- The associated signal indicator illuminates red.

Precondition Fault rectified.

1. Press «Enter» to accept the alarm message.
The alarm indicator is extinguished.
The alarm symbol in the status bar remains active.
2. Restart SIGMA CONTROL SMART in order to acknowledge the alarm message.

8.8.2 Confirming and acknowledging warning messages

Before an alarm, the system displays a warning and the following happens at the same time:

- The assigned signal indicator illuminates orange.

Precondition The cause of the warning is rectified

1. Press «Enter» to confirm the warning message.
The warning message is extinguished.
The warning symbol in the status bar remains active.

2. Restart SIGMA CONTROL SMART in order to acknowledge the warning message.

Further information See separate operating manual for SIGMA CONTROL SMART for further information on the event memory.

8.9 Checking the level of the condensate collection tank

- Check the level of the internal condensate collection tank
- Check the level of the external condensate collection tank.

Precondition The machine is switched off and has cooled down.
«Load isolating switch» of the machine set to position *OFF*,
«Load isolating switch» is locked off,
«Controller ON/OFF» switch set to position *OFF*,
Absence of voltage has been verified.

The butterfly valve at the compressed air outlet is open,
the machine is fully vented, pressure gauge reads 0 psig!

► Comply with all instructions!

8.9.1 Checking the internal condensate collection tank

Check the level of the internal condensate collection tank each time after operating the machine for a short time.

1. Visually inspect the filler level.
2. If necessary, empty the internal condensate collection tank, see chapter 10.7.

8.9.2 Checking the external condensate collection tank

Depending on the design size, check the level of the external condensate collection tank.

1. Visually inspect the filler level.
2. If necessary, empty the external condensate collection tank, see chapter 10.7.

8.10 Cleaning the machine after operation



Proper technical condition of the machine also includes cleanliness. The interior of the machine in particular must not be heavily contaminated with oil.

- Clean the exterior of the machine by using a high-pressure washer.
 - Clean the interior of the machine by using compressed air.
- The machine must be cleaned by authorized and trained personnel only!



Cleaning by using dry-ice blasting is strictly forbidden! This can result in unforeseen damage.

8.10 Cleaning the machine after operation

Material	Eye protection (protective glasses) Cleaning cloth Cleaning agents High-pressure washer Compressed air
Precondition	The machine has been set down in a cleaning area equipped with an oil separator. The machine is on level ground and has cooled down. The machine is isolated from any voltage, the absence of voltage has been verified. The machine is completely de-pressurized, the pressure gauge reads 0 psig!

⚠ WARNING

Stirred up dirt particles and hazardous materials!

Injuries to eyes.

- *Wear safety glasses.*

NOTICE

Hose water can cause machine damage!

Direct hose water may damage or destroy electrical components.

- *Do not use hose water to clean the machine interior.*
- *Do not use hose water to clean sensitive indicating instruments.*

- Follow all instructions carefully.

8.10.1 Cleaning the exterior of the machine

Open closed floor pan



In order to prevent liquid accumulation inside the machine the closed floor pan must be opened.




Fig. 32 Closed floor pan bung

- ① Front side of machine
- ② Skid

- ③ Central drain device
- ④ Plug

1. Remove plug.
2. Clean plug.

Close the control panel cover

- Close control panel cover of SIGMA CONTROL SMART.
Sensitive indicating instruments are protected against direct hose water.

Cleaning the machine from the outside

Maintain the following minimum distances to the object to be cleaned in order to prevent damages to the object when cleaning with the high-pressure washer:

- Rotary jet nozzles: approximately 28 inches
- Fan jet nozzles: approximately 12 inches
- Dirt blasters: approximately 12 inches

- Clean the machine from the outside with a high-pressure washer.

Result Exterior cleaning via high-pressure washer is complete.

Cleaning indicating instruments:

1. Open the control panel cover of SIGMA CONTROL SMART.
2. Manually clean sensitive indicating instruments with a cleaning cloth.

Sealing the floor pan:

Precondition Liquid inside the machine has completely drained.

- Install plug.

8.10.2 Cleaning the interior of the machine

Overview:

- Clean the interior of the machine by using suitable compressed air, see Table 61.
- Manually clean sensitive components.

Suitable compressed air range for cleaning	Value
Working pressure [psi]	≤ 30

Tab. 61 Suitable compressed air range for cleaning

Cleaning the interior of the machine:

Precondition Compressed air generator is available.

Suitable compressed air range is set.

- Clean the interior of the machine by using compressed air.

Manually cleaning sensitive components:

In the event of excessive contamination of the drive motor or the control cabinet, you can also use a gentle degreasing cleaning agent. The cleaning agent must not alter the surfaces of the drive motor or the control cabinet.

- Manually clean the following components with a cleaning cloth:
 - Electric drive motor cooling fins
 - Electric drive motor connector box
 - Control cabinet



Dispose of dirty cleaning cloths in accordance with environmental protection regulations.

8.11 Operating the options

- Comply with all instructions.

8.11.1 Note the automatic operating modes

Overview:

- Note the automatic start/stop
- Note the DUAL control mode

⚠ WARNING

Risk of injury caused by an automatic machine start!

- *Close and lock all doors of the machine already before switching on the controller voltage for SIGMA CONTROL SMART.*

Option ob Note the automatic start/stop

The ready-to-start state of the machine in the automatic operating mode "automatic start/stop" is ensured when the following conditions are met:


- The controller voltage for SIGMA CONTROL SMART is switched on.
 - All required settings have been made in the *<Settings menu>* of SIGMA CONTROL SMART.
 - The «START» key on the control panel of SIGMA CONTROL SMART has been pressed once.
1. Check to ensure that all the doors of the machine are closed and locked.
 2. Switch on the SIGMA CONTROL SMART controller voltage.
 3. Make all required settings in the *<Settings menu>* of SIGMA CONTROL SMART.
 4. Press the «START» key on the control panel of SIGMA CONTROL SMART once only.

Result After the start signal from the master controller has been received, the machine starts automatically. The machine runs through the warm-up phase and automatically switches to LOAD operation.

Option cd Note the DUAL control mode

The ready-to-start state of the automatically-operated machine in DUAL control mode is ensured when the following conditions are met:

- The compressed air hose (network pressure) has been connected to the measuring point.
 - The controller voltage for SIGMA CONTROL SMART is switched on.
 - All required settings have been made in the *<Settings menu>* of SIGMA CONTROL SMART.
 - The «START» key on the control panel of SIGMA CONTROL SMART has been pressed once.
1. Connect the compressed air hose (network pressure) to the measuring point.



08-M3591

Fig. 33 Measuring point information sign

2. Adjusting the lever of the directional control valve.
3. Close and lock all doors of the machine.
4. Switch on the SIGMA CONTROL SMART controller voltage.
5. Make all required settings in the <*Settings menu*> of SIGMA CONTROL SMART.
6. Press the «START» key on the control panel of SIGMA CONTROL SMART once only.

Result The machine starts automatically, if the compressed air pressure in the compressed air network is lower than the cut-in pressure of the pressure switch. The machine runs through the warm-up phase and automatically switches to LOAD operation.

9 Fault Recognition and Rectification

9.1 Basic instructions

The following tables are intended to assist in fault finding and rectification.

1. Do not attempt fault rectification measures other than those given in this manual!
2. In all other cases:
Have the fault rectified by an authorized KAESER service representative.

Further information Observe the instructions in chapter 3 "Safety and Responsibility" and prevailing local safety regulations when rectifying faults and malfunctions.
Comply with local applicable safety provisions!

9.2 Analyzing SIGMA CONTROL SMART messages

There are three types of message:

- Fault messages, see chapter 9.2.1.
- Warning messages, see chapter 9.2.2.
- Maintenance messages, see chapter 10.2

The messages applicable to your machine are dependent on the controller factory settings and individual equipment with which the machine is provided.

9.2.1 Alarm message on the controller (machine off)

Alarm with automatic shutdown of the machine.



After correcting the alarm, carry out the following measures to restart the machine.

- Acknowledge the alarm message
- Restart the controller

Further information Further information on acknowledging alarm messages can be found in chapter 8.8.

Error code, range 1100 – 1199 “Drive motor faults”:

Code	Meaning	Measure	See chapter	Where can I get help?	
				SW	KS
1166	Fault - drive motor over-load	Have it checked.	-	-	X
1167	Fault - drive motor direction of rotation	Have it checked.	-	-	X
1170	Fault - automatic mode start fault	Have it checked.	-	-	X

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 62 Alarm messages and troubleshooting concerning the drive motor

Error codes, range 1200 – 1299 “Compressor faults”:

Code	Meaning	Measure	See chapter	Where can I get help?	
				SW	KS
1200	Fault - ADT high.	Check installation conditions.	5.2	-	-
		Check/clean the cooling air inlet		-	-
		Checking fan function.		-	-
		Clean the cooler.	10.6	-	-
		Check the cooling oil level.	10.5.1	-	-
		Wait until the airend discharge temperature has dropped below the value of the safety shut-down.	2	-	-
1201	Fault - OST pressure high.	Have it checked.	-	-	X

SW = Specialized workshop; KS = KAESER SERVICE

ADT = Airend discharge temperature; OST - Oil separator cartridge

Tab. 63 Alarm messages and troubleshooting concerning “compressor fault”

Error codes, range 1300 – 1399 “Controller faults”:

Code	Meaning	Measure	See chapter	Where can I get help?	
				SW	KS
1300	Fault – PLC memory error.	Have it checked.	-	-	X
1302	Fault - PLC / HMI communication.	Have it checked.	-	-	X
1303	Fault - PLC temperature high.	Check installation conditions. Allow the machine to cool down.	5.2	-	-
1304	Fault – PLC power supply.	Have it checked.	-	-	X
1310	Fault – Watchdog fault.	Have it checked.	-	-	X

SW = Specialized workshop; KS = KAESER SERVICE

PLC = Programmable logic controller; HMI = Human-machine interface; Watchdog = Function monitoring

Tab. 64 Alarm messages and troubleshooting concerning “controller fault”

Error codes, range 1400 – 1499 "General faults":

Code	Meaning	Measure	See chapter	Where can I get help?	
				SW	KS
1400	Fault – EMERGENCY STOP	Disengage «EMERGENCY STOP» push button.	8.6	–	–
		Have it checked.		–	X
1410	Fault - OST pressure sensor open circuit	Have it checked/repaired.	–	–	X
1412	Fault – inlet valve pressure transducer open circuit	Have it checked/repaired.	–	–	X
1414	Fault - ADT sensor	Have it checked.	–	–	X
1420	Fault – venting valve open circuit	Have it checked/repaired.	–	–	X
1424	Fault - inlet valve	Have it checked.	–	–	X
1429	Fault - fan motor	Have it checked/repaired.	–	–	X
1440	Fault – power supply voltage monitoring	Have it checked.	–	–	X
1441	Fault - main contactor malfunction	Have it checked/repaired.	–	–	X
1475	Fault - sensor B13 / pN				

SW = Specialized workshop; KS = KAESER SERVICE

OST = Oil separator tank

ADT = Airend discharge temperature

Tab. 65 Alarm messages and troubleshooting concerning "General faults"

9.2.2 Warning message on the controller

The machine will not be shut down.



- In the case of an overheating warning, the machine switches automatically to IDLE mode to cool down.
- You must acknowledge the warning message upon correction of the fault.

Further information Further information on the acknowledgement of warning messages can be found in chapter 8.8.

9 Fault Recognition and Rectification

9.3 Drive motor faults and alarms

Message codes, range 3200 – 3299 “Compressor unit warnings”:

Code	Meaning	Remedy	See chapter	Where can I get help?	
				SW	KS
3200	Warning – ADT high.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.		–	–
		Check the cooling oil level.		10.5.2	–
		Clean the cooler.		10.6	–
3201	Warning – OST pressure high.	Have checked.	–	–	X

SW = specialized workshop; KS = KAESER SERVICE

ADT = Airend discharge temperature; OST - Oil separator tank

Tab. 66 Warning messages and measures relating to the compressor

Message codes, range 3300 – 3399 “Controller warnings”:

Code	Meaning	Remedy	See chapter	Where can I get help?	
				SW	KS
3303	Warning - PLC temperature high.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.		–	–
3313	Warning - HMI temperature high.	Check operating conditions.	5.2	–	–
		Allow the machine to cool down.		–	–

SW = Specialized workshop; KS = KAESER SERVICE

PLC - Programmable logic controller; HMI = Human-machine interface

Tab. 67 General warning messages and measures

9.3 Drive motor faults and alarms

9.3.1 Drive motor refuses to start or stops

Possible cause	Measure	Where can I get help?	
		SW	KS
Voltage too high or too low.	Check the electrical connection.	X	–
High current cut-out is set incorrectly or defective.	Adjust or replace.	X	X
Control switch defective.	Replace.	X	X

SW = Specialized workshop; KS = KAESER SERVICE

Possible cause	Measure	Where can I get help?	
		SW	KS
Defective coupling relay and/or relay.	Replace.	X	X
Drive motor must start against pressure.	Wait until the machine has vented.	-	-
Drive motor defective, bearing damage, winding short-circuit.	Have the drive motor replaced.	-	X
Incorrect phase sequence of the electric supply (direct connection).	Correct the electrical connection.	X	-
Defective ADT sensor giving no enable signal.	Replace.	-	X
Electrical connections and/or cables loose or broken.	Tighten connection or replace cables.	X	-
Airend defective.	Replace.	-	X

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 68 Fault: "Drive motor refuses to start or stops"

9.4 Compressor faults and alarms

9.4.1 Working pressure too high

Possible cause	Remedy	Where can I get help?	
		SW	KS
Proportional controller maladjusted or defective.	Check the diaphragm and clean the nozzle or replace proportional controller if necessary.	-	X
Inlet valve does not close.	Check the controller, the control air line and the inlet valve and replace if necessary.	-	X
Pressure gauge indicating false pressure.	Replace.	-	X
Venting valve does not blow off.	Check the connections and function and repair or replace as necessary.	-	X

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 69 Fault: working pressure too high

9.4.2 Working pressure too low.

Possible cause	Remedy	Where can I get help?	
		SW	KS
Proportional controller maladjusted or defective.	Check the diaphragm and clean the nozzle or replace proportional controller if necessary.	–	X
Inlet valve not opening or only opening partially.	Repair or replace if necessary.	–	X
Pressure gauge indicating false pressure.	Replace.	–	X
Pressure relief valve maladjusted and/or leaking.	Replace if necessary.	–	X
Venting valve does not close.	Check the connections and function and repair or replace as necessary.	–	X
Compressor air filter clogged.	Clean or replace, see chapter 10.5.7.	–	–
Oil separator cartridge heavily clogged.	Change, see chapter 10.5.6.	–	–

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 70 Fault: working pressure too low

9.4.3 Safety relief valve blowing off

Possible cause	Remedy	Where can I get help?	
		SW	KS
Oil separator cartridge heavily clogged.	Change, see chapter 10.5.6.	–	–
Inlet valve does not close.	Check the controller, the control air line and the inlet valve and replace if necessary.	–	X
Safety relief valve maladjusted and/or leaking.	Replace if necessary.	–	X

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 71 Fault: safety relief valve blowing off

9.4.4 Machine overheating

Possible cause	Remedy	Where can I get help?	
		SW	KS
Defective cooling fan.	Replace blades or the complete fan wheel.	–	X

SW = Specialized workshop; KS = KAESER SERVICE

Possible cause	Remedy	Where can I get help?	
		SW	KS
Oil cooler surface clogged.	Clean surface, see chapter 10.6.	–	–
The working element of the thermostatic valve not working.	Replace.	–	X
Working pressure too high (proportional controller maladjusted).	Reset to the permissible value or replace.	–	X
Oil separator cartridge heavily clogged.	Change oil separator cartridge, see chapter 10.5.6.	–	X
Compressor oil filter cartridge clogged.	Change, see chapter 10.5.4.	–	–
Compressor oil level too low.	Top up, see chapter 10.5.2.	–	–
Oil pipes leaking.	Seal leaks or change pipes.	X	X
Defective cooling fan of the drive motor.	Repair.	X	X
Ambient temperature too high.	See conditions given in chapter 5.2.	–	–

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 72 Fault: machine overheating

9.4.5 Too much oil residue in the compressed air

Possible cause	Remedy	Where can I get help?	
		SW	KS
Oil separator cartridge scavengeline clogged.	Clean the strainer in the separator cartridge dirt trap or change if necessary (see chapter 10.5.6).	–	X
Fractured oil separator cartridge.	Change, see chapter 10.5.6.	–	–
Compressor oil level too high.	Reduce to maximum level, see chapters 10.5.1 and 10.5.3.	–	–

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 73 Alarm: "Too much oil residue in the compressed air"

9.4.6 Oil flows from the compressor air filter after shutdown

Possible cause	Remedy	Where can I get help?	
		SW	KS
Defective non-return function of the inlet valve.	Repair or replace if necessary.	-	X

SW = Specialized workshop; KS = KAESER SERVICE

Tab. 74 Alarm: "Oil flows from the compressor air filter after shutdown"

10 Maintenance

10.1 Ensuring safety

Follow the instructions below to ensure safe machine maintenance.

Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

Compliance with safety warnings

Ignoring safety warnings can cause unforeseeable dangers!

- Follow the instructions in chapter 3 'Safety and Responsibility'.
- Allow maintenance work to be carried out only by authorized personnel.
- Use one of the safety signs below to advise others that the machine is currently being serviced:

Sign	Meaning
	Don't activate the machine.
	Warning: The machine is being serviced.

Tab. 75 Advise others that the machine is being serviced.

- Before switching on, make sure that:
 - no personnel are working on the machine,
 - all protective guards and cover panels are attached,
 - all doors, canopy, and panels are closed,
 - all tools have been removed from the machine.
- Do not perform any checks or maintenance while the machine is running.

When working on live components

Touching voltage carrying components can result in electric shocks, burns or death.

- Work on electrical equipment may only be carried out by authorized electricians.
- Switch off and lock out / tag out the power supply disconnecting device.
- Verify the absence of any voltage.
- Check that the floating relay contacts are voltage-free.
- If necessary, remove electrical connections.

When working on the compressed air system

Compressed air is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following safety instructions relate to any work on components that could be under pressure.

- Disconnect the air consumers.
- De-pressurize all pressurized components and enclosures. Verify the vented state.
- Wait until the machine has automatically vented.
- Carefully open all compressed air outlet valves.
- Check: The pressure gauge must read 0 psig!
- Do not open or dismantle any valves.
- When operating the machine on a compressed air system, close shut-off valves or otherwise isolate the machine from the compressed air system to ensure that no compressed air can flow back into the machine.

When working on the drive system

Touching voltage carrying components can result in electric shocks, burns or death.
 Touching rotating or very hot components can cause severe injuries.

- Switch off and lock out / tag out the power supply disconnecting device.
- Verify the absence of any voltage.
- If necessary, remove electrical connections.
- Ensure that the machine has cooled down.
- Do not open the enclosure and/or panels while the machine is switched on.

Further information Details of authorized personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

10.2 Adhere to the maintenance messages on the controller

SIGMA CONTROL SMART displays selected maintenance intervals of the machine. Display begins 25 hours before the interval will expire.

Upon switching on SIGMA CONTROL SMART, the symbols for the component to be serviced are prominently displayed at SIGMA CONTROL SMART.

The operating hours of the maintenance to be performed and message code of the service task are displayed below.



After the maintenance, the maintenance interval counter must be reset.

- Message code is shown on the display of SIGMA CONTROL SMART.

10.2.1 Evaluating the maintenance message

- Determine any due maintenance tasks using the table below and perform the maintenance according to the maintenance schedule shown in chapter 10.3.2.1.

Code	Meaning	Measure	See chapter
Message codes, range 2100 – 2199 “Drive motor maintenance”:			
2103	Maintenance - drive motor grease bearings	Grease motor bearings.	10.4.1
h - operating hours			

Code	Meaning	Measure	See chapter
Message codes, range 2200 – 2299 “compressor unit maintenance”:			
2200	Maintenance - oil filter.	Change the compressor oil filter.	10.5.4
2201	Maintenance - air filter.	Clean/replace the air filter.	10.5.7
2202	Maintenance – change cooling oil.	Change the cooling oil.	10.5.3
Message codes, range 2400 – 2499 “General maintenance”:			
2400	Maintenance -main contactor h - operating hours	Have the main contactor replaced. 3.7 and 10.3.2.1	

Tab. 76 Maintenance messages and required measures

10.2.2 Completing the maintenance

Resetting the maintenance timer:

Precondition Maintenance carried out

- Reset the maintenance timer as described in the separate User Manual of SIGMA CONTROL SMART, chapter “Reset maintenance timer”.

10.3 Following the maintenance plans

10.3.1 Logging maintenance work



The maintenance intervals given are those recommended for KAESER original components with average operating conditions.

- In adverse conditions (e.g. oil and filter changes), perform maintenance work at shorter intervals.

Adverse conditions are, e.g.:

- high/low temperatures
- a lot of dust
- frequent use

- Adjust the maintenance intervals with regard to local installation and operating conditions.

- Logging all maintenance work.

This enables you to determine the frequency of individual maintenance tasks and deviations from our recommendations.

Further information A list is available in chapter 10.15.

10.3.2 Regular maintenance tasks

The following table lists the various maintenance intervals.

Maintenance interval	Short description
Daily	-
Every 250 h, at least annually.	A250
Every 500 h, at least annually.	A500
Every 1000 h, at least annually.	A1000
Every 1500 h, at least annually.	A1500
Every 2000 h, at least every two years.	A2000
Every 3000 operating hours	A3000
Every 20000 operating hours	A20000
Every 36000 h, at least every six years.	A36000
Every 120000 h; at least every 20 years	A120000

Tab. 77 Maintenance intervals and regular maintenance tasks

The table below lists regular maintenance tasks.

- Carry out maintenance tasks punctually taking ambient and operating conditions into consideration.

10.3.2.1 Machine maintenance schedule

- Carry out maintenance tasks on time in accordance with the table below:

Assembly: Task	Hourly	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	A120000	See chapter	Note
Drive motor:												
SIGMA CONTROL SMART display: Have the bearing of drive motor lubricated/checked.					X							KS, FW
Compressor:												
SIGMA CONTROL SMART display: Change compressor air filter.					X						10.5.7	
Check cooling oil level.	X										10.5.1	
SIGMA CONTROL SMART display: Change cooling oil.					X						10.5.3	
SIGMA CONTROL SMART display: Change compressor oil filter.					X						10.5.4	
Clean compressor oil cooler.		X									10.6	
Check/clean the control valve dirt trap.			X								10.5.5	
Change the oil separator cartridge.						X					10.5.6	
Have the safety relief valve(s) checked.				X							10.5.10	KS, FW
Safety functions:												
Check the functions of the safety shut-down due to excessive airend discharge temperature.				X							10.5.11	
Check the «EMERGENCY STOP» push-button.	X										10.5.12	
Compressed air aftercooler:												
Cleaning the cooler			X								10.5.8	
Centrifugal separator:												
Clean/check the dirt trap.				X							10.5.9	
Condensate collection tank:												
KS ≈ contact KAESER SERVICE, FW ≈ contact specialized workshop												

Assembly: Task	Hourly	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	A120000	See chapter	Note
Check/empty the level of the internal condensate collection tank.	X										10.7	
Condensate hose line:		X									10.7	
Check to ensure that the condensate hose line has been properly fastened.												
Closed floor pan:		X									10.12	
Check the interior of the machine for accumulated fluids.												
Doors:				X							10.10.1	
Maintain rubber sealing strips.					X							
Check function of closed doors.				X							10.10.2	
Check connection elements.		X									10.10.3	
Body:												
Check sound insulation material.				X							10.9	
Arrange for crane suspension to be checked.			X									KS, FW
Hose lines:												
Check all hose lines of the machine for proper seating, leaks and wear; have them replaced if necessary.			X								10.11	KS, FW
Arrange for the compressor pressure hoses to be replaced.								X			10.11.1	KS, FW
Other maintenance tasks:												
Check all accessible screw fittings, lines and clamps for wear and tightness.			X								10.8	KS, FW
Check that all electrical connections are tight.			X									KS, FW
Replace safety-relevant components of the safety functions:												
Have resistance thermometer (Pt100 sensor) replaced.									X		3.7	KS, FW
Have EMERGENCY STOP push button replaced.									X		3.7	KS, FW
KS ≈ contact KAESER SERVICE, FW ≈ contact specialized workshop												

Assembly: Task	Hourly	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	A120000	See chapter	Note
SIGMA CONTROL SMART display: Have the main contactor replaced. KS ≈ contact KAESER SERVICE, FW ≈ contact specialized workshop									X		3.7 10.13	KS, FW

Tab. 78 Regular machine maintenance tasks

10.3.2.2 Maintenance schedule options

- Carry out maintenance tasks according to the following schedule:

Option: Task	Daily	A250	A500	A1000	A1500	A2000	A20000	See chapter	Note
Option dd – Filter combination:									
Draining condensate	X							10.14.1	
Changing filter elements		X						10.14.1	
Replacing seal of filter element		X						10.14.1	
Option ba – Low-temperature equipment:									
Clean the radiator of the auxiliary heater.		X							
KS ≈ Contact KAESER SERVICE, FW ≈ Contact specialized workshop, EF ≈ Contact certified electrician									

Tab. 79 Regular maintenance task options

10.4 Motor maintenance

- Perform maintenance tasks according to the schedule in chapter 10.3.2.1.

10.4.1 Servicing the motor bearings on the drive motor



Only use UNIREX N3 high-temperature grease for relubricating the motor bearings. Further information regarding the grease and the correct grease quantity is provided on the machine nameplate. For the position of the nameplate, see Figure 35. Damage to the bearings caused by the use of alternative brands of grease is excluded from the warranty.

Service the motor bearings should any of the following occur:

- Warning message with specific message code (see Table 80) on the display of the SIGMA CONTROL SMART.
- Maintenance interval as per the maintenance schedule has expired.

Message code	Action
2103	Lubricate the motor bearings

Tab. 80 Specific message code for "Service motor bearings"

Material	UNIREX N3 bearing grease Amount of bearing grease per bearing [g] = 40 Grease gun Cleaning cloth
----------	---

Precondition	Maintenance personnel are wearing suitable tight-fitting protective clothing. Maintenance personnel are wearing eye protection and protective gloves. Maintenance personnel are using ear protection.
--------------	---

Clean the cooling fins and central lubrication device

For the position of the central lubrication device for the motor bearings, see Figure 34.

Precondition	The machine is switched off and has cooled down, the «Controller ON/OFF» switch is set to the <i>OFF</i> position, the «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig!
--------------	---




Fig. 34 Positions of the grease nipples

- | | |
|--|--|
| 1 Central lubrication device
2 Grease line
3 Drive motor | 4 Cooling fins
5 Motor terminal box
6 Flange side of drive motor |
|--|--|

1. Open the door of the cooling air inlet.
2. Clean the cooling fins.
3. If required, clean the central lubrication device.
4. Close the door of the cooling air inlet.

Lubricate the motor bearings



The maintenance task "Lubricating the motor bearings" must be carried out while the machine is running!

A central lubrication device inside the machine facilitates lubrication of the two motor bearings.

- Comply with all measures relating to protective clothing, protective gloves, eye and ear protection!
- Only open the door/s of the machine briefly to carry out relubrication of the motor bearings.
- Maintain a safe distance from rotating parts and hot surfaces.
- Proceed with caution.

- Precondition
- Cooling fins and grease fittings have been cleaned.
 - Grease gun has been filled with suitable high-temperature grease.
 - The «Load isolating switch» on the on-site power supply disconnecting device is switched on at all poles.
 - The «Controller ON/OFF» switch is turned to the *ON* position.




Fig. 35 Lubricating the drive motor bearings

- | | |
|------------------------------|------------------------------|
| ① Grease gun | ④ Drive motor |
| ② Central lubrication device | ⑤ Flange side of drive motor |
| ③ Grease line | ⑥ Drive motor running symbol |

1. Press the «START» key on the SIGMA CONTROL SMART operating panel.
2. Allow the machine to run in IDLE operation.
3. Open the door of the cooling air inlet.
4. Press the grease gun onto the two grease fittings of the central lubrication device for the motor bearings, one after the other.
5. Apply the grease gun until both motor bearings have been lubricated with the required quantity of grease.
6. Switch the drive motor off via the «OFF» key on the SIGMA CONTROL SMART operating panel.

Reset the maintenance timer

- Reset the maintenance timer as described in the separate operating manual for the SIGMA CONTROL SMART, chapter "Resetting the maintenance timer".

Switch off the load isolating switch

1. Turn the «Controller ON/OFF» switch to position *OFF*.
2. Switch off the «Load isolating switch» on the on-site power supply disconnecting device at all poles.
3. Secure the «Load isolating switch» against being switched on again.
4. Close the door/s.

10.4.2 Fan motor maintenance

The following components are cooled by electric fans:

- Oil cooler
 - Control cabinet
- Have the corresponding fan motors checked by an authorized KAESER service representative during the course of a maintenance visit.

10.5 Compressor Maintenance

- Perform maintenance tasks according to the schedule in chapter 10.3.2.1.

10.5.1 Checking the cooling oil level

Two oil sight glasses at the bottom of the oil separator tank indicate the cooling oil level.

The correct cooling oil level is in the following range:

- Center of the upper oil sight glass
- Bottom edge of lower oil sight glass

The cooling oil level must at least be visible in the lower oil level sight glass.

Material Long-sleeved protective clothing

Protective gloves

Eye protection

Cleaning cloth

Precondition The machine is switched off.

The machine is standing level and has cooled down.

The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles,

the «Load isolating switch» is secured against being switched on again,

the absence of all voltage has been verified,

the «Controller ON/OFF» switch is set to the *OFF* position.

The butterfly valve on the compressed air outlet is open,

the machine is fully vented, the pressure gauge reads 0 psig!

The door/s is/are open.




Fig. 36 Checking the cooling oil level

- | | | | |
|---|-----------------------|---|----------------------------------|
| ① | Oil separator tank | ⑤ | Screw plug |
| ② | Upper oil sight glass | A | <i>Maximum</i> cooling oil level |
| ③ | Lower oil sight glass | B | <i>Minimum</i> cooling oil level |
| ④ | Oil filler port | | |

1. If necessary, clean both oil sight glasses.
2. Check the cooling oil level in both oil sight glasses.
When the level reaches *minimum cooling oil level*. Replenish the cooling oil.
3. Close the door/s.

10.5.2 Filling and replenishing with cooling oil

Material	Long-sleeved protective clothing Protective gloves Eye protection New cooling oil Funnel Cleaning cloth Wrench
Precondition	The machine is switched off. The machine is standing level and has cooled down. The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig! The door/s is/are open.

CAUTION

Danger of burning from hot components and escaping cooling oil!

- Wear long-sleeved protective clothing, protective gloves and eye protection.

NOTICE

Incompatible types of cooling oil will damage the machine

- Never mix different types of cooling oil.
- Never replenish with a type of cooling oil that differs from the one already used in the machine.

Fill with cooling oil:

A sticker on the oil separator tank specifies the type of cooling oil used.

1. Loosen the screw plug on the oil filler port.
2. Slowly open and remove the screw plug.
3. Replenish the cooling oil to the maximum level  by means of a funnel.
4. Check the cooling oil level.
5. Check the screw plug seal for damage.
If the seal is damaged: Replace the seal.
6. Refasten the screw plug on the filler port.
7. Close the door/s.

Prepare for operation:

1. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
2. Turn the «Controller ON/OFF» switch to the *ON* position.

Start the machine and perform a test run:

1. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.
2. Warm up the machine by allowing it to run in IDLE.
Warm-up has been achieved when the required airend discharge temperature is reached.
3. Press and hold down the «OFF» key on the SIGMA CONTROL SMART operating panel for longer than 1 second.
The machine is switched off.
4. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!
5. Open the butterfly valve on the compressed air outlet.
6. Open the door/s.
7. Check the cooling oil level after about 5 minutes.



Cooling oil level too low.

➤ Replenish the cooling oil again.

8. Visually inspect for leaks.
9. Close the door/s.

10.5.3 Changing the cooling oil

Drain the oil completely from the following components:

- Airend
- Oil separator tank
- Oil filter
- Oil cooler
- Oil lines

➤ Always change the oil filter when changing the cooling oil.

Change the cooling oil when any of the following events occur:

- Warning message with specific message code (see Table 81) on the display of the SIGMA CONTROL SMART.
- Maintenance interval as per the maintenance schedule has expired.

Message code	Action
2202	Changing the cooling oil

Tab. 81 Specific message code for “Change cooling oil”

Material	Long-sleeved protective clothing Protective gloves Eye protection See chapter 2.4.8 for compressor oil fill volumes. Receptacle Male hose coupling (supplied loose with the machine) Funnel Cleaning cloth
Precondition	The machine is switched off. The machine is standing on level ground and is at operating temperature. The «Controller ON/OFF» switch is set to the <i>OFF</i> position, the «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig! The door/s is/are open.

⚠ CAUTION

Danger of burning from hot components and escaping cooling oil!

- *Wear long-sleeved protective clothing, protective gloves and eye protection.*

- Follow all instructions carefully.

10.5.3.1 Draining the cooling oil

A drain device is installed on the front side of the machine that allows you to drain the entire cooling oil in a user-friendly manner.

Preparatory work on the machine

1. Loosen and remove the screw plug from the oil filler port of the oil separator tank.
2. Remove the gasket at the oil filler port.
3. Dispose of the old gasket.




Fig. 37 Drain device - symbols and arrangement of shut-off valves

- | | |
|--|--|
| ③ Cooling oil shut-off valve
④ Cooling oil shut-off valve | ⑤ Cooling oil shut-off valve
⑥ Cooling oil shut-off valve |
|--|--|

4. Loosen and remove all screw plugs of the corresponding shut-off valves.
5. Install male hose couplings on the corresponding shut-off valves.

Positioning the receptacle

- Position the receptacle underneath the central grouping of shut-off valves.

Open the shut-off valves

1. Open all shut-off valves for the operating fluid cooling oil.
2. Drain the all of the cooling oil from the machine at operating temperature.

Result Cooling oil drains out.

Servicing the oil filter component

- See chapter 10.5.4 for information on replacing the two oil filters.

Close the shut-off valves

1. Close all shut-off valves for the operating fluid cooling oil.
2. Loosen and remove the male hose coupling.
3. If necessary, clean the shut-off valves.
4. Install all screw plugs with new gaskets.
5. Tighten all screw plugs.

Filling in cooling oil

1. Fill new cooling oil into the oil filler port of the oil separator tank.
2. Install the screw plug with a new gasket into the oil filler port of the oil separator tank.
3. Tighten the screw plug.

Further information See chapter 10.5.2 for information on filling in new cooling oil and checking the cooling oil level.

Performing final work steps

- Close door/doors.



Dispose of used oil and oil-contaminated working materials according to applicable environmental protection regulations.

10.5.4 Replacing the compressor oil filter

The filter unit consists of two oil filters that are arranged on a filter base.

The filter housing for each oil filter can be removed in order to replace the filter elements when required. When installing, the two covers must be tightened with a specific torque. The two covers are labeled with the specific torque.

Service the oil filter should any of the following occur:

- Warning message with specific message code (see Table 82) on the display of the SIGMA CONTROL SMART.
- Maintenance interval as per the maintenance schedule has expired.

Message code	Action
2200	Replace oil filter

Tab. 82 Specific message code for "Replace oil filter"

Material	Long-sleeved protective clothing Protective gloves Eye protection Spare parts Tool Receptacle Cleaning cloth
Precondition	The machine is switched off. The machine is standing on level ground, the machine is at operating temperature. The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig! The door is open.

⚠ CAUTION

Danger of burning from hot components and escaping cooling oil!

- *Wear long-sleeved protective clothing, protective gloves and eye protection.*

NOTICE

Do not overstrain components!

Leaking cooling oil circuit.

► *Refit both covers by force of hand.*

► *Tighten both covers with the specified torque.*




Fig. 38 Replacing the oil filter

- | | | | |
|---|-----------------------------------|---|----------------|
| ① | Oil filter base | ⑤ | Cover |
| ② | Oil filter | ⑥ | Filter element |
| ③ | Oil filter | ⑦ | Filter housing |
| ④ | Direction of arrow "Loosen cover" | | |

Remove the cover of the filter housing:

1. In order to loosen the two covers of the two filter housings, turn both covers in the direction of the arrow [4].
2. Remove both covers.
3. Remove both old filter elements.
4. Carefully clean sealing surfaces using a lint-free cloth.

Insert new filter elements:

1. Insert new filter elements in both filter housings.
2. Refit both covers on the filter housing by force of hand.

Correctly tighten both covers

1. Note label on both covers indicating specific torque.
2. Set a torque wrench to the specific torque.
3. Tighten both covers with the specific torque.

Check the cooling oil level:

1. Check the cooling oil level in the oil separator tank.



Cooling oil level too low.

► Replenish the cooling oil.

2. Close the door.

Prepare for operation:

1. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
2. Turn the «Controller ON/OFF» switch to the *ON* position.

Start the machine and perform a test run:

1. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.
2. Warm up the machine by allowing it to run in IDLE.
Warm-up has been achieved when the required airend discharge temperature is reached.
3. Press and hold down the «OFF» key on the SIGMA CONTROL SMART operating panel for longer than 1 second.
The machine is switched off.
4. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!
5. Open the butterfly valve on the compressed air outlet.
6. Open the door.
7. After approximately 5 minutes: Check the cooling oil level.



Cooling oil level too low.

➤ Replenish the cooling oil again.

8. Visually inspect for leaks.
9. Close the door.



Dispose of old cooling oil and any materials or parts contaminated with oil in accordance with the applicable environmental protection regulations.

Reset the maintenance timer

- Reset the maintenance timer as described in the separate operating manual for the SIGMA CONTROL SMART, chapter “Resetting the maintenance timer”.

10.5.5 Servicing the control valve dirt trap

The control valve is mounted on the oil separator tank cover.

The control valve features two different dirt traps:

- Dirt trap, oil return line
- Dirt trap, proportional controller

The two dirt traps must be cleaned at least once every year.

A special service cover inside the bodywork above the oil separator tank ensures access for this maintenance work. To open the service cover, it must first be unlocked in the machine's interior.

Material	Cleaning cloth Wrench Small screwdriver Control valve maintenance kit Cleaning solvent or spirit
Precondition	The machine is switched off. The machine is standing on level ground, the machine has cooled down. The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig!




Fig. 39 Servicing the dirt trap on the oil separator tank

- | | | | |
|---|--------------------------|---|--|
| ① | Oil separator tank cover | ⑦ | Strainer |
| ② | Control valve | ⑧ | Sealing ring |
| ③ | Clamping nut | ⑨ | Detail: Dirt trap, proportional controller |
| ④ | Oil return line | ⑩ | Screw plug |
| ⑤ | Nozzle | ⑪ | O-ring |
| ⑥ | Screw-in connector | | Strainer |

1. Open the door.
2. Unlock the service cover of the oil separator tank inside the machine and fold it upwards.

10.5.5.1 Servicing the dirt trap on the oil return line

See Fig. 39; Detail: A.

1. Loosen and remove the clamping nut ③, bend the oil return line ④ to one side.
2. Remove the screw-in connector ⑥.
3. Remove the strainer ⑦ from the screw-in connector.
4. Use a screwdriver to remove the nozzle ⑤ from the screw-in connector.

5. Clean the screw-in connector, strainer, nozzle and sealing ring **⑧** with cleaning solvent or spirit.
6. Check the nozzle, strainer and sealing ring for wear.
If severely worn: Replace the necessary components.
7. Install the nozzle and strainer in/on the screw-in connector.
8. Install the screw-in connector, ensuring that the sealing ring sits in the correct position.
9. Refit the oil return line.

10.5.5.2 Servicing the dirt trap on the proportional controller

See Fig. 39; Detail: B.

1. Loosen the screw plug **⑨** and remove the strainer **⑪**.
2. Clean the screw plug, strainer and O-ring **⑩** with cleaning solvent or spirit.
3. Check the strainer and O-ring for wear.
If severely worn: Replace the necessary components.
4. Place the screw plug on the strainer.
5. Install the screw plug, ensuring that the O-ring sits in the correct position.

Prepare for operation:

1. Close and lock the service cover.
2. Close the corresponding door.
3. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
4. Turn the «Controller ON/OFF» switch to the *ON* position.



Dispose of old parts and contaminated materials in accordance with environmental regulations.

Start the machine and perform a test run:

1. Switch the machine on and run it in IDLE operation for approx. 5 minutes.
2. Switch the machine off.
3. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!
4. Open the butterfly valve on the compressed air outlet.
5. Open the door/service cover.
6. Visually inspect for leaks.
7. Close and lock the service cover.
8. Close the door/service cover.

10.5.6 Changing the oil separator cartridge

The two dirt traps for the control valve must be cleaned/replaced whenever the oil separator cartridge is changed.

See chapter 10.5.5 for instructions on servicing the two dirt traps.

A special service cover inside the bodywork above the oil separator tank ensures access for this maintenance work. To open the service cover, it must first be unlocked in the machine's interior.



The oil separator cartridge cannot be cleaned.

The service life of the oil separator cartridge is influenced by:

- Contamination in the intake air,
- Adherence to the replacement intervals for the:
 - Cooling oil
 - Oil filter
 - Air filter

Material Spare part

Cleaning cloth

Wrench

Precondition The machine is switched off.

The machine is standing on level ground,
the machine has cooled down.

The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles,
the «Load isolating switch» is secured against being switched on again,
the absence of all voltage has been verified,
the «Controller ON/OFF» switch is set to the *OFF* position.

The butterfly valve on the compressed air outlet is open,
the machine is fully vented, the pressure gauge reads 0 psig!

The door is open,
the service cover is unlocked and open.


NOTICE

Incorrect installation during maintenance

Damage to delicate components

➤ *Proceed with caution.*

➤ Follow all instructions carefully.

10.5.6.1 Changing the oil separator cartridge

Fig. 40 Changing the oil separator cartridge

[1]	Oil separator tank cover	[8]	Solenoid valve
[2]	Output from electric proportional controller	[9]	Sensor
[3]	Oil return line	[10]	Oil separator tank
[4]	Venting line	[11]	Oil filler port
[5]	Control air line pressure gauge	[12]	Fixing screw
[6]	Input for recirculation valve	[13]	Control valve
[7]	Compressed air pipe		

Remove components

1. Loosen and remove the clamping nuts on the oil return line, venting line and control air line.
2. Loosen the clamp on the compressed air hose and move the seal.
3. Loosen and remove the compressed air hose.
4. Loosen and remove the connectors from the two solenoid valves.
5. Loosen and remove the sensor connector.

Loosen the oil separator tank cover

1. Loosen all fixing screws on the oil separator tank cover.
2. Remove all fixing screws.

Lift off the oil separator tank cover

The pipe for the oil return line is screwed to the control valve.

1. Lift the cover off carefully.
2. Lift the cover until the pipe for the oil return line protrudes completely from the oil separator tank.
3. Carefully place down the cover so as not to damage the pipe.


Remove wearing parts

Fig. 41 Removing wearing parts

①	Control valve	⑤	Oil separator cartridge
②	Pipe, oil return line	⑥	O-ring
③	Cover	⑦	Oil separator tank supporting ring
④	O-ring	⑧	Oil separator tank

1. Remove the upper O-ring.
2. Remove the old oil separator cartridge from the oil separator tank.
3. Remove the lower O-ring.

Clean the supporting ring/cover

1. Clean the supporting ring for the oil separator tank.
2. Ensure that no foreign articles (dirt particles) fall into the oil separator tank.
3. Clean the cover.

Install spare parts

The two new O-rings must be correctly inserted into the corresponding grooves.

- Groove for oil separator tank supporting ring
- Groove for oil separator tank cover

1. Position the first O-ring.
2. Insert a new oil separator cartridge into the oil separator tank.
3. Position the second O-ring.

4. Carefully place the cover with the control valve and pipe for the oil return line onto the second seal.
5. Align the cover with the drilled holes on the oil separator tank.

Secure the oil separator tank cover

1. Position all fixing screws.
2. Tighten all fixing screws by hand.
3. Tighten all fixing screws on the oil separator tank with the specific torque (see chapter 2).

Install components

1. Position and tighten the clamping nuts on the oil return line, venting line and control air line.
2. Position the compressed air hose and seal.
3. Fit the clamp.
4. Attach the connectors to the two solenoid valves.
5. Attach the sensor connectors.

Check the cooling oil level

1. Check the cooling oil level in the oil separator tank.
Cooling oil level too low.
2. Replenish the cooling oil.

Prepare for operation:

1. Close and lock the service cover.
2. Close the door.
3. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
4. Turn the «Controller ON/OFF» switch to the *ON* position.



Dispose of old parts and contaminated materials in accordance with environmental regulations.

Start the machine and perform a test run:

1. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.
2. Allow the machine to warm up in IDLE operation.
Warm-up has been successful when the required airend discharge temperature (ADT) has been reached.
3. Press and hold down the «OFF» key on the SIGMA CONTROL SMART operating panel for longer than 1 second.
The machine is switched off.
4. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!
5. Open the butterfly valve on the compressed air outlet.
6. Open door/doors/service cover.

7. After approximately 5 minutes: Check the cooling oil level.
Cooling oil level too low: Replenish the cooling oil.
8. Visually inspect for leaks.
9. Close and lock the service cover.
10. Close the door/s.



Dispose of old parts and contaminated materials in accordance with environmental regulations.

10.5.7 Servicing the compressor air filter



- Operating the machine without filter elements fitted is not permitted!
- Do not use filter elements with damaged surface or seals.
- Reuse cleaned filter elements only as an exception.
- The use of unsuitable or damaged filter elements can allow dirt to enter the pressure system and cause premature wear and damage to the machine.

Service the compressor air filter should any of the following occur:

- Maintenance switch reaches switching point in the event of vacuum, for the value see Table 24.
- Warning message with specific message code (see Table 83) on the display of the SIGMA CONTROL SMART.
- Maintenance interval as per the maintenance schedule has expired.

Message code	Action
2201	Replace / clean the compressor air filter

Tab. 83 Specific message code for "Service air filter"

Material	Spare parts Cleaning cloth
Precondition	The machine is switched off. The machine is standing on level ground, the machine has cooled down. The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig! The door/s is/are open.

NOTICE

*Air filter elements are clogged
Reduced machine performance*

- Replace both filter elements immediately.

- Follow all instructions carefully.


Replace the filter elements:


Fig. 42 Servicing the compressor air filter

- | | |
|--|--|
| 1 Filter cap
2 Retaining clip
3 Filter element | 4 Filter housing
5 Maintenance switch |
|--|--|

1. Loosen both retaining clips.
2. Remove the filter cap.
3. Pull out the old filter element.
4. Carefully clean the filter housing, sealing surfaces and cap with a damp cloth.
5. Insert a new filter element in the housing, ensuring that the filter element is correctly in place and the seals can function properly.
6. Position the filter cap.
7. Secure the filter cap with the two retaining clips.
8. Check to ensure the filter cap is properly attached.

Reset the maintenance timer:

- Reset the maintenance timer as described in the separate operating manual for the SIGMA CONTROL SMART, chapter "Resetting the maintenance timer".

Clean the filter elements


Reuse cleaned filter elements only as an exception.
Always use new filter elements if possible.




Fig. 43 Cleaning the filter element

- | | |
|---|------------------|
| ① Cleaning the filter element | ④ Filter element |
| ② Checking the filter element | ⑤ Flashlight |
| ③ Compressed air gun with blast pipe (bent to approx. 90° at the end) | |

1. Use dry compressed air (<30 psig!) to blow dirt out of the filter element at an angle from the inside to the outside.
2. Blow out the filter element until no further dust appears.
3. In a darkened room, use a suitable flashlight to shine through the cleaned filter element.
The cleaned filter element does not display any cracks or holes.
The cleaned filter element is in a proper condition.
4. Insert the cleaned and checked filter element into the filter housing.
5. Position the filter cap.
6. Secure the filter cap with the two retaining clips.
7. Check to ensure the filter cap is properly attached.

10.5.8 Cleaning the compressed air aftercooler

The compressed air aftercooler is installed separately from the compressed air treatment components. The required cleaning frequency depends heavily on the local operating conditions.

Check the compressed air aftercooler regularly for contamination.

Arrange for heavy contamination to be removed by an authorized KAESER service representative.

Material	Compressed air, breathing mask (if required)
Precondition	<p>The machine is switched off.</p> <p>The machine has been placed in a cleaning area with an oil separator, the machine is standing on level ground, the machine has cooled down.</p> <p>The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position.</p> <p>The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig.</p> <p>The door/s is/are open.</p>

⚠ CAUTION

Swirling dust due to cleaning with compressed air!

Risk of respiratory illness

- *Wear a breathing mask.*

NOTICE

Water jets can damage the machine!

Direct water jets can damage or destroy electrical components.

- *Do not use water jets to clean the interior of the machine.*

NOTICE

Improper cleaning with hard objects!

Damage to the compressed air aftercooler.

- *Do not use hard objects to clean the oil cooler.*

- Follow all instructions carefully.

10.5.8.1 Cleaning the compressed air aftercooler




Clean the compressed air aftercooler by using suitable compressed air, see Table 84.

The cleaning direction of the compressed air must always be in the opposite direction to the cooling air flow.

Suitable compressed air range for cleaning	Value
Working pressure [psig]	≤ 30

Tab. 84 Suitable compressed air range for cleaning



10-M2981-M25xE

Fig. 44 Cleaning the compressed air aftercooler

- ① Compressed air aftercooler
- ② Compressed air cleaning direction
- ③ Centrifugal separator

Cover the intake openings on both air filters:

1. Cover the intake openings on both air filters.
2. Close the door/s.

Clean the compressed air aftercooler

- Clean the cooler fins with compressed air in the opposite direction to the cooling air flow.

Uncover the intake openings on both air filters:

1. Open the door/s.
2. Remove the protective covering from the intake openings on both air filters.
3. Close the door/s.

Prepare for operation:

1. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
2. Turn the «Controller ON/OFF» switch to the *ON* position.

Start the machine:

1. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.
2. Warm up the machine by allowing it to run in IDLE.
Warm-up has been achieved when the required airend discharge temperature is reached.
3. Press and hold down the «OFF» key on the operating panel of the SIGMA CONTROL SMART for longer than 1 second.
The machine is switched off.

4. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!
5. Open the discharge valves.

Check the compressed air aftercooler for leaks:

1. Open the door/s.
2. Visually inspect for leaks: Is condensate escaping?



Is the compressed air aftercooler leaking?

➤ Arrange for the defective compressed air aftercooler to be repaired/replaced immediately by an authorized KAESER service representative.



Only clean the cooling fins at cleaning areas equipped with an oil separator!

10.5.9 Servicing the dirt trap on the centrifugal separator

Clean the dirt trap on the centrifugal separator if the moisture content in the compressed air is too high. The dirt trap ③ is mounted at the bottom of the centrifugal separator ②.

Material	Cleaning cloth Wrench Small screwdriver Dirt trap maintenance kit Cleaning solvent or spirit
Precondition	The machine is switched off. The machine is standing on level ground, the machine has cooled down. The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig! The door/s is/are open.




Fig. 45 Cleaning the dirt trap

- | | | | |
|-----|---------------------------------|------|---------------------|
| [1] | Compressed air aftercooler | [6] | Reducer |
| [2] | Centrifugal separator | [7] | Strainer |
| [3] | Dirt trap | [8] | Screw-in connection |
| [4] | Condensate hose line | [9] | Nozzle |
| [5] | 2-way directional control valve | [10] | Clamping nut |

► Follow all instructions carefully.

Clean the dirt trap:

1. Loosen and remove the clamping nut [10].
2. Remove the nozzle [9].
3. Loosen and remove the screw-in connection [8].
4. Remove the strainer.
5. Clean the nozzle and strainer with cleaning solvent or spirit.
6. Check the nozzle and strainer for wear.



Components are damaged or show signs of wear.

► Replace the components.

7. Clean the screw-in connection, reducer and clamping nut with cleaning solvent or spirit
8. Correctly reinstall all individual parts.
9. Properly tighten all individual parts.
10. Close the door/s.

Prepare for operation:

1. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
2. Turn the «Controller ON/OFF» switch to the *ON* position.

Start the machine and perform a test run:

1. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.

2. Warm up the machine by allowing it to run in IDLE.
Warm-up has been achieved when the required airend discharge temperature is reached.
3. Press and hold down the «OFF» key on the operating panel of the SIGMA CONTROL SMART for longer than 1 second.
The machine is switched off.
4. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!

Check the dirt trap and condensate hose line for leaks:

1. Open the door/s.
2. Visually inspect the dirt trap for leaks.
3. Visually inspect the condensate hose line for leaks.

10.5.10 Checking safety relief valves

- Have safety relief valves checked by an authorized KAESER service representative in accordance with the maintenance schedule.

10.5.11 Checking the excessive temperature shut-down function

The machine should shut down if the discharge temperature reaches a maximum of T_{\max} . [$^{\circ}\text{F}$]. T_{\max} . [$^{\circ}\text{F}$] see table 85.

Machine temperature	Value
Maximum airend discharge temperature [$^{\circ}\text{F}$]	243


Tab. 85 Shut-down at excessive temperature

- Check the excessive temperature shut-down function as described in the SIGMA CONTROL SMART operating manual.
-  The machine does not shut down?
The excessive temperature shut-down function is no longer ensured.
► Shut down the machine immediately and contact an authorized KAESER service representative.

10.5.12 Check the EMERGENCY STOP push button

- In order to shut down the machine in the event of an emergency, the machine is equipped with an EMERGENCY STOP push button.
The EMERGENCY STOP push button must only be used in the event of an emergency.

To enable shutdown of the machine in the event of an emergency, the EMERGENCY STOP push button must be fully functional at all times.



10-M2923-M25xE

Fig. 46 Check the EMERGENCY STOP push button

- ① Control panel cover
- ③ «EMERGENCY STOP» push button
- ④ Direction of arrow

Check «EMERGENCY STOP» push button with the machine switched off

Precondition The machine is switched off.

The drive motor stands still.

1. Press the «EMERGENCY STOP» push button.
2. Check to ensure the «EMERGENCY STOP» push button locks properly and remains locked.
3. Check to ensure the «EMERGENCY STOP» push button unlocks properly by turning it in the direction of the arrow.



Proper functioning of the «EMERGENCY STOP» push button is no longer ensured?

- Shut down the machine immediately and contact an authorized KAESER service representative.

10.6 Cleaning the oil cooler

The required cleaning frequency depends heavily on the local operating conditions.

Heavy contamination of the oil cooler causes excessive temperatures and thus overheating of the machine.

Check the oil cooler regularly for contamination.

Arrange for heavy contamination to be removed by an authorized KAESER service representative.

Material Compressed air,
breathing mask (if required)

Precondition The machine is switched off.

The machine has been placed in a cleaning area with an oil separator,
the machine is standing on level ground,
the machine has cooled down.

⚠ CAUTION

*Swirling dust due to cleaning with compressed air!
Risk of respiratory illness.*

- Wear a breathing mask.

NOTICE

*Water jets can damage the machine!
Direct water jets can damage or destroy electrical components.
➤ Do not use water jets to clean the interior of the machine.*

NOTICE

*Improper cleaning with hard objects!
Damage to oil cooler.
➤ Do not use hard objects to clean the oil cooler.*


- Follow all instructions carefully.

10.6.1 Cleaning the oil cooler

- Clean the oil cooler using suitable compressed air, see Table 86.
The cleaning direction of the compressed air must always be in the opposite direction to the cooling air flow.

Suitable compressed air range for cleaning	Value
Working pressure [psig]	≤ 30

Tab. 86 Suitable compressed air range for cleaning



10-M2907-M25xE

Fig. 47 Cleaning the oil cooler

- | | |
|--|--|
| [1] Right front side of machine (cooling air outlet) | [3] Oil cooler |
| [2] Door | [4] Direction of cleaning with compressed air (from outside to inside) |

Cover the intake openings of both air filters:

1. Open the door on the left front side of machine.

2. Cover the intake openings of both air filters.
3. Close the door.

Clean the oil cooler

1. Open the door on the right front side of the machine (cooling air outlet).
2. Clean the cooler fins with compressed air in the opposite direction to the cooling air flow (from outside to inside).

Uncover the intake openings on both air filters:

1. Open the door on the left end side of machine.
2. Remove the protective coverings from the two air filters.
3. Close the door.

Prepare for operation:

1. Connect the on-site main supply and the machine using a power supply cable.
2. Switch on the «Load isolating switch» on the on-site power supply disconnecting device (all poles).
3. Turn the «Controller ON/OFF» switch to the *ON* position.

Start the machine:

1. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.
2. Warm up the machine by allowing it to run in IDLE.
Warm-up has been achieved when the required airend discharge temperature is reached.
3. Press and hold down the «OFF» key on the SIGMA CONTROL SMART operating panel for longer than 1 second.
The machine is switched off.
4. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!

Check the oil cooler for leaks:

1. Open the door.
2. Visually inspect for leaks: Is any oil escaping?



Is the oil cooler leaking?

- Arrange for the defective oil cooler to be repaired/replaced immediately by an authorized KAESER service representative.

- Close the door.



Only clean the cooler fins at cleaning areas equipped with an oil separator!

10.7 Checking/emptying the condensate collection tank

Overview:

- Emptying the condensate collection tank
- Checking the condensate drain line

Material Cleaning cloth

Tank

Precondition The machine is switched off.

The machine is standing level and has cooled down.

The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles,
the «Load isolating switch» is secured against being switched on again,
the absence of all voltage has been verified.

The «Controller ON/OFF» switch is set to the *OFF* position.

The butterfly valve on the compressed air outlet is open,
the machine is fully vented, the pressure gauge reads 0 psig!

The door/s is/are open.




Fig. 48 Unlocking the venting coupling

- | | | | |
|----------|--|----------|----------------------------|
| A | Venting the condensate collection tank | ③ | Lid |
| B | Unlocking the plug-in fitting | ④ | Condensate collection tank |
| ① | Venting coupling | ⑤ | Condensate drain line |
| ② | Push button | ⑥ | Plug-in fitting |

- Follow all instructions carefully.



Condensate contains pollutants and is harmful to the environment!
Therefore, proceed as follows in accordance with applicable environmental protection regulations:

- Store condensate in special containers.
- Dispose of the container contents regularly and properly.
- Check to see if the condensate is drained internally or externally.

10.7.1 Emptying the condensate collection tank

Emptying the internal condensate collection tank	Emptying the external condensate collection tank
<ol style="list-style-type: none"> 1. Press the venting coupling push button. The condensate collection tank is vented. 2. Press the venting coupling push button once again. The condensate drain line plug-in fitting is unlocked. 3. Pull the plug-in fitting out of the venting coupling. The venting coupling seals on one side. 4. Remove the condensate collection tank from the support inside the machine. 5. Loosen and remove the lid from the internal condensate collection tank. 6. Fill the condensate into an external container. 7. Properly close the condensate collection tank with the lid. 8. Place the condensate collection tank in the support inside the machine. 9. Insert the plug-in fitting of the condensate drain line into the venting coupling as far as it will go. 10. Check that the plug-in fitting of the condensate drain line is correctly locked. 	<ol style="list-style-type: none"> 1. Close the shut-off valve on the draining device outside the machine. 2. Loosen and remove the open hose end from the external condensate collection tank. 3. Fill the condensate from the external condensate collection tank into an external container. 4. Route the open end of the hose into the external condensate collection tank and secure it in place. 5. Open the shut-off valve on the draining device outside the machine.

10.7.2 Checking the condensate drain line

Checking the internal condensate drain line	Checking the external condensate drain line
<p>The internal condensate drain line must always be properly fastened onto the lid of the internal condensate collection tank.</p> <ol style="list-style-type: none"> 1. Check to ensure that the internal condensate drain line has been properly fastened. 2. Check to ensure that the lid of the condensate collection tank is properly closed. 3. Check to ensure that the venting coupling is inserted and locked. 4. Visually check for leaks inside the machine. Leakages of condensate are visible. <ul style="list-style-type: none"> ➤ Check the condensate drain line for leaks. ➤ If necessary, replace/arrange for the internal condensate drain line to be replaced. 	<p>In order for all of the accumulated condensate to reach the external condensate collection tank, the external condensate drain line must always be properly fastened to the shut-off valve on the front side of the machine and the external condensate collection tank.</p> <ol style="list-style-type: none"> 1. Check to ensure that the external condensate drain line has been properly fastened. 2. Visually check for leaks inside and outside the machine. <p>Leakages of condensate are visible.</p> <ul style="list-style-type: none"> ➤ Check the condensate drain line for leaks. ➤ If necessary, replace/arrange for the applicable condensate drain line to be replaced.

10.8 Checking the screw connections

Overview:

- Guideline values for tightening torques.
 - General guideline values for tightening torques.
 - Specific guideline values for tightening torques.
 - Sealed screw connections.
- Follow all instructions carefully.

10.8.1 General guideline values for tightening torques

Guideline values for the required tightening torques are dependent upon the size of the screw connection, the strength class of the screw material and the friction coefficient.

NOTICE

Damage to the machine from insufficient clamping force at screw connections

- *Tighten all screw connections with the defined tightening torque.*

1. Determine the thread size for the screw connection.
2. For determining the defined torque, see chapter 2.3.2.
3. Tighten all screw connections with the defined torque.

10.8.2 Specific guideline values for tightening torques

Screw connections for components that are either safety-related or under particular stress must be tightened with specific tightening torques.

Examples:

- For details of specific tightening torques, see chapter 2.3.2.
 - E.g. Screw connections on lifting eyes.
 - E.g. Cover screws on the oil separator tank.
- Values for further specific tightening torques are provided in the section covering the relevant maintenance task.

NOTICE

Damage to the machine from insufficient clamping force at screw connections

- *Screw connections for components that are either safety-related or under particular stress must be tightened exclusively with the correct specific tightening torque.*

1. Determine the correct specific tightening torque.
2. Tighten the screw connections with the specific tightening torque.

10.8.3 Sealed screw connections

Screw connections which must not be adjusted are sealed with a colored locking varnish.

NOTICE

Damage to the machine caused by adjusting the settings

- *Leave sealed screw connections in their original condition.*

- Do not loosen or adjust sealed screw connections.



Failure to comply with these instructions will invalidate all warranty claims.

10.9 Check sound insulation material

Sound insulation material reduces machine noise emissions to a minimum.

Check your machine's sound insulation material according to the maintenance schedule.

Dismantle the cooling air inlet and outlet grills to properly inspect the sound insulation material.

Have damaged sound insulation material replaced immediately.

Sound insulation material is installed, for example, in the following positions within the machine:

- Cooling air inlet and outlet
- Enclosure, gull-wing doors and swing doors
- Bulkheads

1. Dismantle cooling air inlet and outlet grills.
2. Check the sound insulation material in the cooling air inlet and outlet.
3. Check all sound insulation material inside the machine.
4. Check sound insulation material for condition, attachment and dirt.



The sound insulating material is porous, cracked, no longer exists or is severely contaminated with oil or cleaning agent.

- Have an authorized KAESER service representative replace the sound insulation material that can no longer be used.

10.10 Checking the doors



Closing the doors of the machine during operation fulfills the following functions: Protection against contact, cooling air flow, sound insulation and weather protection.

In order to ensure these functions at all times, the doors and their connection elements must always be in proper condition.

Overview:

- Service the rubber seals
- Check the closed doors
- Check the connection elements

Precondition The machine is switched off.

The machine is standing level and has cooled down.

The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles,

the «Load isolating switch» is secured against being switched on again,
the absence of all voltage has been verified,
the «Controller ON/OFF» switch is set to the *OFF* position.

The butterfly valve on the compressed air outlet is open,
the machine is fully vented, the pressure gauge reads 0 psig!

- Follow all instructions carefully.

10.10.1 Service rubber sealing strips

Material Cleaning cloth

Silicone oil or Vaseline

The rubber sealing strips of the doors seal against rain water and additionally reduce noise emissions. Care of the rubber sealing strips is especially necessary in winter to prevent the strips from sticking and tearing when the access panels are opened.

1. Open all doors.
2. Carefully clean all rubber sealing strips using a lint-free cloth.
3. Check the rubber sealing strips for cracks, holes and other damage.
4. Grease all rubber sealing strips.



Rubber sealing strips are damaged.

- Have an authorized KAESER service representative replace the damaged rubber sealing strips.

10.10.2 Checking function of closed doors

1. Close all doors.
2. Lock all snap fasteners.



One or several doors do not properly rest on the body or cannot be locked.

- Contact an authorized KAESER service representative.

10.10.3 Checking connection elements of doors

Material Acid-free oil

The connection elements of the doors may include:

- Screw connections
- Hinges
- Sash fastener

1. Check all connection elements of the doors for damages, wear and firm seat.
2. If necessary, grease the hinges.

10.11 Checking/replacing hose lines

The machine's hose lines comprise the pressure hoses of the compressor.



The hose lines are subject to natural aging regardless of proper storage or permitted utilization during machine operation. This aging changes the material and compound properties and reduces the performance capability of the hose lines. As a result, the period of use for hose lines is limited.

The operator must ensure that all hose lines are checked at reasonable intervals and are replaced if required, see maintenance schedule 10.3.2.1

- Comply with all instructions!

10.11.1 Replace the pressure hoses of the compressor

Overview of all pressure hoses on the compressor:

- Cooling oil
- Compressed air
- Control air
- Condensate

- Have an authorized KAESER service representative replace the pressure hoses of the compressor.

10.12 Draining accumulated liquid inside the machine

The so-called "closed floor pan" contributes to protection of the environment by preventing ground contamination in the event of operating fluid leaks.

Accumulated liquid inside the machine's bodywork can also cause corrosion or electrical problems. Accumulated liquid must be removed as quickly as possible in order to avoid potential machine faults.

For draining the accumulated liquid, the machine is provided with a service opening in the area of the central condensate and cooling oil draining device, which is sealed with a plug.



Due to the restricted ground clearance, it is recommended to use a lifting ramp or vehicle pit for machines with a stationary frame structure.

It is prohibited to lift the machine by crane and allow it to hang from the hoist for inspection or maintenance purposes!

10.12 Draining accumulated liquid inside the machine

Material	Receptacle Cleaning cloth Seal
Precondition	<p>The machine is switched off.</p> <p>The machine is standing on level ground, the machine has cooled down.</p> <p>The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified.</p> <p>The «Controller ON/OFF» switch is set to the <i>OFF</i> position.</p> <p>The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig!</p>




Fig. 49 Closed floor pan plug

- ① Front side of machine
- ② Skid

- ③ Central draining device
- ④ Plug

1. Place a receptacle beneath the maintenance opening.
2. Loosen and remove the plug.
3. Allow the liquid to drain out.
4. Clean the plug and maintenance opening.
5. Check the seal on the plug.
6. If necessary, replace the plug seal.
7. Insert the plug.
The floor pan is sealed.
8. Open all doors.
9. Using a cleaning cloth, remove any contamination inside the machine.
10. Close all doors.



Dispose of collected liquid and contaminated working materials in accordance with applicable environmental protection regulations.

10.13 Have the main contactor replaced

Service the main contactor when any of the following events occur:

- Warning message indicated with specific message code (see table 87) on the display of SIGMA CONTROL SMART.
- The maximum working life has elapsed.

Message code	Measure
2400	Have the main contactor replaced

Tab. 87 Specific message code for "Service main contactor"

- Have the main contactor replaced by an authorized KAESER service representative.

10.14 Maintenance for Optional Items

- Perform maintenance tasks according to the schedule in chapter 10.3.2.2.

10.14.1 Servicing the filter combination

Overview:

- Draining the condensate
- Changing the filter elements

WARNING

Danger of injury from escaping compressed air!

The filter combination is pressurized during operation. Serious injury can result from loosening or opening components under pressure.

- *Wait until the machine is completely vented (check: pressure gauge reads 0 psig).*
- *Vent the filter combination.*

Option dd




Fig. 50 Compressed air filter combination

- | | |
|-------------------------|------------------------------------|
| ① Centrifugal separator | ④ Fine filter |
| ② Filter combination | ⑤ Condensate drain shut-off valves |
| ③ Prefilter | ⑥ Minimum pressure check valve |

► Open the door/s.

10.14.1.1 Draining the condensate

To blow out the condensate that has been discharged into the filter combination housings, the machine must be run with the condensate drain shut-off valves open for a short period of time.

Material Receptacle
 Cleaning cloth




Fig. 51 Draining the condensate

- | | |
|-----------------------------------|---|
| ① Condensate drain shut-off valve | ⑤ Shut-off valve open |
| ② Condensate drain shut-off valve | ⑥ Lever positioned in direction of flow |
| ③ Hose line | ⑦ Shut-off valve closed |
| ④ Receptacle | ⑧ Lever positioned across direction of flow |

Position the receptacle

- Precondition The machine is switched off.
The machine is standing level.
The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles,
the «Load isolating switch» is secured against being switched on again,
the absence of all voltage has been verified,
the «Controller ON/OFF» switch is set to the *OFF* position.
The butterfly valve on the compressed air outlet is open,
the machine is fully vented, the pressure gauge reads 0 psig.
1. Open the door/s.
 2. Place the receptacle beneath the filter combination hose lines.
 3. Open both condensate drain shut-off valves.
 4. Close the door/s.

Start the machine

1. The «Load isolating switch» on the on-site power supply disconnecting device is switched on at all poles.
2. Turn the «Controller ON/OFF» switch to the *ON* position.
3. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.
4. Allow the machine to run in IDLE operation.
The condensate discharged into the filter combination housings is blown out.
5. Wait until only compressed air is emitted.
6. Press and hold down the «OFF» key on the SIGMA CONTROL SMART operating panel for longer than 1 second.
The machine is switched off.
7. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig.
8. Switch off the «Load isolating switch» (all poles).
9. Turn the «Controller ON/OFF» switch to position *OFF*.
10. Open the door/s.
11. Close both condensate drain shut-off valves.
12. Remove the receptacle from the machine.
13. Close the door/s.



Condensate must be stored in suitable containers and disposed of in accordance with applicable environmental protection regulations.

10.14.1.2 Replacing the filter elements


The prefilter and microfilter both contain two different filter elements, which must be changed in pairs. Note positioning!



Operating the filter combination without filter elements installed is not permitted!

Only handle new filter elements when wearing clean fabric gloves. Do not touch the new filter elements with bare fingers – contamination risk!

Material	Spare parts Filter wrench Wrench Cleaning cloth Clean fabric gloves
Precondition	The machine is switched off. The machine is standing on level ground, the machine has cooled down. The «Load isolating switch» on the on-site power supply disconnecting device is switched off at all poles, the «Load isolating switch» is secured against being switched on again, the absence of all voltage has been verified, the «Controller ON/OFF» switch is set to the <i>OFF</i> position. The butterfly valve on the compressed air outlet is open, the machine is fully vented, the pressure gauge reads 0 psig. The door/s is/are open.


Fig. 52 Changing the filter elements

- | | | | |
|---|---------------------------|---|----------------|
| ① | Filter combination | ⑥ | Filter head |
| ② | Prefilter | ⑦ | Filter element |
| ③ | Fine filter (microfilter) | ⑧ | Housing seal |
| ④ | Hose line clamping nut | ⑨ | Filter housing |
| ⑤ | Hose line clamping nut | | |

Ensure that the filter combination is not under pressure:

- Slowly open the shut-off valves on the prefilter and fine filter condensate drain.
Any remaining pressure is released.

Gain access to the filter housing:

To remove the housing from the prefilter and fine filter, the clamping nuts on the hose lines must first be removed.

1. Loosen both clamping nuts on the hose lines for the condensate drain.
2. Remove both hose lines from the prefilter and fine filter.

Replace both filter elements on the filter combination:

- Follow all instructions carefully.

Replace the filter element on the prefilter	Replace the filter element on the fine filter
➤ Remove the filter housing in an counterclockwise direction	➤ Remove the filter housing in an counterclockwise direction
➤ Pull off the filter element in a downwards direction.	➤ Pull off the filter element in a downwards direction.
➤ Clean the filter head and housing with a lint-free cloth.	➤ Clean the filter head and housing with a lint-free cloth.
➤ Clean all sealing surfaces with a lint-free cloth.	➤ Clean all sealing surfaces with a lint-free cloth.
➤ Check the housing seal, replace with new if required.	➤ Check the housing seal, replace with new if required.
➤ Wear gloves.	➤ Wear gloves.
➤ Insert a new filter element.	➤ Insert a new filter element.
➤ Refit the filter housing by turning clockwise.	➤ Refit the filter housing by turning clockwise.

Tab. 88 Replacing the filter elements

Prepare for operation:

1. Fit both clamping nuts on the hose lines for the condensate drain to the screw connections on the prefilter and fine filter.
2. Close the condensate drain shut-off valves.
3. Tighten all screw connections on the compressed air filter combination.
4. Close the door/s.



Dispose of old parts and contaminated materials in accordance with environmental regulations.

Further information

Further information on replacing filter elements can be found in the "Filter Operating Instructions" in chapter 13.5.

Start the machine and perform a test run:

1. Switch on the Load isolating switch on the on-site power supply disconnecting device (all poles).
2. Switch the machine on via the «START» key on the operating panel of the SIGMA CONTROL SMART.

3. Warm up the machine by allowing it to run in IDLE.
Warm-up has been achieved when the required airend discharge temperature is reached.
4. Press and hold down the «OFF» key on the operating panel of the SIGMA CONTROL SMART for longer than 1 second.
The machine is switched off.
5. Wait until the machine has vented automatically.
The pressure gauge reads 0 psig!

Check the filter combination for leaks:

1. Open the door/s.
2. Visually inspect the filter combination for leaks.
3. Visually inspect the condensate hose lines for leaks.
4. Close the door/s.

10.15 Documenting maintenance and service work

Machine model/part number:

- Enter maintenance and service work carried out in this list.

Date	Maintenance task carried out	Operating hours	Signature

Tab. 89 Maintenance log

11 Spares, Operating Materials, Service

11.1 Note the nameplate

The nameplate contains all information to identify your machine. This information is essential to us in order to provide you with optimal service.

- Please give the information from the nameplate with every inquiry and order for spares.

11.2 Ordering spare parts and operating fluids/materials

KAESER spare parts and operating fluids/materials are original products. They are specifically selected for use in our machines and ensure a machine's trouble-free operation.

Unsuitable or poor quality spare parts and operating fluids/materials may result in damage to the machine or significantly impair its proper function.

Personal injury may result from damage.

⚠ WARNING

There is risk of personal injury or damage to the machine resulting from the use of unsuitable spare parts or operating fluids/materials!

- Use only original parts and operating fluids/materials.
- Do not use alternative spare parts and operating fluids/materials.

Compressor

Name	Number/quantity	Number
Filter element, air filter	1	1260
Filter element, oil filter	2	1210
Oil separator cartridge set	1	1450
Cooling oil	1	1600

Tab. 90 Compressor spare parts

Drive motor

Name	Number/quantity	Number
Bearing grease (100 g)	1	9.0915.0
Bearing grease (400 g)	1	6.3234.0

Tab. 91 Drive motor spare parts

11.3 KAESER AIR SERVICE

KAESER AIR SERVICE offers:

- Authorized service technicians with KAESER factory training.
- Increased operational reliability ensured by preventive maintenance.
- Energy savings achieved by avoidance of pressure losses.

- The security of genuine KAESER spare parts.
 - Increased legal certainty as all regulations are kept to.
- Why not sign a KAESER AIR SERVICE maintenance agreement.
The advantages:
Lower costs and higher compressed air availability.

11.4 Replacement parts for service and repair

Use these parts lists to plan your material requirement according to operating conditions and to order the required spare parts.


⚠ WARNING

*Personal injury or machine damage due to incorrect working on the machine!
Incorrect inspection, service or repair can damage the machine or severely impair its function. Personal injury may result from damage.*

- *Inspections, preventive maintenance or repair tasks not described in this Operating Manual must not be carried out by unqualified personnel.*
- *Have further tasks, not described in this operating manual, carried out by specialist workshops or by an authorized KAESER service representative.*

11.4.1 Spare parts overview

Validity: M250E / M255E



Drawings remain the exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of data processing systems, are only permitted with the written consent of KAESER Kompressoren GmbH.


Das Zeichnungssymbol darf nur für die von uns festgelegte Funktion benutzt werden. Eine unbefugte Verbreitung ist ausdrücklich untersagt. Zeichnungen und technische Daten sind Eigentum von KAESER Kompressoren GmbH. Die Zeichnung darf nur mit schriftlicher Genehmigung von KAESER Kompressoren GmbH kopiert, vervielfältigt oder elektronisch gespeichert, bearbeitet oder verarbeitet werden. Elektronische Systeme dürfen nur sofern wie erlaubt nach den Zwick-Merkblättern genutzt werden.

Originalzeichnung/Vervielfältigungsrechte der Dritten ausgenommen

BAUZEICHNUNG

Overview / Übersicht

Zeilennummern	Zeilenname	Zeichnung	Document-Nr.	Original	A4	Draum	Name	Erstell mit
SEG-Nummer	Service-Satz (Drawing)	Service Ersatzteil-Zeichnung						SoLo Edge
SEG-1176	Service-Kit (Option)	Subassembly / Untergruppe						Blatt
								1 von 1



Drawing remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither original nor copy may be given to a third party.


Das Zeichnung bleibt ausschließlich Eigentum. Nur für die vereinbarte Nutzung darf es hergestellt, bearbeitet und verbreitet werden. Keine Kopie oder sonstige Organisation Vervielfältigung oder Weitergabe an Dritte.

Original und Zeichnung sind urheberrechtlich geschützt. Alle Rechte vorbehalten. Keine Verbreitung oder Weitergabe gestattet.

Baugruppe

KAESER KOMPRESSOREN

Zeilungstyp	Service spare part drawing / Service Ersatzteil Zeichnung	Document-Nr.	Original	Datum	Name
SEG-Nummer	SEG-11277	Aa	Gaz	11.03.2020	PUFF1
<input checked="" type="checkbox"/> ServiceKit (Option)				Preis 07.08.2020	Bauart
				Stück F R E I G E B E N	1 von 1



Drawing elements are exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of data processing systems, are only permitted with the written consent of KAESER Kompressoren GmbH.


Das Zeichnungselement ist Eigentum der Firma. Es darf nur für die vereinbarte Verwendung kopiert werden. Eine Vervielfältigung, Verarbeitung oder Verbreitung aller Werkzeuge, elektronischer Systeme oder auf andere Weise erlaubt ist, ist ausdrücklich untersagt.

Originalzeichnung/Vorablieferung darf nur Dritten ausgetragen werden in strenger Weise ausdrücklich genehmigt.


BAUR-System

Overview / Übersicht

Zeilennamens	Zeilennamens	Dokument-Nr.	Original	A4	Datum	Name	Erstell mit
SEG-Nummer	Service-Kit (Option)	Subassembly / Untergruppe			11.03.2020	PUFFI	SoE/Erfuge
SEG-1128					07.08.2020	PUFFI	Blatt
						Statis F R E I G E C E B E N	1 von 1




Overview Übersicht		KAESER KOMPRESSOREN		
Baugruppe	Zeilenumbrüpf	Service spare part drawing / Service Ersatzteil Zeichnung	Dokument-Nr.	Name
Service spare part drawing / Service Ersatzteil Zeichnung	Original	Document-Nr.	Datum	Erhält mit
SEG-Number	Aa		Gaz.	Soil Edge
SEG-11279			11.03.2020	PUFFI
			Preis 07.08.2020	Bauart
				Statis. F. EIGE GEBEN
				1 von 1




KAESER		KOMPRESSOREN	
Drahtzeichen		Name	
Zeilenumbersp		Zeile mit	
Service-Satz nummer		Zeile 2	
SEG-Nummer		Zeile 3	
SEG-1052-01		Blatt	1 von 1

1001 - Inlet air/Cooling air/Exhaust / Ansaugluft/Kühlluft/Abgas


Dokument-Nr.	Original	Druck	Druck
	A4	Ges.	Zeit
1001-1			
Service-Kit (Option)			
Subassembly / Unterguppe			




6452




6431



6454




KAESER		KOMPRESSOREN	
Zeilenumfang			
Zeichnungsnr.	Service Zeichnung / Service Einzelteil Zeichnung	Dokument-Nr.	Name
SEG-Nummer		Original	Ersatzteil mit
SEG-13693		A4	Solid Edge
		Cad:	Bauart
		Freige:	PUFFI
			11/02/2022
			Statisi F R E I G E O E B E N
			1 von 1
Baugruppe:		1270 - Compressor air filt. w/housing / Kompressorluftfilter mit Geh.	
Service-KIT (Option)		Subassembly / Untergruppe	




Drawing release our exclusive property. They are entered only for the assigned purpose. Copies or any other reproduction, including storage, transmission and dissemination by use of electronic systems must not be made for any other than the assigned purpose. Neither original nor reproductions may be given to third parties.
 Do Zulässung allein unter Ausschluß Eigenart. Bei und zu übernahmener Zweck, Amtswahl und der zu denken haben Zweck von oben. Kopie oder sonstige Vervielfältigung ist untersagt. Verbreitung oder Weiterleitung ist untersagt. Verarbeitung oder Verwendung ist untersagt. Dies gilt für alle Zeichnungen und technische Dokumente, die in der Firma KAESER-KOMPRESSOREN AG erstellt werden.


KAESER KOMPRESSOREN	
Ersatzteil-Nr.	Name
Original-Nr.	Zeichnung
Aa	Gez.
1042 - Option auxiliary heater / Option Stillstandserzung	Frühjahr2
1042 - Option auxiliary heater / Option Stillstandserzung	Frühjahr1
1042 - Option auxiliary heater / Option Stillstandserzung	Dorfst1
1042 - Option auxiliary heater / Option Stillstandserzung	Batt
1042 - Option auxiliary heater / Option Stillstandserzung	1 von 1
Zeilenummer	
Service spare part drawing / Service Ersatzteil Zeichnung	
SEI-Kennnummer	
SEI-10545.01	
<input checked="" type="checkbox"/> Service-Kit	<input type="checkbox"/> Option
<input type="checkbox"/> Subassembly / Untergruppe	




KAESER KOMPRESSOREN	
Drahtzugseil Original-Nr. 10546.01	
Zeilenumbersp	
Service-Satz-Zeilenummer	
SEG-Nummer	
SEG-10546.01	
(Optional)	
Subassembly / Unterguppe	
Baugruppe	
1087 - Set dokument-box / Satz Dokumenttasche	
Zeilenumbersp	
Service-Satz-Zeilenummer	
Document-Nr.	
Original	
A4	
Zeichnung mit	
Name	
Franziska2	
Gez:	
17.06.2019	
Blatt:	
Franziska2	
Replay	
17.06.2019	
Status	
frisch erhalten	
1 von 1	



KAESER KOMPRESSOREN			
Zeilungssyp	Service-Kit (Option)	Subassembly / Untergruppe	
SEG-Nr.: 2001 - Oil circuit/Air outlet / Ölkreislauf/Airoutlet	Document-Nr.:	Original	Datum:
SEG-Nr.: 10547.01	7841	Aa	Gez. 27.06.2019
		Fremdauf2	
		Fremdauf2	
		Status für Lieferanfrage	
		Blatt:	1 von 1






3192

5410

9708

Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor copies may be given to third parties.
Das Zeichnung bleibt unser ausschließlich Eigentum. Es wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keinem anderen Zweck verwendet werden.
Zeichnungen unterliegen dem Urheberrecht. Verbreitung und Speicherung in elektronischen Systemen dürfen nur zu dem vereinbarten Zweck erfolgen. Kopiere oder sonstige Vervielfältigungen sind ausdrücklich untersagt.
Original und Kopie sind nicht an Dritte weiterzuverleihen.

BAUTRAGEN		Zeilungssymp		Service-Kit (Option)		Subassembly / Untergruppe	
3023 - Dryer / Trockner		Document-Nr.	Original	Datum	Gez.	Name	Ersatz mit
				08.08.2019	Puff		Solid Edge
				Printed 08.08.2019			Blatt:
							1 von 1
SEG-10549.01							



KAESER		KOMPRESSOREN	
Zeilenumbersp	Zeilenumbersp	Erstellt mit	
SEG-Kennnummer	Service-Sparz. / Service-Ersatzteil-Zeichnung	Name	
SEG-10560,01	(Option) Subassembly / Untergruppe	Punkt	
		Blatt	
		1 von 1	

Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of data processing systems must not be made without the prior written permission of KAESER Kompressoren GmbH.

Die Zeichnungen sind urheberrechtlich geschützt. Nachdruck, Vervielfältigung und Verbreitung ist ohne schriftliche Genehmigung der KAESER Kompressoren GmbH untersagt. Die Zeichnungen sind nur für den Betrieb, die Wartung und die Reparatur des Kompressors bestimmt. System- und Montage-Zeichnungen sind für den Monteur und die Montage bestimmt.

Original nach Vervielfältigung durch Druck auf dem Ausdruck

Bearbeitungs-

3910 - Instrument panel / Bedientafel

Service-Kit

Original

Zeilenumm

Ad

Gez:


Druck

Name


Punkt

Blatt

1 von 1



KAESER KOMPRESSOREN	
Drahtseil zum exclusive property. They are exhausted only for the signed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the signed purpose. Weiterer Kopien oder Reproduktionen sind ausdrücklich untersagt.	Erlaubt mit Name
Das Zeichnung bleibt Urheberrechtlich geschützt. Sie wird nur zum inneren Betrieb benutzt und darf außerhalb des Betriebsbereichs nicht weiterverbreitet werden. Kopien oder Reproduktionen sind ausdrücklich untersagt.	Zeichnung Ges.
Original nicht mehr verfügbare Teile können durch die KAESER WERKE ersetzt werden. Diese ausgetauschten Teile müssen dem Kunden gegen eine Gebühr von 100,- € abgenommen werden.	Ingress 05.07.2021 PUFF1
Baugruppe	Statische Fliegende Ebenen
1195 - Oil filter with housing / Ölfilter mit Gehäuse	
Zeilenumgrupp	
Service sparte part drawing / Service Teil-Zeichnung	Dokument-Nr.
Service-Nr. 00000000000000000000000000000000	Original A4
SEG-Number 00000000000000000000000000000000	Datum 05.07.2021
SEG-2841	Erstellt mit Soil Edge
	Bauart
	1 von 1



KAESER		KOMPRESSOREN	
Zeichnungspflichtig Service-Spare-Part-Zeichnung / Service-Ersatzteil-Zeichnung SEG-Kennnummer SEG-10830.01	Dokument-Nr. Original Ab Gez. Reparatur Dokument-Nr. Status für Lieferanten	Datum 02.10.2019 Reparatur 02.10.2019 Dokument 1 von 1	Erlaubt mit Sicher Edges Blatt


3001 - Electrical Instruments / Tools


3201 - Electrical Instruments / Tools

Original **Ab** **Gez.** **Datum** **Name**


(Optional) **Subassembly / Untergruppe**

KAESER KOMPRESSOREN					
Drawing retain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by used of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.					
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird zu überlieferten Zweck verwahrt und darf zu keinem anderen Zweck verwendet werden. Systeme sollten nur zu dem vereinbarten Zweck eingesetzt werden. Kopiere oder sonstige Vervielfältigungen sind untersagt. Verwendung dieser Zeichnung ist nur für den vereinbarten Zweck erlaubt. Dies gilt auch für elektronische Systeme.					
Baugruppe	Zeilungssyp	Dokument-Nr.	Original	Datum	Name
3248 - Terminal box / Anschlusskasten	Service spare part drawing Service Ersatzteil Zeichnung	SEG-10831-01	Aa	13.09.2019	Dorsat1
	Service part number			Revised	13.09.2019
	Subassembly / Untergruppe				Blatt
	Service Kit (Option)				1 von 1






KAESER		KOMPRESSOREN	
Drahtzugspannung			
Zugrichtung			
Zeichnungsnr.	Document-Nr.	Datum	Name
Service-Sammelpartnr. / Service-Ersatzteil-Zeichnung	Original	13.08.2019	Ende der mit
SEG-Kennnummer	Ach	Gez:	Sofern Edge
SEG-10832.01	(Service-Kit)	Reparat.	Blaßt
	(Option)	13.09.2019	Dosat!
	Subassembly / Unterguppe		
			Statisch freie Abstände
			1 von 1





KAESER KOMPRESSOREN	
Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor copies may be given to be made available to third parties.	
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu überlieferten Zweck verwandt und darf zu keinem anderen Zweck verwendet werden. Systemen dürfen nur zu dem vereinbarten Zweck eingespeist werden. Kopien oder solche	erstellen mit
Original Zeichnung Reisepk. 13.09.2019 Service part drawing Service Ersatzteil Zeichnung SEIG-Nr.: 35G-10833.01	Gez. Name Dorsat1
Zeichnungsgruppe Baugruppe 3248 - Terminal box / Anschlusskasten	Datum Solid Edge Blatt Status für Lieferation 1 von 1





KAESER		KOMPRESSOREN	
Zeilenumbersp			
Servicepart-Zeichnung		Document-Nr.	
SEG-Nummer	Original	Datum	Name
SEG-10834-01	A4	Gez.	E-Mail mit Sicherer Edge
	(Repro)	13.09.2019	Blaat
	(Option)	Dosatt	
	(Subassembly / Untergruppe)		Statisit fr. Doseben
			1 von 1

11.4 Replacement parts for service and repair














KAESER KOMPRESSOREN	
Drawing released exclusively for the agreed purpose. Copies or any other reproduction, copying or any other use of the drawings, whether partial or total, is prohibited without written permission from KAESER.	Erlaubt mit Softe Edige
Das Zeichnung darf nur für die von uns vereinbarte Zweck bestimmt werden. Eine Vervielfältigung ist ausdrücklich untersagt. Sie ist nur für den Betrieb und Wartung elektronischer Systeme oder zur Herstellung von Ersatzteilen zugelassen. Zwick geltend, wenn weiteres Vervielfältigen vorgenommen wird.	Blaß
Originalzeichnung/Vorabauslage oder deren Dritten Ausgabedrucke dürfen in keiner Weise ausgetauscht werden.	1 von 1
Zeichnungs-Nr. Service-Satz per Zeichnung / Service-Ersatzteil-Zeichnung SEG-Nummer SEG-11958	Document-Nr.: Original: A4 C�ec: Fertig: 30.07.2020 PUFFI Subassembly / Untergruppe: Service-Kit (Option) Status: F R E I G E C H E B E N






















KAESER KOMPRESSOREN	
Drawing remains our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither original nor copy may be given to third parties. Nachdruck und zu den vertraglichen Zwecken hinzuverwendete Kopien oder sonstige Originale sind nur für die hierfür vorgesehene Verwendung bestimmt. Keine weitere Verbreitung oder Weitergabe ist gestattet.	
Erlaubnis mit Name	Datum
Aa	18.08.2020
SEG-Number	Preisgr.
SEG-11985	PUFF1
Baugruppe	
1079 - Terminal strip / Klemmleisten	Stück für EIGE GEBEN
Zeilengruppe	1 von 1
Document-Nr.	Original
3421	Subassembly / Untergruppe
3390 - Q4	ServiceKit (Option)
3993 - B28	
3436 - F4	
3283	
















Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor copies may be given to be made available to third parties.
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu den vereinbarten Zweck heruntergeladen und darf zu keiner anderen Zweck verwendet werden. Kopie oder sonstige Vervielfältigung ist untersagt. Keine weiterverbreitung ist erlaubt. Systeme zur automatischen Verarbeitung oder Speicherung von Daten jeglicher Art sind ausdrücklich untersagt.


KAESER KOMPRESSOREN	
Bauteile	3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger
Zeilungssyp	Zeilungssyp
Service-a-partei part drawing Service Ersatzteil Zeichnung	Document-Nr.: 3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger
SEG-Nummer: 3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Original Document-Nr.: 3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger
3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Datum: 17.06.2019 Name: Name
3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Ersetzt mit: 3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger Solide Edge
3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Gez.: AA Gez.: AA
3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Inspektion: 17.06.2019 Inspektion: 17.06.2019
3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Blatt: 1 von 1 Status: freigegeben
3008-GSM modem/GPS receiver / GSM-Modem/GPS-Empfänger	Service-Kit Subassembly / Untergruppe




KAESER		KOMPRESSOREN	
Drawings remain our exclusive property. They are enlisted only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made without the given permission.			
Do Zulassung, wenn erforderlich für das Produkt oder die Teile des Produkts, die auf dem Markt vertrieben werden. Zu diesem Zweck ist eine Genehmigung durch die zuständige Behörde erforderlich. Es kann keine Haftung übernommen werden, wenn die Genehmigung nicht vorliegt. Sollte es sich um einen Betrieb handeln, der nicht mit dem zugelassenen Bereich übereinstimmt, so muss eine entsprechende Genehmigung vorliegen. Sollte es sich um einen Betrieb handeln, der nicht mit dem zugelassenen Bereich übereinstimmt, so muss eine entsprechende Genehmigung vorliegen. Sollte es sich um einen Betrieb handeln, der nicht mit dem zugelassenen Bereich übereinstimmt, so muss eine entsprechende Genehmigung vorliegen.			
Original nach Verarbeitung darf nicht weiter ausgetauscht werden. Zur Wiederverwendung ist der neue Kondensator zu verwenden. Zur Wiederverwendung ist der neue Kondensator zu verwenden. Zur Wiederverwendung ist der neue Kondensator zu verwenden.			
Original nach Verarbeitung darf nicht weiter ausgetauscht werden. Zur Wiederverwendung ist der neue Kondensator zu verwenden. Zur Wiederverwendung ist der neue Kondensator zu verwenden. Zur Wiederverwendung ist der neue Kondensator zu verwenden.			
Baugruppe:		3009 - Autom. start-stop assembly / Baugruppe Start Stopp	
Zeilenumbersp.:	Service Start part number / Service Ersatzteil-Zeichnung		
SEG-Kennnummer:	Original	Abl.	Datum
SEG-1053.01	(Option)	(Subassembly / Unterguppe)	17.06.2019
Name:		Name:	
Fischer/2		Fischer/2	
Gez.: 17.06.2019		Blatt:	
Status freigegeben		1 von 1	

11.4 Replacement parts for service and repair









Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor copies may be given to be made available to third parties.
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keinem anderen Zweck verwendet werden. Systematische Herstellung von Kopien oder Code-Speicherung ist ausdrücklich untersagt. Verbreitung und Weitergabe ist ausdrücklich untersagt.


Original drawings are issued in accordance with the following code of practice:
Originalzeichnungen werden nach folgenden Regeln ausgetragen:


KAESER KOMPRESSOREN	
Zeilenummer	Service-Kit
SEG-Nr.: 4400 - Drive coupling / Antriebskupplung	Option
Zeichnungstyp	Subassembly / Untergruppe
Service - spare part drawing / Service Ersatzteil Zeichnung	
Document-Nr.:	
Original:	
Gez.:	06.08.2019
Datum:	Freihand/2
Ersatzteile mit	
Name:	Solid Edge
Reinsp.:	05.08.2019
Blatt:	Freihand/2
Status / Freigabe:	1 von 1








KAESER KOMPRESSOREN	
Erlaubt mit Name	Datum
Gaz	25.02.2022
Ingress	25.02.2022
PUFF1	Batt
Status F E I G E G E B E N	1 von 1
Baugruppe	
6001 - Oil separation/control air /Oilabscheidung Steuerluft	
Zeilenummer / Typ	Document-Nr.
Service spare part drawing / Service Er satzteil Zeichnung	Original
SEG-Nummer	A4
SEG-13751	
Service-Kit (Option)	Staubsauger / Untergruppe













Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by used electronic systems must not be made for any other purpose. Neither originals nor copies may be given to be made available to third parties.
 Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu den vereinbarten Zweck heruntergeladen und darf zu keinem anderen Zweck verwendet werden. Kopiere oder sonstige Vervielfältigungen unterbleiben. Keine Originale oder Kopien dürfen an Dritte weitergegeben werden. Dies gilt insbesondere für elektronische Speicher- und Verarbeitungssysteme.


KAESER KOMPRESSOREN	
Baugruppe	
Zeilungssyp	8730 - Upper canopy / Haube oben
Service - spare part drawing Service Ersatzteil Zeichnung	
SEG-Nummer	SEG-10561.01
Original	
Dokument-Nr.	
Aa	
Datum	
Ges.	
Ersetzt mit	
Name	
Stahl / Edge	
Frachtaufz	
Frachtaufz2	
Blatt:	
Status / Freigabe von	
Service-Kit (Option) Subassembly / Untergruppe	





Drawings remain our exclusive property. They are intended only for the assigned purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu den vewiesener Zweck verwandt und darf zu keinem anderen Zweck verwendet werden. Kopien oder sonstige Nachzeichnungen sind nicht für andere Zwecke herzustellen. Reproduktionen dürfen weder ausgetauscht noch anderen Dritten zugänglich gemacht werden.

KAESER KOMPRESSOREN	
Baugruppe	8130 - Cover / Abdeckung
Zeilungssyp	
Service-a spare part drawing Service Ersatzteil Zeichnung	
Document-Nr.:	
Original	
Datum:	
Aa	
Ges.	
Ersetzt mit	
Name	
SG-Nummer	27.06.2019
SEG-10563.01	Freihand/2
	Solid Edge
	Blatt:
	1 von 1
	Status: freigeschrieben
	Service-Kit Option Subassembly / Untergruppe





KAESER KOMPRESSOREN	
Draufsicht	Ansicht von oben
Zeichnungs-Nr.	Technical Drawing No.
Service-Satz-Nr.	Service Part No.
SEG-Nr.	SEG-Nr.
Original	Original
Aa	Aa
Ges.	Ges.
Erstellt mit	Created with
Freihand2	Freihand2
Name	Name
Solide Edge	Solid Edge
Blaat:	Blatt:
1 von 1	1 von 1

8131-Cover / Abdeckung
Baugruppe:
Original-Nr. Vervollständigung dienten Dränen abgehängt werden in engem Weise zugänglich gemacht werden.


8131-Cover / Abdeckung
Baugruppe:
Original-Nr. Vervollständigung dienten Dränen abgehängt werden in engem Weise zugänglich gemacht werden.

KAESER KOMPRESSOREN	
Drahtzettel mit der Zeichnung für den angeforderten Zweck. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.	Do Ziehung nicht unter ausschließlichen Eigenart. Be wird zu dem vorgenommenen Zweck verwandt und darf zu einem anderen Zweck verwendet werden. System sollte nur zur Unterhaltung und Reparatur benutzt werden. Kopie oder sonstige Vervielfältigung ist ausdrücklich untersagt. Keine Kopie oder sonstige Vervielfältigung ist ausdrücklich untersagt.
Original Zeichnung Service part drawing Service Ersatzteil Zeichnung	Original-Nr. Name Datum Gez. Ersetzt mit Name Soild Edge Datei Fresnair2 Fresnair2 Blatt Status für Lieferation
8132 - Cover / Abdeckung	Baugruppe Ziehungssyp Service part number SEI-G-10565.01 Service Kit (Option) Subassembly / Untergruppe 8798
8132 - Cover / Abdeckung	1 von 1







Drawing remains our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.	
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keinem anderen Zweck verwendet werden. Systeme dürfen nur zu dem vereinbarten Zweck eingesetzt werden. Kopiere oder sonstige Vervielfältigungen sind untersagt. Verbreitung und Weitergabe ist ausdrücklich untersagt. Datenverarbeitungsgesetz.	
Original Zeichnung Rechtsauflage Ersetzt mit Name Datum Gez. Blatt Baugruppe 8412 - Door / Tür	
Service part drawing Service Ersatzteil Zeichnung Document-Nr.: SEG-10567-01	
Original Aa Rechtsauflage Name Datum Gez. Blatt Baugruppe 8601	
Service-Kit (Option) Subassembly / Untergruppe Status (Revision)	
8798	
8713	
8713	
8798	




KAESER KOMPRESSOREN	
Draughts remain our exclusive property. They are enlisted only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made without the prior written consent of KAESER Kompressoren GmbH.	Drawings remain our exclusive property. They are enlisted only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made without the prior written consent of KAESER Kompressoren GmbH.
Do Zulassung, wenn erforderlich, ist die Verwendung dieses Produktes nach den Vorschriften der betreffenden Normen zu überprüfen. Sollte es keine entsprechende Normen geben, so ist die Anwendung des Produktes auf Basis der technischen Dokumentation zu bewerten. Werden die Vorschriften nicht eingehalten, so kann die Haftung für die Folgen ausgeschlossen werden.	Do Zulassung, wenn erforderlich, ist die Verwendung dieses Produktes nach den Vorschriften der betreffenden Normen zu überprüfen. Sollte es keine entsprechende Normen geben, so ist die Anwendung des Produktes auf Basis der technischen Dokumentation zu bewerten. Werden die Vorschriften nicht eingehalten, so kann die Haftung für die Folgen ausgeschlossen werden.
Original nach Verarbeitung darf der Draht abgeschnitten werden.	Original nach Verarbeitung darf der Draht abgeschnitten werden.
8413 - Door / Tür	8413 - Door / Tür
Zeilenumbersp	Zeilenumbersp
Service-Kartei / Service-Ersatzteil-Zeichnung	Service-Kartei / Service-Ersatzteil-Zeichnung
Document-Nr.	Document-Nr.
Original	Original
A4	A4
Datum	Datum
Gez:	Gez:
Eingesch. mit	Eingesch. mit
Frachtklasse 2	Frachtklasse 2
Frachtklasse 2	Frachtklasse 2
Blatt	Blatt
1 von 1	1 von 1
Status: freigegeben	Status: freigegeben





Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.
Die Zeichnung bleibt unser exklusives Eigentum. Sie ist nur für den vereinbarten Zweck bestimmt und darf zu keinem anderen Zweck verwendet werden. Systematische Herstellung von Kopien oder sonstige Vervielfältigungen sind ausdrücklich untersagt. Keine Originale oder Kopien dürfen an Dritte weitergegeben werden. Dies gilt insbesondere für elektronische Speicher- und Übertragungssysteme.

KAESER KOMPRESSOREN	
Baugruppe	8674 - Inlet air grill / Zulufiltergitter
Zeilungstyp	Zeichnungsp
Service spare part drawing Service Ersatzteil Zeichnung	Document-Nr.
SEG-Nummer	Original
SEG-10569_01	Aa
	Datum
	Ersetzt mit
	Name
	Freihand/2
	Solid Edge
	Freihand/2
	Blatt:
	1 von 1
	Service-Kit (Option)
	Subassembly / Untergruppe




KAESER KOMPRESSOREN	
Draughts demand our exclusive property. They are enlisted only for the agreed purpose. Copies or any other reproduction, including storage, treatment or dissemination by use of electronic systems must not be made without the prior written consent of the supplier. Any unauthorized use will be subject to criminal prosecution.	Excluded from the scope of delivery are parts which are supplied to the customer for his own assembly.
Do Zulassungsaufnahmen und Prüfungen nach DIN EN ISO 9001:2008 und DIN EN ISO 14001:2004 sowie nach VDE 0830-2000 und DIN EN 60068-2-27.	Werkzeug, Betriebsmittel und Sonderzubehör sind nicht im Lieferumfang enthalten. Systeme werden nur für den inneren Zweck eingebaut. Zu montierende Bauteile werden nicht geliefert.
Original nach Vorschriften der DKEV ausgestellt.	Weder Montage noch Verarbeitung darf dieser Draht ausgeschlagen oder in sonstige Weise zugeschnitten werden.

Bearbeitungs-
8490 - Upper inlet air grill / Zuluftgitter oben

Zeilenumbersp	Dokument-Nr.	Original	Druck	Name
Zeilenumbersp	Document-Nr.	Original	Druck	Name
Service-Spare-Part-Zeichnung / Service-Ersatzteil-Zeichnung	Document-Nr.	Ad	Gez:	Name
SEG-Kennnummer	Document-Nr.			Erlaubt mit
SEG-10571_01	Document-Nr.			Freihand/2
	Document-Nr.			Freihand/2
	Document-Nr.			Blatt:
	Document-Nr.			1 von 1


KONTAKT
Services-Kit (Option) Subassembly / Unterguppe




Drawings remain our exclusive property. They are intended only for the assigned purpose. Copies or any other reproduction, including storage, treatment and dissemination by used electronic systems must not be made for any other purpose. Neither originals nor copies may be given to be made available to third parties.

Die Zeichnung bleibt unser exklusives Eigentum. Sie wird nur zu dem vorgesehenen Zweck heruntergeladen und darf zu keinem anderen Zweck verwendet werden. Systeme zur elektronischen Speicherung, Verarbeitung oder Weiterleitung sowie Kopier- oder Scannevorgänge sind untersagt. Keine weiterverbreitung unter Verwendung von Originalen oder Kopien ist erlaubt.

KAESER KOMPRESSOREN	
Zeilungssyp	Baugruppe
Service spare part drawing Service Ersatzteil Zeichnung	8520 - Door, right front/ Tür rechts vorne
SEG-Nr.: SEG-10572_01	
Service-Kit (Option)	
Subassembly / Untergruppe	
Document-Nr.:	
Original	
Gez.	
Datum	
Ersetzt mit	
Name	
Solid Edge	
Freihand2	
Freihand2	
Blatt:	
1 von 1	



KAESER		KOMPRESSOREN	
Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must be made with the prior written permission of KAESER Kompressoren GmbH. Any unauthorized use will be subject to criminal prosecution.			
Due to the complexity of the drawings, they are not suitable for reproduction by means of a copy machine. Reproduction may only be carried out by means of a photographic process. Reproducing or otherwise using the drawings without the express written consent of KAESER Kompressoren GmbH is prohibited. Systems with more than four cylinders. Zylindergruppe 2.			
Original ohne Verzettelung oder Druck ausdrucken. In Farbe ausdrucken.			
Baugruppe: 8525-Door, right rear: Tür rechts hinten			
Zeilenumbersp	Service-Sammel-Zeichnung	Document-Nr.	
SEG-Kennnummer SEG-10575.01	(Optional)	Original A4	Date Name Gez. Fremdauf2 Soil Edge Blatt:
		Repro 27.05.2019	Repro 27.05.2019
		Fremdauf2	Fremdauf2
		Status fr. Druck erhalten	1 von 1




Drawings remain our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.


Die Zeichnung bleibt unser exklusives Eigentum. Sie wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keinem anderen Zweck verwendet werden. Systema outlet oder zu dritten Personen weitergegeben werden darf. Keine Kopie oder sonstige Vervielfältigung ist erlaubt. Dies gilt auch für elektronische Speicher- und Verarbeitungssysteme.


KAESER KOMPRESSOREN	
Baugruppe	8530 - Door, left front / Tür links vorne
Zeilungssyp	
Service spare part drawing / Service Ersatzteil Zeichnung	
SEG-Nummer	SEG-10574_01
Service-Kit (Option)	
Subassembly / Untergruppe	
Original	Document-Nr.
Aa	
	Datei
	Name
	Ersatz mit
	Freihand/2
	Freihand/2
	Soild Edge
	Format:
	Blatt:
	1 von 1

KAESER		KOMPRESSOREN	
Drahtseil			
Zur Nutzung der Zeichnung ist eine freie Zeichnungslizenz erforderlich.			
Do Not Copy. This drawing is the property of KAESER Kompressoren AG. It is to be used only for the intended purpose. Copying or any other reproduction, including storage, treatment or dissemination by use of electronic systems must not be made for any other purpose than the one given. It may not be available to third parties.			
Vorbehaltlich Änderungen durch technische Veränderungen oder Verarbeitungstechniken. Änderungen können jederzeit ohne vorherige Ankündigung vorgenommen werden. Systeme mit Wartungszeitraum für mehr als 2 Jahre müssen die Wartungszeitraum für das System umfassen. Zu kürzende Wartungszeitraum kann zu einem Verlust der Garantie führen.			
Original nach Vervielfältigung darf der Druck ausgetragen werden in ungefähr gleicher Ausführung.			
Blatt:	1 von 1		
SEG-Kennnummer	SEG-10575.01		




Drawing remains our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions may be given to be made available to third parties.			
Die Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keiner anderen Zweck verwendet werden. Systemaustausch ist ausdrücklich untersagt. Verwendung unerlaubt hergestellter oder kopierter Zeichnungen ist ausdrücklich untersagt. Dies gilt für alle Zeichnungen, technische Dokumente, technische Berichte sowie für alle technischen Informationen, die in den Zeichnungen enthalten sind.			
Baugruppe	88000 - Sub-frame/Lighting / Unterbau/Beleuchtung	Dokument-Nr.	
Zeilungssyp		Original	
Service-a spare part drawing Service Ersatzteil Zeichnung		Gez.	Datum
SEG-10476_01		Aa	07.06.2019
Ersetzt mit		Name	
Do Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keiner anderen Zweck verwendet werden. Systemaustausch ist ausdrücklich untersagt. Verwendung unerlaubt hergestellter oder kopierter Zeichnungen ist ausdrücklich untersagt. Dies gilt für alle Zeichnungen, technische Dokumente, technische Berichte sowie für alle technischen Informationen, die in den Zeichnungen enthalten sind.		Freihand/2	Solid Edge
Original		Friseau/2	Blatt:
Orignial		Friseau/2	1 von 1
Status (revised version)			






KAESER		KOMPRESSOREN	
Draughts demand our exclusive property. They are enlisted only for the agreed purpose. Copies or any other reproduction, including storage, treatment or dissemination by use of electronic systems must not be made for any other purpose.	Do Zulassung, wenn erforderlich für das jeweilige Land und die jeweilige Anwendung. Zu diesem Zweck ist eine entsprechende Genehmigung durch den zuständigen Behörden zu beantragen.	Erstellen mit	
Original	Aa	Name	
Gez:		Franziska2	
Reparo	07.05.2019	Franziska2	
(Service-Kit)	(Option)	Subassembly / Untergruppe	
SEG-10477.01		Status fr. Lieferanten	1 von 1

Drawing retains our exclusive property. They are intended only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of electronic systems must not be made for any other purpose. Neither originals nor reproductions may be given to be made available to third parties.					
Die Zeichnung bleibt unser ausschließlich Eigentum. Sie wird nur zu dem vereinbarten Zweck heruntergeladen und darf zu keiner anderen Zweck verwendet werden. Systemtouter für Zulassungserklärung Kupferrohre sowie Rohrleitungsteile sind ausdrücklich untersagt. Eine Weiterverbreitung oder Verarbeitung ist verboten. Dies gilt auch für elektronische Systeme wie z.B. Kopieren, Scannen, Speichern, Spezifizieren, etc.					
Baugruppe					
4149-Lifting plate/ Kranaufhängung					
Zzeichnungspyp	Dokument-Nr.	Original	Datum	Name	Ersatzte mit
Service - spare part drawing Service Ersatzteil Zeichnung		Aa	Ges.	Freihand/2	Solid Edge
SEG-Nummer			07.06.2019	Freihand/2	
SEG-10478.01					Blatt:
					1 von 1
Service-Kit	(Option)	Subassembly / Untergruppe	Status / Freigabe		







KAESER		KOMPRESSOREN	
Zeichnungspapier	Service-Satz Nummer	Dokument-Nr.	Ersatzteile mit Name Bestell-Nr. Bestell-Edt. Blatt

9400- Compressed air treatment / Druckluftaufbereitung

Original | Ad. | Druck | Name
Service-Satz Nummer | Service-Zeichnung | Dokument-Nr. | Bestell-Nr.
SEG-Nummer | SEG-Zeichnung | Druck | Name
SEG-10579.01 | (Option) Services-Kit | (Option) Subassembly / Untergruppe | Bestell-Nr.
Status für Lieferfrist ein


Drawings remain our exclusive property. They are enlisted only for the agreed purpose. Copies or any other reproduction, including storage, treatment and dissemination by use of
Do. Zeichnungen sind unser exklusives Eigentum. Sie werden nur für die vereinbarte Verwendung hergestellt. Kopien oder andere Wiedergabe, einschließlich Speicherung, Behandlung und Ausbreitung, ist ausdrücklich untersagt.
Vervielfältigung oder andere Wiedergabe, einschließlich Speicherung, Behandlung oder Ausbreitung, ist ausdrücklich untersagt. Nur für den vom Käufer bestellten Zweck zugelassen. Zulässige Vervielfältigung oder andere Wiedergabe ist ausdrücklich untersagt.






Service-Kit
(Option)

SEG-4229_01





12 Decommissioning, Storage and Transport

12.1 Decommissioning

Decommissioning is necessary, for example, under the following circumstances:

- The machine is temporarily not needed
- The machine will not be needed for a considerable time.
- The machine is to be scrapped.

Precondition The machine is shut down.

Machine dry and cool.

1. Carry out the following decommissioning procedures.
2. Place a notice on the instrument panel describing the decommissioning procedures carried out.

12.1.1 Temporary decommissioning

Decommissioning for about 4 months.

Material Plastic sheeting

Moisture-resistant adhesive tape

1. Close the air inlet opening with plastic foil and moisture-resistant adhesive tape.
2. Attach the following notice on the instrument panel showing the decommissioning measures taken.

Attention!

1. The machine is temporarily decommissioned.
2. The air inlet opening of the compressor has been closed.
3. Recommission according to service manual.

Date / signature:

Tab. 92 "Temporarily decommissioned" information notice

12.1.2 Long-term decommissioning

Long-term decommissioning:	Interval / designation
Decommissioning	> 5 months
Final decommissioning	Shutdown

Tab. 93 Definition of long-term decommissioning

Material Receptacle

Preserving oil

Preservative

Desiccant

Plastic sheeting

Moisture-resistant adhesive tape

- The following measures must be taken for long-term decommissioning:

Long-term decommissioning tasks	See chapter	Confirmed?
➤ Drain all cooling oil from the machine.	10.5.3	
➤ Fill the oil separator tank with preserving oil.	10.5.2	
➤ Run the machine for about 10 minutes to coat all parts with a protective oil film.	-	
➤ Empty the internal condensate collection tank.	10.7	
➤ Drain liquid accumulation within the machine.	10.12	
➤ Close the butterfly valve of the compressed air outlet.	-	
➤ Cover the following openings with plastic foil and moisture-proof duct tape: – Compressor air inlet	-	
➤ Clean the bodywork and treat with preservative.	-	

Tab. 94 Long-term decommissioning checklist

- Attach the following information sign on the control panel cover of SIGMA CONTROL SMART regarding the decommissioning measures taken:

Attention!

1. The machine is decommissioned.
2. It is filled with preserving oil.
3. For recommissioning:
 - Take measures for recommissioning after a long period of storage.
 - Recommission according to the Operating Manual.

Date / signature:

Tab. 95 "Long-term decommissioning" information sign

- Store machine in a dry place at a constant temperature.

12.2 Transport

To locally move the machine or to transport the machine as load, you can select one of these transport options:

- Transport by crane.
 - Transport by crane is permitted for all machines with crane lifting eye.
- Transport using a forklift truck.
 - Transport by forklift truck is allowed only for stationary machines with the frame designed as skid.
- Pull the machine along the ground.
 - Machines with skid-type frames may be pulled along the ground.
- Transporting the machine as load.

- Precondition The machine is switched off.
The machine has cooled down.
«Load isolating switch» of the machine set to position *OFF*,
«Load isolating switch» is locked off,
«Controller ON/OFF» switch set to position *OFF*.
The absence of voltage has been verified,
the power supply cable has been removed.
The butterfly valve at the compressed air outlet is open,
the machine is fully vented, pressure gauge reads 0 psig!
All connecting cables of the shut-down machine are disconnected and removed,
any loose or movable parts that may fall when transporting the machine are removed or secured.
- Comply with all instructions!

12.2.1 Safety



Allow transport only by personnel trained in safely dealing with motor vehicles and the transport of goods.

1. **⚠ WARNING** *Risk of being run over or crushed by an overturning vehicle!*
Death or severe injury from the machine falling off.
➤ *Persons are forbidden to ride on, or be in the direct vicinity of, the machine during transportation.*
2. Make sure the danger area is clear of personnel.

12.2.2 Transporting the machine by crane

Additional precautions for conditions of snow and ice:

- Considerable snow and/or ice may build up on the machine under low temperature conditions. This may adversely effect the machine's center of gravity (tilting). The permissible load on the crane or lifting eye may be exceeded.
- Additional measures should be taken under conditions of snow or ice:
 - Remove any snow and/or ice from the machine before lifting by crane.
 - Make sure the lifting eye cover plate is freely accessible and can be opened.

Carry out the following tasks before lifting the machine by crane:

A lifting eye is provided for transporting with a crane. The lifting eye is located beneath a lift-up cover in the centre of the enclosure. The crane lifting eye is identified with an information sign.




Fig. 53 Crane lifting eye information sign

- | | | | |
|---|-------------------------|---|--|
| ① | Crane lifting eye cover | ③ | Crane lifting eye |
| ② | Crane suspension | ④ | Machine lifting point information sign |

1. **NOTICE** *The machine can be damaged by jerky lifting!
Components may break.*
➤ *Lift the machine carefully.*
2. Unlock the lifting eye cover from inside and lift up.
3. Position the crane hook vertically over the lifting eye.
4. Engage the hook in the eye.
5. Close and lock all doors.
6. Lift up the machine slowly and carefully.
7. Transport the machine slowly and carefully.

Keep in mind when setting down the machine:

1. **NOTICE** *Incorrect setting down can damage the machine!
Machine components, particularly the skids, can be damaged by incorrectly setting the machine down.*
➤ *Set the machine down carefully.*
➤ *Do not set down unevenly.*
2. Set the machine down slowly and carefully.

12.2.3 Transporting the machine with a forklift truck

Stationary machines with skid frame are fitted with lifting lugs into which forks can be driven. Only stationary machines with skid-type frames may be lifted and locally transported with a forklift truck.

- Precondition The machine's weight is available (nameplate)
A suitable forklift truck (designed for the machine's weight) is available
The machine is switched off.
All connecting lines and hoses have been disconnected and removed.
► Comply with all instructions!

12.2.3.1 Preparing for transport

When using a forklift truck to transport a stationary machine with skid-type frame, you must first drive the forks into the lifting lugs. Each lifting lug is marked with an information sign.

NOTICE

Incorrect fork placement can damage the machine!

► Insert the lifting forks only into the lifting lugs marked with information signs.




Fig. 54 Prepare for transport using a forklift truck

- | | | | |
|---|--|---|-----------------------------------|
| ① | Front side of machine | ④ | Lifting lug |
| ② | Skid-type frame design | ⑤ | Forks pushed through lifting lugs |
| ③ | Location of lifting lug information sign | | |

- Precondition The machine is parked on even ground.
1. Close and lock the doors.
 2. Position the forklift truck in front of the front side of the machine with the forks opposite to the lifting lugs.
 3. Align the forks with the machine's lifting lugs.
 4. Carefully drive the full length of the forks through the lifting lugs.
- Result Full length of forks driven through the lifting lugs.


12.2.3.2 Lifting the machine with a forklift truck

Fig. 55 Lifting the machine with a forklift truck

Precondition The machine is parked on even ground.

- Lift the machine carefully.

Result The machine rests fully on the lifting forks.

Proper transport position and transport elevation (minimum clearance to ground) for horizontal transport are given.

12.2.3.3 Transporting the machine with a forklift truck

Example: The machine is unloaded from the loading bay/lorry loading platform and transported from A to B.

Following the unloading from a loading bay or lorry loading platform, always lower the elevated forks as a prerequisite for horizontal transport.

Precondition The machine is unloaded and rests on the forks.

The forks are elevated, see Fig. 56.


NOTICE

The machine falls off the elevated forks during transport

Heavy machine damage

- *After unloading from the loading bay/lorry load platform, lower the forks immediately.*

Option rw



12-M2935

Fig. 56 Transporting the machine with a forklift truck

- | | |
|--|---|
| <p>① Lift the machine from loading bay or lorry load platform</p> <p>② Lower the machine for horizontal transport</p> <p>③ Loading bay/lorry load platform</p> | <p>④ Improper transport elevation</p> <p>⑤ Proper transport elevation</p> |
|--|---|

1. Carefully reverse the forklift truck with the machine from the loading bay or lorry load platform.
2. Reverse the forklift truck until you have sufficient clear space to lower the forks.
3. Lower the forks immediately.
4. Lower the forks until the proper transport elevation (minimum clearance to the ground) is reached.
5. Transport the machine on the lowered forks from A to B.

12.2.4 Transporting the machine locally on site

The support frame of the machine is in a skid design.

In order to transport a machine that has already been set down at the building site to the installation location without using lifting machines, the machine can be pulled along the ground with corresponding hoisting ropes. This type of transport is only suitable for small distances.

The machine is fitted with two lashing eyes on each side where the hoisting ropes can be attached, see dimensional drawing in chapter 13.3.

Lashing eye	Value
Maximum load force [lbf]	3000

Tab. 96 Maximum load force of lashing eye

Precondition Level ground at installation location
Ground at installation is capable of bearing the machine weight

1. **⚠ WARNING Taut hoisting ropes**
Danger of injury torn hoisting ropes
 - *Do not enter the danger area between the towing vehicle and the machine.*
2. Attach hoisting ropes to both lashing eyes of the machine.
3. Attach hoisting ropes to lashing eyes of towing vehicle.
4. Carefully pull the machine along the ground.

12.2.5 Transporting the machine as load

The transporting method will determine the type of packing and load securing.

Packing and securing methods must be such that, assuming proper handling, the goods arrive in proper condition at the destination.

Additional measures must be taken for the transport of machines by sea or air. Please contact an authorized KAESER service representative for more information.



- National directives and regulations for securing loads during transport must always be complied with.
- Load securing is taken to mean that, by full braking or sudden turning, the load will not slide, fall, roll or cause unnecessary noise. Generally accepted technical regulations should be observed.
- The driver, the vehicle keeper and the carrier are responsible for properly secured loads.


Material Tie down straps

NOTICE

Damage to the body!

Movement during transportation damages the bodywork.

- *Do not use tie down straps across the bodywork.*



12-M3535-M25xE

Fig. 57 Improperly lashed down across bodywork

Securely lash down the load:



- Comply with any safety and accident prevention regulations for transport and applicable guidelines for load safety.
- The load must be secured against rolling, tipping, slipping and falling.

Each side of the machine's support frame is equipped with two lashing points, see dimensional drawing in chapter 13.3. At each lashing point you will find one lashing eye.

Lashing eye	Value
Maximum load force [lbf]	3000

Tab. 97 Maximum load force of lashing eye




Fig. 58 Properly lashed down using lashing points on support frame

- | | |
|----------------------------------|-----------------------------|
| [1] Machine's support frame | [3] Lashing eye on load bed |
| [2] Lashing eye on support frame | [4] Tie down strap |

1. Select tie down straps suitable for the load force.
 2. Check that all the tie down straps are in a proper condition.
 3. Connect the corresponding lashing eyes of the machine and load bed using tie down straps.
 4. Tighten the tie down straps using the ratchet.
- The machine is lashed down on the load bed.



Contact KAESER SERVICE with any questions regarding transporting or load securing.

KAESER accepts no liability and provides no guarantee for damage arising from incorrect transport or insufficient or incorrect load securing provisions.

For hire, rental and trade show machines, any transport safety devices used for the delivery must also be used for the return transport.

Before shipment as air freight:

The machine is designated as hazardous goods for air freight purposes; any disregard can result in a heavy fine!

1. **⚠ WARNING** *Danger of fire or explosion from operating fluids/materials!*
The machine is fitted with an airend.
➤ *Any dangerous fluids/materials contained within the machine must be removed before transport by air.*
2. Remove all dangerous fluids/materials.
 - Compressor lubricating oil

12.3 Storage

Moisture can lead to corrosion, particularly in the airend and oil separator tank.

Frozen moisture can damage components, valve diaphragms and gaskets.

The following measures also apply to machines not yet commissioned.



Please consult with an authorized KAESER service representative if you have questions to the appropriate storage and commissioning.

NOTICE

Moisture and frost can damage the machine!

- Prevent ingress of moisture and formation of condensation.
- Maintain a storage temperature of >32°F.

- Store the machine in a dry place, free from frost if possible.

12.4 Disposal



To dispose of the machine in accordance with environmental regulations, all environmentally harmful substances must be removed from it. Substances that are harmful to living things and the environment can be separated and disposed of efficiently or reprocessed.

All operating fluids in the machine must be drained and disposed of in accordance with environmental regulations. All components contaminated with operating fluids must be removed and disposed of in accordance with environmental regulations.

Any residual quantities of condensate must be drained and disposed of in accordance with environmental regulations.

Once these conditions have been fulfilled, deliver the machine to an authorized disposal agent.

Overview:

- Drain all operating fluids.
- Drain the condensate.
- Remove used filters/filter elements.
- Deliver the machine to an authorized disposal agent.

- Follow all instructions carefully.

12.4.1 Draining operating fluids

Material Receptacle

Cleaning cloth

- Drain and collect the following operating fluids from your machine.

Designation	Compressor
Fluid	Cooling oil
	—

Tab. 98 Machine fluids



Dispose of operating fluids and working materials and components contaminated with them in accordance with applicable environmental protection regulations.

12.4.2 Draining the condensate

Material Receptacle
Cleaning cloth

- Empty the condensate collection tank.



Dispose of any residual quantities of condensate and contaminated working materials in accordance with applicable environmental protection regulations.

12.4.3 Removing filters/filter elements

Material Cleaning cloth
Receptacle

1. Remove all filters/filter elements from the machine.

Designation	Compressor
Filters/filter elements	Oil filter
	Oil separator cartridge
	—

Tab. 99 Machine filters/filter elements

2. Remove all filters/filter elements from the options specified on the machine.

Designation	Filter combination option
Filters/filter elements	Prefilter
	Fine filter

Tab. 100 Machine option filters/filter elements



Dispose of working materials and components contaminated with operating fluids in accordance with applicable environmental protection regulations.

12.4.4 Disposing of the machine

Precondition All operating fluids have been drained and disposed of in accordance with applicable environmental regulations.
Any residual quantities of condensate have been drained and disposed of in accordance with applicable environmental regulations.
All used filters/filter elements have been removed and disposed of in accordance with applicable environmental regulations.

- Deliver the machine to an authorized disposal agent.

13 Annex

13.1 Labeling





Fig. 59 Labeling M250E/M255E/60Hz

- | | | | |
|---|--------------------------|---|---|
| ① | Front side of machine | ⑥ | VIN *) * Vehicle identification number |
| ② | Nameplate US/CA | ⑦ | Rear side of machine |
| ③ | Nameplate CE | ⑧ | Position of drive motor inside machine |
| ④ | Options label | ⑨ | Drive motor nameplate, with drive motor serial number |
| ⑤ | Left end side of machine | | |


13.2 Pipeline and instrument diagram (P&I diagram)



1	Compressor - Air filter	21	Oil filter
1.1	Vacuum switch	21.3	Overflow valve
3	Inlet valve	21.4	Shut-off valve - Oil drain device
3.2	Pressure transducer - Control pressure	21.5	Screw plug - Oil drain device
4	Rotary screw arend	23	Electric proportional controller
4.2	Shut-off valve - Oil drain device	27	Venting valve
4.3	Screw plug - Oil drain device	30	Compressed air aftercooler
5	Oil separator tank	32	Centrifugal separator
5.2	Screw plug	33	Dirt trap
5.6	Oil sight glass: oil level maximum	33.1	Nozzle
5.7	Oil sight glass: oil level minimum	33.2	Directional control valve
5.9	Shut-off valve - Oil drain device	33.4	Condensate collection tank
5.11	Screw plug - Oil drain device	33.6	Shut-off valve - Condensate drainage device
5.13	Pressure transducer - Internal pressure	33.7	Screw plug - Condensate drainage device
6	Oil reserve	33.8	Filter combination
7	Oil separator cartridge	36	Condensate drain shut-off valve
10.8	Shut-off valve	36.1	Minimum pressure check valve
11	Oil filler port with plug	37	Nozzle (Secondary side Proportional controller)
13	Safety relief valve	46	Directional control valve
14	Pressure gauge - Control panel	49	Hose coupling
15	Drive motor	49.3	Control valve
15.5	Fan motor	52	Regulating valve (Recirculation valve)
16	Oil return line	78	Pressure transducer
17	Dirt trap	pN - Network pressure	
17.1	Nozzle	p5 - Air pressure at the machine outlet	
19	Thermostatic valve	Option	
20	Oil cooler	dd	Filter combination
20.5	Screw plug - Oil drain device		
20.6	Shut-off valve - Oil drain device		

c		Datum	19/02/2019		KAESER KOMPRESSOREN	P&I diagram legend MOBILAIR M250E / M255E
b		Bearb.	Pau			
a	Änderung	Datum	Name	Ersatz durch:		FFMM250EST-01107.00
						Blatt 2 E

13.3 Dimensional Drawing



13.4 Electrical Diagram

Wiring Diagram

MOBILAIR M250E/M255E

SIGMA CONTROL SMART

460V±10% 60Hz

575V±10% 60Hz

Power supply:

WYE system with center point solidly grounded

ATTENTION !!!
The document gives collective information on
power supply voltages and frequencies for all machines.
The voltage and frequency and local conditions under
which any particular machine may be used
are given on the nameplate of the machine
and in the accompanying service manual.

manufacturer: KAESER KOMPRESSOREN SE
Postfach 2143
96410 Coburg

The drawings remain our exclusive property. They are entrusted
only for the agreed purpose. Copies or any other reproductions,
including storage, treatment and dissemination by use of
electronic systems must not be made for any other than the
agreed purpose. Neither originals nor reproductions must be
forwarded or otherwise made accessible to third parties.

c		Date	13.06.2022	USE	=	
b		Drawn	Talmann		+	
a		Released	Schröder			
A Change	Date	Name		DFA250255E-U3032.00	page	1 Sht.

Lfd. Nr. No.	Benennung Name	Zeichnungsnr. (Kunde) Drawing No. (customer)	Zeichnungsnr. (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	cover page		DFA250255E-U3032.00	1	
2	list of contents		ZFA250255E-U3032.00	1	
3	general instructions		UFA250255E-U3032.00	1	
4	electrical equipment identification		UFA250255E-U3032.00	2	
5	electrical component parts list		UFA250255E-U3032.00	3	
6	electrical component parts list		UFA250255E-U3032.00	4	
7	electrical component parts list		UFA250255E-U3032.00	5	
8	wiring diagram		SFA250255E-U3032.00	1	
9	wiring diagram		SFA250255E-U3032.00	2	
10	wiring diagram		SFA250255E-U3032.00	3	
11	wiring diagram		SFA250255E-U3032.00	4	
12	wiring diagram		SFA250255E-U3032.00	5	
13	wiring diagram		SFA250255E-U3032.00	6	
14	wiring diagram		SFA250255E-U3032.00	7	
15	wiring diagram		SFA250255E-U3032.00	8	
16	wiring diagram		SFA250255E-U3032.00	9	
17	wiring diagram		SFA250255E-U3032.00	10	
18	wiring diagram		SFA250255E-U3032.00	11	
19	wiring diagram		SFA250255E-U3032.00	12	
20	wiring diagram		SFA250255E-U3032.00	13	
21	wiring diagram		SFA250255E-U3032.00	14	
22	wiring diagram		SFA250255E-U3032.00	15	
23	wiring diagram		SFA250255E-U3032.00	16	
24	wiring diagram	GSM/GPS Modem - option oc	SFA250255E-U3032.00	17	
25	wiring diagram	volt-free contacts - option ob	SFA250255E-U3032.00	18	
26	terminal connection	terminal strip X0-X11	KFA250255E-U3032.00	1	
27	terminal connection	terminal strip X12	KFA250255E-U3032.00	2	
28	terminal connection	terminal strip X14-X15	KFA250255E-U3032.00	3	
29	lay-out	Switchboard / control cabinet bottom / instrument panel	AFA250255E-U3032.00	1	

KAESER
KOMPRESSOREN

list of contents
MOBILAIR M250E/M255E

c				=
b				+
a				
B Change	Date	Name		page 1 1 St.
			ZFA250255E-U3032.00	

general instructions

ATTENTION !!!

Install supplies, grounding and shock protection
to local safety regulations.
Do not make or break
live plug-in connectors.

control cabinet wiring for non-designated conductors

with multi-standard stranded conductors

primary circuits:

grey

red 1mm² H05V-K, 18AWG UL-Style 1015, CSA-TEW

white 1mm² H05V-K, 18AWG UL-Style 1015, CSA-TEW

blue 1mm² H05V-K, 18AWG UL-Style 1015, CSA-TEW

white/blue 1mm² H05V-K, 18AWG UL-Style 1015, CSA-TEW

orange 1,5mm² H07V-K, 16AWG UL-Style 1015, CSA-TEW

violet 1mm² H05V-K, 18AWG UL-Style 1015, CSA-TEW

green/yellow H07V-K, UL-Style 1015, CSA-TEW

primary circuits grounded:

control voltage AC ungrounded:

control voltage AC grounded:

control voltage DC ungrounded:

control voltage DC grounded:

external voltage:

measuring circuits:
ground conductor:

option ba = low temperature equipment

option cd = DUAL control mode

option ob = Automatic-start-stop

option oc = GSM/GPS Modem

c		Date	13.06.2022	=
b		Drawn	Talmann	+
a		Released	Schröder	
C/Change	Date	Name		page 1 5 Sht.

KAESER
KOMPRESSOREN

general instructions
MOBILAIR M250E/M255E

electrical equipment identification <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">1</th><th style="text-align: center;">2</th><th style="text-align: center;">3</th><th style="text-align: center;">4</th><th style="text-align: center;">5</th><th style="text-align: center;">6</th><th style="text-align: center;">7</th><th style="text-align: center;">8</th></tr> </thead> <tbody> <tr> <td colspan="8" style="text-align: center; height: 100px;"></td></tr> </tbody> </table>	1	2	3	4	5	6	7	8									general components <ul style="list-style-type: none"> -B28 Monitoring relay (direction of rotation, voltage) -B29 overload relay, compressor motor -K20 Control board SIGMA CONTROL SMART -K21 Operating unit SIGMA CONTROL SMART -K25 Control board SIGMA CONTROL SMART -K40 control relay EMERGENCY STOP -K51 coupling relay main contactor -K52 coupling relay delta contactor -K53 coupling relay wye contactor -K54 coupling relay vent motor -M1 compressor motor -M4 vent motor -M7 controller ventilator -Q1 main contactor -Q2 delta contactor -Q3 wye contactor -Q4 starter vent motor -R11,-R12 Resistor -S1 EMERGENCY STOP pushbutton -S10 switch control ON/OFF -T11 control transformer -T21 power unit 	sensors/actuators <ul style="list-style-type: none"> -B5 air filter flow compressor pressure transducer -B10 package internal pressure pressure transducer, -B11 pressure transducer, -B40 Control pressure inlet solenoid temperature probe airtend discharge temperature -K1 control valve -K7 drain solenoid 	terminal strips, plug connection <ul style="list-style-type: none"> -X0 terminal strip, ground -X1 plug, power supply -X11 terminal strip, control 230VAC -X12 terminal strip, control 24VDC -X100 Diagnostic socket KAESER 	model-dependent components <ul style="list-style-type: none"> -B13 pressure transducer, Network pressure external, pN -B30 thermostat heating -E30,-E31,-E32 -K27 GSM/GPS Modem -43FU, -44FU, -45FU coupling relay control ON -K61 fuses vent motor -Q30 contactor heating -T4 transformer vent motor -T27 GSM/GPS antenna -X13 GSM/GPS Modem interface -X14,-X15 terminal strip heating -X50,-X51 Adaptor connector or SSA -30FU, -31FU, -32FU fuses auxiliary heating -T30 transformer auxiliary heating -K64 coupling relay compressor motor running -K65 coupling relay compressor motor Under load 	KAESER KOMPRESSOREN <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%;">electrical equipment identification MOBILAIR M250E/M255E</td><td style="width: 50%;">=</td></tr> <tr> <td></td><td>+ UFA250255E-U3032.00</td></tr> <tr> <td></td><td>page 2 5 Sht.</td></tr> </table>	electrical equipment identification MOBILAIR M250E/M255E	=		+ UFA250255E-U3032.00		page 2 5 Sht.
1	2	3	4	5	6	7	8																				
electrical equipment identification MOBILAIR M250E/M255E	=																										
	+ UFA250255E-U3032.00																										
	page 2 5 Sht.																										

model	electrical component parts list				UFA250255E-U3032.00	page 3 5 Sht.
	M250E	M255E	M250E	M255E		
machine power supply	460 V ±10 %, 60 Hz UL	460 V ±10 %, 60 Hz UL	575 V ±10 %, 60 Hz UL	575 V ±10 %, 60 Hz UL		
motor -M1	132 kW / 175 HP	160 kW / 215 HP	132 kW / 175 HP	160 kW / 215 HP	" +	
motor -M4	3 ~ 380-480 V / 6 kW / 8 HP	3 ~ 380-480 V / 6 kW / 8 HP	3 ~ 380-480 V / 6 kW / 8 HP	3 ~ 380-480 V / 6 kW / 8 HP		
CAM-LOK-Connector housing -X1	GRD 7.9256.00200/E-Z200074-64 L1 7.9256.00210/E-Z200074-67 L2 7.9256.00240/E-Z200074-60 L3 7.9256.00230/E-Z200074-61 7.9257.00010/A200639-1 Contact only					
contactor -Q1/-Q2	7.3140.02170 3RT1064-6AF36	7.3140.02170 3RT1064-6AF36	7.3140.02170 3RT1064-6AF36	7.3140.02170 3RT1064-6AF36		
interference suppressor Siemens	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00		
contactor -Q3	7.3140.02140 3RT1054-1AF36	7.3140.02140 3RT1054-1AF36	7.3140.02140 3RT1054-1AF36	7.3140.02140 3RT1054-1AF36		
interference suppressor Siemens	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00	7.3140.02020 3RT1956-1CC00		
contactor -Q4	7.8740.00310 3RT2016-1AK61	7.8740.00310 3RT2016-1AK61	7.8740.00310 3RT2016-1AK61	7.8740.00310 3RT2016-1AK61		
interference suppressor Siemens	7.8740.05130 3RT2916-1CC00	7.8740.05130 3RT2916-1CC00	7.8740.05130 3RT2916-1CC00	7.8740.05130 3RT2916-1CC00		
control relay -K40	7.8740.04200 3RH2140-1JB40	7.8740.04200 3RH2140-1JB40	7.8740.04200 3RH2140-1JB40	7.8740.04200 3RH2140-1JB40		
coupling relay -K51-K54, Phoenix	7.3172.00310 RIF-0-RPT-24DC/21	7.3172.00310 RIF-0-RPT-24DC/21	7.3172.00310 RIF-0-RPT-24DC/21	7.3172.00310 RIF-0-RPT-24DC/21		
Monitoring relay -B28	7.9225.0 Siemens 3UG4617-2CR20	7.9225.0 3UG4617-2CR20	7.9225.0 3UG4617-2CR20	7.9225.0 3UG4617-2CR20		
overload relay -B29	7.6873.00250 3RB2066 55-250 A setting: 143 A 8,6 bar setting: 145 A 12,0 bar setting: 141 A 14,0 bar	7.6873.00250 3RB2066 55-250 A setting: 174 A 8,6 bar setting: 164 A 10,0 bar setting: 164 A 14,0 bar	7.6873.00250 3RB2066 55-250 A setting: 115 A 8,6 bar setting: 117 A 12,0 bar setting: 114 A 14,0 bar	7.6873.00250 3RB2066 55-250 A setting: 142 A 8,6 bar setting: 134 A 10,0 bar setting: 134 A 14,0 bar		
main fuses -1FU -2FU -3FU	7.3161.00460 fuse UL Class CC ATQR 12 A					
fuse socket Wöhner	7.3320.00060 31297	7.3320.00060 31297	7.3320.00060 31297	7.3320.00060 31297		
fuses vent motor -43FU -44FU -45FU	-	-	7.3161.00440 fuse UL Class CC ATDR 8 A	7.3161.00440 fuse UL Class CC ATDR 8 A		
fuse socket Wöhner	-	-	7.3320.00060 31297	7.3320.00060 31297		
fuses auxiliary heating -30FU (option ba)	7.3164.0 fuse UL Class CC ATDR 5 A					
-31FU (option ba)	7.3164.0 fuse UL Class CC ATDR 5 A					
-32FU (option ba)	7.3161.00300 fuse UL Class CC ATDR 10 A					
fuse socket (option ba) Wöhner	7.3320.00060 31297	7.3320.00060 31297	7.3320.00060 31297	7.3320.00060 31297		
control fuse -10FU -11FU -12FU	7.3161.00170 fuse UL Class CC ATQR 6 A					
fuse socket Wöhner	7.3320.00060 31297	7.3320.00060 31297	7.3320.00060 31297	7.3320.00060 31297		
transformer -T4 Hammond	-	-	7.9707.0 Trafo IP 3Ph 6kVA, 480/600/380/480V	7.9707.0 Trafo IP 3Ph 6kVA, 480/600/380/480V		
transformer -T11 Block	7.2238.10060 USTE 208-600 V/2x 115 V, 630 VA					
power supply -T21 Wieland	7.9665.1 power unit 115 VAC/24 V DC 2,5 A	7.9665.1 power unit 115 VAC/24 V DC 2,5 A	7.9665.1 power unit 115 VAC/24 V DC 2,5 A	7.9665.1 power unit 115 VAC/24 V DC 2,5 A		
transformer -T30 (option ba) ACME	7.9713.0 Trafo IP 1Ph 2kVA, 240/480/120/240V	7.9713.0 Trafo IP 1Ph 2kVA, 240/480/120/240V	7.9708.0 Trafo IP 1Ph 2kVA, 600/120/240V	7.9708.0 Trafo IP 1Ph 2kVA, 600/120/240V		

KAESER
KOMPRESSOREN

electrical component parts list
MOBILAIR M250E/M255E

Date	Drawn	Released
a		
b		
c		

Date	Name

model	electrical component parts list				UFA250255E-U3032.00	page 4 5 St.
	M250E	M255E	M250E	M255E		
machine power supply	460 V ±10 %, 60 Hz UL	460 V ±10 %, 60 Hz UL	575 V ±10 %, 60 Hz UL	575 V ±10 %, 60 Hz UL		
connection -W11.1/2/4	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x120 mm ² , 4/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW		
connection -W14	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x120 mm ² , 4/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW		
connection -W19.1/2	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x120 mm ² , 4/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW	H07V-K 3x95 mm ² , 3/0 AWG black 600 V, 90°C UL MTW		
connection -W11.3	H07V-K 3x6 mm ² , 10 AWG black 600 V, 90°C UL MTW	H07V-K 3x6 mm ² , 10 AWG black 600 V, 90°C UL MTW	H07V-K 3x6 mm ² , 10 AWG black 600 V, 90°C UL MTW	H07V-K 3x6 mm ² , 10 AWG black 600 V, 90°C UL MTW		
connection -W4.0/1/2	5G2,5 mm ² , 14 AWG 600 V, 90°C UL	5G2,5 mm ² , 14 AWG 600 V, 90°C UL	5G2,5 mm ² , 14 AWG 600 V, 90°C UL	5G2,5 mm ² , 14 AWG 600 V, 90°C UL		
connection -W30.1/W30.2	3G2,5 mm ² , 14 AWG 600 V, 90°C UL	3G2,5 mm ² , 14 AWG 600 V, 90°C UL	3G2,5 mm ² , 14 AWG 600 V, 90°C UL	3G2,5 mm ² , 14 AWG 600 V, 90°C UL		
connection -W61/W62/W63	3G2,5 mm ² , 14 AWG 600 V, 90°C UL	3G2,5 mm ² , 14 AWG 600 V, 90°C UL	3G2,5 mm ² , 14 AWG 600 V, 90°C UL	3G2,5 mm ² , 14 AWG 600 V, 90°C UL		
connection -W12	7G1 mm ² , 18 AWG 600 V, 90°C UL	7G1 mm ² , 18 AWG 600 V, 90°C UL	7G1 mm ² , 18 AWG 600 V, 90°C UL	7G1 mm ² , 18 AWG 600 V, 90°C UL		
connection -W31/W37	3G1,5 mm ² , 16 AWG 600 V, 90°C UL	3G1,5 mm ² , 16 AWG 600 V, 90°C UL	3G1,5 mm ² , 16 AWG 600 V, 90°C UL	3G1,5 mm ² , 16 AWG 600 V, 90°C UL		
connection -W50 (option ob)	12G1,5 mm ² , 16 AWG 600 V, 90°C UL	12G1,5 mm ² , 16 AWG 600 V, 90°C UL	12G1,5 mm ² , 16 AWG 600 V, 90°C UL	12G1,5 mm ² , 16 AWG 600 V, 90°C UL		
connection -W51 (option ob)	7G1 mm ² , 18 AWG 600 V, 90°C UL	7G1 mm ² , 18 AWG 600 V, 90°C UL	7G1 mm ² , 18 AWG 600 V, 90°C UL	7G1 mm ² , 18 AWG 600 V, 90°C UL		
Operating unit SIGMA CONTROL SMART IFM	7.9200.11010 CR9047	7.9200.11010 CR9047	7.9200.11010 CR9047	7.9200.11010 CR9047		
EMERGENCY STOP pushbutton -S1	7.3217.0 / QRUVE	7.3217.0 / QRUVE	7.3217.0 / QRUVE	7.3217.0 / QRUVE		
auxiliary contact Schlegel	7.3218.0 / MTHOO	7.3218.0 / MTHOO	7.3218.0 / MTHOO	7.3218.0 / MTHOO		
control switch -S10	7.9027.10050 / RKWA	7.9027.10050 / RKWA	7.9027.10050 / RKWA	7.9027.10050 / RKWA		
auxiliary contact Schlegel	7.9027.10030 / BTLS5	7.9027.10030 / BTLS5	7.9027.10030 / BTLS5	7.9027.10030 / BTLS5		
Control board -K20/-K25 IFM	7.9200.11000 CR9052	7.9200.11000 CR9052	7.9200.11000 CR9052	7.9200.11000 CR9052		
Control board -K20N1/-K25N1 AMP	7.9200.01310 928343-6	7.9200.01310 928343-6	7.9200.01310 928343-6	7.9200.01310 928343-6		
Control board -K20 AI-K20B/-K20C AMP	7.9200.01320 3-928343-8	7.9200.01320 3-928343-8	7.9200.01320 3-928343-8	7.9200.01320 3-928343-8		
Control board -K20E/-K20F/-K25F AMP	7.9200.01330 928343-8	7.9200.01330 928343-8	7.9200.01330 928343-8	7.9200.01330 928343-8		

 electrical component parts list
 MOBILAIR M250E/M255E


KAESER
KOMPRESSOREN


c	Date	13/06/2022	Taumann
b	Date		Schröder
a	Drawn		
C Change	Released		


model	electrical component parts list				UFA250255E-U3032.00	page 5 5 Stk.
	M250E	M255E	M250E	M255E		
machine power supply	460 V ±10 %, 60 Hz UL	460 V ±10 %, 60 Hz UL	575 V ±10 %, 60 Hz UL	575 V ±10 %, 60 Hz UL		
control valve -K1 Bürkert	7.7089.1 solenoid valve 24 V DC G3/8 2/2-W	" +				
drain solenoid -K7 Bürkert	7.5453.10030 solenoid valve 24 V DC 3/2-W					
air filter flow compressor -BS 55 mbar	7.5429.00030 55 mbar	7.5429.00030 55 mbar	7.5429.00030 55 mbar	7.5429.00030 55 mbar		
pressure transducer -B10 system pressure Hubacontrol	7.9204.0 511.931603542	7.9204.0 511.931603542	7.9204.0 511.931603542	7.9204.0 511.931603542		
pressure transducer -B11 Control pressure inlet solenoid Hubacontrol	7.9203.0 511.917603542W	7.9203.0 511.917603542W	7.9203.0 511.917603542W	7.9203.0 511.917603542W		
temperature probe -B40 block discharge temperature Wika	7.8291.0 TF35	7.8291.0 TF35	7.8291.0 TF35	7.8291.0 TF35		
converter -T40 block discharge temperature	7.2887.00063 Signalwandler Pt100 > U					
Resistor -R11 Conrad	7.5392.00030 120R 0,5W + -5 %					
controller ventilator -M7 ebm-papst	7.9660.0 614 NGML-283	7.9660.0 614 NGML-283	7.9660.0 614 NGML-283	7.9660.0 614 NGML-283		
terminal strip -X11 Wieland	7.3149.02080; 7.3149.01850 WKFN 2,5D2/2/35; WKFN 4D2/2/SL/35					
terminal strip -X12 Wieland	7.3149.00860; 7.3149.01850 WKFN 1,5E/35; WKFN 4D2/2/SL/35	25x 7.3149.00860; 2x7.3149.01850 WKFN 2,5D2/2/35; WKFN 4D2/2/SL/35	25x 7.3149.00860; 2x7.3149.01850 WKFN 2,5D2/2/35; WKFN 4D2/2/SL/35	25x 7.3149.00860; 2x7.3149.01850 WKFN 2,5D2/2/35; WKFN 4D2/2/SL/35		
Diagnostic socket -X100 AMP	7.6589.12000 206043-4	7.6589.12000 206043-4	7.6589.12000 206043-4	7.6589.12000 206043-4		
pressure transducer -B13 (option od) Network pressure external Hubacontrol	7.9204.0 511.931603542	7.9204.0 511.931603542	7.9204.0 511.931603542	7.9204.0 511.931603542		
thermostat -B30 (option ba) Jumo	7.2000.32000 thermostat -10 - + 40 °C					
heating -E30/-E31/-E32 (Op. ba) Helios	7.9714.0 Rippenrohrheizkörper 500W	7.9714.0 Rippenrohrheizkörper 500W	7.9714.0 Rippenrohrheizkörper 500W	7.9714.0 Rippenrohrheizkörper 500W		
contactor -Q30 (option ba)	7.8740.00310 3RT2016-1AK61	7.8740.00310 3RT2016-1AK61	7.8740.00310 3RT2016-1AK61	7.8740.00310 3RT2016-1AK61		
interference suppressor Siemens	7.8740.05130 3RT2916-1CC00	7.8740.05130 3RT2916-1CC00	7.8740.05130 3RT2916-1CC00	7.8740.05130 3RT2916-1CC00		
terminal strip -X14, X15 (option ba) Wieland	7.3149.02080; 7.3149.01850 WKFN 2,5D2/2/35; WKFN 4D2/2/SL/35					
coupling relay -K61 K64 K65 (option ob) Phoenix	7.3172.00310 RIF-0-RPT-24DC/21	7.3172.00310 RIF-0-RPT-24DC/21	7.3172.00310 RIF-0-RPT-24DC/21	7.3172.00310 RIF-0-RPT-24DC/21		
Adaptor connector SSA -X50 (option ob) Harting	7.3704.00170/16B 7.3704.00200/16E 7.3704.00180/16B/M25 7.3704.00190/16E	7.3704.00170/16B 7.3704.00200/16E 7.3704.00180/16B/M25 7.3704.00190/16E	7.3704.00170/16B 7.3704.00200/16E 7.3704.00180/16B/M25 7.3704.00190/16E	7.3704.00170/16B 7.3704.00200/16E 7.3704.00180/16B/M25 7.3704.00190/16E		
Adaptor connector SSA -X51 (option ob) Harting	7.3704.00210/6B 7.3704.00240/6E 7.3704.00220/6B/M20 7.3704.00230/6E	7.3704.00210/6B 7.3704.00240/6E 7.3704.00220/6B/M20 7.3704.00230/6E	7.3704.00210/6B 7.3704.00240/6E 7.3704.00220/6B/M20 7.3704.00230/6E	7.3704.00210/6B 7.3704.00240/6E 7.3704.00220/6B/M20 7.3704.00230/6E		
GSM/GPS Modem -K27 (option oc) Proemion	7.9208.04000 model 3651	7.9208.04000 model 3651	7.9208.04000 model 3651	7.9208.04000 model 3651		
GSM/GPS antenna -T27 (option oc) Proemion	7.9208.03010 GPS antenna	7.9208.03010 GPS antenna	7.9208.03010 GPS antenna	7.9208.03010 GPS antenna		
GSM/GPS Modem -X13/W130 (option oc) IFM	7.9208.01020 Paar-Tronic-CY 3x2x0,5 mm²	7.9208.01020 Paar-Tronic-CY 3x2x0,5 mm²	7.9208.01020 Paar-Tronic-CY 3x2x0,5 mm²	7.9208.01020 Paar-Tronic-CY 3x2x0,5 mm²		


KAESER
KOMPRESSOREN
electrical component parts list
MOBILAIR M250E/M255E


c	Date	13.06.2022
b	Drawn	Talmann
a	Released	Schröder
C Change	Date	Name



















































performance-related components,
see: electrical component parts list

7) model-dependent components

Operator manual Portable Rotary Screw Compressor
MOBILAIR M250E / M255E SIGMA CONTROL SMART

No.: 902482 00 USE



13.5 Operator manual for compressed air filter combination



Filters for Compressed Air

005-055 (AO, AA, ACS, AR, AAR)

(EN) Original Language

(NL) (DE) (FR) (FI) (SV) (NO) (DA) (EL) (ES) (PT) (IT) (PL)
(SK) (CS) (ET) (HU) (LV) (LT) (RU) (SL) (TR) (MT) (RO)

aerospace
climate control
electromechanical
filtration
fluid & gas handling
hydraulics
pneumatics
process control
sealing & shielding



ENGINEERING YOUR SUCCESS.

FILTER DH-OIL-X EVO AO AA_01-

FILTER DH-OIL-X EVO AO AA_01-



Warning

- Highlights actions or procedures, which if not performed correctly, may lead to personal injury or death.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, lichamelijk letsel of de dood kunnen veroorzaken.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Verletzungen und tödlichen Unfällen führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent entraîner des dommages corporels ou la mort.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuna saattavat aiheuttaa henkilövahingon tai kuoleman.
- Anger átgárðar og metoder som kan orsaka personskadur eller dödsfall om de inte utförs korrekt.
- Fremhever handlinger eller prosedyrer som kan føre til personskade eller dødsfall hvis de ikke utføres på korrekt måte.
- Fremhæver handlinger eller fremgangsmåder, som kan medføre personskade eller dødsfall, hvis de ikke udføres korrekt.
- Επισημαίνεται τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να οδηγήσουν σε τραυματισμό προσωπικού ή σε θάνατο.
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar daños personales o la muerte.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão provocar danos pessoais ou morte.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di infiuti o morte.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonania mogą prowadzić do obrażeń ciała lub śmierci.
- Zvyražňuje činnosti alebo postupy, ktoré môžu v prípade nesprávneho vykonania viest zraneniu alebo usmrteniu.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést ke zranění nebo usmrcení osob.
- Tóstab esile toiminguud vői protseduurid, mis väärä teostamise korral võivad põhjustada kehavigastusi või surma.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása súlyos vagy végzetes személyi sérfélést okozhat.
- Uzsvet darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var izraisīt ievainojumus vai nāvi.
- Zīmi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima susizeisti ar mīri.
- Указывает на действия, ненадлежащее выполнение которых может привести к нанесению вреда здоровью или смерти
- Oznáčuje dejania ali postopky, ki lahko ob nepravilnem izvajjanju poškodujejo človeka ali povzročijo smrť.
- Doğru bir şekilde yerine getirilmemiği takdirde bu ürüne hasar verebilecek işlem ve süreçleri vurgular.
- Tissottolinea l-azzjonijiet jew il-proceduri, li jekk ma jsirux kif suppost, jista' jkun hemm korriment jew mewt
- Evidențiază acțiuni sau proceduri care, dacă nu sunt corect efectuate, pot duce la leziuni personale sau la deces.



Caution

- Highlights actions or procedures, which if not performed correctly, may lead to damage to this product.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, schade kunnen berokkenen aan dit product.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Schäden am Gerät führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent endommager ce produit.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuna saattavat vaurioittaa täti laitetta.
- Anger átgárðar og metoder som kan orsaka skadur på den här produkten om de inte utförs korrekt.
- Fremhever handlinger eller prosedyrer som kan føre til skade på produktet hvis de ikke utføres på korrekt måte.
- Fremhæver handlinger eller fremgangsmåder, som kan medføre beskadigelse af dette produkt, hvis de ikke udføres korrekt.
- Επισημαίνεται τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να προκαλέσουν ζημιά στο προϊόν αυτό
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar el deterioro del producto.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão danificar este produto.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di danneggiare il prodotto.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonania mogą powodować uszkodzenie produktu.
- Zvyražňuje činnosti alebo postupy, ktoré v prípade nesprávneho vykonania môžu viest k poškodeniu tohto výrobku.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést ke poškození tohoto výrobku.
- Tóstab esile toiminguud vői protseduurid, mis väärä teostamise korral võivad kääsolevat toodet kahjustada.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása a termék károsodásához vezethet.
- Uzsvet darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var sabojāt šo izstrādājumu.
- Zīmi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima sugadinti šī gaminī.
- Указывает на действия, ненадлежащее выполнение которых может привести к повреждениям данного изделия
- Oznáčuje dejania ali postopky, ki lahko ob nepravilnem izvajjanju poškodujejo izdelek.
- Doğru bir şekilde yerine getirilmemiği takdirde yaralanma ya da ölüme yol açabilecek işlem ve süreçleri vurgular
- Tissottolinea l-azzjonijiet jew il-proceduri, li jekk ma jsirux kif suppost, tista' ssir hsara lil dan il prodott
- Evidențiază acțiuni sau proceduri care, dacă nu sunt corect efectuate, pot duce la deteriorarea acestui produs.



- Suitable gloves must be worn.
- Geeignete Schutzhandschuhe tragen.
- Käytettävä asianmukaisia käsineitä.
- Bruk egnede hanskter.
- Апарате́йті ва форате каталлъла ўяңтіа
- Devem ser utilizadas luvas adequadas.
- Należy zakładać odpowiednie rękawice
- Kohustuslik kanda sobivaid kaitsekindaid
- Jávalkā piemēroti cimdi.
- Работы должны проводиться в соответствующих перчатках
- Uygın eldiven giyilmelidir
- Este necesară purtarea unor mănuși adecvate.

- Altijd geschikte handschoenen dragen.
- Le port de gants adaptés est obligatoire.
- Använd lämpliga handskar.
- Der skal anvendes egnede handsker.
- Se deben llevar guantes quentes apropiados.
- Indossare guanti di protezione.
- Je nutné použiť vhodné rukavice.
- Viseljen megfelelő védőkesztyűt.
- Reikia művétő tinkamas pirštines.
- Uporabiti je treba ustrezne rokavice.
- Għandhom jintibbs ingwanti adatti



- Highlights the requirements for disposing of used parts and waste.
- Benadrukt de vereisten voor het weggoeden van gebruikte onderdelen en afval.
- Weist auf die Anforderungen zur Entsorgung gebrauchter Teile und Abfall hin.
- Met en relief les consignes de mise au rebut des pièces usagées et des déchets.
- Osoittaa käytettyin osien ja jäteen hävitämistä koskevia vaatimuksia.
- Anger de krav som ställs på bortskaffande av gamla delar och avfall.
- Fremhever kravene for avhending av brukte deler og avfall.
- Fremhæver kravene til bortskaftelse af udjiente dele og affald.
- Επισημαίνεται τις απαιτήσεις απόρριψης των χρησιμοποιημένων εξαρτημάτων και των απορριμμάτων
- Destaca los requisitos para desechar las piezas usadas y los residuos.
- Realça os requisitos para eliminar as peças utilizadas e os desperdícios.
- Segnala i criteri per lo smaltimento di componenti usati e rifiuti.
- Wskazuje wymagania dotyczące usuwania zużytych części i odpadów.
- Zvyražňuje požiadavky pre zneškodňovanie použitých dielov a odpadu.
- Upozornění na požadavky týkající se likvidace použitých dílů a odpadu.
- Tóstab esile kasutatud osade ja jääkide utiliseerimisele esitatavad nõuded
- A használt alkatrészek és a hulladék megfelelő módon történő elhelyezésére hívja fel a figyelmet.
- Uzsvet prasības tam, kā atrīvoties no lietotajām detaļām un atkritumiem.
- Zīmi panaudotu daliu ir atlieku išmetimo reikalavimus.
- Указывает на требования по уничтожению использованных деталей и отходов
- Oznáčuje zahteve za odlaganje rabljenih delov en odpadkov.
- Kullanılmış parçaların ve atıkların atılmasıyla ilişkin gereklilikleri vurgular
- Tissottolinea l-kundizzonijiet biex wiehed jarmi l-partijiet użati u l-iskart
- Evidențiază cerințele pentru depunerea la deșeuri a pieselor uzate și a reziduurilor.

 <ul style="list-style-type: none"> Pressure. Paine. Πίεση Ciśnienie Nyomás alatt. Tlak  <ul style="list-style-type: none"> Release Pressure. Évacuation de pression. Avlast trykk Despresurizar. Ciśnienie spustowe Surve väljälase Išleiskite slėgį. Basinci Kaldırın  <ul style="list-style-type: none"> Replace every year Remplacer tous les ans. Skift ut hvert år Sustituir anualmente Należy wymieniać raz w roku Asendage igal aastal Keiskite kartu per metus Her yıl değiştirin  <ul style="list-style-type: none"> Filter housing / Model Logement du filtre/modèle. Filterhus-/modell Caja de filtro/modelo. Obudowa filtra / model. Filti korpus/mudel Filtro korpusas / modelis Filtre muhafazası / Model  <ul style="list-style-type: none"> High efficiency filter element Hochleistungsfilterelement Tehokas suodatin-elementti Høyeffektivt filterelement Φίλτρο υψηλής απόδοσης Elemento de filtro de elevado rendimento Wysokowydajny wkład filtra Vysoko účinný filtrační prvek Nagy hatékonyságú szűrőelem Labai efektyvus filtravimo elementas Visoko učinkovit filtrirni element Element tal-filtri b'efficjenza kbira  <ul style="list-style-type: none"> Ensure correct tool is used Zorg dat het juiste gereedschap wordt gebruikt Vérifier que les outils adéquats sont utilisés. Se till att rätt verktyg används. Sørg for at benytte korrekt værktøj Asegúrese de que se utiliza la herramienta adecuada Assicurarsi di utilizzare l'utensile corretto Uistite sa, že používate správny nástroj Tagage õige tööriista kasutamine Izmantojiet tikai atbilstošus darbarīkus Убедитесь, что используется правильный инструмент Doğru alet kullanılmamasını sağlayın  <ul style="list-style-type: none"> Next service date (month/year) Nächster Wartungstermin (Monat/Jahr) Seuraava huollon päivämäärä (kuukausi/vuosi) Neste servicedato (máned/ár) Επόμενη ημερομηνία σέρβις (μήνας / έτος) Data da próxima intervenção técnica (mês / ano) Data następnego serwisu (miesiąc/rok) Datum příští prohlídky (měsíc / rok) Következő szerviz dátuma (hó / év) Kitos techninės priežiūros data (mėnuo / metai) Datum naslednjega servisa (mesec / leto) Id-data tas-servis li jmiss (xahar / sena) 	<ul style="list-style-type: none"> Druck. Trykk. Pressão. Tlak. Slēgis. Pressjoni <ul style="list-style-type: none"> Druck abblassen. Tryckutsläpp. Εκτόνωση πίεσης Scaricare la pressione. Uvolnění tlaku. Pazeminent spiedienu. Sprostitev tlaka. Depresurizare. <ul style="list-style-type: none"> Jährlich austauschen Byt varje år Αντικατάσταση κάθε χρόνου Sostituire ogni anno Nutná výmena každý rok. Nomainiet reizi gadā. Zamenjajte vsako leto. Înlocuire anuală. <ul style="list-style-type: none"> Filtergehäuse / Modell Filterhus/modell Υποδοχή/μοντέλο φίλτρου Corpo del filtro / Modello Kryt filtra / Model Filtra korpus / modelis Ohiše filtra / Model Carcasă filtru / Model <ul style="list-style-type: none"> Zeer efficiënt filterelement Cartouche filtrante haute efficacité. Högeffektivt filterelement Högeffektivt filterelement Elemento filtrante de gran eficiencia. Elemento filtrante ad alta efficienza Vysoko účinný filtrační článok Kõrgtootlik filterelement Augstas produktivitātes filtra elements Высокоэффективный фильтрующий элемент Yüksek etkinlikli filtre öğesi Element filtrant cu eficiență ridicată <ul style="list-style-type: none"> Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden. Käytettävä oikeaa työkalua Pass på att korrekt verktyg brukes Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο Certifice-se de que é utilizada a ferramenta correcta Należy używać odpowiedniego narzędzia. Zkontrolujte použití správného nástroje Mindig a célnak megfelelő szerszámost használja Isitikinkite, kad naudojamas reikiamas įrankis Poskrbite, da boste uporabili ustrezno orodje Kun žgur li tinxija i-ghoddha t-tajba Asigurați-vă că este utilizată scula corectă <ul style="list-style-type: none"> Volgende onderhoudsdatum (maand / jaar) Date de la prochaine révision (mois/année) Nästa servicedatum (månad/år) Næste servicedato (máned/ár) Fecha de siguiente revisión (mes/año) Prossimo intervento di assistenza (mese / anno) Dátum nasledujúcej opravy (mesiac/rok) Järgmise hoolduse kuupäev (kuu / aasta) Näkamais arkkopes datums (mēnesis / gads) Дата следующего обслуживания (месяц/год) Bir sonraki servis tarihi (ay / yıl) Data următoarei vizite de service (lună/an)
--	---

**Warning!**

This product must be installed and maintained by competent and authorised personnel only, under strict observance of these operating instructions, any relevant standards and legal requirements where appropriate.

Retain this user guide for future reference

Waarschuwing!

Dit product mag alleen geïnstalleerd en onderhouden worden door deskundig en bevoegd personeel met strikte inachtneming van deze bedieningsinstructies en de betreffende normen en wettelijke vereisten indien van toepassing.

Bewaar deze handleiding als naslag.

Warnung!

Das Produkt darf ausschließlich von autorisiertem Fachpersonal unter strikter Befolgung dieser Betriebsanleitung, ggf. relevanter Normen sowie gesetzlicher Vorschriften installiert und gewartet werden.

Bewahren Sie die Bedienungsanleitung zu Referenzzwecken auf.

Attention !

Ce produit doit être installé et entretenu exclusivement par un personnel compétent et autorisé, dans le respect le plus strict de ce mode d'emploi et des normes applicables et exigences légales éventuelles.

Conserver ce guide de l'utilisateur à titre de référence future

Varoitus!

Tämä tuotteen saa asentaa ja huoltaa vain pätevä ja valtuutettu henkilöstö, noudattaen tarkasti näitä käyttöohjeita, kaikkia asiaankuuluvia normeja ja tarpeen vaatessa lain asettamia vaatimuksia.

Säilytä tämä käyttöohje tulevaa tarvetta varten.

Varning!

Produkten får endast installeras och underhållas av utbildad och behörig personal, som följer denna bruksanvisning och eventuella tillämpliga normer och lagföreskrifter noga i förekommande fall.

Behåll denna användarhandbok som referens

Advarsel!

Dette produktet må bare installeres og vedlikeholdes av kompetent og autorisert personale, i streng overholdelse av disse betjeningsanvisningene, alle relevante standarder og rettslige krav der det passer.

Ta vare på denne brukerveiledningen for senere bruk

Advarsel!

Dette produktet må kun installeres og vedligeholdes af autoriseret personale, under nøje overholdelse af disse driftsinstruktioner, relevante standarder og lovgivningsmæssige krav, hvor dette er aktuelt.

Gem denne vejledning til senere reference.

Προειδοποίηση!

Η εγκατάσταση και συντήρηση αυτού του προϊόντος πρέπει να γίνεται μόνο από κατάλληλα εκπαιδευμένο και εξουσιοδοτημένο προσωπικό, με αυστηρή τήρηση των οδηγιών χειρισμού, των εφαρμοζόμενων προτύπων και των νομικών απαιτήσεων όπου απαιτείται.

Φυλάξτε αυτό το εγχειρίδιο χρήσης για μελλοντική αναφορά

Advertencia

La instalación y mantenimiento de este producto debe ser efectuada únicamente por personal competente y autorizado, respetándose de forma estricta estas instrucciones de funcionamiento, así como cualquier norma y requerimiento legal que sean aplicables.

Conserve esta guía del usuario para poder consultarla en el futuro.

Advertência!

A instalação e a manutenção deste produto só deve ser realizada por pessoal autorizado e competente, sob estrita observância destas instruções de utilização e de quaisquer normas e requisitos legais relevantes, quando adequado.

Conserve este guia do utilizador para referência futura

Attenzione

L'installazione e la manutenzione del prodotto devono essere affidate a personale competente e autorizzato, nel rigoroso rispetto delle presenti istruzioni di funzionamento, degli standard applicabili e delle normative in vigore, qualora appropriato.

Conservare questa guida utente per consultarla in seguito**Ostrzeżenie!**

Instalacja i konserwacja urządzenia muszą być prowadzone przez wykwalifikowany personel, w zgodzie z poniższymi instrukcjami, obowiązującymi standardami i wymogami prawa.

Niniejszą instrukcję należy zachować do późniejszego wykorzystania.

Pozor!

Tento výrobok musí byť nainštalovaný a udržiavaný iba kompetentnou a autorizovanou osobou, pri prísnom dodržiavaní tohto návodu na použitie, príslušných štandardov a zákonných požiadaviek v prípade potreby.

Uschovajte túto užívateľskú príručku pre budúce použitie

Upozornění!

Tento produkt smí instalovat a údržbu smí provádět pouze kompetentní a autorizovaný personál, a to za přísného dodržování tohoto návodu k obsluze, veškerých relevantních norem a zákonných požadavků tam, kde je to nutné.

Tuto uživatelskou příručku uschovejte pro pozdější potřebu.

Hoiatus!

Toote paigaldamine ja hooldamine on lubatud ainult pädeval, vastavate volitustega töötajal, kes tegutseb kasutusjuhendi nõudeid, asjakohaseid standardeid ja kehtivaid eeskirju järgides.

Hoidke käesolev kasutusjuhend alal edaspidiseks kasutamiseks

Fügylem!

A terméket csak szakképzett és felhatalmazott személy helyezheti üzembe és tarthatja karban, a kezelési utasítások, a vonatkozó szabványok és jogi előírások szigorú betartása mellett, ahol azok alkalmazhatóak.

A leírást tartsa minden elérhető helyen

Brīdinājums!

Iekārtas uztādišanu un apkopi drīkst veikt tikai kompetents un pilnvarots personāls, stingri ievērojot lietošanas instrukciju un citus saistītus standartus un likumdošanā noteiktās prasības, kad nepieciešams.

Saglabājiet šo lietotāja rokasgrāmatu turpmākām uzziņām

Ispėjimas!

Montuoti ir prižirėti šį gaminį gali tik kompetentingi ir įgalioti darbuotojai, griežtai laikydamiesi šių naudojimo instrukcijų, visų atitinkamų standartų bei teisinių reikalavimų, jei tai yra taikytina.

Pasilikite šį vartotojo vadovą, tame esančios informacijos gali prieikti vēliau

Предупреждение!

Установку и техническое обслуживание данного оборудования разрешается выполнять только специалисту, имеющему допуск к выполнению таких работ, при строгом соблюдении данной инструкции по эксплуатации, соответствующих стандартов и применимых нормативных актов.

Сохраните это руководство пользователя, чтобы обращаться к нему в дальнейшем

Opozorilo!

Izdelek lahko namestijo in vzdržujejo le usposobljeni in pooblaščeni delavci, ki morajo pri tem strogo upoštevati navodila za uporabo, vse standarde in zakonske zahteve, ki veljajo za posamezno situacijo.

Shranite ta navodila za uporabo za v prihodnje

Dikkat!

Bu ürün yalnızca yetkili ve kalifiye personel tarafından monte edilmeli ve bakımı yapılmalıdır. Kullanım talimatına, ilgili standartlara ve yasal şartlara harfiyen uyulmalıdır.

Bu kullanım kılavuzunu ileride başvurmak için saklayın.

Twissija!

Dan il-prodott għandu jiġi installat u jingħata l-manutenzjoni minn personal kompetenti u awtorizzat biss, taħt sorveljanza stretta ta' dawn l-istruzzjonijiet tat-thaddim, u kwalunkwe standards u htigżejjet legali rilevanti fejn hu xieraq.

Erfa' din il-għida biex tikkonsulta fil-fil-futur.

Vertizare!

Acest produs trebuie instalat și întreținut numai de către personal competent și autorizat, cu respectarea strictă a acestor instrucțiuni de utilizare, a tuturor standardei relevante și a cerințelor legale, unde este cazul.

Păstrați acest ghid al utilizatorului pentru consultări ulterioare

Index

- **Index** • Stichwortverzeichnis • **Index** • Sisältö • **Index** • Innholdsfortegnelse • **Indeks** • Ευρετήριο • **Índice** • Índice • **Indice** • Skorowidz
- Obsah • Rejstřík • Register • Index • Saturs • Turinys • Указатель • Kazalo • **Dizin** • **Índici** • **Index**

1. Technical Specification

- Technische spezifikationen • Technische Angaben • Caractéristiques techniques • Tekniset tiedot • Tekniska specifikationer
- Tekniske spesifikasjoner • Tekniske specifikationer • Τεχνικές προδιαγραφές • Especificaciones técnicas • Especificações Técnicas
- Caratteristiche tecniche • Dane techniczne • Technická špecifikácia • Technická specifikace • Tehnilised andmed • Műszaki adatok
- Tehnická specifikácia • Technične specifikacija • Технические характеристики • Tehnične specifikacije • **Teknik Spesifikasyon**
- Specifikazzjoni **Teknika** • Specificație tehnică

2. Installation Recommendations

- Installatie • Installation • Installation • Asennus • Installation • Innstallasjon • Installation • Εγκατάσταση • Instalação • Instalação
- Installazione • Zalecenia dotyczące instalacji • Odporúčania ohľadom inštalácie • Doporučení ohľadně instalace • Paigaldussoovitused
- Telepítési követelmények • Ieteikumi uzstādīšanai • Montavimo rekomendacijos • Рекомендации по установке
- Priporočila za nameštitev • Kurma Konusunda Tavsiyeler • Rakkomandazzjoni jet ghall-Installazzjoni • Recomandări de instalare

3. Startup and Operation

- Starten en bediening • Start und Betrieb • Démarrage et exploitation • Käynnistys ja toiminta • **Start och drift** • Oppstart og betjening
- Start og drift • Έναρξη λειτουργίας και χειρισμός • Puesta en marcha y funcionamiento • Arranque e Operação • Avvio e funzionamento
- Uruchomienie i eksploatacja • Spustenie a prevádzka • Spuštění a provoz • Käikulaskmine ja töötamine • Beindítás és üzemeltetés
- Darbības uzsākšana un darbība • Paleidimas ir naudojimas • Запуск и эксплуатация • Zagon in uporaba • Çalıştırma ve İşletme
- **Kif Tixxhel u Kif Thaddeem** • Pornire și funcționare

4. Accessories

- Toebehoren • Zubehör • Accessoires • Lisävarusteet • Tillbehör Tilbehør • **Tilbehør** • Εξαρτήματα • Accesorios • Acessórios • **Accessori**
- Wyposażenie • Príslušenstvo • Příslušenství • Tarvikud • Tartozékok • Piederumi • Priedai • Принадлежности • Dodatna oprema
- Aksesuarlar • **Aćessorji** • **Accesorii**

5. Spare Parts (Service Kits)

- Reserve-onderdelen (servicekits) • Ersatzteile (Service-Kits) • Pièces de recharge (nécessaires d'entretien) • Varaosat (Huoltopakkaukset)
- Reservdelar (servicesatser) • Reservedeler (service-sett) • Reservedele (Servicekit) • Ανταλλακτικά (Πακέτα τεχνικής υποστήριξης)
- Piezas de repuesto (kits de mantenimiento) • Peças Sobressalentes (Kit de Reparação) • Ricambi (kit per l'assistenza)
- Części zamienne (zestawy serwisowe) • Náhradné diely (Servisná súprava) • Náhradní díly (Sady pro údržbu)
- Varuosad (hoolekomplektid) • Pótalkatrész (szervizkészletek) • Rezerves daļas (apkopes komplekti)
- Atsarginės dalys (priežiuros detalių komplektai) • Запасные части (ЗИП) • Nadomestni deli (servisni kompleti)
- **Yedek parça (Servis kitleri)** • Partijiet Għat-Tibdil (Kitts tas-Servizz) • **Piese de schimb (Truse de service)**

6. Maintenance

- Onderhoud • Wartung • Entretien • Kunnossapito • **Underhåll** • Vedlikehold • **Vedligeholdelse** • Συντήρηση • Mantenimiento • Manutenção
- Manutenzione • Konserwacja • Údržba • Údržb • Hooldus • Karbantartás • Tehnická apkope • Techninē priežiūra • Обслуживание
- Vzdrževanja • Bakım • **Maintenzjoni** • Întreținere

(EN)	Model	BSPT/NPT Port Size	Flow Rate	Dimensions	Weight	Operating Parameters	Filter Grade	Filter Models	Max Operating Pressure	Max Operating Temperature	Min Operating Temperature
(NL)	Model	BSP/T/NPT poortafmeting	Stroom snelheid	Afmetingen	Gewicht	Bedrijfs parameters	Filter	Maximale bedrijfs temperatuur	Maximale bedrijfs temperatuur	Minimale bedrijfs temperatuur	Min. Betriebstemperatur
(DE)	Modell	BSP/T/NPT AnschlussgröÙe	Durchfluss- rate	Abmessungen	Gewicht	Betriebsparameter	Filterklasse	Filtermodell	Max. Betriebsdruck	Max. Betriebstemperatur	Min. Betriebstemperatur
(FR)	Modèle	BSP/T/NPT Taille du port	Débit	Dimensions	Poids	Paramètres de fonctionnement	Grade de filtres	Modèles de filtres	Pression de fonctionnement max.	Température de fonctionnement max.	Température de fonctionnement min.
(F)	Malli	BSP/T/NPT portin koko	Virtaus-nopeus	Mittat	Paino	Käyttö-parametriit	Suođatin-luokka	Suođatin-mallit	Suurin käyttö-paine	Suurin käyttö-lämpötila	Pienin käyttö-lämpötila
(SV)	Modell	BSP/T/NPT öppningsstörlek	Flödes-hastighet	Mått	Vikt	Drifts-parametrar	Filter-klass	Filter-modeller	Högsta driftstryck	Högsta drifts-temperatur	Lägsta drifts-temperatur
(NO)	Modell	BSP/T/NPT- portstørrelse	Strømnings- hastighet	Mål	Vekt	Drifts-parametere	Filter-type	Filter-modeller:	Maks. driftstrykk	Maks. drifts-temperatur	Min. drifts-temperatur
(DA)	Model	BSP/T/NPT- portstørrelse	Flow- hastighed	Mål	Vægt	Drifts-parametre	Filter- kvalitet	Filter- modeller	Maks. drifts-tryk	Maks. drifts-temperatur	Min. drifts-temperatur
(EL)	Μοντέλο	Μεγέθεος θύρας BSPT/NPT	Πυρήνας ποροκίσης	Διαστάσεις	Βάρος	Πορόδιοι λεπτούργιας	Kannypia φίλτρου	Μοντέλα φίλτρων	Μέγ. πίεση λεπτούργιας	Μέγ. Θρυκοσοί λεπτούργιας	Ελάχ. θερικοροια λεπτούργιας
(ES)	Modelo	Tamaño de puerto BSPT/NPT	Caudal	Dimensiones	Peso	Parámetros de funcionamiento	Grado del filtro	Modelos de filtros	Presión de funcionamiento máxima	Temperatura de funcionamiento máxima	Temperatura de funcionamiento mínima
(PT)	Modelo	Tamanho da Porta BSPT NPT	Taxa de Fluxo	Dimensões	Peso	Parâmetros de Funcionamento	Grau do Filtro	Modelos de Filtro	Pressão Máx. de Funcionamento	Temperatura Máxima de Funcionamento	Temperatura Mínima de Funcionamento
(T)	Modello	Dimensioni collegamento BSPT/NPT	Portata	Dimensioni	Peso	Parametri di esercizio	Grado di filtrazione	Filtri	Pressione di esercizio massima	Temperatura di esercizio massima	Temperatura di esercizio minima
(PL)	Model	Wielkość otworu BSPT/NPT	Predkość przepływu	Wymiary	Ciężar	Parametry pracy	Klasa filtra	Typy filtrów	Maks. ciśnienie robocze	Maks. temperatura pracy	Min. temperatura pracy
(SK)	Model	BSPT/NPT Velkost portu	Prietoková rýchlosť Rate	Rozmery	Hmotnosť	Prevádzkové parametre	Trieda filtra	Typy filtrov	Max. prevádzkový tlak	Max. prevádzková teplota	Min. prevádzková teplota
(CS)	Model	BSPT/NPT pordi suurus	Rychlosť prútu	Rozmery	Hmotnosť	Provozní parametry	Klasifikace filtra	Modely filtra	Maximální provozní tlak	Maximální provozní teplota	Minimální provozní teplota
(ET)	Model	BSPT/NPT Csőszénsk mérete	Voolukulu	Mõõtmed	Kaal	Talitusparametrid	Filtritsiooniaste	Filtreid	Max. töötavuse	Maksimalne töötavuse	Minimaalne töötavatuur
(HU)	Modelis	BSPT/NPT porta lielums	Áramlási sebesség	Méreték	Tömeg	Üzem parameterek	Szűrő fókuszát	Szűrő tipusa	Max. üzemi nyomás	Max. Üzem hőmérséklet	Min. Üzem hőmérséklet
(LV)	Modelis	BSPT/NPT Priegādo dydis	Plūsmas ātrums	Izmēri	Svars	Darbības parametri	Filtru kategorija	Filtre modeli	Maks. darbības spiediens	Maks. darbības temperatūra	Min. darbības temperatūra
(LT)	Modelis	BSPT/NPT Csőszénsk mérete	Srauto tekmgreitīsēs	Matmenys	Svoris	Darbībai parametri	Filtro klasē	Filtro modelai	Maks. darbinis slēgls	Maks. darbinē temperatūra	Min. darbinē temperatūra
(RU)	Модель	диаметр передней BSPT/NPT	скорлопотка	Габариты	Вес	Рабочие параметры	Качество фильтра	Модели фильтров	Макс. рабочее давление	Макс.	Мин.
(SL)	Model	BSP/T/NPT Port Boyu	Hitrost pretoka	Mere	Teža	Delovni parametri	Razred filtra	Modeli filtri	Maks. delovni tlak	Maks. delovna temperatura	Min. delovna temperatura
(TR)	Model	BSP/T/NPT Rata tal-Port BSP/T/NPT	Akim Hizi Rata tal-Fluss	Boyuutar	Ağırlık Dimensijsnijiet	İşletim Parametreleri	Filtre Derecesi	Filtre Modeleri	Azami İşletme Basinci	Azami İşleme İssi	Asgari İşleme İssi
(MT)	Modell	Dags tal-Port BSP/T/NPT	Debi	Dimensiun	Greutat	Parametri de func.ionar	Gradul filtrului	Modelle de filtr	Presiune maximă de func.ionar	Temperatură maximă de func.ionar	Temperatura Minima ta I-Operat
(RO)	Mode	BSPT/NP									Temperatură minimă de func.ionar

1. Technical Specification

- Technische specificaties • Technische Angaben • Caractéristiques techniques • Tekniset tiedot • Tekniska specifikationer
- Tekniske spesifikasjoner • Tekniske specifikasjoner • Τεχνικές προδιαγραφές • Especificaciones técnicas • Especificações Técnicas
- Caratteristiche tecniche • Dane techniczne • Technická špecifikácia • Technická specifikace • Tehnilised andmed • Műszaki adatok
- Tehnická špecifikácia • Tehnické špecifikácia • Технические характеристики • Tehnične specifikacije • Teknik Spesifikasyon
- Specifikazzjoni Teknika • Specificație tehnică

Model	Pipe Size	L/s	m³/min	m³/hr	cfm
005A	1/4"	6	0.4	22	13
005B	3/8"	6	0.4	22	13
005C	1/2"	6	0.4	22	13
010A	1/4"	10	0.6	36	21
010B	3/8"	10	0.6	36	21
010C	1/2"	10	0.6	36	21
015B	3/8"	20	1.2	72	42
015C	1/2"	20	1.2	72	42
020C	1/2"	30	1.8	108	64
020D	3/4"	30	1.8	108	64
020E	1"	30	1.8	108	64
025D	3/4"	60	3.6	216	127
025E	1"	60	3.6	216	127
030E	1"	110	6.6	396	233
030F	1 1/4"	110	6.6	396	233
030G	1 1/2"	110	6.6	396	233
035F	1 1/4"	160	9.6	576	339
035G	1 1/2"	160	9.6	576	339
040G	1 1/2"	220	13.2	792	466
040H	2"	220	13.2	792	466
045H	2"	330	19.8	1188	699
050I	2 1/2"	430	25.9	1548	911
050J	3"	430	25.9	1548	911
055I	2 1/2"	620	37.3	2232	1314
055J	3"	620	37.3	2232	1314

BSPT / NPT
AA005A □ FX


B = BSPT
N = NPT


Filter Grade	Models	Max Operating Pressure		Max Recommended Operating Temperature		Min Recommended Operating Temperature	
		bar g	psi g				
AO	005□□F□-055□□F□	16	232	80°C	176°F	1.5°C	35°F
AO	005□□M□-055□□M□	20	290	100°C	212°F	1.5°C	35°F
AA	005□□F□-055□□F□	16	232	80°C	176°F	1.5°C	35°F
AA	005□□M□-055□□M□	20	290	100°C	212°F	1.5°C	35°F
AR	005□□M□-055□□M□	20	290	100°C	212°F	1.5°C	35°F
AAR	005□□M□-055□□M□	20	290	100°C	212°F	1.5°C	35°F
ACS	005□□M□-055□□M□	20	290	50°C	122°F	1.5°C	35°F


Weights and Dimensions

- Gewichten en afmetingen • Gewicht und Abmessungen • Poids et dimensions • Painot ja mitat • Vikter och mått • Vekt og dimensjone
- Vægt og mål • Vægt og m'l • Pesos y dimensiones • Pesos e Dimensões • Pesi e dimensioni • Ciężary i wymiary • Hmotnosti a rozmetry
- Hmotnost arozméry • Kaalud ja mõõtmed • Tömeg és méretek • Svars un izmēri • Svoris ir matmenys • Вес и габариты • Teže in mere
- Ağırlıklar ve Boyutlar • Pízijet u Dimensjonijet • **Greutăți și dimensiuni**

Model	Pipe Size	A		B		C		D		Weight	
		mm	ins	mm	ins	mm	ins	mm	ins	kg	lbs
005A	1/4"	76	3	154.5	6.1	126.5	5	40	1.58	0.5	1.1
005B	3/8"	76	3	154.5	6.1	126.5	5	40	1.58	0.5	1.1
005C	1/2"	76	3	154.5	6.1	126.5	5	40	1.58	0.5	1.1
010A	1/4"	76	3	181.5	7.2	153	6	40	1.58	0.6	1.3
010B	3/8"	76	3	181.5	7.2	153	6	40	1.58	0.6	1.3
010C	1/2"	76	3	181.5	7.2	153	6	40	1.58	0.6	1.3
015B	3/8"	97.5	3.8	235	9.3	201	7.9	50	1.97	1.1	2.4
015C	1/2"	97.5	3.8	235	9.3	201	7.9	50	1.97	1.1	2.4
020C	1/2"	97.5	3.8	235	9.3	201	7.9	50	1.97	1.1	2.4
020D	5/8"	97.5	3.8	235	9.3	201	7.9	50	1.97	1.1	2.4
020E	1"	97.5	3.8	235	9.3	201	7.9	50	1.97	1.1	2.4
025D	5/8"	129	5.1	275	10.8	232.5	9.2	70	2.76	2.2	2.5
025E	1"	129	5.1	275	10.8	232.5	9.2	70	2.76	2.2	2.5
030E	1"	129	5.1	364.5	14.3	322	12.7	70	2.76	2.7	2.9
030F	1 1/4"	129	5.1	364.5	14.3	322	12.7	70	2.76	2.7	2.9
030G	1 1/2"	129	5.1	364.5	14.3	322	12.7	70	2.76	2.7	2.9
035F	1 1/4"	170	6.7	432.5	17	382.5	15.1	100	3.94	5.1	11.2
035G	1 1/2"	170	6.7	432.5	17	382.5	15.1	100	3.94	5.1	11.2
040G	1 1/2"	170	6.7	524.5	20.6	474.5	18.7	100	3.94	7	12.5
040H	2"	170	6.7	524.5	20.6	474.5	18.7	100	3.94	7	12.5
045H	2"	170	6.7	524.5	20.6	474.5	18.7	100	3.94	7	12.5
050I	2 1/2"	205	8.1	641.5	25.3	581.5	22.9	120	4.72	11.1	24.4
050J	3"	205	8.1	641.5	25.3	581.5	22.9	120	4.72	11.1	24.4
055I	2 1/2"	205	8.1	832	32.8	772	30.4	120	4.72	13.9	30.6
055J	3"	205	8.1	832	32.8	772	30.4	120	4.72	13.9	30.6







- (EN) The lower closure plate may move when the filter is not pressurised.
- (NL) Het onderste sluitplaatje zou kunnen bewegen wanneer het filter niet onder druk staat.
- (DE) Die untere Verschlussplatte kann sich bewegen, wenn der Filter nicht mit Druck beaufschlagt ist.
- (FR) La plaque d'obturation la plus basse peut bouger si le filtre n'est pas pressurisé.
- (FI) Alempi sulkulevy saattaa liikkua, kun suodatin ei ole paineistettu.
- (SV) Den lägre slutningsplattan kan rubbas när filtret inte är trycksatt.
- (NO) Den nedre trykkplaten kan bevege seg når filteret ikke er trykksatt.
- (DA) Den nedre lukkeplade kan bevæge sig, når filtret ikke sættes under tryk.
- (EL) Η κάτω πλάκα κλεισίματος μπορεί να μετακινηθεί εάν το φίλτρο δεν βρίσκεται υπό πίεση.
- (ES) La placa inferior de cierre puede moverse si el filtro no está presurizado.
- (PT) A placa de isolamento inferior pode deslocar-se se o filtro não estiver pressurizado.
- (IT) Quando il filtro non è sotto pressione, la piastra di chiusura inferiore potrebbe spostarsi.

(PL) Pokrywa dolna może się przesuwać, gdy filtr nie będzie pod ciśnieniem.

(SK) Ak filter nie je natlakovaný, spodná uzatváracia platňa sa môže posunúť.

(CS) Spodní uzavírací deska se může pohybovat, pokud je filtr pod tlakem.

(ET) Alumine sulgurplaat võib liikuda, kui filter ei ole rõhu all.

(HU) Az alsó zárólemez elmozdulhat, ha a szűrő nincs nyomás alatt.

(LV) Apakšējā noslēgplāksne var kustēties, ja filtrs nav zem spiediena.

(LT) Jeigu filtre néra slégio, apatiné uždaromoji plokštė gali judėti.

(RU) Если фильтр не герметизирован, возможно смещение нижней замыкающей пластины.

(SL) Spodnja plošča za zapiranje se lahko premika, ko filter ni pod pritiskom.

(TR) Filtreye basınç uygulanmadığında alt kapama levhası hareket edebilir.

(MT) L-aċċessorji għandhom ikunu mqabbdin ma' l-ert - art

(RO) Placa inferioară de acoperire se poate deplasa atunci când filtrul nu este presurizat

3. Startup and Operation

- Starten en bediening • Start und Betrieb • Démarrage et exploitation • Käynnistys ja toiminta • Start och drift • Oppstart og betjening
- Start og drift • Έναρξη λειτουργίας και χειρισμός • Puesta en marcha y funcionamiento • Arranque e Operação • Avvio e funzionamento
- Uruchomienie i eksploatacja • Spustenie a prevádzka • Spuštění a provoz • Käikulaskmine ja töötamine • Beindítás és üzemeltetés
- Darbības uzsākšana un darbība • Paleidimas ir naudojimas • Запуск и эксплуатация • Zagon in uporaba • Çalıştırma ve İşletme
- Kif Tixghel u Kif Thaddem

(EN)

1. Open inlet valve slowly to gradually pressurise the unit.
2. Open outlet valve slowly to re-pressurise the downstream piping

Do not open inlet or outlet valves rapidly or subject unit to excessive pressure differential or damage may occur.

(NL)

1. Doe de inlaatklep langzaam open om het toestel geleidelijk onder druk te zetten.
2. Doe de uitlaatklep langzaam open om de leidingen verderop in het systeem opnieuw onder druk te zetten.

De inlaat- en uitlaatkleppen niet snel openen en het toestel niet aan een te groot drukdifferentieel blootstellen om schade te voorkomen.

(DE)

1. Einlassventil langsam öffnen, damit Einheit allmählich mit Druck beaufschlagt wird.
 2. Auslassventil langsam öffnen, damit nachgeschaltete Rohrleitungen erneut mit Druck beaufschlagt werden.
- Einlass- und Auslassventil nicht schnell öffnen. Einheit nicht extremen Druckunterschieden aussetzen. Gefahr von Schäden.

(FR)

1. Ouvrez lentement la soupape d'admission pour mettre progressivement l'unité sous pression.
2. Ouvrez lentement la soupape de refoulement pour faire remonter la pression des conduits en aval.

Évitez d'ouvrir la soupape d'admission ou la soupape de refoulement trop rapidement ou de soumettre l'unité à une pression différentielle trop importante au risque d'entraîner des dommages.

(FI)

1. Paineista yksikkö asteittain avaamalla tuloventtiili.
2. Paineista laskuputkisto uudelleen avaamalla lähtöventtiili hitaasti

Älä avaa tulo- tai lähtöventtiiliä nopeasti tai altista yksikköä liialliselle paine-erolle, sillä yksikkö voi vaurioitua.

(SV)

1. Öppna inloppsventilen långsamt så att enheten trycksätts gradvis.
2. Öppna utloppsventilen långsamt för att trycksätta rören nedströms på nytt.

Öppna inte inlopps- eller utloppsventilerna snabbt och utsätt inte enheten för överdrivet differentialtryck, eftersom det kan orsaka skador.

(NO)

1. Åpne inntaksventilen langsomt for å sette enheten gradvis under trykk.
2. Åpne uttaksventilen langsomt for å sette nedstrømsrørene under trykk igjen.

Ikke åpne inntaks- eller uttaksventilene rast eller utsatt enheten for høyt differensialtrykk, da dette kan føre til skade.

(DA)

1. Åbn langsomt indgangsventilen for gradvist at sætte enheden under tryk.
2. Åbn langsomt udløbsventilen for at sætte rørene længere fremme under tryk igen.

Åbn ikke indgangs- eller udgangsventiler hurtigt, og udsæt ikke enheden for store trykforskelle, da det kan medføre skader.

(EL)

1. Ανοίξτε αργά τη βαλβίδα εισαγωγής για να ανέβει σταδιακά η πίεση της μονάδας.
2. Ανοίξτε αργά τη βαλβίδα εξαγωγής για να ανέβει η πίεση της σωλήνωσης κατάντι

Μην ανοίγετε γρήγορα τις βαλβίδες εισαγωγής ή εξαγωγής και μην υποβάλλετε τη μονάδα σε υπερβολική διαφορική πίεση, διότι μπορεί να προκύψει βλάβη.

(ES)

1. Abra lentamente la válvula de admisión para presurizar progresivamente la unidad.
2. Abra lentamente la válvula de descarga para volver a presurizar las tuberías aguas abajo.

Para evitar daños, no abra bruscamente las válvulas de admisión o de descarga ni someta la unidad a una diferencia de presiones excesiva.

(PT)

1. Abra lentamente a válvula de entrada para pressurizar gradualmente a unidade.
2. Abra lentamente a válvula de saída para pressurizar novamente a tubagem a jusante

Não abra rapidamente as válvulas de entrada ou saída nem sujeite a unidade a uma pressão diferencial excessiva, caso contrário poderão ocorrer danos.

(IT)

1. Aprire lentamente la valvola di mandata per aumentare gradualmente la pressione nell'unità.
2. Aprire lentamente la valvola di scarico per pressurizzare i tubi a valle

Non aprire rapidamente le valvole di mandata o scarico o sottoporre l'unità a una differenza di pressione eccessiva; rischio di danni.

(PL)

1. Powoli otwórz zawór wlotowy, aby stopniowo zwiększyć ciśnienie w urządzeniu.
2. Powoli otwórz zawór wylotowy, aby zwiększyć ciśnienie w rurach w dół przepływu.

Nie wolno szybko otwierać zaworów wlotowych ani wylotowych, ponieważ może to doprowadzić do zbyt dużej różnicy ciśnień w urządzeniu i do jego uszkodzenia.

(SK)

1. Pre postupné natlakovanie jednotky pomaly otvorte prívodný ventil.
2. Pre opäťovné natlakovanie potrubia v smere toku pomaly otvorte vývodný ventil.

Neotvárajte prívodný alebo vývodný ventil rýchlo ani nevystavujte jednotku nadmernému rozdielu tlaku, lebo môže dôjsť k poškodeniu.

(CS)

1. Pomalým otevřením přívodního ventilu jednotku pozvolna natlakujte.
2. Pomalým otevřením výstupního ventilu znova natlakujte potrubí ve směru rozvodu.

Přívodní ani výstupní ventily neotvírejte rychle, ani jednotku nevystavujte nadmerným rozdílům tlaku, v opačném případě může dojít k poškození.

(ET)

1. Üksuse jätkjärguliseks survestamiseks avage sisselaskeventiil aeglaset.
2. Surve taastamiseks väljavoolutorustikus avage väljalaskeventiil aeglaset.

Sisselask- ja väljalaskeventile ei tohi avada kiiresti ega põhjustada üksuses liiga suurt surveangu, mis võib tekitada sellele kahjustusi.

(HU)

1. Az egység fokozatosan történő nyomás alá helyezéséhez a bemenő szelepet lassan nyissa meg.
2. Az elmenő csővezeték nyomásának visszaállításához lassan nyissa meg az elmenő szelepet

A berendezés károsodásának elkerülése érdekében ne nyissa meg túl gyorsan a bemenő vagy az elmenő szelepet, és ne tegye ki az egységet nagy nyomáskülönbségeknek.

(LV)

1. Lēnām atveriet ieplūdes vārstu, lai iekārtā pamazām paaugstinātu spiedienu.
2. Lēnām atveriet izplūdes vārstu, lai caurulēs plūsmas virzienā samazinātu spiedienu

Neatveriet ieplūdes un izplūdes vārstus strauji, pretējā gadījumā attiecīgajā iekārtā var rasties pārmērīgi liels spiediens vai tā var sabojāties.

(LT)

1. Lėtai atidarydami įleidimo vožtuvą, palaipsniui sudarykite slēgį įrenginyje.
2. Lėtai atidarydami išleidimo vožtuvą, iš naujo sudarykite slēgį pasroviui esančiam vamzdynę

Negalima stāgaiā atidaryti įleidimo ar išleidimo vožtuvu, nei paveikti įrenginio pernelyg dideliu diferencialiniu slēgiu, nes galima sugadinti īranga.

(RU)

1. Впускной клапан следует открывать плавно, чтобы постепенно создать давление в устройстве.
2. Плавно откройте выпускной клапан, чтобы создать давление в системе трубопровода

Запрещено резко открывать выпускной или выпускной клапаны, а также используемое устройство, так как это может привести к перепаду давления и повреждениям.

(SL)

1. Za počasno dajanje pod pritisk počasi odprite dovodni ventil.
2. Počasi odprite dovodni ventil za ponovno dajanje spodnjih cevi pod pritisk.

Dovodne ali odvodne ventile odpirajte počasi in enote ne izpostavljajte prevelikim nihanjem tlaka, saj lahko to povzroči škodo.

(TR)

1. Giriş valfini yavaşça açıp üniteye yavaş basınç uygulayın.
2. Mensap tarafındaki borulara yeniden basınç uygulamak için çıkış valfini yavaşça açın

Giriş ve çıkış valflerini hızla açmayın ve üniteyi aşırı basınç farklarına maruz bırakmayın; aksi halde hasar görebilir.

(MT)


1. Iftah il-valv tad-dhul bil-mod, biex bil-mod tiżdied il-pressjoni fit-tagħmir.
2. Iftah il-valv tal-hruġ bil-mod biex terġa' tibni l-pressjoni fil-pajps li jwasslu 'l-isfel

Ara li ma tiftahx il-valvs tad-dhul jew tal-hruġ f'daqqa jew b'xi mod tikkawża differenza eċċessiva fil-pressjoni tat-tagħmir ghax tista' tagħmel il-hsara.

(RO)


1. Deschideți lent supapa de admisie, pentru a presuriza gradat aparatul.
2. Deschideți lent supapa de evacuare pentru a represuriza sistemul de conducte din aval

Nu deschideți rapid supapele de admisie sau de evacuare și nu supuneți aparatul la o diferență excesivă de presiune; În caz contrar, aparatul poate suferi deteriorări.



4. Accessories





- Toebehoren • Zubehör • Accessoires • Lisävarusteet • Tillbehör • Tilbehør • Tilbehør • Εξαρτήματα • Accesorios • Acessórios • Accessori
- Wyposażenie • Príslušenstvo • Příslušenství • Tarvikud • Tartozékok • Piederumi • Priedai • Принадлежности • Dodatna oprema
- Aksesuarlar • Acessorji • Accesorii




AO, AA, ACS, AR, AAR 005 - 055

5. Spare Parts (Service Kits)

- Reserve-onderdelen (servicekits) • Ersatzteile (Service-Kits) • Pièces de rechange (nécessaires d'entretien) • Varaosat (Huoltopakkaukset)
- Reservdelar (servicesatser) • Reservedele (Servicekit) • Ανταλλακτικά (Πακέτα τεχνικής υποστήριξης)
- Piezas de repuesto (kits de mantenimiento) • Peças Sobressalentes (Kit de Reparação) • Ricambi (Kit per l'assistenza)
- Części zamienne (zestawy serwisowe) • Náhradné diely (Servisná súprava) • Náhradní díly (Sady pro údržbu) • Varuosad (hoolekomplektid)
- Pótalkatrészek (szervizkészletek) • Rezerves daļas (apkopēs komplekti) • Atsarginės dalys (priežiūros detalių komplektai)
- Запасные части (ЗИП) • Nadomestni deli (servisni komplet) • Yedek parça (Servis kitleri) • Partijet Għat-Tibdil (Kits tas-Servizz) • Pieze de schimb (Truse de service)




 EF1	AUTOMATIC DRAIN • AUTOMATISCHER ABLAUF • VIDANGE AUTOMATIQUE • AUTOMISCHAFTAPPEN • DRENAJE AUTOMATICO • SCARIO AUTOMATICO • AUTOMATISK AFLØB • DRENO AUTOMÁTICO • ΑΥΤΟΜΑΤΗ ΑΠΟΣΤΡΑΓΓΙΣΗ • AUTOMATDRÄNERING • AUTOMAAATTINEN • TYHJENNYSKAPPALE • DREN AUTOMATYCZNY • AUTOMATICKÉ VYSUŠENIE • AUTOMATICKÉ VYPOUŠTĚNÍ • AUTOMAATNE VÄLJALASE • AUTOMATIKUS LEERESZTÉS • AUTOMÁTISKA IZTECINĀŠANA • AUTOMATINIS ISLEIDIMAS • АВТОМАТИЧЕСКИЙ ДРЕНАЖ • SAMODEJNJI ODTOK • OTOMATİK SÜZDÜRÜCÜ • DREJN AWATOMATIKU • EVACUARE AUTOMAT/		 EM1	MANUAL DRAIN • MANUELLER ABLAUF • VIDANGE MANUELLE • MANUEEL AFTAPPEN • DRENAJE MANUAL • SCARIO MANUALE • MANUELT AFLØB • DRENO MANUAL • ΧΕΙΡΟΚΙΝΗΤΗ ΑΠΟΣΤΡΑΓΓΙΣΗ • MANUELL DRÄNERING • KÄSIKÄYTÖINEN • TYHJENNYSKAPPALE • DREN RĘCZNY • RUČNÉ VYSUŠENIE • RUČNÍ VYPOUŠTĚNÍ • KÄSITSI VÄLJALASE • KÉZI LEERESZTÉS • MANUĀLA IZTECINĀŠANA • RANKINIS ISLEIDIMAS • ДРЕНАЖ ВРУЧНУЮ • ROČNÍ ODTOK • ELLE KULLANILACAK SÜZDÜRÜCÜ • DREJN MANWALI • EVACUARE MANUAL/	
					
AO005A	005AO	AA005A	005AA	ACS005A	005ACS
AO005B	005AO	AA005B	005AA	AR005A	005AR
AO005C	005AO	AA005C	005AA	AR005B	005AR
AO010A	010AO	AA010A	010AA	AR005C	005AR
AO010B	010AO	AA010B	010AA	AR010A	010AR
AO010C	010AO	AA010C	010AA	AR010B	010AR
AO015B	015AO	AA015B	015AA	AR010C	010AR
AO015C	015AO	AA015C	015AA	AR015B	015AR
AO020C	020AO	AA020C	020AA	AR015C	015AR
AO020D	020AO	AA020D	020AA	AR020C	020AR
AO020E	020AO	AA020E	020AA	AR020D	020AR
AO025D	025AO	AA025D	025AA	AR020E	020AR
AO025E	025AO	AA025E	025AA	AR025D	025AR
AO030E	030AO	AA030E	030AA	AR025E	025AR
AO030F	030AO	AA030F	030AA	AR030E	030AR
AO030G	030AO	AA030G	030AA	AR030F	030AR
AO040G	040AO	AA040G	040AA	AR030G	030AR
AO040H	040AO	AA040H	040AA	AR040G	040AR
AO045H	045AO	AA045H	045AA	AR040H	040AR
AO050I	050AO	AA050I	050AA	AR045H	045AR
AO050J	050AO	AA050J	050AA	AR050I	050AR
AO055I	055AO	AA055I	055AA	AR050J	050AR
AO055J	055AO	AA055J	055AA	AR055I	055AR
				AR055J	055AR




EMAK1	005 - 010
EMAK2	015 - 020
EMAK3	025 - 030
EMAK4	035 - 045
EMAK5	050 - 055

6. Maintenance


- Onderhoud • Wartung • Entretien • Kunnossapito • Underhåll • Vedlikehold • Vedlikeholdelse • Συντήρηση • Mantenimiento • Manutenção
- Manutenzione • Konserwacja • Údržba • Údržba • Hooldus • Karbantartás • Tehnická apkope • Techniné priežiúra • Обслуживание
- Vzdrževanja • Bakım • Manutenzjoni • Întreținere




3



4




5




6




7




8




9





10



11



12



- (EN) Align the arrow to the month and year of the next service
- (NL) Breng de pijl op een lijn met de maand en het jaar van de volgende onderhoud beurt
- (DE) Stellen Sie den Pfeil auf Monat und Jahr der nächsten Wartung termin
- (FR) Alignez la flèche sur le mois et l'année de la prochaine révision
- (FI) Kohdi ta nuoli euraavan huollon kuukauteen ja vuoteen
- (SV) Rikta pilen mot månaden och året för nästa service
- (NO) Ju ter pilen til måneden og året for neste service
- (DA) Stil pilen på måned og år for næste service
- (EL) Ευθυγραμμίστε το βέλος με το μήνα και έτος του επόμενου σέρβις
- (ES) Alinee la flecha con el mes y año de la siguiente revisión
- (PT) Alineie a seta com o mês e o ano da próxima intervenção técnica
- (IT) Allineare la freccia in corrispondenza del mese e dell'anno del prossimo intervento di manutenzione
- (PL) Należy ustawić strzałkę na miesiąc i rok daty następnego serwisu
- (SK) Šípku nasmerujte na mesiac a rok nasledujucej opravy
- (CS) Umístěte šípku na měsíc a rok příští prohlídky
- (ET) Joondagé nool järgmisi hooldust ja aasta taga
- (HU) Irányítsa a nyílat a következő szerviz hónapjára és évre
- (LV) Irányítsa a nyílat a következő szerviz hónapjára és évre
- (LT) Nustatykite rodyklę ties kitos techninės priežiūros mėnesiu ir metais
- (RU) Совместите стрелку с месяцем и годом следующего обслуживания
- (SL) Puščico nastavite na mesec in leto naslednjega servisa
- (TR) Oku bir sonraki servis işleminin ay ve yılina hizalayın
- (MT) Allinja l-vleġġa għax-xahar u s-sena tas-servis li jmiss
- (RO) Aliniati săgeata în dreptul lunii și al anului următoarei vizite de service



FILTER DH-OIL-X EVO AO AA_01-

ПРИЛОЖЕНИЕ

к разрешению № PPC 00-32481 от 17.12.2008
(без разрешения недействительно)

ПЕРЕЧЕНЬ

оборудования фирмы "Parker Hannifin Ltd. domnick hunter division",
разрешенного к применению на территории Российской Федерации :

1. Фильтры для взрывобезопасных газов типов:

- OIL-X-EVOLUTION (модели от 010 до 055);
- OIL-X-EVOLUTION 4" (модели 060);
- OIL-X-EVOLUTION Fabricated (модели от 100 до 500);
- OIL-X-EVOLUTION OVR (модели от OVR 100 до OVR 250);
- OIL-X-EVOLUTION AC (модели от AC 010 до AC 030);
- OIL-X-EVOLUTION WS (модели от WS 010 до WS 055);
- OIL-X Plus TF-G/H (модели от TF 55 до TF 870);
- OIL-X-EVOLUTION (модели от TFE 060 до TFE 660).

2. Осушители и аппараты для взрывобезопасных газов типов:

- MINI (модели от DM 002 до DM 006);
- Midas (модели от Das 1 до Das 7);
- MIDI DME / DM (модели от DME 012 до DME 080; от DM 012 до DM 080);
- MIDI Transportation (модели TDV – TDH – TDS - TDVC);
- MX/MPX (модели от MX 102c до MX 110; от MPX 110 до MPX 112);
- DH (модели от DH 102 до DH 110);
- PCO2 Maxi (модели от PCO2/0 до PCO2/3);
- PCO2 Maxi Plus (модели от MPlus 4000 до MPlus 10000);
- CDP (модели от CDP1 до CDP6);
- CDPlus (модели от CDPlus 8 до CDPlus 12);
- G (модели от G1 до G9);
- LC/MS (LCMS) (модели LCMS 12/2; 20; 30 – 40);
- Zero Air (модели от UHP-10ZA до UHP-200 ZA);
- CO2RP (модели от CO2RP015 до CO2RP850);
- N2Midi (модели от N2Mid350 до N2Mid601);
- Maxigas (модели от 104 до 120).



Заместитель руководителя
Б.А. Красных

ЛВ 087863

FILTER DH-OIL-X EVO AO AA_01-

<p>Declaration of Conformity</p> <p>Parker Hannifin Ltd domm ck hunter divis on Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK</p> <p>OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055</p> <p>Directives 97/23/EC</p> <p>Standards used Generally in accordance with ASMEVIII Div 1 2004</p> <p>PED Assessment Route Article 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Module A (AO AA ACS AAR 035 040 045) Module B (AO AA ACS AAR AAR 050 055) Lloyds Register Verification 71 Fenchurch St London EC3M 4BS COV0413459/TEC</p> <p>Notified body for PED Lloyds Register Verification 71 Fenchurch St London EC3M 4BS COV0413459/TEC</p> <p>EC Type exam nat on Certificate</p> <p>Authorized Representative Derek Banker Divisional Quality Manager Parker Hannifin Ltd domm ck hunter d v s on</p> <p>Declaration</p> <p>I declare that as the authorized representative, I have the above information in relation to the supply / manufacture of this product is in conformity with the standards and/or related documents following the provisions of the above Directives.</p> <p>Signature  Date 8/8/2007</p> <p>Declaration Number 0002/8807</p>	<p>Déclaration de conformité</p> <p>Parker Hannifin Ltd domm ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK</p> <p>OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055</p> <p>Directives 97/23/EC</p> <p>Normes utilisées Généralement conforme à ASMEVIII d v 1 2004</p> <p>Méthode d'évaluation de la directive d'équipements de pression Article 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Module A (AO AA ACS AAR 035 040 045) Module B (AO AA ACS AAR AAR 050 055)</p> <p>Organisme de notification pour la directive d'équipement sous précontrat Lloyds Register Verification 71 Fenchurch St London EC3M 4BS COV0413459/TEC</p> <p>CE</p> <p>Représentant agréé Derek Banker Divisional Quality Manager Parker Hannifin Ltd domm ck hunter division</p> <p>Déclaration</p> <p>Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents édictés selon les dispositions des directives susmentionnées.</p> <p>S gnature  Date 8/8/2007</p> <p>N° de déclaration 0002/8807</p>
<p>Verklaring van Conformiteit</p> <p>Parker Hannifin Ltd domm ck hunter divis on Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK</p> <p>OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055</p> <p>Richtlijnen 97/23/EC</p> <p>Gehanteerde normen Geenwijzig volgens ASMEVII D v 1 2004</p> <p>PED beoordelingstraject Artikel 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Module A (AO AA ACS AAR 035 040 045) Module B (AO AA ACS AAR AAR 050 055)</p> <p>Aangemelde instantie voor PED Lloyds Register Verification 71 Fenchurch St London EC3M 4BS</p> <p>EC Type onderzoeks certificaat COV0413459/TEC</p> <p>Bevoegde vertegenwoordiger Derek Banker Divisional Quality Manager Parker Hannifin Ltd domm ck hunter d v s on</p> <p>Verklaring</p> <p>Als bevoegd verlegerovergoed voor verklaring, ik dat bovenstaande informatie met betrekking tot de levering / levering van dit product overeenstemt met de normen en andere behorende documentatie volgens de bepalingen van bovengenoemde richtlijnen.</p> <p>Handtekening  Datum 8/8/2007</p> <p>Verklaringnummer 0002/8807</p>	<p>Vaatinutmustukaisuusvakuutus</p> <p>Parker Hannifin Ltd domm ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK</p> <p>OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055</p> <p>Direktiivit 97/23/EC</p> <p>Käytetyt standardit Yleensä seuraavien standardien mukaan asetettu ASMEVII D v 1 2004</p> <p>PED arviointi menetely Artikla 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modulaari A (AO AA ACS AAR 035 040 045) Modulaari B (AO AA ACS AAR AAR 050 055)</p> <p>PED säännösten Imoitettu laitos Lloyds Register Verification 71 Fenchurch St London EC3M 4BS COV0413459/TEC</p> <p>EY tyyppihyväksynnit</p> <p>Valtuuttetu edustaja Derek Banker Divisional Quality Manager Parker Hannifin Ltd domm ck hunter d v s on</p> <p>Vakuutus</p> <p>Vakuutettuna edustajana vakuutan, että ylläolevat tiedot, jotka iittyytämän tuotteen toimiin taiseen tai välttämisseen ovat standardien ja muiden asianmukaisten asetuksen mukaisia ja noudattavat välttämistä.</p> <p>Allekirjoitus  Päiväys 8/8/2007</p> <p>Vakuutusnumero 0002/8807</p>
<p>Konformitätskärung</p> <p>Parker Hannifin Ltd domm ck hunter divis on Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK</p> <p>OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055</p> <p>Richtlinien 97/23/EC</p> <p>Angewandte Normen Allgemein in Übereinstimmung mit ASMEVII D v 1 2004</p> <p>Beurteilungsroute der Druckgeräterichtlinie Artikel 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modular A (AO AA ACS AAR 035 040 045) Modular B (AO AA ACS AAR AAR 050 055)</p> <p>Benannte Stelle für die Druckgeräterichtlinie Lloyds Register Verification 71 Fenchurch St London EC3M 4BS COV0413459/TEC</p> <p>EG Baumusterprüfungserklärung</p> <p>Bevollmächtigter Vertreter Derek Banker Divisional Quality Manager Parker Hannifin Ltd domm ck hunter d v s on</p> <p>Erklärung</p> <p>Hiermit erklären wir als bevollmächtigter Vertreter die Konformität der oben aufgeführten Informationen in Bezug auf die Lieferung/Herstellung dieses Produkts mit den Normen und anderen zugehörigen Dokumenten gemäß den Bestimmungen der oben genannten Richtlinie.</p> <p>Unterschrift  Datum 8/8/2007</p> <p>Nummer der Erklärung 0002/8807</p>	<p>Försäkran om överensstämmelse</p> <p>Parker Hannifin Ltd domm ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK</p> <p>OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055</p> <p>Direktiv 97/23/EC</p> <p>Används standarder Genomgått enligt med ASMEVII D v 1 2004</p> <p>Fastställningsväg för PED Artikel 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modular A (AO AA ACS AAR 035 040 045) Modular B (AO AA ACS AAR AAR 050 055)</p> <p>Anmält organ för PED Lloyds Register Verification 71 Fenchurch St London EC3M 4BS COV0413459/TEC</p> <p>EG intyg om typprovning</p> <p>Auktoriserad representant Derek Banker Divisional Quality Manager Parker Hannifin Ltd domm ck hunter division</p> <p>Försäkran</p> <p>Jag försäkrar i egen hand att auktoriseringen tillverkning av detta produkt överensstämmer med standarder och övriga relevanta dokument enligt vilken i ovanstående direktiv.</p> <p>Underskrift  Datum 8/8/2007</p> <p>Försäkran nummer 0002/8807</p>

FILTER DH-OIL-X EVO AO AA_01-

Konformitetskæring		NO
Parker Hannifin Ltd domnick hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055 Direktiver 97/23/EC Benyttede standarder Hovedsakelig i samsvar med ASMEVIII div 1 2004 Rute for vurdering av PED (d rett ved for trykkpålegg utstyr) Paragraf 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055) Underrettelser organ for PED Lloyds Register Verification 71 Fenchurch St London EC3M 4BS EC typegodkjenningsattestat COV0413459/TEC Autorisert representant Derek Bankier D v s oral Quality Manager Parker Hannifin Ltd domnick hunter division Erklæring Jeg erklærer som autor servert representant at informasjonen ovenfor med henvis til levering/produksjon av dette produktet er i overensstemmelse med standardene og andre relevante dokumenter følger bestemmelserne i direktivene ovenfor Signatur  Dato 8/8/2007 Erklæring nr 0002/8807		

Declaración de conformidad		ES
Parker Hannifin Ltd domnick hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055 Directivas 97/23/EC Normas utilizadas Generalmente de conformidad con ASMEVIII Div 1 2004 Ruta de evaluación de la normativa Artículo 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modulo A (AO AA ACS AAR 035 040 045) Modulo B (AO AA ACS AR AAR 050 055) Organismo notificado para la normativa PED Lloyds Register Verificación 71 Fenchurch St London EC3M 4BS Certificado de examen CE de tipo COV0413459/TEC Representante autorizado Derek Bankier D v s oral Quality Manager Parker Hannifin Ltd domnick hunter division Declaración Como representante autorizado, declaro que la información anteriormente expuesta en relación con el suministro y/o fabricación mencionada en este producto cumple las normativas indicadas y otros documentos adjuntos según las disposiciones de las Directivas establecidas anteriormente Firma  Fecha 8/8/2007 Número de declaración 0002/8807		

Overensstemmelseserklæring		DA
Parker Hannifin Ltd domnick hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055 Direktiver 97/23/EC Anvendte standarder Generelt i overensstemmelse med ASMEVIII div 1 2004 Forløb for PED bedømmelse Artikel 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055) Notificeret organ for PED Lloyds Register Verifikation 71 Fenchurch St London EC3M 4BS EF typeprøvningsattestat COV0413459/TEC Autoriseret representant Derek Bankier D v s oral Quality Manager Parker Hannifin Ltd domnick hunter division Erklæring Jeg erklærer hermed som autor servert representant at ovennævnte oplysninger ved ørende levering/produktion af dette produktet er i overensstemmelse med de anførte standarder og øvrige tilknyttede dokumenter i henhold til bestemmelserne i ovenstående direktiv Underskrift  Dato 8/8/2007 Erklæring nummer 0002/8807		

Declaração de Conformidade		PT
Parker Hannifin Ltd domnick hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055 Directivas 97/23/EC Padrões utilizados De forma geral em concordância com ASMEVIII Div 1 2004 Percurso de Avaliação do PED Artigo 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modulo A (AO AA ACS AAR 035 040 045) Modulo B (AO AA ACS AR AAR 050 055) Notificado para o PED Lloyds Register Verificação 71 Fenchurch St London EC3M 4BS Certificado de Inspeção Tipo CE COV0413459/TEC Revendedor Autorizado Derek Bankier D v s oral Quality Manager Parker Hannifin Ltd domnick hunter division Declaração Declaro que o representante acima listado, que as informações acima contidas referentes ao fornecimento / fabrico deste produto estão em conformidade com as normas e outros documentos relativos, de acordo com as disposições das Directivas anteriores Assinatura  Data 8/8/2007 Número da Declaração 0002/8807		

Δήλωση συμμόρφωσης		EL
Parker Hannifin Ltd domnick hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055 Οδηγίες 97/23/EC Πρότυπα που χρησιμοποιήθηκαν Γεν κά σε σύμφωνη με τη ASMEVIII Div 1 2004 Διεθνής αξιολόγηση για κανονικούς PED Άρθρο 3 (AO AA ACS AAR 005 010 015 020 025 030) Ενότητα A (AO AA ACS AAR 035 040 045) Ενότητα B (AO AA ACS AR AAR 050 055) Ενήμερος οργανισμός για κανονικούς PED Lloyds Register Verification 71 Fenchurch St London EC3M 4BS Πιστοποιητικό εξέτασης τύπου EK COV0413459/TEC Εξουσιοδοτημένος αντιπρόσωπος Derek Bankier Divisional Quality Manager Parker Hannifin Ltd domnick hunter division Δήλωση Δηλώνω ότι ο εξουσιοδοτημένος αντιπρόσωπος στη παραπάνω πληροφορία έχει στην θέση της κατανοήσει αυτού του προϊόντος, συμφέρονταν να προστατεύεται και ως προς τα δώλα σχετικά με ηγεργεία που συνοδεύουν τις άντεξεις των πιο πάνω σημείων Υπογραφή  Ημερομηνία 8/8/2007 Αριθμός δήλωσης 0002/8807		

Dichiarazione di conformità		IT
Parker Hannifin Ltd domnick hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055 Directive 97/23/EC Norme utilizzate Generalmente conforme alle ASMEVIII Div 1 2004 Procedura di valutazione PED Articolo 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modulo A (AO AA ACS AAR 035 040 045) Modulo B (AO AA ACS AR AAR 050 055) Organismo accreditato per PED Lloyds Register Verifikation 71 Fenchurch St London EC3M 4BS Attestato di certificazione tipo CE COV0413459/TEC Rappresentante autorizzato Derek Bankier D v s oral Quality Manager Parker Hannifin Ltd domnick hunter division Dichiarazione In qualità di rappresentante autorizzato dichiaro che le informazioni qui sopra in merito alla fornitura fabbricazione del prodotto in oggetto sono conformi alle norme indicate e si qualificano a tre documenti correlati a la fornitura basato su quanto prescritto dalle direttive menzionate Firma  Data 8/8/2007 Dichiarazione numero 0002/8807		

Deklaracija zgodnosti		PL
Parker Hannifin Ltd domn ck hunter divis on Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktwy	97/23/EC	
Stosowane standardy	Ogólne zgodny z ASMEVIII dzial 1 2004	
Ścieżka potwierdzania zgodności z PED	Arykuł 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Moduł A (AO AA ACS AAR 035 040 045) Moduł B (AO AA ACS AR AAR 050 055)	
Organizacja powiadamiana na mocy PED	Lloyds Register Verificat on 71 Fenchurch St London EC3M 4BS COVO413459/TEC	
Autoryzowany przedstawiciel	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
Deklaracja		
Oświadczam jako auto zyzwany przedstawiciel że powyższe informacje dotyczące dostawy / wytworzenia o niniejszego produktu są zgodne ze standardami i innymi dokumentami powiązanymi zgodnie z postanowieniami powyższych dyrektywy.		
Podpis		
Data	8/8/2007	
Numer deklaracji	0002/8807	

Vastavusudeklaratsioon		ET
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktviid	97/23/EC	
Kasutatud standardid	Üld sell vastavuses standard ga ASMEVI I D v 1 2004	
PED vastavushinang jaotus	A liikl 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Moduul A (AO AA ACS AAR 035 040 045) Moduul B (AO AA ACS AR AAR 050 055)	
PEDist (urveseadeandmete direktiivit) teavatud asutus	Lloyds Register Verificat on 71 Fenchurch St London EC3M 4BS	
EÜ tüüblihndamistest	COVO413459/TEC	
Vollitud es ndaja	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
Deklaratsioon		
Vollitud esindajana kinn t ulatoodud teave seoses antud tööderni m seetoomisega on vastavuses standardide ja muude seotud dokumentidega vastava t ulatoodud d reiki v de sättele		
Alikiri		
Kuupäev	8/8/2007	
Deklaratsiooni number	0002/8807	

Vyhľásenie o zhode		SK
Parker Hannifin Ltd domn ck hunter divis on Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Smern ce	97/23/EC	
Použ t normy	Vo všeobecnosti v zhode s ASMEVII oddiel 1 2004	
Spôsob posudzovania podla smernice PED	Člensk 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055) Lloyds Register Verificat on 71 Fenchurch St London EC3M 4BS	
Oboznamený orgán podla smernice PED	COVO413459/TEC	
Osevdenie typovej skúsky ES	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter d v s on	
Spinoznomenný zástupca		
Vyhľásenie		
Akto spomincnený zástupca vyhľasuje že informácie uvedené výšie sú v súlade s dodávkou / výrobou tohto výrobku v zhode s normami a rymími súvisiac mi dokumentmi podľa ustanovení uvedených smernic		
Podpis		
Dátum	8/8/2007	
Číslo vyhľasenia	0002 8807	

Megfelelésig nyi atkozat		HU
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktivák	97/23/EC	
Alkalmazott szabványok	Általánosan a következő alapján ASMEVII D v 1 2004	
PED értékelési irányvonala	3.3-as törly (AO AA ACS AAR 005 010 015 020 025 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055)	
PED del kapcsolatban értesített testület	Lloyds Register Verificat on 71 Fenchurch St London EC3M 4BS	
EC tpusztizgalati bizonyítvány	COVO413459/TEC	
Hivatalos képviselő	Derek Bankier Divisional Quality Manager Parker Hannifin Ltd domn ck hunter division	
Nyilatkozat		
Hivatalos képviselőkön kívül, hogy a termék szállításból / gyártásával kapcsolatos lenti elválasztott információk megfelelnek a fentie Direktivák előírásai szerinti szabványoknak és egyéb kapcsolódó dokumentumoknak		
Aláírás		
Dátum	8/8/2007	
Nyilatkozat száma	0002/8807	

Prohlášení o shodě		CS
Parker Hannifin Ltd domn ck hunter divis on Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Směrn ce	97/23/EC	
Použ t normy	Obecné v souladu ASMEVII Div 1 2004	
Metoda stanovení shody pro tlakov záření (PED)	Člensk 3.3 (AO AA ACS AAR 005 010 015 020 025 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055)	
Notifikovaný orgán pro PED	Lloyds Register Verificat on 71 Fenchurch St London EC3M 4BS COVO413459/TEC	
Osvědčení o zkoušce typu ES	Derek Bankier Divisional Quality Manager Parker Hannifin Ltd domn ck hunter d v s on	
Oprávněný zástupce		
Prohlášení		
Jako oprávněný zástupce prohlašuji že výše uvedené informace týkající se dodávky/výroby tohoto produktu jsou v souladu s normami a rymí souvisej cimi dokumenty využívanými z ustanovení výše uvedených směrnic		
Podpis		
Datum	8/8/2007	
Číslo prohlášení	0002/8807	

Atibilstības deklarācija		LV
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktivas	97/23/EC	
Izmantotie standarti	Parasti saskaja ar ASMEVII D v 1 2004	
PED novērtējums	Parasti saskaja ar ASMEVII D v 1 2004 Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055)	
Par PED informātā organiza ja	Lloyds Register Verificat on 71 Fenchurch St London EC3M 4BS COVO413459/TEC	
EK sertifikāts Eksaminācijas sertifikāts	Derek Bankier Divisional Quality Manager Parker Hannifin Ltd domn ck hunter d v s on	
Pinvarotais pārstāvis		
Deklarācija		
Es kā pārstāvis pārstāvis ar šo pažīmju ka lepiet kāminātā informācija kas a tiecas uz šī produkta piegādi / izšūnu atbilst standartiem un citem a bilstošiem dokumentiem saskaņā ar iep iekārtām D rektīvām		
Paraksts		
Datums	8/8/2007	
Deklarācijas numurs	0002/8807	

FILTER DH-OIL-X EVO AO AA_01-

Atitikties deklaracija		LT
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktivas	97/23/EC	
Naudoti standartai	Atitinkamasis standartas ASMEVIII Div 1 : 2004 nuostatos	
PED (vertinimo pakopa):	3 3 straipsnis (AO AA ACS AR AAR 005 010 015 020 025 030) Modulis A (AO AA ACS AR AAR 035 040 045) Modulis B (AO AA ACS AR AAR 050 055)	
PED notifikuojoji institucija	Lloyd's Register Verification 71 Fenchurch St London EC3M 4BS	
EB t po testavimo sertifikatas	COV0413459/TEC	
Igaliojatus atstovas	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division d v s on	
Deklaracija		
Aš, galiojusias atstovas, patvirtina, kad šiuoje pateiktu gaminiu teknologijos informacija atitinka atitinkamus standartus ir kiti su nurodyti direktivų nuostatomis susijusią dokumentaciją.		
Parasas	Date	8/8/2007
Deklaracijos numeris: 0002 8807		

Декларация соответствия		RU
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Требования	97/23/EC	
Применимые стандарты	В соответствии с правилами, определяющими соответствие стандарту ASMEVIII, Раздел 1: 2004.	
Система обеспечения качества PED	Стандарт 3 (AO AA ACS AR AAR - 005, 010, 015, 020, 025, 030) Модуль A (AO AA ACS AR AAR - 035, 040 045) Модуль B (AO AA ACS AR AAR - 050 055)	
Уполномоченный орган для PED:	Lloyd's Register Verification 71 Fenchurch St London EC3M 4BS	
Сертификат ЕС на проведение типовых испытаний:	COV0413459/TEC	
Уполномоченный представитель	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
Декларация		
Как уполномоченный представитель, я заявляю, что приведенная выше информация точно отражает характеристики данного продукта, соответствует стандартам, другим связанным документам и положениям, указанным выше требованиями.		
Подпись:	Date: 8/8/2007	
Номер декларации: 0002 8807		

Izjava o skladnosti		SL
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktive	97/23/EC	
Uporabjeni standardi	Splošno skladno z ASMEVIII Div 1 2004	
Ocenjevalna pot PED	Članek 3.3 (AO AA ACS AR AAR - 005, 010, 015, 020, 025, 030) Modul A (AO AA ACS AR AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055)	
Priglašeni organ za PED	Lloyd's Register Verification 71 Fenchurch St London EC3M 4BS	
Certifikat o tipskem pregledu ES	COV0413459/TEC	
Pooblaščeni zastopnik	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
Izjava		
Kot pooblaščeni zastopnik izjavljam, da so zgornji podatki glede dobička/ročnega zvezdca tega zdeleka skladni s standardi in ostalimi sorodnimi dokumenti, ki sledijo določbam zgornjih direktiv.		
Podpis	Datum: 8/8/2007	
Štev. lka izjave: 0002 8807		

Uyum Beyani		TR
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktifler	97/23/EC	
Kullanılan standartlar	Genelde ASMEV II D v 1 2004'e uygun	
PED (Bassinci Ekibi)	Modül 3 3 (AO AA ACS AAR 005 010 015 020 025 030) Direktif (Değerlendirmesi) Modül A (AO AA ACS AAR 035 040 045) Yer: Modül B (AO AA ACS AR AAR 050 055)	
PED için bildirim bulunulan kuruluş:	Lloyd's Register Verification 71 Fenchurch St London EC3M 4BS	
AT Tip İncelemesi Sertifikası:	COV0413459/TEC	
Yetkili Temsilci	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
Beyan		
Yetkili temsilci olarak beyan ediyorum ki bu ürünün temininde / üretilmeye ilişkin olarak yukarıda verilen bilgiler yukarıda anılan Direktiflerin hükümlerine uygun standartlara ve ilgili başka belgelere uygundur.		
İmza:	Tarih: 8/8/2007	
Beyan No: 0002 8807		

Dikjarazzjoni tal Konformità		MT
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Direktivi	97/23/EC	
Standards użati	Generalment l'konformità ma' ASMEVIII Div 1 : 2004	
Rotta ta' i Assessar tal PED	Artikolu 3 (AO AA ACS AAR 005 010 015 020 025 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055)	
Korp notifikat ghall-PED:	Lloyd's Register Verfication 71 Fenchurch St London EC3M 4BS	
Certifikat tal-KE ta' I-ezaminazzjoni tal-Tip:	COV0413459/TEC	
Rapprežentant Autorizat	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
D kjarazzjoni		
Niddikka li bħala r-repräsentant autorizzat, l-informazzjoni ta' hawn fuq, f'dak li għandha x-jaqsim mal-formann/ma-nufera ta' dan il-prodott, hija l'konformità ma' l-standards u d-dokumenti lu-oħra relatati li jiegħu d-dispozizzjonijiet tad-Direktivi msemmejha hawn fuq		
Firma	Data: 8/8/2007	
Numru tad-Dikjarazzjoni: 0002 8807		

Declaratie de conformitate		RO
Parker Hannifin Ltd domn ck hunter division Dukesway TVTE Gateshead Tyne & Wear NE11 0PZ UK		
OIL X Evolution AO AA ACS AR AAR 005 010 015 020 025 030 AO AA ACS AR AAR 035 040 045 AO AA ACS AR AAR 050 055		
Directive	97/23/EC	
Standarde u ilizata	Splošno skladno z ASMEV II D v 1 2004	
Traseu de evaluare PED	Članek 3.3 (AO AA ACS AR AAR - 005, 010, 015, 020, 025, 030) Modul A (AO AA ACS AAR 035 040 045) Modul B (AO AA ACS AR AAR 050 055)	
Organismus no ificat pentru PED	Lloyd's Register Verfication 71 Fenchurch St London EC3M 4BS	
Certificat de examinare de tip CE	COV0413459/TEC	
Reprezentant autorizat	Derek Bankier D v s onal Quality Manager Parker Hannifin Ltd domn ck hunter division	
Declarație		
În calitate de reprezentant autorizat, declar că informațiile de mai sus, referitoare la funcționalitatea acestui produs, sunt în conformitate cu standardele și alte documente constătoare care respectă prevederile Directivei de mai sus.		
Semnătură:	Data: 8/8/2007	
Număr declaratie: 0002 8807		

FILTER DH-OIL-X EVO AO AA_01-

13.6 Installing CAM-LOK

EATON CROUSE-HINDS SERIES

CAM-LOK® SINGLE POLE CONNECTORS

E-Z1016 & E-Z1018 SERIES

Installation and Maintenance Information

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

APPLICATION

Eaton Crouse-Hinds Cam-Lok connectors are designed to meet NEC code requirements for listed connectors that are of the locking type. These single pole plugs and receptacles are insulated in a specially formulated elastomeric material for safety and water tightness. They allow you to connect or disconnect electrical equipment instantly without any tools. Cam-Lok connectors are the industry standard.

INSTALLATION

WARNING
Installation and Maintenance should be performed by authorized personnel only.


WARNING
To avoid damage to equipment or injury to personnel, electrical power must be OFF before and during installation and maintenance.

CAUTION


Connector installation must comply with NEC and any local codes.

Note: Use Copper (CU) Conductors Only.


1. Measure cable jacket diameter.




2. Cut sleeve to match cable jacket diameter.




3. Slide sleeve on to cable.



7.a For #10 size conductor:




7.b For all other conductor sizes:




8. Complete conductor termination


8.a. Tighten set screw using 7/32" hex key.




9. Lubricate contact.




10. Line up drive pin on contact with 'mate' arrow on sleeve.




11. Slide sleeve over contact.




12. Ensure drive pin stops at end of key-way and tighten retaining screw.



13. Check final position.




7. Insert conductor into contact.



8. Complete conductor termination

8.a. Tighten set screw using 7/32" hex key.



OPERATION

- To mate, fully engage male to female and rotate 1/3 of a turn clockwise.
- To unmate, rotate counter clockwise 1/3 of a turn and pull straight out.

INSULATOR SLEEVE REMOVAL


WARNING

Installation and Maintenance should be performed by authorized personnel only.

WARNING

To avoid damage to equipment or injury to personnel, electrical power must be OFF before and during installation and maintenance.

1. Loosen retaining screw 4-6 turns.



2. Slide sleeve off contact.



3. Clean all external parts of the connector



MAINTENANCE

Note: Perform visual, electrical and mechanical checks of all components on a regular schedule. This should be determined by the environment and frequency of use, but it is recommended that it occur at least once per year.

- Make sure retaining screw is tight. (See Fig 11)
- Clean contact thoroughly.
- Clean all external parts of the connector



WARNING

If any part of this connector appears to be broken or shows signs of any damage – DISCONTINUE USE IMMEDIATELY. Replace or properly repair the connector BEFORE continuing service.

All statements, technical information and recommendations contained herein are based on information and tests we believe to be reliable. The accuracy or completeness thereof is not guaranteed. In accordance with Eaton Crouse-Hinds' Terms and Conditions of Sale, and since conditions of sale are outside our control, the purchaser should determine the suitability of the product for his intended use and assumes all risk and liability whatsoever in connection therewith.

IM 1012 REVISION REV E/IC-ECDN04483
CROUSE-HINDS SERIES
Copyright © 2017, Eaton Corporation

EATON CROUSE-HINDS
SERIES
CAM-LOK® SINGLE POLE CONNECTORS
E-Z1016 & E-Z1018 SERIES
Installation and Maintenance Information
IM 1012

 SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Note: Eaton Crouse-Hinds E-Z1016 and E-Z1018 connectors are designed to be used with the following contacts only.

CONTACT AND CONDUCTOR INFORMATION					
Series	Style	Conductor Size	Continuous Amp Rating	Conductor Entrance Diameter (in)	Contact Part Number
				Male	Female
E-Z1016	Crimp	#2-1	190	0.402	A200036-18 A200037-23
E-Z1016	Crimp	1/0-2/0	300	0.495	A200038-11 A200035-17
E-Z1016	Crimp	3/0-4/0	400	0.620	A200038-6 A200035-14
E-Z1016	Double Set Screw	#6-#2	190	0.406	A200630-13 A200640-13
E-Z1016	Double Set Screw	#2-2/0	300	0.578	A200630-1 A200640-3
E-Z1016	Double Set Screw	2/0-4/0	400 - Use 90°C Cable	0.656	A200639-1 A200641-1
E-Z1018	Double Set Screw	#2-2/0	300	0.578	A200630-1 A200640-4
E-Z1018	Double Set Screw	2/0-4/0	400 - Use 90°C Cable	0.656	A200639-1 A200641-2

Eaton.com/recycling

All statements, technical information and recommendations contained herein are based on information and tests we believe to be reliable. The accuracy or completeness thereof are not guaranteed. In accordance with Eaton Crouse-Hinds "Terms and Conditions of Sale," and since conditions of use are outside our control, the purchaser should determine the suitability of the product for his intended use and assumes all risk and liability whatsoever in connection therewith.



EATON CROUSE-HINDS
SERIES
 Crouse-Hinds Division
 4758 Washington Street, LaGrange, NC 28551 USA
 Copyright © 2017, Eaton Corporation

Copyright © 2017, Eaton Corporation

Page 2

EATON CROUSE-HINDS
SERIES
CONECTORES UNIPOLARES CAM-LOK®
SERIES E-Z1016 Y E-Z1018
Información de instalación y mantenimiento
GUARDE ESTAS INSTRUCCIONES PARA REFERENCIA FUTURA
IM 1012

Nota: Los conectores E-Z1016 y E-Z1018 de Eaton Crouse-Hinds están diseñados para utilizarse con los siguientes contactos únicamente.

INFORMACIÓN DE CONTACTOS Y CONDUCTORES					
Serie	Estilo	Tamaño del conductor	Amperaje continuo nominal	Diámetro de entrada del conductor (pulgadas)	Número de pieza del contacto
				Macho	Hembra
E-Z1016	Crimpado	#2-1	190	0.402	A200036-18 A200037-23
E-Z1016	Crimpado	1/0-2/0	300	0.495	A200038-11 A200035-17
E-Z1016	Crimpado	3/0-4/0	400	0.620	A200038-6 A200035-14
E-Z1016	Dos tornillos de ajuste	#6/#2	190	0.406	A200630-13 A200640-13
E-Z1016	Dos tornillos de ajuste	#2-2/0	300	0.578	A200630-1 A200640-3
E-Z1016	Dos tornillos de ajuste	2/0-4/0	400 - Utilice cable de 90°C	0.656	A200639-1 A200641-1
E-Z1018	Dos tornillos de ajuste	#2-2/0	300	0.578	A200630-1 A200640-4
E-Z1018	Dos tornillos de ajuste	2/0-4/0	400 - Utilice cable de 90°C	0.656	A200639-1 A200641-2

Eaton.com/recycling

Todas las declaraciones, la información técnica y las recomendaciones contenidas en la presente se fundamentan en información y pruebas que se consideran confiables. Su precisión e integridad no están garantizadas. De conformidad con los "Términos y condiciones de venta" que se conocen como "Términos y condiciones de uso" que gobiernan el uso de Eaton Crouse-Hinds, el comprador debe determinar la idoneidad del producto para el uso que planea hacer de él y asume todo riesgo y responsabilidad respecto de ello.



Eaton Corporation
Crouse-Hinds Division
4758 Washington Street, LaGrange, NC 28551 USA
Copyright © 2017, Eaton Corporation

EATON CROUSE-HINDS
SERIES
IM 1012
Copyright © 2017, Eaton Corporation

Página 2

EATON CROUSE-HINDS
SÉRIES
CONNECTEURS UNIPOLAIRES CAM-LOK®
SÉRIES E-Z1016 ET E-Z1018
Installation et entretien
IM 1012
CONSERVER CES INSTRUCTIONS POUR POUVOIR LES CONSULTER ULTÉRIEUREMENT

Remarque : Les connecteurs E-Z1016 et E-Z1018 de Eaton Crouse-Hinds sont conçus pour les contacts suivants uniquement.

RENSEIGNEMENTS SUR LES CONTACTS ET LES CONDUCTEURS

Série	Style	Calibre du conducteur	Intensité nominale en régime permanent	Diamètre (po) de l'entrée du conducteur	Numéro de pièce du contact	
					Male	Femelle
E-Z1016	Serti	#2-1	190	0.402	A200036-18	A200037-23
E-Z1016	Serti	1/0-2/0	300	0.495	A200038-11	A200035-17
E-Z1016	Serti	3/0-4/0	400	0.620	A200038-6	A200035-14
E-Z1016	Double vis de pression	#6-#2	190	0.406	A200630-13	A200640-13
E-Z1016	Double vis de pression	#2-2/0	300	0.578	A200630-1	A200640-3
E-Z1016	Double vis de pression	2/0-4/0	400 - utilise un câble de 90 °C	0.656	A200639-1	A200641-1
E-Z1018	Double vis de pression	#2-2/0	300	0.578	A200630-1	A200640-4
E-Z1018	Double vis de pression	2/0-4/0	400 - utilise un câble de 90 °C	0.656	A200639-1	A200641-2



Eaton.com/recycling

Toutes les déclarations et tous les renseignements techniques contenues dans le présent document sont basées sur des informations et des essais que nous avons faits. Ni leur précision ni leur exhaustivité ne sont garanties. Conformément aux conditions de vente de Eaton Crouse-Hinds, et étant donné que les conditions d'utilisation sont hors de notre contrôle, l'acheteur doit déterminer si le produit convient à l'utilisation prévue et en assume tous les risques et toutes les responsabilités associées.

IM 1012

Copyright © 2017, Eaton Corporation

Page 2

EATON CROUSE-HINDS
SÉRIES
 Eaton Corporation
 Crouse-Hinds Division
 4758 Washington Street, LaGrange, NC 28551 USA
 Copyright © 2017, Eaton Corporation